



# **Manage cluster software**

## **ONTAP 9.14.1 REST API reference**

NetApp  
April 02, 2024

This PDF was generated from [https://docs.netapp.com/us-en/ontap-restapi/ontap/cluster\\_software\\_endpoint\\_overview.html](https://docs.netapp.com/us-en/ontap-restapi/ontap/cluster_software_endpoint_overview.html) on April 02, 2024. Always check docs.netapp.com for the latest.

# Table of Contents

- Manage cluster software ..... 1
  - Cluster software endpoint overview ..... 1
  - ONTAP Error Response codes ..... 35
  - Retrieve the cluster software profile ..... 37
  - Update the cluster software version ..... 50
  - Retrieve software or firmware download status ..... 69
  - Download a software or firmware package ..... 72
  - Retrieve software installation requests history details ..... 77
  - Retrieve cluster software packages ..... 83
  - Delete a software package from the cluster ..... 88
  - Retrieve the software package information ..... 91
  - Upload a software or firmware package located on the local file system ..... 94

# Manage cluster software

## Cluster software endpoint overview

### Overview

You can use the ONTAP cluster software API to retrieve and display relevant information about a software profile, software packages collection, software history collection, and firmware packages collection. This API retrieves the information about all software packages present in the cluster, or a specific software package, or firmware upgrade status.

You can use the POST request to download a software package/firmware from an HTTP or FTP server. The PATCH request provides the option to upgrade the cluster software version. Select the `validate_only` field to validate the package before triggering the update. Set the `version` field to trigger the installation of the package in the cluster. You can pause, resume, or cancel any ongoing software upgrade by selecting `action`. You can use the DELETE request to remove a specific software package present in the cluster.

### Examples

#### Retrieving software profile information

The following example shows how to retrieve software and firmware profile information. You can check the validation results after selecting the `validate_only` field. Upgrade progress information is available after an upgrade has started.

```
# The API:
/api/cluster/software

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software?return_timeout=15" -H
"accept: application/hal+json"

# The response:
{
  "validation_results": [
    {
      "update_check": "NFS mounts",
      "status": "warning",
      "issue": {
        "message": "Use NFS hard mounts, if possible.",
      }
    },
    {
      "action": {
        "message": "Use NFS hard mounts, if possible.",
      }
    }
  ]
}
```

```

],
"version": "9.5.0",
"pending_version": "9.6.0",
"nodes": [
  {
    "node": "Node 1",
    "version": "9.5.0",
    "firmware": {
      "cluster_fw_progress": [
        {
          "job": {
            "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
            "_links": {
              "self": {
                "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
              }
            }
          },
          "zip_file_name": "abc.zip",
          "update_type": "automatic_update",
          "update_state": [
            {
              "worker_node": {
                "name": "Node 1",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
              },
              "status": "failed",
              "attempts": 3,
              "message": "Cannot open the local staging zip file.",
              "code": 2228325
            },
            {
              "worker_node": {
                "name": "Node 2",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
              },
              "status": "complete",
              "attempts": 3,
              "message": "Success",
              "code": 0
            }
          ]
        }
      ]
    },
    "job": {

```

```

    "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
      }
    }
  },
  "zip_file_name": "xyz.zip",
  "update_type": "manual_update",
  "update_state": [
    {
      "worker_node": {
        "name": "Node 1",
        "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
      },
      "status": "failed",
      "attempts": 3,
      "message": "Cannot open the local staging zip file.",
      "code": 2228325
    },
    {
      "worker_node": {
        "name": "Node 2",
        "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
      },
      "status": "complete",
      "attempts": 3,
      "message": "Success",
      "code": 0
    }
  ]
},
"disk": {
  "num_waiting_download": 0,
  "total_completion_estimate": 0,
  "average_duration_per_disk": 120,
  "update_status": "idle"
},
"shelf": {
  "update_status": "idle",
  "in_progress_count": 2
},
"dqp": {
  "revision": "20200117",

```

```

    "version": "3.17",
    "file_name": "qual_devices_v2",
    "record_count": {
      "drive": 680,
      "alias": 200,
      "device": 29,
      "system": 3
    }
  },
  "sp_bmc": {
    "fw_type": "SP",
    "image": " primary",
    "status": "installed",
    "is_current": true,
    "running_version": "1.2.3.4",
    "autoupdate": false,
    "last_update_status": "passed",
    "start_time": "2018-05-21T09:53:04+05:30",
    "percent_done": 100,
    "end_time": "2018-05-21T09:53:04+05:30",
    "in_progress": false
  }
}
],
"metrocluster": {
  "progress_summary": {
    "message": "Update paused by user"
  },
  "progress_details": {
    "message": "Installing software image on cluster \"sti70-vsim-ucsl65n_siteA\"."
  },
  "clusters": [
    {
      "name": "sti70-vsim-ucsl65n_siteA",
      "uuid": "720f046c-4b13-11e9-9c34-005056ac5626",
      "estimated_duration": 3480,
      "elapsed_duration": 0,
      "state": "waiting"
    }
  ],
  "state": "in_progress",
  "start_time": "2018-05-21T09:53:04+05:30",
  "end_time": "2018-05-21T11:53:04+05:30",

```

```

"estimated_time": 5220,
"elapsed_time": 2140,
"update_details": [
  {
    "phase": "Data ONTAP updates",
    "state": "in_progress",
    "estimated_duration": 4620,
    "elapsed_duration": 29,
    "node": {
      "name": "sti70-vsim-ucs165n"
    }
  }
],
"status_details": [
  {
    "name": "do-download-job",
    "state": "completed",
    "issue": {
      "message": "Image update complete",
      "code": 0
    },
    "start_time": "2018-05-21T09:53:04+05:30",
    "end_time": "2018-05-21T11:53:04+05:30",
    "node": {
      "name": "sti70-vsim-ucs165n"
    }
  }
],
"_links": {
  "self": {
    "href": "/api/cluster/software/"
  }
}
}

```

## Upgrading the software version

The following example shows how to upgrade cluster software. Set the `version` field to trigger the installation of the package. You can select the `validate_only` field to validate the package before the installation starts. Setting `skip_warning` as `true` ignores the validation warning before the installation starts. Setting the `action` field performs a pause, resume, or cancel operation on an ongoing upgrade. An upgrade can only be resumed if it is in the paused state. Setting `stabilize_minutes` allows each node a specified amount of time to stabilize after a reboot; the default is 8 minutes. If `show_validation_details` is set to `"true"`, all validation details will be shown in the output.

You can start the upgrade process at the cluster level. There are no options available to start the upgrade for a specific node or HA pair.

### 1. Validating the package and verifying the validation results

The following example shows how to validate a cluster software package. You must validate the package before the software upgrade. Set the `validate_only` field to `true` to start the validation. You can check for validation results in the GET `/cluster/software` endpoint.

```
# The API:
/api/cluster/software

# The call:
curl -X PATCH "https://<mgmt_ip>/api/cluster/software?validate_only=true"
-H "accept: application/json" -H "Content-Type: application/hal+json" -d
'{"version": "9.5.0"}'

# The response:
{
  "job": {
    "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
      }
    }
  }
}
```

The call to validate the software cluster version returns the job UUID, including a HAL link to retrieve details about the job. The job object includes a `state` field and a message to indicate the progress of the job. When the job is complete and the application is fully created, the message indicates success and the `state` field of the job is set to `success`.



```
# The API:
/api/cluster/jobs/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc" -H "accept: application/hal+json"

# The response:
{
  "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
  "description": "PATCH /api/cluster/software",
  "state": "success",
  "message": "success",
  "code": 0,
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
    }
  }
}
```

You can check for validation results in the GET /cluster/software endpoint. The following example shows how to check the validation warnings and errors after setting the `validate_only` field to `true`.

```
# The API:
/api/cluster/software

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software" -H "accept: application/hal+json"

# The response:
{
  "version": "9.7.0",
  "validation_results": [
    {
      "update_check": "High Availability status",
      "status": "error",
      "issue": {
        "message": "Cluster HA is not configured in the cluster. Storage failover is not enabled on node \"node1\", \"node2\".",
      },
      "action": {
```

```

    "message": "Check cluster HA configuration. Check storage failover
status."
  }
},
{
  "update_check": "Manual checks",
  "status": "warning",
  "issue" : {
    "message": "Manual validation checks need to be performed. Refer to
the Upgrade Advisor Plan or the \"What should I verify before I upgrade
with or without Upgrade Advisor\" section in the \"Upgrade ONTAP\"
documentation for the remaining validation checks that need to be
performed before update. Failing to do so can result in an update failure
or an I/O disruption."
  },
  "action": {
    "message": "Refer to the Upgrade Advisor Plan or the \"What should I
verify before I upgrade with or without Upgrade Advisor\" section in the
\"Upgrade ONTAP\" documentation for the remaining validation checks that
need to be performed before update."
  }
}
],
"nodes": [
  {
    "node": "sti70-vsims-ucsl65n",
    "version": "9.5.0",
    "firmware": {
      "cluster_fw_progress": [
        {
          "job": {
            "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
            "_links": {
              "self": {
                "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
              }
            }
          },
          "zip_file_name": "abc.zip",
          "update_type": "automatic_update",
          "update_state": [
            {
              "worker_node": {
                "name": "Node 1",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
              }
            }
          ]
        }
      ]
    }
  }
]

```

```

    },
    "status": "failed",
    "attempts": 3,
    "message": "Cannot open the local staging zip file.",
    "code": 2228325
  },
  {
    "worker_node": {
      "name": "Node 2",
      "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
    },
    "status": "complete",
    "attempts": 3,
    "message": "Success",
    "code": 0
  }
]
},
{
  "job": {
    "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
      }
    }
  },
  "zip_file_name": "xyz.zip",
  "update_type": "automatic_update",
  "update_state": [
    {
      "worker_node": {
        "name": "Node 1",
        "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
      },
      "status": "failed",
      "attempts": 3,
      "message": "Cannot open the local staging zip file.",
      "code": 2228325
    },
    {
      "worker_node": {
        "name": "Node 2",
        "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
      },

```

```

        "status": "complete",
        "attempts": 3,
        "message": "Success",
        "code": 0
    }
]
}
],
"disk": {
    "num_waiting_download": 0,
    "total_completion_estimate": 0,
    "average_duration_per_disk": 120,
    "update_status": "idle"
},
"shelf": {
    "update_status": "idle",
    "in_progress_count": 2
},
"dqp": {
    "revision": "20200117",
    "version": "3.17",
    "file_name": "qual_devices_v2",
    "record_count": {
        "drive": 680,
        "alias": 200,
        "device": 29,
        "system": 3
    }
},
"sp_bmc": {
    "fw_type": "SP",
    "image": " primary",
    "status": "installed",
    "is_current": true,
    "running_version": "1.2.3.4",
    "autoupdate": false,
    "last_update_status": "passed",
    "start_time": "2018-05-21T09:53:04+05:30",
    "percent_done": 100,
    "end_time": "2018-05-21T09:53:04+05:30",
    "in_progress": false
}
}
},
"state": "failed",

```

```
"elapsed_duration": 56,
"estimated_duration": 600,
"_links": {
  "self": {
    "href": "/api/cluster/software"
  }
}
}
```

## 2. Updating the cluster

The following example shows how to initiate a cluster software upgrade. You must validate the package before the software upgrade starts. Set the `skip_warnings` field to `true` to skip validation warnings and start the software package upgrade. You can specify the `stabilize_minutes` value between 1 to 60 minutes. Setting `stabilize_minutes` allows each node a specified amount of time to stabilize after a reboot; the default is 8 minutes. If the value of `show_validation_details` is set to `"true"`, then all validation details will be shown in the output.

```
# The API:
/api/cluster/software

# The call:
curl -X PATCH "https://<mgmt_ip>/api/cluster/software?skip_warnings=true"
-H "accept: application/json" -H "Content-Type: application/hal+json" -d
'{"version": "9.5.0"}'

# The response:
{
  "job": {
    "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
      }
    }
  }
}
```

The call to update the software cluster version returns the job UUID, including a HAL link to retrieve details about the job. The job object includes a `state` field and a message to indicate the progress of the job. When the job is complete and the application is fully created, the message indicates success and the `state` field of the job is set to `success`.

```

# The API:
/api/cluster/jobs/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc" -H "accept: application/hal+json"

# The response:
{
  "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
  "description": "PATCH /api/cluster/software",
  "state": "success",
  "message": "success",
  "code": 0,
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
    }
  }
}

```

You can check the update progress information in the GET /cluster/software endpoint. The following example shows how to check the progress of an update after setting the `skip_warnings` field to `true`. Each node's object also includes information about the firmware update status on the node.

```

# The API:
/api/cluster/software

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software" -H "accept: application/hal+json"

# The response:
{
  "version": "9.7.0",
  "validation_results": [
    {
      "update_check": "Manual checks",
      "status": "warning",
      "issue": {
        "message": "Manual validation checks need to be performed. Refer to the Upgrade Advisor Plan or the \"What should I verify before I upgrade with or without Upgrade Advisor\" section in the \"Upgrade ONTAP\"

```

documentation for the remaining validation checks that need to be performed before update. Failing to do so can result in an update failure or an I/O disruption."

```
    },
    "action": {
      "message": "Refer to the Upgrade Advisor Plan or the \"What should I
verify before I upgrade with or without Upgrade Advisor\" section in the
\"Upgrade ONTAP\" documentation for the remaining validation checks that
need to be performed before update."
    }
  ],
  "nodes": [
    {
      "node": "sti70-vsimg-ucs165n",
      "version": "9.5.0",
      "firmware": {
        "cluster_fw_progress": [
          {
            "job": {
              "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
              "_links": {
                "self": {
                  "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
                }
              }
            },
            "zip_file_name": "abc.zip",
            "update_type": "automated_update",
            "update_state": [
              {
                "worker_node": {
                  "name": "Node 3",
                  "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
                },
                "status": "failed",
                "attempts": 3,
                "message": "Cannot open the local staging zip file.",
                "code": 2228325
              },
              {
                "worker_node": {
                  "name": "Node 4",
                  "uuid": "fcd40f70-f531-11eb-b235-005056bb3498"
                }
              }
            ]
          }
        ]
      }
    }
  ]
}
```

```

        "status": "complete",
        "attempts": 3,
        "message": "Success",
        "code": 0
    }
]
},
{
    "job": {
        "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
        "_links": {
            "self": {
                "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
            }
        }
    },
    "zip_file_name": "xyz.zip",
    "update_type": "automated_update",
    "update_state": [
        {
            "worker_node": {
                "name": "Node 1",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
            },
            "status": "failed",
            "attempts": 3,
            "message": "Cannot open the local staging zip file.",
            "code": 2228325
        },
        {
            "worker_node": {
                "name": "Node 2",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
            },
            "status": "complete",
            "attempts": 3,
            "message": "Success",
            "code": 0
        }
    ]
}
],
"disk": {
    "num_waiting_download": 0,
    "total_completion_estimate": 0,

```



```

    "average_duration_per_disk": 120,
    "update_status": "idle"
  },
  "shelf": {
    "update_status": "idle",
    "in_progress_count": 2
  },
  "dqp": {
    "revision": "20200117",
    "version": "3.17",
    "file_name": "qual_devices_v2",
    "record_count": {
      "drive": 680,
      "alias": 200,
      "device": 29,
      "system": 3
    }
  },
  "sp_bmc": {
    "fw_type": "SP",
    "image": " primary",
    "status": "installed",
    "is_current": true,
    "running_version": "1.2.3.4",
    "autoupdate": false,
    "last_update_status": "passed",
    "start_time": "2018-05-21T09:53:04+05:30",
    "percent_done": 100,
    "end_time": "2018-05-21T09:53:04+05:30",
    "in_progress": false
  }
}
],
"pending_version": "9.7.0",
"state": "in_progress",
"elapsed_duration": 63,
"estimated_duration": 5220,
"status_details": [
  {
    "name": "do-download-job",
    "status": "running",
    "issue": {
      "message": "Installing software image.",
      "code": 10551400
    }
  },

```

```

    "start_time": "2019-01-14T23:12:14+05:30",
    "end_time": "2019-01-14T23:12:14+05:30",
    "node": {
      "name": "node1"
    }
  },
  {
    "name": "do-download-job",
    "status": "running",
    "issue": {
      "message": "Installing software image.",
      "code": 10551400
    },
    "start_time": "2019-01-14T23:12:14+05:30",
    "end_time": "2019-01-14T23:12:14+05:30",
    "node": {
      "name": "node2"
    }
  }
],
"update_details": [
  {
    "phase": "Data ONTAP updates",
    "status": "in-progress",
    "estimated_duration": 4620,
    "elapsed_duration": 10,
    "node": {
      "name": "node1"
    }
  },
  {
    "phase": "Data ONTAP updates",
    "status": "in-progress",
    "estimated_duration": 4620,
    "elapsed_duration": 10,
    "node": {
      "name": "node2"
    }
  }
],
"_links": {
  "self": {
    "href": "/api/cluster/software"
  }
}
}

```

In the case of a post update check failure, the details are available under the heading "post\_update\_checks" in the GET /cluster/software endpoint. The following example shows how to check the progress of an update after a post update check has failed. Each node's object also includes information about the firmware update status on the node.

```
# The API:
/api/cluster/software

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software" -H "accept:
application/hal+json"

# The response:
{
  "version": "9.7.0",
  "validation_results": [
    {
      "update_check": "Manual checks",
      "status": "warning",
      "issue": {
        "message": "Manual validation checks need to be performed. Refer to
the Upgrade Advisor Plan or the \"What should I verify before I upgrade
with or without Upgrade Advisor\" section in the \"Upgrade ONTAP\"
documentation for the remaining validation checks that need to be
performed before update. Failing to do so can result in an update failure
or an I/O disruption."
      },
      "action": {
        "message": "Refer to the Upgrade Advisor Plan or the \"What should I
verify before I upgrade with or without Upgrade Advisor\" section in the
\"Upgrade ONTAP\" documentation for the remaining validation checks that
need to be performed before update."
      }
    }
  ],
  "nodes": [
    {
      "node": "sti70-vsims-ucs165n",
      "version": "9.5.0",
      "firmware": {
        "cluster_fw_progress": [
          {
            "job": {
              "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
              "_links": {
                "self": {
```

```

        "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
    }
}
},
"zip_file_name": "abc.zip",
"update_type": "automated_update",
"update_state": [
    {
        "worker_node": {
            "name": "Node 1",
            "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
        },
        "status": "working",
        "attempts": 3,
        "message": "<message catalog text>",
        "code": 3
    },
    {
        "worker_node": {
            "name": "Node 2",
            "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
        },
        "status": "completed",
        "attempts": 3,
        "message": "Error message",
        "code": 0
    }
]
},
{
    "job": {
        "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
        "_links": {
            "self": {
                "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
            }
        }
    },
    "zip_file_name": "xyz.zip",
    "update_type": "automated_update",
    "update_state": [
        {
            "worker_node": {
                "name": "Node 1",

```

```

        "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
    },
    "status": "completed",
    "attempts": 1,
    "message": "Error message",
    "code": 0
},
{
    "worker_node": {
        "name": "Node 2",
        "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
    },
    "status": "completed",
    "attempts": "3",
    "message": "Error message",
    "code": 0
}
]
}
],
"disk": {
    "num_waiting_download": 0,
    "total_completion_estimate": 0,
    "average_duration_per_disk": 120,
    "update_status": "idle"
},
"shelf": {
    "update_status": "idle",
    "in_progress_count": 2
},
"dqp": {
    "revision": "20200117",
    "version": "3.17",
    "file_name": "qual_devices_v2",
    "record_count": {
        "drive": 680,
        "alias": 200,
        "device": 29,
        "system": 3
    }
},
"sp_bmc": {
    "fw_type": "SP",
    "image": " primary",
    "status": "installed",
    "is_current": "true",

```

```

        "running_version": "1.2.3.4",
        "autoupdate": "false",
        "last_update_status": "passed",
        "start_time": "2018-05-21T09:53:04+05:30",
        "percent_done": 100,
        "end_time": "2018-05-21T09:53:04+05:30",
        "in_progress": "yes"
    }
}
],
"pending_version": "9.7.0",
"state": "in_progress",
"elapsed_duration": 63,
"estimated_duration": 5220,
"status_details": [
    {
        "name": "do-download-job",
        "status": "completed",
        "issue": {
            "message": "Image update complete.",
            "code": 0
        },
        "start_time": "2019-01-14T23:12:14+05:30",
        "end_time": "2019-01-14T23:12:14+05:30",
        "node": {
            "name": "node1"
        }
    },
    {
        "name": "do-download-job",
        "status": "completed",
        "issue": {
            "message": "Image update complete.",
            "code": 0
        },
        "start_time": "2019-01-14T23:12:14+05:30",
        "end_time": "2019-01-14T23:12:14+05:30",
        "node": {
            "name": "node2"
        }
    }
],
"update_details": [
    {
        "phase": "Data ONTAP updates",

```

```

    "status": "completed",
    "estimated_duration": 4620,
    "elapsed_duration": 3120,
    "node": {
      "name": "node1"
    }
  },
  {
    "phase": "Data ONTAP updates",
    "status": "completed",
    "estimated_duration": 4620,
    "elapsed_duration": 3210,
    "node": {
      "name": "node2"
    }
  },
  {
    "phase": "Post-update checks",
    "status": "paused_on_error",
    "estimated_duration": 600,
    "elapsed_duration": 10,
    "node": {
      "name": "node2"
    }
  }
],
"post_update_checks": [
  {
    "update_check": "Aggregate Health Status",
    "status": "error",
    "issue": {
      "message": "Not all aggregates are online"
    },
    "action": {
      "message": "Ensure all aggregates are online."
    }
  },
  {
    "update_check": "HA Health Status",
    "status": "error",
    "issue": {
      "message": "Storage failover is not enabled on nodes of the
cluster."
    },
    "action": {
      "message": "Ensure storage failover is enabled on all nodes of the

```

```

cluster."
  }
}
],
"_links": {
  "self": {
    "href": "/api/cluster/software"
  }
}
}
}

```

### 3. Pausing, resuming or canceling an upgrade

The following example shows how to pause an ongoing cluster software package upgrade. Set the `action` field to `pause`, `resume`, or `cancel` to pause, resume or cancel the upgrade respectively. Not all update operations support these actions. An update can only be resumed if it is in the paused state.

```

# The API:
/api/cluster/software

# The call:
curl -X PATCH "https://<mgmt_ip>/api/cluster/software?action=pause" -H
"accept: application/json" -H "Content-Type: application/hal+json" -d '{
"version": "9.5.0"}'

# The response:
{
  "job": {
    "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
      }
    }
  }
}
}

```

The call to update the software cluster version and/or firmware version returns the job UUID, including a HAL link to retrieve details about the job. The job object includes a `state` field and a message to indicate the progress of the job. When the job is complete and the application is fully created, the message indicates success and the `state` field of the job is set to `success`.



```

# The API:
/api/cluster/jobs/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc" -H "accept: application/hal+json"

# The response:
{
  "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
  "description": "PATCH /api/cluster/software",
  "state": "success",
  "message": "success",
  "code": 0,
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
    }
  }
}

```

You can check the progress of the upgrade in the GET /cluster/software endpoint. The following example shows how to check the progress of the pause upgrade state after setting the action field to pause.

```

# The API:
/api/cluster/software

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software" -H "accept: application/hal+json"

# The response:
{
  "version": "9.7.0",
  "validation_results": [
    {
      "update_check": "Manual checks",
      "status": "warning",
      "issue": {
        "message": "Manual validation checks need to be performed. Refer to the Upgrade Advisor Plan or the \"What should I verify before I upgrade with or without Upgrade Advisor\" section in the \"Upgrade ONTAP\" documentation for the remaining validation checks that need to be

```

performed before update. Failing to do so can result in an update failure or an I/O disruption."

```
    },
    "action": {
      "message": "Refer to the Upgrade Advisor Plan or the \"What should I
verify before I upgrade with or without Upgrade Advisor\" section in the
\"Upgrade ONTAP\" documentation for the remaining validation checks that
need to be performed before update."
    }
  }
],
"nodes": [
  {
    "node": "sti70-vsimg-ucs165n",
    "version": "9.5.0",
    "firmware": {
      "cluster_fw_progress": [
        {
          "job": {
            "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
            "_links": {
              "self": {
                "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
              }
            }
          },
          "zip_file_name": "abc.zip",
          "update_type": "automated_update",
          "update_state": [
            {
              "worker_node": {
                "name": "Node 1",
                "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
              },
              "status": "failed",
              "attempts": 3,
              "message": "Cannot open the local staging zip file.",
              "code": 2228325
            },
            {
              "status": "complete",
              "attempts": 3,
              "message": "Success",
              "code": 0
            }
          ]
        }
      ]
    }
  }
]
```

```

    ]
  },
  {
    "job": {
      "uuid": "5a21663c-a9a0-11ea-af9a-005056bb44d7",
      "_links": {
        "self": {
          "href": "/api/cluster/jobs/5a21663c-a9a0-11ea-af9a-
005056bb44d7"
        }
      }
    },
    "zip_file_name": "xyz.zip",
    "update_type": "automated_update",
    "update_state": [
      {
        "worker_node": {
          "name": "Node 1",
          "uuid": "fcd40f70-f531-11eb-b235-005056bb3497"
        },
        "status": "failed",
        "attempts": 3,
        "message": "Cannot open the local staging zip file.",
        "code": 2228325
      },
      {
        "status": "complete",
        "attempts": 3,
        "message": "Success",
        "code": 0
      }
    ]
  }
],
"disk": {
  "num_waiting_download": 0,
  "total_completion_estimate": 0,
  "average_duration_per_disk": 120,
  "update_status": "idle"
},
"shelf": {
  "update_status": "idle",
  "in_progress_count": 2
},
"dqp": {
  "revision": "20200117",

```

```

    "version": "3.17",
    "file_name": "qual_devices_v2",
    "record_count": {
      "drive": 680,
      "alias": 200,
      "device": 29,
      "system": 3
    }
  },
  "sp_bmc": {
    "fw_type": "SP",
    "image": " primary",
    "status": "installed",
    "is_current": true,
    "running_version": "1.2.3.4",
    "autoupdate": false,
    "last_update_status": "passed",
    "start_time": "2018-05-21T09:53:04+05:30",
    "percent_done": 100,
    "end_time": "2018-05-21T09:53:04+05:30",
    "in_progress": false
  }
}
],
"pending_version": "9.7.0",
"state": "pause_pending",
"elapsed_duration": 103,
"estimated_duration": 5220,
"status_details": [
  {
    "status": "in-progress",
    "issue": {
      "message": "Installing software image.",
      "code": 10551400
    },
    "start_time": "2019-01-08T02:54:36+05:30",
    "node": {
      "name": "node1"
    }
  },
  {
    "status": "in-progress",
    "issue": {
      "message": "Installing software image.",
      "code": 10551400
    }
  }
]

```

```

    },
    "start_time": "2019-01-08T02:54:36+05:30",
    "node": {
      "name": "node2"
    }
  }
],
"update_details": [
  {
    "phase": "Pre-update checks",
    "status": "completed",
    "estimated_duration": 600,
    "elapsed_duration": 54,
    "node": {
      "name": "node1"
    }
  },
  {
    "phase": "Data ONTAP updates",
    "status": "pause-pending",
    "estimated_duration": 4620,
    "elapsed_duration": 49,
    "node": {
      "name": "node2"
    }
  },
  {
    "phase": "Data ONTAP updates",
    "status": "pause-pending",
    "estimated_duration": 4620,
    "elapsed_duration": 49
  }
],
"_links": {
  "self": {
    "href": "/api/cluster/software"
  }
}
}
}

```

## Downloading the software package

The following example shows how to download the software/firmware package from an HTTP or FTP server. Provide the `url`, `username`, and `password`, if required, to start the download of the package to the cluster.

```
# The API:
/api/cluster/software/download

# The call:
curl -X POST "https://<mgmt-
ip>/api/cluster/software/download?return_timeout=0" -H "accept:
application/json" -H "Content-Type: application/hal+json" -d '{ "url":
"http://server/package", "username": "admin", "password": "*****"}'

# The response:
{
  "job": {
    "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
      }
    }
  }
}
```

The call to download the software/firmware package returns the job UUID, including a HAL link to retrieve details about the job. The job object includes a `state` field and a message to indicate the progress of the job. When the job is complete and the application is fully created, the message indicates success and the job `state` field is set to `success`.

```
# The API:
/api/cluster/jobs/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc" -H "accept: application/hal+json"

# The response:
{
  "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
  "description": "POST /api/cluster/software/download",
  "state": "success",
  "message": "success",
  "code": 0,
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
    }
  }
}
```

---

### Checking the progress of the software package being downloaded from an HTTP or FTP server

The following example shows how to retrieve the progress status of the software package being downloaded from a HTTP or FTP server.

```

# The API:
/api/cluster/software/download

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software/download" -H "accept:
application/hal+json"

# The response:
{
  "state": "running",
  "message": "Package download in progress",
  "code": 10551382,
  "_links": {
    "self": {
      "href": "/api/cluster/software/download"
    }
  }
}

```

## HTTPS error codes

The following is a list of possible error codes that can be returned during a package download operation.

### ONTAP Error Response Codes

Error Code	Description
2228324	Failed to access the remote zip file on node.
2228325	Cannot open local staging ZIP file
2228326	File copy to local staging failed.
2228327	Firmware file already exists.
2228328	Firmware update of node failed.
2228329	Attempt to start worker on node failed
2228330	Uploaded firmware file is not present.
2228331	Copy of file from webserver failed.
2228428	Firmware update completed with errors
2228429	Firmware update completed.
10551327	Package image with the same name already exists.
10551357	Cannot perform an update when a previous update is still in progress.
10551381	Package download failed.



Error Code	Description
10551382	Package download is still running.
10551384	Package download has not started.
10551496	Failed to download package.
10551797	Internal error. Failed to check if file upload is enabled. Contact technical support for assistance.

Also see the table of common errors in the [Response body](#) overview section of this documentation.

## Uploading a software/firmware package

The following example shows how to upload a software package.

```
# The API:
/api/cluster/software/upload

# The call:
curl -ku username:password -F "file=@image.tgz" -X POST "https://<mgmt-
ip>/api/cluster/software/upload?return_timeout=0"

# The response:
{
  "job": {
    "uuid": "12db53fd-8326-11ea-91eb-005056bb16e5",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/12db53fd-8326-11ea-91eb-005056bb16e5"
      }
    }
  }
}
```

## HTTPS error codes

The following is a list of possible error codes that can be returned during a package upload operation.

### ONTAP Error Response Codes

Error Code	Description
2228324	Failed to access the remote zip file on node.
2228325	Cannot open local staging ZIP file

Error Code	Description
2228326	File copy to local staging failed.
2228327	Firmware file already exists.
2228328	Firmware update of node failed.
2228329	Attempt to start worker on node failed
2228330	Uploaded firmware file is not present.
2228331	Copy of file from webserver failed.
2228428	Firmware update completed with errors
2228429	Firmware update completed.
10551395	Validation checks failed with warnings.
10551797	Internal error. Failed to check if file upload is enabled.
10551798	File upload is disabled. Enable file upload by setting "ApacheUploadEnabled 1" in the web services configuration file or contact technical support for assistance.
10551800	Internal error. Access permissions restrict file upload. This is likely due to a bad web jail setup. Contact technical support for assistance.
10551801	Internal error. A read/write error occurred when uploading this file. Contact technical support for assistance
10551802	An invalid argument was supplied to create a file handle. Try uploading the file again or contact technical support for assistance.
10551803	An unknown error occurred. Retry file upload operation again or contact technical support for assistance.
10551804	Internal error. There is not sufficient space in the file upload directory to upload this file. Contact technical support for assistance.
10551805	Internal error in JAIL setup. Contact technical support for assistance.
10551806	Internal error. Failed to write to file in the webjail directory. Contact technical support for assistance.
10551807	The request must only contain a single file. More than one file per request is not supported.
10551808	The request must be of type multipart/form-data.

Also see the table of common errors in the [Response body](#) overview section of this documentation.

## Retrieving cluster software packages information

The following example shows how to retrieve the ONTAP software packages in a cluster.

```
# The API:
/api/cluster/software/packages

# The call:
curl -X GET "https://<mgmt-
ip>/api/cluster/software/packages?return_records=true&return_timeout=15"
-H "accept: application/hal+json"

# The response:
{
  "records": [
    {
      "version": "9.7.0",
      "_links": {
        "self": {
          "href": "/api/cluster/software/packages/9.7.0"
        }
      }
    },
    {
      "version": "9.5.0",
      "_links": {
        "self": {
          "href": "/api/cluster/software/packages/9.5.0"
        }
      }
    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/cluster/software/packages"
    }
  }
}
```

The following example shows how to retrieve the details of a given cluster software package.

```
# The API:
/api/cluster/software/packages/{version}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software/packages/9.7.0" -H
"accept: application/hal+json"

# The response:
{
  "version": "9.7.0",
  "create_time": "2018-05-21T10:06:59+05:30",
  "_links": {
    "self": {
      "href": "/api/cluster/software/packages/9.7.0"
    }
  }
}
```

---

### Deleting a cluster software package

The following example shows how to delete a package from the cluster. You need to provide the package version that you want to delete. The software package delete creates a job to perform the delete operation.

```
# The API:
/api/cluster/software/packages/{version}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/cluster/software/packages/9.6.0" -H
"accept: application/hal+json"

# The response:
{
  "job": {
    "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
      }
    }
  }
}
```

The call to delete the package returns the job UUID, including a HAL link to retrieve details about the job. The job object includes a `state` field and a message to indicate the progress of the job. When the job is complete and the application is fully created, the message indicates success and the job `state` field is set to `success`.

```
# The API:
/api/cluster/jobs/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc" -H "accept: application/hal+json"

# The response:
{
  "uuid": "f587d316-5feb-11e8-b0e0-005056956dfc",
  "description": "DELETE /api/cluster/software/packages/9.6.0",
  "state": "success",
  "message": "success",
  "code": 0,
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f587d316-5feb-11e8-b0e0-005056956dfc"
    }
  }
}
```

## HTTPS error codes

The following is a list of possible error codes that can be returned during a package delete operation.

## ONTAP Error Response codes

Error codes	Description
10551315	Package store is empty
10551322	Error in retrieving package cleanup status
10551323	Error in cleaning up package information on a node
10551324	Error in cleaning up package information on both nodes
10551325	Package does not exist on the system
10551326	Error in deleting older package cleanup tasks
10551346	Package delete failed since a validation is in progress
10551347	Package delete failed since an update is in progress

Error codes	Description
10551367	A package synchronization is in progress
10551388	Package delete operation timed out
10551566	Validation is not completed on the MetroCluster partner cluster
10551567	Package version is not available in the package repository on the MetroCluster partner cluster

### Retrieving software installation history information

The following example shows how to:

- retrieve the software package installation history information.
- display specific node level software installation history information.
- provide all the attributes by default in response when the self referential link is not present.

```
# The API:
/api/cluster/software/history

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/software/history" -H "accept:
application/hal+json"

# The response:
{
  "node": {
    "uuid": "58cd3a2b-af63-11e8-8b0d-0050568e7279",
    "name": "sti70-vsimg-ucs165n",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/58cd3a2b-af63-11e8-8b0d-0050568e7279"
      }
    }
  },
  "start_time": "2018-09-03T16:18:46+05:30",
  "state": "successful",
  "from_version": "9.4.0",
  "to_version": "9.5.0",
  "end_time": "2018-05-21T10:14:51+05:30"
}
```

---

## Retrieve the cluster software profile

GET /cluster/software

**Introduced In:** 9.6

Retrieves the software profile of a cluster.

### Related ONTAP commands

- `cluster image show`
- `cluster image show-update-progress`
- `system node image package show`

### Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul>

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
action	string	User triggered action to apply to the install operation
elapsed_duration	integer	Elapsed time during the upgrade or validation operation
estimated_duration	integer	Overall estimated time for completion of the upgrade or validation operation.
metrocluster	<a href="#">metrocluster</a>	
nodes	array[ <a href="#">software_node_reference</a> ]	List of nodes, active versions, and firmware update progressions.



Name	Type	Description
pending_version	string	Version being installed on the system. <ul style="list-style-type: none"> <li>• example: ONTAP_X_1</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>
post_update_checks	array[ <a href="#">software_validation_reference</a> ]	List of failed post-update checks' warnings, errors, and advice.
state	string	Operational state of the upgrade
status_details	array[ <a href="#">software_status_details_reference</a> ]	Display status details.
update_details	array[ <a href="#">software_update_details_reference</a> ]	Display update progress details.
validation_results	array[ <a href="#">software_validation_reference</a> ]	List of validation warnings, errors, and advice.
version	string	Version of ONTAP installed and currently active on the system. During PATCH, using the 'validate_only' parameter on the request executes pre-checks, but does not perform the full installation. <ul style="list-style-type: none"> <li>• example: ONTAP_X</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "action": "pause",
  "elapsed_duration": 2140,
  "estimated_duration": 5220,
  "metrocluster": {
    "clusters": {
      "elapsed_duration": 2140,
      "estimated_duration": 3480,
      "name": "cluster_A",
      "state": "in_progress"
    },
    "progress_details": {
      "message": "Switchover in progress"
    },
    "progress_summary": {
      "message": "MetroCluster updated successfully."
    }
  },
  "nodes": {
    "firmware": {
      "cluster_fw_progress": {
        "job": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "uuid": "string"
        },
        "update_state": {
          "attempts": 3,
          "code": 2228325,
          "message": "Cannot open local staging ZIP file
disk_firmware.zip",
          "status": "idle",
          "worker_node": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            }
          }
        }
      }
    }
  }
}
```

```

    }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"update_type": "manual_update",
"zip_file_name": "disk_firmware.zip"
},
"disk": {
  "average_duration_per_disk": 120,
  "num_waiting_download": 0,
  "total_completion_estimate": 0,
  "update_status": "running"
},
"dqp": {
  "file_name": "qual_devices_v3",
  "record_count": {
    "alias": 200,
    "device": 29,
    "drive": 680,
    "system": 3
  },
  "revision": "20200117",
  "version": "3.18"
},
"shelf": {
  "in_progress_count": 2,
  "update_status": "running"
},
"sp_bmc": {
  "autoupdte": "",
  "end_time": "2020-05-17 20:00:00 +0000",
  "fw_type": "SP",
  "image": "primary",
  "is_current": 1,
  "last_update_state": "passed",
  "percent_done": 100,
  "running_version": "1.2.3.4",
  "start_time": "2020-05-17 20:00:00 +0000",
  "state": "installed"
}
},
"name": "node1",
"software_images": {
  "package": "image.tgz"
}

```

```

    },
    "version": "ONTAP_X"
  },
  "pending_version": "ONTAP_X_1",
  "post_update_checks": {
    "action": {
      "message": "Use NFS hard mounts, if possible."
    },
    "issue": {
      "message": "Cluster HA is not configured in the cluster."
    },
    "status": "warning",
    "update_check": "nfs_mounts"
  },
  "state": "completed",
  "status_details": {
    "end_time": "2019-02-02 19:00:00 +0000",
    "issue": {
      "code": 10551399,
      "message": "Image update complete"
    },
    "name": "initialize",
    "node": {
      "name": "node1"
    },
    "start_time": "2019-02-02 19:00:00 +0000",
    "state": "failed"
  },
  "update_details": {
    "elapsed_duration": 2100,
    "estimated_duration": 4620,
    "node": {
      "name": "node1"
    },
    "phase": "Post-update checks",
    "state": "failed"
  },
  "validation_results": {
    "action": {
      "message": "Use NFS hard mounts, if possible."
    },
    "issue": {
      "message": "Cluster HA is not configured in the cluster."
    },
    "status": "warning",
    "update_check": "nfs_mounts"
  }
}

```

```
},
"version": "ONTAP_X"
}
```

## Error

Status: Default, Error

Name	Type	Description
error	returned_error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

software\_mcc\_reference

Name	Type	Description
elapsed_duration	integer	Elapsed duration of update time (in seconds) of MetroCluster.
estimated_duration	integer	Estimated duration of update time (in seconds) of MetroCluster.
name	string	Name of the site in MetroCluster.
state		Upgrade state of MetroCluster.

progress\_details

Name	Type	Description
message	string	MetroCluster update progress details.

progress\_summary

Name	Type	Description
message	string	MetroCluster update progress summary.

metrocluster

Name	Type	Description
clusters	array[ <a href="#">software_mcc_reference</a> ]	List of MetroCluster sites, statuses, and active ONTAP versions. <ul style="list-style-type: none"> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul>
progress_details	<a href="#">progress_details</a>	
progress_summary	<a href="#">progress_summary</a>	

#### job\_link

Name	Type	Description
_links	<a href="#">_links</a>	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

#### worker\_node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

#### firmware\_update\_progress\_state

Name	Type	Description
attempts	integer	
code	integer	Code corresponding to the status message.
message	string	Error message returned when a cluster firmware update job fails.
status	string	
worker_node	<a href="#">worker_node</a>	

#### firmware\_update\_progress

Name	Type	Description
job	<a href="#">job_link</a>	

Name	Type	Description
update_state	array[ <a href="#">firmware_update_progress_state</a> ]	
update_type	string	Specifies the type of update.
zip_file_name	string	

#### firmware\_disk

Name	Type	Description
average_duration_per_disk	integer	Average firmware update duration per disk (in seconds).
num_waiting_download	integer	The number of disks waiting to download the firmware update.
total_completion_estimate	integer	Estimated firmware update duration to completion (in minutes).
update_status		Status of the background disk firmware update.

#### firmware\_dqp\_record\_count

Name	Type	Description
alias	integer	Alias record count
device	integer	Device record count
drive	integer	Drive record count
system	integer	System record count

#### firmware\_dqp

Name	Type	Description
file_name	string	Firmware file name
record_count	<a href="#">firmware_dqp_record_count</a>	
revision	string	Firmware revision
version	string	Firmware version



### firmware\_shelf

Name	Type	Description
in_progress_count	integer	
update_status		Status of the shelf firmware update.

### firmware\_sp\_bmc

Name	Type	Description
autoupdte	boolean	
end_time	string	
fw_type	string	
image	string	
in_progress	boolean	
is_current	boolean	
last_update_state	string	
percent_done	integer	
running_version	string	
start_time	string	
state	string	

### firmware

Name	Type	Description
cluster_fw_progress	array[ <a href="#">firmware_update_progress</a> ]	
disk	<a href="#">firmware_disk</a>	
dqp	<a href="#">firmware_dqp</a>	
shelf	<a href="#">firmware_shelf</a>	
sp_bmc	<a href="#">firmware_sp_bmc</a>	

### software\_images

Name	Type	Description
package	string	Package file name.

### software\_node\_reference

Name	Type	Description
firmware	<a href="#">firmware</a>	
name	string	Name of the node.
software_images	array[ <a href="#">software_images</a> ]	List of software image information.
version	string	ONTAP version of the node. <ul style="list-style-type: none"> <li>• example: ONTAP_X</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>

#### action

Name	Type	Description
message	string	Specifies the corrective action to take to resolve an error.

#### issue

Name	Type	Description
message	string	Details of the error or warning encountered by the update checks.

#### software\_validation\_reference

Name	Type	Description
action	<a href="#">action</a>	
issue	<a href="#">issue</a>	
status	string	Status of the update check.
update_check	string	Name of the update check.

#### action

Name	Type	Description
code	integer	Error code corresponding the status error

Name	Type	Description
message	string	Corrective action to be taken to resolve the status error.

issue

Name	Type	Description
code	integer	Error code corresponding to update status
message	string	Update status details

node

Name	Type	Description
name	string	Name of the node to be retrieved for status details.

software\_status\_details\_reference

Name	Type	Description
action	<a href="#">action</a>	
end_time	string	End time for each status phase.
issue	<a href="#">issue</a>	
name	string	Name of the phase to be retrieved for status details.
node	<a href="#">node</a>	
start_time	string	Start time for each status phase.
state	string	Status of the phase

node

Name	Type	Description
name	string	Name of the node to be retrieved for update details.

software\_update\_details\_reference

Name	Type	Description
elapsed_duration	integer	Elapsed duration for each update phase
estimated_duration	integer	Estimated duration for each update phase
node	<a href="#">node</a>	
phase	string	Phase details
state	string	State of the update phase

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Update the cluster software version

PATCH /cluster/software

**Introduced In:** 9.6

Updates the cluster software version. Important note:

- Setting 'version' triggers the package installation.
- To validate the package for installation but not perform the installation, use the `validate_only` field on the request.

## Required properties

- `version` - Software version to be installed on the cluster.

## Recommended optional parameters

- `validate_only` - Required to validate a software package before an upgrade.
- `skip_warnings` - Used to skip validation warnings when starting a software upgrade.
- `action` - Used to pause, resume, or cancel an ongoing software upgrade.
- `stabilize_minutes` - Specifies a custom value between 1 to 60 minutes that allows each node a specified amount of time to stabilize after a reboot; the default is 8 minutes.
- `estimate_only` - Estimates the time duration; does not perform any update.
- `nodes_to_update` - Specifies a subset of the cluster's nodes for update.
- `show_validation_details` - If the value is set to true, then all validation details will be shown in the output.

## Related ONTAP commands

- `cluster image validate`
- `cluster image update`
- `cluster image pause-update`
- `cluster image resume-update`
- `cluster image cancel-update`

## Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
<code>skip_warnings</code>	boolean	query	False	Ignore warnings and proceed with the install.

Name	Type	In	Required	Description
action	string	query	False	<p>Requests an upgrade to pause, resume, or cancel. Note that not all upgrades support these actions. An upgrade can only be resumed if it is in the paused state. When a request to cancel an upgrade is successful, the upgrade state changes to either <code>success</code> or <code>failure</code>.</p> <ul style="list-style-type: none"> <li>enum: ["pause", "resume", "cancel"]</li> </ul>
stabilize_minutes	integer	query	False	<p>Sets a custom value between 1 to 60 minutes for the upgrade, allowing each node a specified amount of time to stabilize after a reboot.</p> <ul style="list-style-type: none"> <li>Introduced in: 9.8</li> </ul>
estimate_only	boolean	query	False	<p>Generates an estimate of the time required for the overall update operation for the specified package. No update is performed when this option is used. The default is false.</p> <ul style="list-style-type: none"> <li>Introduced in: 9.9</li> </ul>

Name	Type	In	Required	Description
force_rolling	boolean	query	False	<p>Forces a rolling upgrade on the cluster. This option is not applicable for a single-node cluster and for a two-node MetroCluster. The default is false.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>
nodes_to_update	string	query	False	<p>A comma separated list of node names to be updated. The nodes must be a part of a HA Pair. The default is all nodes. If the nodes_to_update parameter is empty then upgrade will error out and will not proceed.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>
show_validation_details	boolean	query	False	<p>If the value is set to true, then all validation details will be shown in the output.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.11</li> </ul>

Name	Type	In	Required	Description
pause_after	string	query	False	<p>The pause after specified tasks option. When ANDU is paused user interaction is required to resume the update. The default is none.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> <li>• enum: ["none", "takeover_giveback", "all"]</li> </ul>
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>



Name	Type	In	Required	Description
validate_only	boolean	query	False	Validate the operation and its parameters, without actually performing the operation.

## Request Body

Name	Type	Description
_links	<a href="#">_links</a>	
action	string	User triggered action to apply to the install operation
elapsed_duration	integer	Elapsed time during the upgrade or validation operation
estimated_duration	integer	Overall estimated time for completion of the upgrade or validation operation.
metrocluster	<a href="#">metrocluster</a>	
nodes	array[ <a href="#">software_node_reference</a> ]	List of nodes, active versions, and firmware update progressions.
pending_version	string	Version being installed on the system. <ul style="list-style-type: none"> <li>• example: ONTAP_X_1</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>
post_update_checks	array[ <a href="#">software_validation_reference</a> ]	List of failed post-update checks' warnings, errors, and advice.
state	string	Operational state of the upgrade
status_details	array[ <a href="#">software_status_details_reference</a> ]	Display status details.
update_details	array[ <a href="#">software_update_details_reference</a> ]	Display update progress details.
validation_results	array[ <a href="#">software_validation_reference</a> ]	List of validation warnings, errors, and advice.

Name	Type	Description
version	string	<p>Version of ONTAP installed and currently active on the system. During PATCH, using the 'validate_only' parameter on the request executes pre-checks, but does not perform the full installation.</p> <ul style="list-style-type: none"><li>• example: ONTAP_X</li><li>• Introduced in: 9.6</li><li>• x-nullable: true</li></ul>

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "action": "pause",
  "elapsed_duration": 2140,
  "estimated_duration": 5220,
  "metrocluster": {
    "clusters": {
      "elapsed_duration": 2140,
      "estimated_duration": 3480,
      "name": "cluster_A",
      "state": "in_progress"
    },
    "progress_details": {
      "message": "Switchover in progress"
    },
    "progress_summary": {
      "message": "MetroCluster updated successfully."
    }
  },
  "nodes": {
    "firmware": {
      "cluster_fw_progress": {
        "job": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "uuid": "string"
        },
        "update_state": {
          "attempts": 3,
          "code": 2228325,
          "message": "Cannot open local staging ZIP file
disk_firmware.zip",
          "status": "idle",
          "worker_node": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            }
          }
        }
      }
    }
  }
}
```

```

    }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"update_type": "manual_update",
"zip_file_name": "disk_firmware.zip"
},
"disk": {
  "average_duration_per_disk": 120,
  "num_waiting_download": 0,
  "total_completion_estimate": 0,
  "update_status": "running"
},
"dqp": {
  "file_name": "qual_devices_v3",
  "record_count": {
    "alias": 200,
    "device": 29,
    "drive": 680,
    "system": 3
  },
  "revision": "20200117",
  "version": "3.18"
},
"shelf": {
  "in_progress_count": 2,
  "update_status": "running"
},
"sp_bmc": {
  "autoupdte": "",
  "end_time": "2020-05-17 20:00:00 +0000",
  "fw_type": "SP",
  "image": "primary",
  "is_current": 1,
  "last_update_state": "passed",
  "percent_done": 100,
  "running_version": "1.2.3.4",
  "start_time": "2020-05-17 20:00:00 +0000",
  "state": "installed"
}
},
"name": "node1",
"software_images": {
  "package": "image.tgz"
}

```

```

    },
    "version": "ONTAP_X"
  },
  "pending_version": "ONTAP_X_1",
  "post_update_checks": {
    "action": {
      "message": "Use NFS hard mounts, if possible."
    },
    "issue": {
      "message": "Cluster HA is not configured in the cluster."
    },
    "status": "warning",
    "update_check": "nfs_mounts"
  },
  "state": "completed",
  "status_details": {
    "end_time": "2019-02-02 19:00:00 +0000",
    "issue": {
      "code": 10551399,
      "message": "Image update complete"
    },
    "name": "initialize",
    "node": {
      "name": "node1"
    },
    "start_time": "2019-02-02 19:00:00 +0000",
    "state": "failed"
  },
  "update_details": {
    "elapsed_duration": 2100,
    "estimated_duration": 4620,
    "node": {
      "name": "node1"
    },
    "phase": "Post-update checks",
    "state": "failed"
  },
  "validation_results": {
    "action": {
      "message": "Use NFS hard mounts, if possible."
    },
    "issue": {
      "message": "Cluster HA is not configured in the cluster."
    },
    "status": "warning",
    "update_check": "nfs_mounts"
  }
}

```

```
},
  "version": "ONTAP_X"
}
```

## Response

Status: 200, Ok

Name	Type	Description
job	job_link	

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Response

Status: 202, Accepted

## Error

Status: Default, Error

Name	Type	Description
error	returned_error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

software\_mcc\_reference

Name	Type	Description
elapsed_duration	integer	Elapsed duration of update time (in seconds) of MetroCluster.
estimated_duration	integer	Estimated duration of update time (in seconds) of MetroCluster.
name	string	Name of the site in MetroCluster.
state		Upgrade state of MetroCluster.

progress\_details

Name	Type	Description
message	string	MetroCluster update progress details.

progress\_summary

Name	Type	Description
message	string	MetroCluster update progress summary.

metrocluster



Name	Type	Description
clusters	array[ <a href="#">software_mcc_reference</a> ]	List of MetroCluster sites, statuses, and active ONTAP versions. <ul style="list-style-type: none"> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul>
progress_details	<a href="#">progress_details</a>	
progress_summary	<a href="#">progress_summary</a>	

#### job\_link

Name	Type	Description
_links	<a href="#">_links</a>	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

#### worker\_node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

#### firmware\_update\_progress\_state

Name	Type	Description
attempts	integer	
code	integer	Code corresponding to the status message.
message	string	Error message returned when a cluster firmware update job fails.
status	string	
worker_node	<a href="#">worker_node</a>	

#### firmware\_update\_progress

Name	Type	Description
job	<a href="#">job_link</a>	

Name	Type	Description
update_state	array[ <a href="#">firmware_update_progress_state</a> ]	
update_type	string	Specifies the type of update.
zip_file_name	string	

#### firmware\_disk

Name	Type	Description
average_duration_per_disk	integer	Average firmware update duration per disk (in seconds).
num_waiting_download	integer	The number of disks waiting to download the firmware update.
total_completion_estimate	integer	Estimated firmware update duration to completion (in minutes).
update_status		Status of the background disk firmware update.

#### firmware\_dqp\_record\_count

Name	Type	Description
alias	integer	Alias record count
device	integer	Device record count
drive	integer	Drive record count
system	integer	System record count

#### firmware\_dqp

Name	Type	Description
file_name	string	Firmware file name
record_count	<a href="#">firmware_dqp_record_count</a>	
revision	string	Firmware revision
version	string	Firmware version

### firmware\_shelf

Name	Type	Description
in_progress_count	integer	
update_status		Status of the shelf firmware update.

### firmware\_sp\_bmc

Name	Type	Description
autoupdte	boolean	
end_time	string	
fw_type	string	
image	string	
in_progress	boolean	
is_current	boolean	
last_update_state	string	
percent_done	integer	
running_version	string	
start_time	string	
state	string	

### firmware

Name	Type	Description
cluster_fw_progress	array[ <a href="#">firmware_update_progress</a> ]	
disk	<a href="#">firmware_disk</a>	
dqp	<a href="#">firmware_dqp</a>	
shelf	<a href="#">firmware_shelf</a>	
sp_bmc	<a href="#">firmware_sp_bmc</a>	

### software\_images

Name	Type	Description
package	string	Package file name.

### software\_node\_reference

Name	Type	Description
firmware	<a href="#">firmware</a>	
name	string	Name of the node.
software_images	array[ <a href="#">software_images</a> ]	List of software image information.
version	string	ONTAP version of the node. <ul style="list-style-type: none"> <li>• example: ONTAP_X</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>

#### action

Name	Type	Description
message	string	Specifies the corrective action to take to resolve an error.

#### issue

Name	Type	Description
message	string	Details of the error or warning encountered by the update checks.

#### software\_validation\_reference

Name	Type	Description
action	<a href="#">action</a>	
issue	<a href="#">issue</a>	
status	string	Status of the update check.
update_check	string	Name of the update check.

#### action

Name	Type	Description
code	integer	Error code corresponding the status error

Name	Type	Description
message	string	Corrective action to be taken to resolve the status error.

issue

Name	Type	Description
code	integer	Error code corresponding to update status
message	string	Update status details

node

Name	Type	Description
name	string	Name of the node to be retrieved for status details.

software\_status\_details\_reference

Name	Type	Description
action	<a href="#">action</a>	
end_time	string	End time for each status phase.
issue	<a href="#">issue</a>	
name	string	Name of the phase to be retrieved for status details.
node	<a href="#">node</a>	
start_time	string	Start time for each status phase.
state	string	Status of the phase

node

Name	Type	Description
name	string	Name of the node to be retrieved for update details.

software\_update\_details\_reference

Name	Type	Description
elapsed_duration	integer	Elapsed duration for each update phase
estimated_duration	integer	Estimated duration for each update phase
node	<a href="#">node</a>	
phase	string	Phase details
state	string	State of the update phase

#### software\_reference

Name	Type	Description
_links	<a href="#">_links</a>	
action	string	User triggered action to apply to the install operation
elapsed_duration	integer	Elapsed time during the upgrade or validation operation
estimated_duration	integer	Overall estimated time for completion of the upgrade or validation operation.
metrocluster	<a href="#">metrocluster</a>	
nodes	array[ <a href="#">software_node_reference</a> ]	List of nodes, active versions, and firmware update progressions.
pending_version	string	Version being installed on the system. <ul style="list-style-type: none"> <li>• example: ONTAP_X_1</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>
post_update_checks	array[ <a href="#">software_validation_reference</a> ]	List of failed post-update checks' warnings, errors, and advice.
state	string	Operational state of the upgrade

Name	Type	Description
status_details	array[ <a href="#">software_status_details_reference</a> ]	Display status details.
update_details	array[ <a href="#">software_update_details_reference</a> ]	Display update progress details.
validation_results	array[ <a href="#">software_validation_reference</a> ]	List of validation warnings, errors, and advice.
version	string	Version of ONTAP installed and currently active on the system. During PATCH, using the 'validate_only' parameter on the request executes pre-checks, but does not perform the full installation. <ul style="list-style-type: none"> <li>• example: ONTAP_X</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve software or firmware download status

GET /cluster/software/download

**Introduced In:** 9.7

Retrieves the software or firmware download status.

## Related ONTAP commands

- `cluster image package check-download-progress`

## Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul>

## Response

Status: 200, Ok

Name	Type	Description
code	integer	Code returned corresponds to a download message
message	string	Download progress details



Name	Type	Description
state	string	Download status of the package

### Example response

```
{
  "code": 10551382,
  "message": "Package download in progress",
  "state": "success"
}
```

### Error

Status: Default, Error

Name	Type	Description
error	returned_error	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Download a software or firmware package

POST `/cluster/software/download`

**Introduced In:** 9.6

Downloads a software or firmware package from the server.

### Required properties

- `url` - URL location of the software package

### Recommended optional parameters

- `username` - Username of HTTPS/FTP server
- `password` - Password of HTTPS/FTP server

### Related ONTAP commands

- `cluster image package get`

### Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul>

## Request Body

Name	Type	Description
password	string	Password for download
url	string	HTTP or FTP URL of the package through a server
username	string	Username for download

### Example request

```
{
  "password": "admin_password",
  "url": "http://server/package",
  "username": "admin"
}
```

### Response

Status: 202, Accepted

Name	Type	Description
job	job_link	

### Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

### Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

### Response

Status: 201, Created

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

### software\_package\_download

Name	Type	Description
password	string	Password for download
url	string	HTTP or FTP URL of the package through a server
username	string	Username for download

### href

Name	Type	Description
href	string	

### \_links

Name	Type	Description
self	<a href="#">href</a>	

### job\_link

Name	Type	Description
_links	<a href="#">_links</a>	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve software installation requests history details

GET `/cluster/software/history`

**Introduced In:** 9.6

Retrieves the history details for software installation requests.

### Related ONTAP commands

- `cluster image show-update-history`

### Learn more

- [DOC /cluster/software](#)

### Parameters

Name	Type	In	Required	Description
node.name	string	query	False	Filter by node.name <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
node.uuid	string	query	False	Filter by node.uuid <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
start_time	string	query	False	Filter by start_time <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
end_time	string	query	False	Filter by end_time <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>

Name	Type	In	Required	Description
state	string	query	False	Filter by state <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
from_version	string	query	False	Filter by from_version <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
to_version	string	query	False	Filter by to_version <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul>
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>



Name	Type	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records
records	array[ <a href="#">software_history</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": {
    "end_time": "2019-02-02 20:00:00 +0000",
    "from_version": "ONTAP_X1",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "start_time": "2019-02-02 19:00:00 +0000",
    "state": "successful",
    "to_version": "ONTAP_X2"
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

software\_history

Name	Type	Description
end_time	string	Completion time of this installation request.
from_version	string	Previous version of node <ul style="list-style-type: none"><li>• example: ONTAP_X1</li><li>• readOnly: 1</li><li>• Introduced in: 9.7</li><li>• x-nullable: true</li></ul>
node	<a href="#">node</a>	
start_time	string	Start time of this installation request.
state	string	Status of this installation request.

Name	Type	Description
to_version	string	Updated version of node <ul style="list-style-type: none"> <li>• example: ONTAP_X2</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.7</li> <li>• x-nullable: true</li> </ul>

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve cluster software packages

GET `/cluster/software/packages`

**Introduced In:** 9.6

Retrieves the software packages for a cluster.

### Related ONTAP commands

- `cluster image package show-repository`

### Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
create_time	string	query	False	Filter by create_time  <ul style="list-style-type: none"> <li>Introduced in: 9.7</li> </ul>
version	string	query	False	Filter by version  <ul style="list-style-type: none"> <li>Introduced in: 9.7</li> </ul>
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  <ul style="list-style-type: none"> <li>Default value: 1</li> </ul>
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  <ul style="list-style-type: none"> <li>Default value: 1</li> <li>Max value: 120</li> <li>Min value: 0</li> </ul>
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records
records	array[ <a href="#">software_package</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "create_time": "2019-02-04 19:00:00 +0000",
    "version": "ONTAP_X"
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

software\_package

Name	Type	Description
_links	<a href="#">_links</a>	
create_time	string	Indicates when this package was loaded
version	string	Version of this package <ul style="list-style-type: none"><li>• example: ONTAP_X</li><li>• readOnly: 1</li><li>• Introduced in: 9.6</li><li>• x-nullable: true</li></ul>

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Delete a software package from the cluster

DELETE /cluster/software/packages/{version}

**Introduced In:** 9.6

Deletes a software package from the cluster. The delete operation fails if the package is currently installed.

### Related ONTAP commands

- `cluster image package delete`

### Learn more

- [DOC /cluster/software](#)

### Parameters

Name	Type	In	Required	Description
version	string	path	True	

Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>

## Response

Status: 200, Ok

## Response

Status: 202, Accepted

## Error

Status: Default

## ONTAP error response codes

Error codes	Description
10551315	Package store is empty
10551322	Error in retrieving package cleanup status
10551323	Error in cleaning up package information on a node
10551324	Error in cleaning up package information on multiple nodes
10551325	Package does not exist on the system
10551326	Error in deleting older package cleanup tasks. Clean up images from the store and retry
10551346	Package delete failed since a validation is in progress
10551347	Package delete failed since an update is in progress
10551367	A package synchronization is in progress
10551388	Package delete operation timed out

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve the software package information

GET /cluster/software/packages/{version}

**Introduced In:** 9.6

Retrieves the software package information.

### Related ONTAP commands

- `cluster image package show-repository`

### Learn more

- [DOC /cluster/software](#)

### Parameters

Name	Type	In	Required	Description
version	string	path	True	
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	
create_time	string	Indicates when this package was loaded
version	string	Version of this package <ul style="list-style-type: none"><li>• example: ONTAP_X</li><li>• readOnly: 1</li><li>• Introduced in: 9.6</li><li>• x-nullable: true</li></ul>

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "create_time": "2019-02-04 19:00:00 +0000",
  "version": "ONTAP_X"
}
```

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Upload a software or firmware package located on the local file system

POST `/cluster/software/upload`

**Introduced In:** 9.8

Uploads a software or firmware package located on the local filesystem.

### Related ONTAP commands

- `cluster image package get`



## Learn more

- [DOC /cluster/software](#)

## Parameters

Name	Type	In	Required	Description
file	file	formData	False	Info specification
return_records	boolean	query	False	<p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"><li>• Default value:</li></ul>
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul>

## Response

Status: 202, Accepted

Name	Type	Description
job	<a href="#">job_link</a>	

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Response

Status: 201, Created

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

job\_link

Name	Type	Description
_links	<a href="#">_links</a>	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.