



## **View NFS connected clients**

REST API reference

NetApp

February 06, 2026

This PDF was generated from [https://docs.netapp.com/us-en/ontap-restapi/protocols\\_nfs\\_connected-clients\\_endpoint\\_overview.html](https://docs.netapp.com/us-en/ontap-restapi/protocols_nfs_connected-clients_endpoint_overview.html) on February 06, 2026. Always check docs.netapp.com for the latest.

# Table of Contents

- View NFS connected clients. . . . . 1
  - View NFS connected clients. . . . . 1
    - Overview . . . . . 1
    - Related CLI command . . . . . 1
    - Example . . . . . 1
  - Retrieve the NFS configuration for an SVM. . . . . 3
    - Expensive properties . . . . . 3
    - Parameters. . . . . 3
    - Response . . . . . 5
    - Error . . . . . 7
    - Definitions . . . . . 8

# View NFS connected clients

## View NFS connected clients

### Overview

ONTAP connected clients show functionality is mainly used to provide a list of currently connected NFS clients. It also provides a potential list of other NFS clients that can be connected but are currently idle and a list of recently unmounted clients. If a client connected to the NFS server is idle for longer than the maximum cache idle time, then the entry will be removed. By default, the maximum cache idle time is 48 hours.

The following are details of the fields retrieved for the Connected Clients GET API:

node.name: The node name hosting this record; basically the node hosting the "server\_ip". node.uuid: The node UUID hosting this record; basically the node hosting the "server\_ip". svm.name: The svm name to which the "server\_ip" belongs to. svm.uuid: The svm uuid to which the "server\_ip" belongs to. server\_ip: All clients that are connected to this interface are displayed in rows. client\_ip: The IP address of the client that is connected to the interface. volume.name: The name of the volume the client is accessing. volume.uuid: The UUID of the volume the client is accessing. This field is expensive field and will be fetched in advance privilege level. protocol: The NFS protocol version over which client is accessing the volume. export\_policy.id: The export policy ID associated with the volume. export\_policy.name: The export policy name associated with the volume. idle\_duration: The time elapsed since the last request was sent by the client for this volume. local\_request\_count: A counter that tracks requests that are sent to the volume with fast-path to local node. remote\_request\_count: A counter that tracks requests that are sent to the volume with slow-path to remote node. trunking\_enabled: Flag that indicates the trunking status for the specified SVM connection. True indicates that the trunking feature is enabled while false indicates that the trunking feature is disabled.

### Related CLI command

The CLI command for ONTAP connected clients is: "nfs connected-clients show" cluster-1::\*> nfs connected-clients show Node: node1 Vserver: vs1 Data-Ip: xxx.xxx.xxx.xxx Local Remote Client-Ip Protocol Volume Policy Idle-Time Reqs Reqs Trunking -----

xxx.xxx.xxx.xxx nfs4.1 root\_vol pol1 6s 9 0 false xxx.xxx.xxx.xxx nfs3 vol1 pol1 56s 7 0 false xxx.xxx.xxx.xxx nfs4.1 vol1 pol1 6s 7 0 false 3 entries were displayed.

### Example

#### Retrieves connected client information

```
# The API:
GET /protocols/nfs/connected-clients

# The call:
curl -X GET "https://<cluster-mgmt-ip>/api/protocols/nfs/connected-clients?return_timeout=15&return_records=true" -H "accept: application/json"
```

```
# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "c642db55-b8d0-11e9-9ad1-0050568e8480",
        "name": "vs1"
      },
      "node": {
        "uuid": "cc282893-b82f-11e9-a3ad-0050568e8480",
        "name": "vsim1"
      },
      "server_ip": "10.140.72.214",
      "client_ip": "10.140.137.57",
      "volume": {
        "name": "rvol1",
        "uuid": "c6bbc6f2-b8d0-11e9-9ad1-0050568e8480"
      },
      "protocol": "nfs4"
    },
    {
      "svm": {
        "uuid": "c642db55-b8d0-11e9-9ad1-0050568e8480",
        "name": "vs1"
      },
      "node": {
        "uuid": "cc282893-b82f-11e9-a3ad-0050568e8480",
        "name": "vsim1"
      },
      "server_ip": "10.140.72.214",
      "client_ip": "10.140.137.57",
      "volume": {
        "name": "vol1",
        "uuid": "d28d1999-b8d0-11e9-9ad1-0050568e8480"
      },
      "protocol": "nfs3"
    },
    {
      "svm": {
        "uuid": "c642db55-b8d0-11e9-9ad1-0050568e8480",
        "name": "vs1"
      },
      "node": {
        "uuid": "cc282893-b82f-11e9-a3ad-0050568e8480",
        "name": "vsim1"
      }
    }
  ]
}
```

```

"server_ip": "10.140.72.214",
"client_ip": "10.140.137.57",
"volume": {
  "name": "vol1",
  "uuid": "d28d1999-b8d0-11e9-9ad1-0050568e8480"
},
"protocol": "nfs4"
}],
"num_records": 3
}

```

## Retrieve the NFS configuration for an SVM

GET /protocols/nfs/connected-clients

**Introduced In:** 9.7

Retrieves the NFS configuration of SVMs.

### Expensive properties

export\_policy.id is expensive field. It is not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- export\_policy.id

### Parameters

Name	Type	In	Required	Description
volume.name	string	query	False	Filter by volume.name
volume.uuid	string	query	False	Filter by volume.uuid
client_ip	string	query	False	Filter by client_ip
trunking_enabled	boolean	query	False	Filter by trunking_enabled <ul style="list-style-type: none"> <li>• Introduced in: 9.12</li> </ul>
protocol	string	query	False	Filter by protocol

Name	Type	In	Required	Description
export_policy.name	string	query	False	Filter by export_policy.name  • Introduced in: 9.9
export_policy.id	integer	query	False	Filter by export_policy.id  • Introduced in: 9.9
idle_duration	string	query	False	Filter by idle_duration
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
server_ip	string	query	False	Filter by server_ip
remote_request_count	integer	query	False	Filter by remote_request_count
node.name	string	query	False	Filter by node.name
node.uuid	string	query	False	Filter by node.uuid
local_request_count	integer	query	False	Filter by local_request_count
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.

Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 15</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>
return_records	boolean	query	False	<p>The default is true for GET calls. When set to false, only the number of records is returned.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records
records	array[ <a href="#">nfs_clients</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "client_ip": "string",
      "export_policy": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "id": 100,
        "name": "default"
      },
      "idle_duration": "P4DT84H30M5S",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "protocol": "nfs3",
      "server_ip": "string",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        }
      }
    }
  ]
}
```



```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
]
}

```

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
917887	The first character of the volume name must be a letter or underscore.
917888	Invalid character in volume name. It can have '_' and alphanumeric characters.

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

export\_policy

Export Policy

Name	Type	Description
_links	<a href="#">_links</a>	
id	integer	
name	string	

node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.

Name	Type	Description
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

#### volume

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the volume. This field cannot be specified in a PATCH method.
uuid	string	<p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> <li>• x-nullable: true</li> </ul>

#### nfs\_clients

Name	Type	Description
_links	<a href="#">_links</a>	
client_ip	string	Specifies IP address of the client.
export_policy	<a href="#">export_policy</a>	Export Policy
idle_duration	string	Specifies an ISO-8601 format of date and time to retrieve the idle time duration in hours, minutes, and seconds format.
local_request_count	integer	A counter that tracks requests that are sent to the volume with fast-path to local node.
node	<a href="#">node</a>	

Name	Type	Description
protocol	string	The NFS protocol version over which client is accessing the volume. The following values are supported: <ul style="list-style-type: none"> <li>• nfs - All NFS versions are considered</li> <li>• nfs3 - NFS version 3 protocol</li> <li>• nfs4 - NFS version 4 protocol</li> <li>• nfs4.1 - NFS version 4 minor version 1 protocol</li> <li>• nfs4.2 - NFS version 4 minor version 2 protocol</li> </ul>
remote_request_count	integer	A counter that tracks requests that are sent to the volume with slow-path to remote node.
server_ip	string	Specifies the IP address of the server.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.
trunking_enabled	boolean	Flag that indicates the trunking status for the specified SVM connection. True indicates that the trunking feature is enabled while false indicates that the trunking feature is disabled.
volume	<a href="#">volume</a>	

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.