



Cisco Nexus 5596 switch migration

Install and maintain

NetApp

November 21, 2025

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems-switches/switch-cisco-3132q-v/cn5596-migrate-workflow.html> on November 21, 2025. Always check docs.netapp.com for the latest.

Table of Contents

Cisco Nexus 5596 switch migration	1
Migrate from Nexus 5596 switches to Nexus 3132Q-V switches workflow	1
Migration requirements	1
Cisco Nexus 5596 requirements	1
Prepare for migration from Nexus 5596 switches to Nexus 3132Q-V switches	4
Configure your ports for migration from 5596 switches to 3132Q-V switches	14
Complete the migration from Nexus 5596 switches to Nexus 3132Q-V switches	27

Cisco Nexus 5596 switch migration

Migrate from Nexus 5596 switches to Nexus 3132Q-V switches workflow

Follow these workflow steps to migrate your Cisco Nexus 5596 switches to Cisco Nexus 3132Q-V switches.

1

Migration requirements

Review the requirements and example switch information for the migration process.

2

Prepare for migration

Prepare your Nexus 5596 switches for migration to Nexus 3132Q-V switches.

3

Configure your ports

Configure your ports for migration to the new Nexus 3132Q-V switches.

4

Complete your migration

Complete your migration to the new Nexus 3132Q-V switches.

Migration requirements

Cisco Nexus 3132Q-V switches can be used as cluster switches in your AFF or FAS cluster. Cluster switches allow you to build ONTAP clusters with more than two nodes.



The procedure requires the use of both ONTAP commands and Cisco Nexus 3000 Series Switches commands; ONTAP commands are used unless otherwise indicated.

For more information, see:

- [Cisco Ethernet Switch](#)
- [Hardware Universe](#)

Cisco Nexus 5596 requirements

The cluster switches use the following ports for connections to nodes:

- Nexus 5596: ports e1/1-40 (10 GbE)
- Nexus 3132Q-V: ports e1/1-30 (10/40/100 GbE)

The cluster switches use the following Inter-Switch Link (ISL) ports:

- Nexus 5596: ports e1/41-48 (10 GbE)
- Nexus 3132Q-V: ports e1/31-32 (40/100 GbE)

The [Hardware Universe](#) contains information about supported cabling to Nexus 3132Q-V switches:

- Nodes with 10 GbE cluster connections require QSFP to SFP+ optical fiber breakout cables or QSFP to SFP+ copper breakout cables.
- Nodes with 40/100 GbE cluster connections require supported QSFP/QSFP28 optical modules with fiber cables or QSFP/QSFP28 copper direct-attach cables.

The cluster switches use the appropriate ISL cabling:

- Beginning: Nexus 5596 (SFP+ to SFP+)
 - 8x SFP+ fiber or copper direct-attach cables
- Interim: Nexus 5596 to Nexus 3132Q-V (QSFP to 4xSFP+ break-out)
 - 1x QSFP to SFP+ fiber break-out or copper break-out cables
- Final: Nexus 3132Q-V to Nexus 3132Q-V (QSFP28 to QSFP28)
 - 2x QSFP28 fiber or copper direct-attach cables
- On Nexus 3132Q-V switches, you can operate QSFP/QSFP28 ports in either 40/100 Gigabit Ethernet or 4 x10 Gigabit Ethernet modes.

By default, there are 32 ports in the 40/100 Gigabit Ethernet mode. These 40 Gigabit Ethernet ports are numbered in a 2-tuple naming convention. For example, the second 40 Gigabit Ethernet port is numbered as 1/2.

The process of changing the configuration from 40 Gigabit Ethernet to 10 Gigabit Ethernet is called *breakout* and the process of changing the configuration from 10 Gigabit Ethernet to 40 Gigabit Ethernet is called *breakin*.

When you break out a 40/100 Gigabit Ethernet port into 10 Gigabit Ethernet ports, the resulting ports are numbered using a 3-tuple naming convention. For example, the break-out ports of the second 40/100 Gigabit Ethernet port are numbered as 1/2/1, 1/2/2, 1/2/3, and 1/2/4.

- On the left side of Nexus 3132Q-V switches are 2 SFP+ ports, called 1/33 and 1/34.
- You have configured some of the ports on Nexus 3132Q-V switches to run at 10 GbE or 40/100 GbE.



You can break out the first six ports into 4x10 GbE mode by using the `interface breakout module 1 port 1-6 map 10g-4x` command. Similarly, you can regroup the first six QSFP+ ports from breakout configuration by using the `no interface breakout module 1 port 1-6 map 10g-4x` command.

- You have done the planning, migration, and read the required documentation on 10 GbE and 40/100 GbE connectivity from nodes to Nexus 3132Q-V cluster switches.
- The ONTAP and NX-OS versions supported in this procedure are here: [Cisco Ethernet Switches](#).

About the examples used

The examples in this procedure describe replacing Cisco Nexus 5596 switches with Cisco Nexus 3132Q-V switches. You can use these steps (with modifications) for other older Cisco switches.

The procedure also uses the following switch and node nomenclature:

- The command outputs might vary depending on different releases of ONTAP.
- The Nexus 5596 switches to be replaced are **CL1** and **CL2**.
- The Nexus 3132Q-V switches to replace the Nexus 5596 switches are **C1** and **C2**.
- **n1_clus1** is the first cluster logical interface (LIF) connected to cluster switch 1 (CL1 or C1) for node **n1**.
- **n1_clus2** is the first cluster LIF connected to cluster switch 2 (CL2 or C2) for node **n1**.
- **n1_clus3** is the second LIF connected to cluster switch 2 (CL2 or C2) for node **n1**.
- **n1_clus4** is the second LIF connected to cluster switch 1 (CL1 or C1) for node **n1**.
- The number of 10 GbE and 40/100 GbE ports are defined in the reference configuration files (RCFs) available on [Cisco® Cluster Network Switch Reference Configuration File Download](#).
- The nodes are **n1**, **n2**, **n3**, and **n4**.

The examples in this procedure use four nodes:

- Two nodes use four 10 GbE cluster interconnect ports: **e0a**, **e0b**, **e0c**, and **e0d**.
- The other two nodes use two 40 GbE cluster interconnect ports: **e4a** and **e4e**.

The [Hardware Universe](#) lists the actual cluster ports on your platforms.

Scenarios covered

This procedure covers the following scenarios:

- The cluster starts with two nodes connected and functioning in a two Nexus 5596 cluster switches.
- The cluster switch CL2 to be replaced by C2 (steps 1 to 19):
 - Traffic on all cluster ports and LIFs on all nodes connected to CL2 are migrated onto the first cluster ports and LIFs connected to CL1.
 - Disconnect cabling from all cluster ports on all nodes connected to CL2, and then use supported break-out cabling to reconnect the ports to new cluster switch C2.
 - Disconnect cabling between ISL ports between CL1 and CL2, and then use supported break-out cabling to reconnect the ports from CL1 to C2.
 - Traffic on all cluster ports and LIFs connected to C2 on all nodes is reverted.
- The cluster switch CL2 to be replaced by C2.
 - Traffic on all cluster ports or LIFs on all nodes connected to CL1 are migrated onto the second cluster ports or LIFs connected to C2.
 - Disconnect cabling from all cluster port on all nodes connected to CL1 and reconnect, using supported break-out cabling, to new cluster switch C1.
 - Disconnect cabling between ISL ports between CL1 and C2, and reconnect using supported cabling, from C1 to C2.
 - Traffic on all cluster ports or LIFs connected to C1 on all nodes is reverted.
- Two FAS9000 nodes have been added to cluster with examples showing cluster details.

What's next?

After you've reviewed the migration requirements, you can [prepare to migrate your switches](#).

Prepare for migration from Nexus 5596 switches to Nexus 3132Q-V switches

Follow these steps to prepare your Cisco Nexus 5596 switches for migration to Cisco Nexus 3132Q-V switches.

Steps

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message: `system node autosupport invoke -node * -type all -message MAINT=xh`

x is the duration of the maintenance window in hours.



The message notifies technical support of this maintenance task so that automatic case creation is suppressed during the maintenance window.

2. Display information about the devices in your configuration:

```
network device-discovery show
```

Show example

The following example shows how many cluster interconnect interfaces have been configured in each node for each cluster interconnect switch:

```
cluster::> network device-discovery show
      Local  Discovered
      Node   Port   Device           Interface      Platform
      -----  -----  -----
      n1      /cdp
              e0a    CL1           Ethernet1/1    N5K-C5596UP
              e0b    CL2           Ethernet1/1    N5K-C5596UP
              e0c    CL2           Ethernet1/2    N5K-C5596UP
              e0d    CL1           Ethernet1/2    N5K-C5596UP
      n2      /cdp
              e0a    CL1           Ethernet1/3    N5K-C5596UP
              e0b    CL2           Ethernet1/3    N5K-C5596UP
              e0c    CL2           Ethernet1/4    N5K-C5596UP
              e0d    CL1           Ethernet1/4    N5K-C5596UP
8 entries were displayed.
```

3. Determine the administrative or operational status for each cluster interface:

- a. Display the network port attributes:

```
network port show
```

Show example

The following example displays the network port attributes on a system:

```
cluster::*> network port show -role cluster
  (network port show)
Node: n1

Ignore                                         Speed (Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper
Status   Status

-----
-----
e0a      Cluster      Cluster          up   9000 auto/10000 -
-
e0b      Cluster      Cluster          up   9000 auto/10000 -
-
e0c      Cluster      Cluster          up   9000 auto/10000 -
-
e0d      Cluster      Cluster          up   9000 auto/10000 -
-
Node: n2

Ignore                                         Speed (Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper
Status   Status

-----
-----
e0a      Cluster      Cluster          up   9000 auto/10000 -
-
e0b      Cluster      Cluster          up   9000 auto/10000 -
-
e0c      Cluster      Cluster          up   9000 auto/10000 -
-
e0d      Cluster      Cluster          up   9000 auto/10000 -
-
8 entries were displayed.
```

b. Display information about the logical interfaces:

```
network interface show
```

Show example

The following example displays the general information about all of the LIFs on your system:

```
cluster::*> network interface show -role cluster
(network interface show)
      Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----
-----
Cluster
      n1_clus1      up/up      10.10.0.1/24      n1
e0a      true
      n1_clus2      up/up      10.10.0.2/24      n1
e0b      true
      n1_clus3      up/up      10.10.0.3/24      n1
e0c      true
      n1_clus4      up/up      10.10.0.4/24      n1
e0d      true
      n2_clus1      up/up      10.10.0.5/24      n2
e0a      true
      n2_clus2      up/up      10.10.0.6/24      n2
e0b      true
      n2_clus3      up/up      10.10.0.7/24      n2
e0c      true
      n2_clus4      up/up      10.10.0.8/24      n2
e0d      true
8 entries were displayed.
```

c. Display information about the discovered cluster switches:

```
system cluster-switch show
```

Show example

The following example displays the cluster switches that are known to the cluster, along with their management IP addresses:

```
cluster::*> system cluster-switch show

Switch          Type          Address
Model

-----
-----
CL1            cluster-network 10.10.1.101
NX5596

    Serial Number: 01234567
    Is Monitored: true
    Reason:
    Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
    7.1(1)N1(1)
    Version Source: CDP
CL2            cluster-network 10.10.1.102
NX5596

    Serial Number: 01234568
    Is Monitored: true
    Reason:
    Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
    7.1(1)N1(1)
    Version Source: CDP

2 entries were displayed.
```

4. Set the `-auto-revert` parameter to `false` on cluster LIFs `clus1` and `clus2` on both nodes:

```
network interface modify
```

Show example

```
cluster::*> network interface modify -vserver node1 -lif clus1 -auto
-revert false
cluster::*> network interface modify -vserver node1 -lif clus2 -auto
-revert false
cluster::*> network interface modify -vserver node2 -lif clus1 -auto
-revert false
cluster::*> network interface modify -vserver node2 -lif clus2 -auto
-revert false
```

5. Verify that the appropriate RCF and image are installed on the new 3132Q-V switches as necessary for your requirements, and make the essential site customizations, such as users and passwords, network addresses, and so on.

You must prepare both switches at this time. If you need to upgrade the RCF and image, follow these steps:

- Go to [Cisco Ethernet Switches](#) on the NetApp Support Site.
- Note your switch and the required software versions in the table on that page.
- Download the appropriate version of the RCF.
- Select **CONTINUE** on the **Description** page, accept the license agreement, and then follow the instructions on the **Download** page to download the RCF.
- Download the appropriate version of the image software.

See the *ONTAP 8.x or later Cluster and Management Network Switch Reference Configuration Files* Download page, and then select the appropriate version.

To find the correct version, see the *ONTAP 8.x or later Cluster Network Switch Download page*.

6. Migrate the LIFs associated with the second Nexus 5596 switch to be replaced:

```
network interface migrate
```

Show example

The following example shows n1 and n2, but LIF migration must be done on all of the nodes:

```
cluster::*> network interface migrate -vserver Cluster -lif n1_clus2
-source-node n1 -
destination-node n1 -destination-port e0a
cluster::*> network interface migrate -vserver Cluster -lif n1_clus3
-source-node n1 -
destination-node n1 -destination-port e0d
cluster::*> network interface migrate -vserver Cluster -lif n2_clus2
-source-node n2 -
destination-node n2 -destination-port e0a
cluster::*> network interface migrate -vserver Cluster -lif n2_clus3
-source-node n2 -
destination-node n2 -destination-port e0d
```

7. Verify the cluster's health:

```
network interface show
```

Show example

The following example shows the result of the previous network interface migrate command:

```
cluster::*> network interface show -role cluster
(network interface show)
      Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----
----- Cluster
      e0a      n1_clus1  up/up      10.10.0.1/24      n1
      e0a      true
      e0a      n1_clus2  up/up      10.10.0.2/24      n1
      e0d      false
      e0d      n1_clus3  up/up      10.10.0.3/24      n1
      e0d      false
      e0d      n1_clus4  up/up      10.10.0.4/24      n1
      e0a      true
      e0a      n2_clus1  up/up      10.10.0.5/24      n2
      e0a      true
      e0a      n2_clus2  up/up      10.10.0.6/24      n2
      e0d      false
      e0d      n2_clus3  up/up      10.10.0.7/24      n2
      e0d      false
      e0d      n2_clus4  up/up      10.10.0.8/24      n2
      e0d      true
8 entries were displayed.
```

8. Shut down the cluster interconnect ports that are physically connected to switch CL2:

```
network port modify
```

Show example

The following commands shut down the specified ports on n1 and n2, but the ports must be shut down on all nodes:

```
cluster::*> network port modify -node n1 -port e0b -up-admin false
cluster::*> network port modify -node n1 -port e0c -up-admin false
cluster::*> network port modify -node n2 -port e0b -up-admin false
cluster::*> network port modify -node n2 -port e0c -up-admin false
```

9. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check  
cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

		Source	Destination	
Packet				
Node	Date	LIF	LIF	
Loss				

n1				
	3/5/2022 19:21:18 -06:00	n1_clus2	n2_clus1	none
	3/5/2022 19:21:20 -06:00	n1_clus2	n2_clus2	none
n2				
	3/5/2022 19:21:18 -06:00	n2_clus2	n1_clus1	none
	3/5/2022 19:21:20 -06:00	n2_clus2	n1_clus2	none

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster::*> cluster ping-cluster -node n1
Host is n1
Getting addresses from network interface table...
Cluster n1_clus1 n1      e0a 10.10.0.1
Cluster n1_clus2 n1      e0b 10.10.0.2
Cluster n1_clus3 n1      e0c 10.10.0.3
Cluster n1_clus4 n1      e0d 10.10.0.4
Cluster n2_clus1 n2      e0a 10.10.0.5
Cluster n2_clus2 n2      e0b 10.10.0.6
Cluster n2_clus3 n2      e0c 10.10.0.7
Cluster n2_clus4 n2      e0d 10.10.0.8

Local = 10.10.0.1 10.10.0.2 10.10.0.3 10.10.0.4
Remote = 10.10.0.5 10.10.0.6 10.10.0.7 10.10.0.8
Cluster Vserver Id = 4294967293
Ping status:....
Basic connectivity succeeds on 16 path(s)
Basic connectivity fails on 0 path(s)
.
.
.
Detected 1500 byte MTU on 16 path(s):
  Local 10.10.0.1 to Remote 10.10.0.5
  Local 10.10.0.1 to Remote 10.10.0.6
  Local 10.10.0.1 to Remote 10.10.0.7
  Local 10.10.0.1 to Remote 10.10.0.8
  Local 10.10.0.2 to Remote 10.10.0.5
  Local 10.10.0.2 to Remote 10.10.0.6
  Local 10.10.0.2 to Remote 10.10.0.7
  Local 10.10.0.2 to Remote 10.10.0.8
  Local 10.10.0.3 to Remote 10.10.0.5
  Local 10.10.0.3 to Remote 10.10.0.6
  Local 10.10.0.3 to Remote 10.10.0.7
  Local 10.10.0.3 to Remote 10.10.0.8
  Local 10.10.0.4 to Remote 10.10.0.5
  Local 10.10.0.4 to Remote 10.10.0.6
  Local 10.10.0.4 to Remote 10.10.0.7
  Local 10.10.0.4 to Remote 10.10.0.8

Larger than PMTU communication succeeds on 16 path(s)
RPC status:
  4 paths up, 0 paths down (tcp check)
  4 paths up, 0 paths down (udp check)

```

10. Shut down the ISL ports 41 through 48 on the active Nexus 5596 switch CL1:

Show example

The following example shows how to shut down ISL ports 41 through 48 on the Nexus 5596 switch CL1:

```
(CL1) # configure
(CL1) (Config) # interface e1/41-48
(CL1) (config-if-range) # shutdown
(CL1) (config-if-range) # exit
(CL1) (Config) # exit
(CL1) #
```

If you are replacing a Nexus 5010 or 5020, specify the appropriate port numbers for ISL.

11. Build a temporary ISL between CL1 and C2.

Show example

The following example shows a temporary ISL being set up between CL1 and C2:

```
C2# configure
C2(config)# interface port-channel 2
C2(config-if)# switchport mode trunk
C2(config-if)# spanning-tree port type network
C2(config-if)# mtu 9216
C2(config-if)# interface breakout module 1 port 24 map 10g-4x
C2(config)# interface e1/24/1-4
C2(config-if-range) # switchport mode trunk
C2(config-if-range) # mtu 9216
C2(config-if-range) # channel-group 2 mode active
C2(config-if-range) # exit
C2(config-if) # exit
```

What's next?

After you've prepared to migrate your switches, you can [configure your ports](#).

Configure your ports for migration from 5596 switches to 3132Q-V switches

Follow these steps to configure your ports for migration from the Nexus 5596 switches to the new Nexus 3132Q-V switches.

Steps

1. On all nodes, remove all cables attached to the Nexus 5596 switch CL2.

With supported cabling, reconnect disconnected ports on all nodes to the Nexus 3132Q-V switch C2.

2. Remove all the cables from the Nexus 5596 switch CL2.

Attach the appropriate Cisco QSFP to SFP+ break-out cables connecting port 1/24 on the new Cisco 3132Q-V switch, C2, to ports 45 to 48 on existing Nexus 5596, CL1.

3. Verify that interfaces eth1/45-48 already have channel-group 1 mode active in their running configuration.
4. Bring up ISLs ports 45 through 48 on the active Nexus 5596 switch CL1.

Show example

The following example shows ISLs ports 45 through 48 being brought up:

```
(CL1) # configure
(CL1) (Config) # interface e1/45-48
(CL1) (config-if-range) # no shutdown
(CL1) (config-if-range) # exit
(CL1) (Config) # exit
(CL1) #
```

5. Verify that the ISLs are up on the Nexus 5596 switch CL1:

```
show port-channel summary
```

Show example

Ports eth1/45 through eth1/48 should indicate (P) meaning that the ISL ports are up in the port-channel:

Example

```
CL1# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
      I - Individual    H - Hot-standby (LACP only)
      S - Suspended      r - Module-removed
      S - Switched       R - Routed
      U - Up (port-channel)
      M - Not in use. Min-links not met
```

Group	Port- Channel	Type	Protocol	Member Ports
1	Po1 (SU) Eth1/43 (D)	Eth	LACP	Eth1/41 (D) Eth1/42 (D) Eth1/44 (D) Eth1/45 (P) Eth1/46 (P) Eth1/47 (P) Eth1/48 (P)

6. Verify that the ISLs are up on the 3132Q-V switch C2:

```
show port-channel summary
```

Show example

Ports eth1/24/1, eth1/24/2, eth1/24/3, and eth1/24/4 should indicate (P) meaning that the ISL ports are up in the port-channel:

```
C2# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
      I - Individual    H - Hot-standby (LACP only)
      S - Suspended      r - Module-removed
      S - Switched       R - Routed
      U - Up (port-channel)
      M - Not in use. Min-links not met
-----
-----
Group Port-      Type   Protocol Member Ports
      Channel
-----
1      Po1 (SU)    Eth    LACP     Eth1/31 (D)   Eth1/32 (D)
2      Po2 (SU)    Eth    LACP     Eth1/24/1 (P) Eth1/24/2 (P)
                           Eth1/24/3 (P)
                                         Eth1/24/4 (P)
```

7. On all nodes, bring up all the cluster interconnect ports connected to the 3132Q-V switch C2:

```
network port modify
```

Show example

The following example shows the specified ports being brought up on nodes n1 and n2:

```
cluster::*> network port modify -node n1 -port e0b -up-admin true
cluster::*> network port modify -node n1 -port e0c -up-admin true
cluster::*> network port modify -node n2 -port e0b -up-admin true
cluster::*> network port modify -node n2 -port e0c -up-admin true
```

8. On all nodes, revert all of the migrated cluster interconnect LIFs connected to C2:

```
network interface revert
```

Show example

The following example shows the migrated cluster LIFs being reverted to their home ports on nodes n1 and n2:

```
cluster::*> network interface revert -vserver Cluster -lif n1_clus2
cluster::*> network interface revert -vserver Cluster -lif n1_clus3
cluster::*> network interface revert -vserver Cluster -lif n2_clus2
cluster::*> network interface revert -vserver Cluster -lif n2_clus3
```

9. Verify all the cluster interconnect ports are now reverted to their home:

```
network interface show
```

Show example

The following example shows that the LIFs on clus2 reverted to their home ports and shows that the LIFs are successfully reverted if the ports in the Current Port column have a status of true in the Is Home column. If the Is Home value is false, the LIF has not been reverted.

```
cluster::*> network interface show -role cluster
(network interface show)
      Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----
-----
Cluster
      n1_clus1  up/up      10.10.0.1/24      n1
e0a      true
      n1_clus2  up/up      10.10.0.2/24      n1
e0b      true
      n1_clus3  up/up      10.10.0.3/24      n1
e0c      true
      n1_clus4  up/up      10.10.0.4/24      n1
e0d      true
      n2_clus1  up/up      10.10.0.5/24      n2
e0a      true
      n2_clus2  up/up      10.10.0.6/24      n2
e0b      true
      n2_clus3  up/up      10.10.0.7/24      n2
e0c      true
      n2_clus4  up/up      10.10.0.8/24      n2
e0d      true
8 entries were displayed.
```

10. Verify that the clustered ports are connected:

```
network port show
```

Show example

The following example shows the result of the previous `network port modify` command, verifying that all the cluster interconnects are up:

```
cluster::*> network port show -role cluster
  (network port show)
Node: n1

Ignore

Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster          up   9000 auto/10000 -
-
e0b      Cluster      Cluster          up   9000 auto/10000 -
-
e0c      Cluster      Cluster          up   9000 auto/10000 -
-
e0d      Cluster      Cluster          up   9000 auto/10000 -
-
Node: n2

Ignore

Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster          up   9000 auto/10000 -
-
e0b      Cluster      Cluster          up   9000 auto/10000 -
-
e0c      Cluster      Cluster          up   9000 auto/10000 -
-
e0d      Cluster      Cluster          up   9000 auto/10000 -
-
8 entries were displayed.
```

11. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check  
cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

		Source	Destination	
Packet				
Node	Date	LIF	LIF	
Loss				

n1				
	3/5/2022 19:21:18 -06:00	n1_clus2	n2_clus1	none
	3/5/2022 19:21:20 -06:00	n1_clus2	n2_clus2	none
n2				
	3/5/2022 19:21:18 -06:00	n2_clus2	n1_clus1	none
	3/5/2022 19:21:20 -06:00	n2_clus2	n1_clus2	none

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster::*> cluster ping-cluster -node n1
Host is n1
Getting addresses from network interface table...
Cluster n1_clus1 n1      e0a 10.10.0.1
Cluster n1_clus2 n1      e0b 10.10.0.2
Cluster n1_clus3 n1      e0c 10.10.0.3
Cluster n1_clus4 n1      e0d 10.10.0.4
Cluster n2_clus1 n2      e0a 10.10.0.5
Cluster n2_clus2 n2      e0b 10.10.0.6
Cluster n2_clus3 n2      e0c 10.10.0.7
Cluster n2_clus4 n2      e0d 10.10.0.8

Local = 10.10.0.1 10.10.0.2 10.10.0.3 10.10.0.4
Remote = 10.10.0.5 10.10.0.6 10.10.0.7 10.10.0.8
Cluster Vserver Id = 4294967293
Ping status:....
Basic connectivity succeeds on 16 path(s)
Basic connectivity fails on 0 path(s)
.
.
.
Detected 1500 byte MTU on 16 path(s):
  Local 10.10.0.1 to Remote 10.10.0.5
  Local 10.10.0.1 to Remote 10.10.0.6
  Local 10.10.0.1 to Remote 10.10.0.7
  Local 10.10.0.1 to Remote 10.10.0.8
  Local 10.10.0.2 to Remote 10.10.0.5
  Local 10.10.0.2 to Remote 10.10.0.6
  Local 10.10.0.2 to Remote 10.10.0.7
  Local 10.10.0.2 to Remote 10.10.0.8
  Local 10.10.0.3 to Remote 10.10.0.5
  Local 10.10.0.3 to Remote 10.10.0.6
  Local 10.10.0.3 to Remote 10.10.0.7
  Local 10.10.0.3 to Remote 10.10.0.8
  Local 10.10.0.4 to Remote 10.10.0.5
  Local 10.10.0.4 to Remote 10.10.0.6
  Local 10.10.0.4 to Remote 10.10.0.7
  Local 10.10.0.4 to Remote 10.10.0.8

Larger than PMTU communication succeeds on 16 path(s)
RPC status:
  4 paths up, 0 paths down (tcp check)
  4 paths up, 0 paths down (udp check)

```

12. On each node in the cluster, migrate the interfaces associated with the first Nexus 5596 switch, CL1, to be replaced:

```
network interface migrate
```

Show example

The following example shows the ports or LIFs being migrated on nodes n1 and n2:

```
cluster::*> network interface migrate -vserver Cluster -lif n1_clus1
-source-node n1 -
destination-node n1 -destination-port e0b
cluster::*> network interface migrate -vserver Cluster -lif n1_clus4
-source-node n1 -
destination-node n1 -destination-port e0c
cluster::*> network interface migrate -vserver Cluster -lif n2_clus1
-source-node n2 -
destination-node n2 -destination-port e0b
cluster::*> network interface migrate -vserver Cluster -lif n2_clus4
-source-node n2 -
destination-node n2 -destination-port e0c
```

13. Verify the cluster status:

```
network interface show
```

Show example

The following example shows that the required cluster LIFs have been migrated to appropriate cluster ports hosted on cluster switch C2:

```
(network interface show)
  Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port        Home
-----
-----
Cluster
  e0b          n1_clus1  up/up      10.10.0.1/24      n1
  e0b          false
  e0b          n1_clus2  up/up      10.10.0.2/24      n1
  e0b          true
  e0c          n1_clus3  up/up      10.10.0.3/24      n1
  e0c          true
  e0c          n1_clus4  up/up      10.10.0.4/24      n1
  e0b          n2_clus1  up/up      10.10.0.5/24      n2
  e0b          false
  e0b          n2_clus2  up/up      10.10.0.6/24      n2
  e0b          true
  e0c          n2_clus3  up/up      10.10.0.7/24      n2
  e0c          true
  e0c          n2_clus4  up/up      10.10.0.8/24      n2
  e0c          false
8 entries were displayed.
-----
```

14. On all the nodes, shut down the node ports that are connected to CL1:

```
network port modify
```

Show example

The following example shows the specified ports being shut down on nodes n1 and n2:

```
cluster::*> network port modify -node n1 -port e0a -up-admin false
cluster::*> network port modify -node n1 -port e0d -up-admin false
cluster::*> network port modify -node n2 -port e0a -up-admin false
cluster::*> network port modify -node n2 -port e0d -up-admin false
```

15. Shut down the ISL ports 24, 31, and 32 on the active 3132Q-V switch C2:

shutdown

Show example

The following example shows how to shut down ISLs 24, 31, and 32:

```
C2# configure
C2(Config)# interface e1/24/1-4
C2(config-if-range)# shutdown
C2(config-if-range)# exit
C2(config)# interface 1/31-32
C2(config-if-range)# shutdown
C2(config-if-range)# exit
C2(config-if)# exit
C2#
```

16. On all nodes, remove all cables attached to the Nexus 5596 switch CL1.

With supported cabling, reconnect disconnected ports on all nodes to the Nexus 3132Q-V switch C1.

17. Remove the QSFP breakout cable from Nexus 3132Q-V C2 ports e1/24.

Connect ports e1/31 and e1/32 on C1 to ports e1/31 and e1/32 on C2 using supported Cisco QSFP optical fiber or direct-attach cables.

18. Restore the configuration on port 24 and remove the temporary Port Channel 2 on C2:

```
C2# configure
C2(config)# no interface breakout module 1 port 24 map 10g-4x
C2(config)# no interface port-channel 2
C2(config-if)# int e1/24
C2(config-if)# description 40GbE Node Port
C2(config-if)# spanning-tree port type edge
C2(config-if)# spanning-tree bpduguard enable
C2(config-if)# mtu 9216
C2(config-if-range)# exit
C2(config)# exit
C2# copy running-config startup-config
[#####] 100%
Copy Complete.
```

19. Bring up ISL ports 31 and 32 on C2, the active 3132Q-V switch: no shutdown

Show example

The following example shows how to bring up ISLs 31 and 32 on the 3132Q-V switch C2:

```
C2# configure
C2(config)# interface ethernet 1/31-32
C2(config-if-range)# no shutdown
C2(config-if-range)# exit
C2(config)# exit
C2# copy running-config startup-config
[#####] 100%
Copy Complete.
```

What's next?

After you've configured your switch ports, you can [complete your migration](#).

Complete the migration from Nexus 5596 switches to Nexus 3132Q-V switches

Complete the following steps to finalize the Nexus 5596 switches migration to Nexus 3132Q-V switches.

Steps

1. Verify that the ISL connections are up on the 3132Q-V switch C2:

```
show port-channel summary
```

Show example

Ports Eth1/31 and Eth1/32 should indicate (P), meaning that both the ISL ports are up in the port-channel:

```
C1# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
      I - Individual    H - Hot-standby (LACP only)
      S - Suspended      r - Module-removed
      S - Switched       R - Routed
      U - Up (port-channel)
      M - Not in use. Min-links not met
-----
-----
Group Port-      Type     Protocol Member Ports
      Channel
-----
1      Po1 (SU)      Eth      LACP      Eth1/31 (P)   Eth1/32 (P)
```

2. On all nodes, bring up all the cluster interconnect ports connected to the new 3132Q-V switch C1:

```
network port modify
```

Show example

The following example shows all the cluster interconnect ports being brought up for n1 and n2 on the 3132Q-V switch C1:

```
cluster::*> network port modify -node n1 -port e0a -up-admin true
cluster::*> network port modify -node n1 -port e0d -up-admin true
cluster::*> network port modify -node n2 -port e0a -up-admin true
cluster::*> network port modify -node n2 -port e0d -up-admin true
```

3. Verify the status of the cluster node port:

```
network port show
```

Show example

The following example verifies that all cluster interconnect ports on all nodes on the new 3132Q-V switch C1 are up:

```
cluster::*> network port show -role cluster
  (network port show)
Node: n1

Ignore
                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up      9000  auto/10000  -
-
e0b      Cluster      Cluster      up      9000  auto/10000  -
-
e0c      Cluster      Cluster      up      9000  auto/10000  -
-
e0d      Cluster      Cluster      up      9000  auto/10000  -
-
Node: n2

Ignore
                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up      9000  auto/10000  -
-
e0b      Cluster      Cluster      up      9000  auto/10000  -
-
e0c      Cluster      Cluster      up      9000  auto/10000  -
-
e0d      Cluster      Cluster      up      9000  auto/10000  -
-
8 entries were displayed.
```

4. On all nodes, revert the specific cluster LIFs to their home ports:

```
network interface revert
```

Show example

The following example shows the specific cluster LIFs being reverted to their home ports on nodes n1 and n2:

```
cluster::>*> network interface revert -vserver Cluster -lif n1_clus1
cluster::>*> network interface revert -vserver Cluster -lif n1_clus4
cluster::>*> network interface revert -vserver Cluster -lif n2_clus1
cluster::>*> network interface revert -vserver Cluster -lif n2_clus4
```

5. Verify that the interface is home:

```
network interface show
```

Show example

The following example shows the status of cluster interconnect interfaces is up and Is home for n1 and n2:

```
cluster::*> network interface show -role cluster
(network interface show)
      Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----
-----
Cluster
      n1_clus1  up/up      10.10.0.1/24      n1
e0a      true
      n1_clus2  up/up      10.10.0.2/24      n1
e0b      true
      n1_clus3  up/up      10.10.0.3/24      n1
e0c      true
      n1_clus4  up/up      10.10.0.4/24      n1
e0d      true
      n2_clus1  up/up      10.10.0.5/24      n2
e0a      true
      n2_clus2  up/up      10.10.0.6/24      n2
e0b      true
      n2_clus3  up/up      10.10.0.7/24      n2
e0c      true
      n2_clus4  up/up      10.10.0.8/24      n2
e0d      true
8 entries were displayed.
```

6. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check  
cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

		Source	Destination	
Packet				
Node	Date	LIF	LIF	
Loss				

n1				
	3/5/2022 19:21:18 -06:00	n1_clus2	n2_clus1	none
	3/5/2022 19:21:20 -06:00	n1_clus2	n2_clus2	none
n2				
	3/5/2022 19:21:18 -06:00	n2_clus2	n1_clus1	none
	3/5/2022 19:21:20 -06:00	n2_clus2	n1_clus2	none

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster::*> cluster ping-cluster -node n1
Host is n1
Getting addresses from network interface table...
Cluster n1_clus1 n1      e0a 10.10.0.1
Cluster n1_clus2 n1      e0b 10.10.0.2
Cluster n1_clus3 n1      e0c 10.10.0.3
Cluster n1_clus4 n1      e0d 10.10.0.4
Cluster n2_clus1 n2      e0a 10.10.0.5
Cluster n2_clus2 n2      e0b 10.10.0.6
Cluster n2_clus3 n2      e0c 10.10.0.7
Cluster n2_clus4 n2      e0d 10.10.0.8

Local = 10.10.0.1 10.10.0.2 10.10.0.3 10.10.0.4
Remote = 10.10.0.5 10.10.0.6 10.10.0.7 10.10.0.8
Cluster Vserver Id = 4294967293
Ping status:....
Basic connectivity succeeds on 16 path(s)
Basic connectivity fails on 0 path(s)
.
.
.
Detected 1500 byte MTU on 16 path(s):
  Local 10.10.0.1 to Remote 10.10.0.5
  Local 10.10.0.1 to Remote 10.10.0.6
  Local 10.10.0.1 to Remote 10.10.0.7
  Local 10.10.0.1 to Remote 10.10.0.8
  Local 10.10.0.2 to Remote 10.10.0.5
  Local 10.10.0.2 to Remote 10.10.0.6
  Local 10.10.0.2 to Remote 10.10.0.7
  Local 10.10.0.2 to Remote 10.10.0.8
  Local 10.10.0.3 to Remote 10.10.0.5
  Local 10.10.0.3 to Remote 10.10.0.6
  Local 10.10.0.3 to Remote 10.10.0.7
  Local 10.10.0.3 to Remote 10.10.0.8
  Local 10.10.0.4 to Remote 10.10.0.5
  Local 10.10.0.4 to Remote 10.10.0.6
  Local 10.10.0.4 to Remote 10.10.0.7
  Local 10.10.0.4 to Remote 10.10.0.8

Larger than PMTU communication succeeds on 16 path(s)
RPC status:
  4 paths up, 0 paths down (tcp check)
  4 paths up, 0 paths down (udp check)

```

7. Expand the cluster by adding nodes to the Nexus 3132Q-V cluster switches.
8. Display the information about the devices in your configuration:

◦ network device-discovery show

- network port show -role cluster
- network interface show -role cluster
- system cluster-switch show

Show example

The following examples show nodes n3 and n4 with 40 GbE cluster ports connected to ports e1/7 and e1/8, respectively on both the Nexus 3132Q-V cluster switches, and both nodes have joined the cluster. The 40 GbE cluster interconnect ports used are e4a and e4e.

```
cluster::> network device-discovery show
      Local   Discovered
      Node    Port   Device        Interface      Platform
-----  -----  -----  -----
-----  -----
n1      /cdp
      e0a    C1          Ethernet1/1/1    N3K-
C3132Q-V
      e0b    C2          Ethernet1/1/1    N3K-
C3132Q-V
      e0c    C2          Ethernet1/1/2    N3K-
C3132Q-V
      e0d    C1          Ethernet1/1/2    N3K-
C3132Q-V
n2      /cdp
      e0a    C1          Ethernet1/1/3    N3K-
C3132Q-V
      e0b    C2          Ethernet1/1/3    N3K-
C3132Q-V
      e0c    C2          Ethernet1/1/4    N3K-
C3132Q-V
      e0d    C1          Ethernet1/1/4    N3K-
C3132Q-V
n3      /cdp
      e4a    C1          Ethernet1/7     N3K-
C3132Q-V
      e4e    C2          Ethernet1/7     N3K-
C3132Q-V
n4      /cdp
      e4a    C1          Ethernet1/8     N3K-
C3132Q-V
      e4e    C2          Ethernet1/8     N3K-
C3132Q-V
12 entries were displayed.
```

```
cluster::*> network port show -role cluster
  (network port show)
Node: n1
```

Ignore

Speed (Mbps)

Health	Health						
Port Status	IPspace Status	Broadcast	Domain	Link	MTU	Admin/Oper	
<hr/>							
<hr/>							
e0a	Cluster	Cluster		up	9000	auto/10000	-
-							
e0b	Cluster	Cluster		up	9000	auto/10000	-
-							
e0c	Cluster	Cluster		up	9000	auto/10000	-
-							
e0d	Cluster	Cluster		up	9000	auto/10000	-
-							

Node: n2

Ignore

Speed (Mbps)

Health	Health						
Port Status	IPspace Status	Broadcast	Domain	Link	MTU	Admin/Oper	
<hr/>							
<hr/>							
e0a	Cluster	Cluster		up	9000	auto/10000	-
-							
e0b	Cluster	Cluster		up	9000	auto/10000	-
-							
e0c	Cluster	Cluster		up	9000	auto/10000	-
-							
e0d	Cluster	Cluster		up	9000	auto/10000	-
-							

Node: n3

Ignore

Speed (Mbps)

Health	Health						
Port Status	IPspace Status	Broadcast	Domain	Link	MTU	Admin/Oper	
<hr/>							
<hr/>							
e4a	Cluster	Cluster		up	9000	auto/40000	-
-							
e4e	Cluster	Cluster		up	9000	auto/40000	-

Node: n4

Ignore

Speed (Mbps)

Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					
e4a	Cluster	Cluster		up	9000	auto/40000
e4e	Cluster	Cluster		up	9000	auto/40000

12 entries were displayed.

```

cluster::*> network interface show -role cluster
(network interface show)
      Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----  -----  -----  -----
-----  -----  -----
Cluster
      n1_clus1      up/up      10.10.0.1/24      n1
e0a      true
      n1_clus2      up/up      10.10.0.2/24      n1
e0b      true
      n1_clus3      up/up      10.10.0.3/24      n1
e0c      true
      n1_clus4      up/up      10.10.0.4/24      n1
e0d      true
      n2_clus1      up/up      10.10.0.5/24      n2
e0a      true
      n2_clus2      up/up      10.10.0.6/24      n2
e0b      true
      n2_clus3      up/up      10.10.0.7/24      n2
e0c      true
      n2_clus4      up/up      10.10.0.8/24      n2
e0d      true
      n3_clus1      up/up      10.10.0.9/24      n3
e4a      true
      n3_clus2      up/up      10.10.0.10/24      n3
e4e      true
      n4_clus1      up/up      10.10.0.11/24      n4
e4a      true
      n4_clus2      up/up      10.10.0.12/24      n4
e4e      true
12 entries were displayed.

```

```

cluster::*> system cluster-switch show

Switch          Type          Address
Model

-----
-----



C1             cluster-network 10.10.1.103
NX3132V

    Serial Number: FOX000001
    Is Monitored: true
    Reason:
        Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
        7.0(3)I4(1)
    Version Source: CDP

C2             cluster-network 10.10.1.104
NX3132V

    Serial Number: FOX000002
    Is Monitored: true
    Reason:
        Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
        7.0(3)I4(1)
    Version Source: CDP

CL1            cluster-network 10.10.1.101
NX5596

    Serial Number: 01234567
    Is Monitored: true
    Reason:
        Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
        7.1(1)N1(1)
    Version Source: CDP

CL2            cluster-network 10.10.1.102
NX5596

    Serial Number: 01234568
    Is Monitored: true
    Reason:
        Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
        7.1(1)N1(1)
    Version Source: CDP

4 entries were displayed.

```

9. Remove the replaced Nexus 5596 if they are not automatically removed:

```
system cluster-switch delete
```

Show example

The following example shows how to remove the Nexus 5596:

```
cluster::> system cluster-switch delete -device CL1
cluster::> system cluster-switch delete -device CL2
```

10. Configure clusters clus1 and clus2 to auto revert on each node and confirm.

Show example

```
cluster::*> network interface modify -vserver node1 -lif clus1 -auto
-revert true
cluster::*> network interface modify -vserver node1 -lif clus2 -auto
-revert true
cluster::*> network interface modify -vserver node2 -lif clus1 -auto
-revert true
cluster::*> network interface modify -vserver node2 -lif clus2 -auto
-revert true
```

11. Verify that the proper cluster switches are monitored:

```
system cluster-switch show
```

Show example

```
cluster::> system cluster-switch show

Switch          Type          Address
Model

-----
-----
C1             cluster-network  10.10.1.103
NX3132V

  Serial Number: FOX000001
  Is Monitored: true
  Reason:
  Software Version: Cisco Nexus Operating System (NX-OS) Software,
Version
  7.0(3)I4(1)
  Version Source: CDP

C2             cluster-network  10.10.1.104
NX3132V

  Serial Number: FOX000002
  Is Monitored: true
  Reason:
  Software Version: Cisco Nexus Operating System (NX-OS) Software,
Version
  7.0(3)I4(1)
  Version Source: CDP

2 entries were displayed.
```

12. If you suppressed automatic case creation, reenable it by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=END
```

What's next?

After you've completed your switch migration, you can [configure switch health monitoring](#).

Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.