



Migrate the switches

Install and maintain

NetApp

February 13, 2026

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems-switches/switch-cisco-9336c-fx2/migrate-cn1610-9336c-cluster.html> on February 13, 2026. Always check docs.netapp.com for the latest.

Table of Contents

Migrate the switches	1
Migrate from NetApp CN1610 cluster switches to Cisco 9336C-FX2 and 9336C-FX2-T cluster switches	1
Review requirements	1
Migrate the switches	1
Migrate from older Cisco switches to Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches	19
Review requirements	20
Migrate the switches	20
Migrate to two-node switched cluster	38
Review requirements	38
Migrate the switches	39

Migrate the switches

Migrate from NetApp CN1610 cluster switches to Cisco 9336C-FX2 and 9336C-FX2-T cluster switches

You can migrate NetApp CN1610 cluster switches for an ONTAP cluster to Cisco 9336C-FX2 and 9336C-FX2-T cluster switches. This is a nondisruptive procedure.

Review requirements

You must be aware of certain configuration information, port connections and cabling requirements when you are replacing NetApp CN1610 cluster switches with Cisco 9336C-FX2 and 9336C-FX2-T cluster switches. You must also verify the switch serial number to ensure that the correct switch is migrated.

Supported switches

The following cluster switches are supported:

- NetApp CN1610
- Cisco 9336C-FX2
- Cisco 9336C-FX2-T

For details of supported ports and their configurations, see the [Hardware Universe](#). See [What additional information do I need to install my equipment that is not in HWU?](#) for more information about switch installation requirements.

What you'll need

Verify that your configuration meets the following requirements:

- The existing cluster is correctly set up and functioning.
- All cluster ports are in the **up** state to ensure nondisruptive operations.
- The Cisco 9336C-FX2 and 9336C-FX2-T cluster switches are configured and operating under the correct version of NX-OS installed with the reference configuration file (RCF) applied.
- The existing cluster network configuration has the following:
 - A redundant and fully functional NetApp cluster using NetApp CN1610 switches.
 - Management connectivity and console access to both the NetApp CN1610 switches and the new switches.
 - All cluster LIFs in the up state with the cluster LIFs are on their home ports.
- Some of the ports are configured on Cisco 9336C-FX2 and 9336C-FX2-T switches to run at 40GbE or 100GbE.
- You have planned, migrated, and documented 40GbE and 100GbE connectivity from nodes to Cisco 9336C-FX2 and 9336C-FX2-T cluster switches.

Migrate the switches

About the examples

The examples in this procedure use the following switch and node nomenclature:

- The existing CN1610 cluster switches are C1 and C2.
- The new 9336C-FX2 cluster switches are *cs1* and *cs2*.
- The nodes are *node1* and *node2*.
- The cluster LIFs are *node1_clus1* and *node1_clus2* on node 1, and *node2_clus1* and *node2_clus2* on node 2 respectively.
- The `cluster1::*` prompt indicates the name of the cluster.
- The cluster ports used in this procedure are *e3a* and *e3b*.

About this task

This procedure covers the following scenario:

- Switch C2 is replaced by switch *cs2* first.
 - Shut down the ports to the cluster nodes. All ports must be shut down simultaneously to avoid cluster instability.
 - All cluster LIFs fail over to the new switch *cs2*.
 - The cabling between the nodes and C2 is then disconnected from C2 and reconnected to *cs2*.
- Switch C1 is replaced by switch *cs1*.
 - Shut down the ports to the cluster nodes. All ports must be shut down simultaneously to avoid cluster instability.
 - All cluster LIFs fail over to the new switch *cs1*.
 - The cabling between the nodes and C1 is then disconnected from C1 and reconnected to *cs1*.

 No operational inter-switch link (ISL) is needed during this procedure. This is by design because RCF version changes can affect ISL connectivity temporarily. To ensure non-disruptive cluster operations, the following procedure fails over all of the cluster LIFs to the operational partner switch while performing the steps on the target switch.

Step 1: Prepare for migration

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=xh
```

where *x* is the duration of the maintenance window in hours.

2. Change the privilege level to advanced, entering **y** when prompted to continue:

```
set -privilege advanced
```

The advanced prompt (`*>`) appears.

3. Disable auto-revert on the cluster LIFs.

By disabling auto-revert for this procedure, the cluster LIFs will not automatically move back to their home port. They remain on the current port while it continues to be up and operational.

```
network interface modify -vserver Cluster -lif * -auto-revert false
```

Step 2: Configure ports and cabling

1. Determine the administrative or operational status for each cluster interface.

Each port should display up for Link and healthy for Health Status.

- a. Display the network port attributes:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore                                                 Speed (Mbps)
Health     Health
Port       IPspace     Broadcast Domain Link MTU   Admin/Oper
Status     Status

-----
-----
e3a        Cluster     Cluster           up    9000  auto/100000
healthy   false
e3b        Cluster     Cluster           up    9000  auto/100000
healthy   false

Node: node2

Ignore                                                 Speed (Mbps)
Health     Health
Port       IPspace     Broadcast Domain Link MTU   Admin/Oper
Status     Status

-----
-----
e3a        Cluster     Cluster           up    9000  auto/100000
healthy   false
e3b        Cluster     Cluster           up    9000  auto/100000
healthy   false
```

- b. Display information about the LIFs and their designated home nodes:

```
network interface show -vserver Cluster
```

Each LIF should display up/up for Status Admin/Oper and true for Is Home.

Show example

```
cluster1::*> network interface show -vserver Cluster

          Logical      Status      Network      Current
Current  Is
Vserver   Interface   Admin/Oper  Address/Mask      Node
Port     Home
-----
-----
Cluster
          node1_clus1  up/up      169.254.209.69/16  node1
e3a      true
          node1_clus2  up/up      169.254.49.125/16  node1
e3b      true
          node2_clus1  up/up      169.254.47.194/16  node2
e3a      true
          node2_clus2  up/up      169.254.19.183/16  node2
e3b      true
```

2. The cluster ports on each node are connected to existing cluster switches in the following way (from the nodes' perspective) using the command:

```
network device-discovery show -protocol
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
node1      /cdp
          e3a    C1  (6a:ad:4f:98:3b:3f)  0/1
          e3b    C2  (6a:ad:4f:98:4c:a4)  0/1
node2      /cdp
          e3a    C1  (6a:ad:4f:98:3b:3f)  0/2
          e3b    C2  (6a:ad:4f:98:4c:a4)  0/2
```

3. The cluster ports and switches are connected in the following way (from the switches' perspective) using the command:

```
show cdp neighbors
```

Show example

```
C1# show cdp neighbors
```

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge

S - Switch, H - Host, I - IGMP, r - Repeater,
V - VoIP-Phone, D - Remotely-Managed-Device,
s - Supports-STP-Dispute

Device-ID Port ID	Local Intrfce	Hldtme	Capability	Platform
node1 e3a	Eth1/1	124	H	AFF-A400
node2 e3a	Eth1/2	124	H	AFF-A400
C2 0/13	0/13	179	S I s	CN1610
C2 0/14	0/14	175	S I s	CN1610
C2 0/15	0/15	179	S I s	CN1610
C2 0/16	0/16	175	S I s	CN1610

```
C2# show cdp neighbors
```

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge

S - Switch, H - Host, I - IGMP, r - Repeater,
V - VoIP-Phone, D - Remotely-Managed-Device,
s - Supports-STP-Dispute

Device-ID Port ID	Local Intrfce	Hldtme	Capability	Platform
node1 e3b	Eth1/1	124	H	AFF-A400
node2 e3b	Eth1/2	124	H	AFF-A400
C1 0/13	0/13	175	S I s	CN1610
C1 0/14	0/14	175	S I s	CN1610
C1 0/15	0/15	175	S I s	CN1610
C1 0/16	0/16	175	S I s	CN1610

4. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check  
cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show  
Source Destination  
Packet  
Node Date LIF LIF  
Loss  
-----  
-----  
node1  
3/5/2022 19:21:18 -06:00 node1_clus2 node2-clus1  
none  
3/5/2022 19:21:20 -06:00 node1_clus2 node2_clus2  
none  
node2  
3/5/2022 19:21:18 -06:00 node2_clus2 node1_clus1  
none  
3/5/2022 19:21:20 -06:00 node2_clus2 node1_clus2  
none
```

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node local
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1      e3a
Cluster node1_clus2 169.254.49.125 node1      e3b
Cluster node2_clus1 169.254.47.194 node2      e3a
Cluster node2_clus2 169.254.19.183 node2      e3b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:....
Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)
.....
Detected 9000 byte MTU on 4 path(s):
  Local 169.254.19.183 to Remote 169.254.209.69
  Local 169.254.19.183 to Remote 169.254.49.125
  Local 169.254.47.194 to Remote 169.254.209.69
  Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

5. On switch C2, shut down the ports connected to the cluster ports of the nodes in order to fail over the cluster LIFs.



Do not attempt to manually migrate the cluster LIFs.

```

(C2) # configure
(C2) (Config) # interface 0/1-0/12
(C2) (Interface 0/1-0/12) # shutdown
(C2) (Interface 0/1-0/12) # exit
(C2) (Config) # exit

```

6. Move the node cluster ports from the old switch C2 to the new switch cs2, using appropriate cabling supported by Cisco 9336C-FX2 and 9336C-FX2-T.
7. Display the network port attributes:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e3a      Cluster      Cluster          up    9000  auto/100000
healthy  false
e3b      Cluster      Cluster          up    9000  auto/100000
healthy  false

Node: node2

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e3a      Cluster      Cluster          up    9000  auto/100000
healthy  false
e3b      Cluster      Cluster          up    9000  auto/100000
healthy  false
```

8. The cluster ports on each node are now connected to cluster switches in the following way, from the nodes' perspective:

```
network device-discovery show -protocol
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp

Node/          Local   Discovered
Protocol      Port    Device  (LLDP: ChassisID)  Interface
Platform

-----
-----
```

node1	/cdp				
	e3a	C1	(6a:ad:4f:98:3b:3f)	0/1	
CN1610					
	e3b	cs2	(b8:ce:f6:19:1a:7e)	Ethernet1/1/1	N9K-
C9336C-FX2					
node2	/cdp				
	e3a	C1	(6a:ad:4f:98:3b:3f)	0/2	
CN1610					
	e3b	cs2	(b8:ce:f6:19:1b:96)	Ethernet1/1/2	N9K-
C9336C-FX2					

9. On switch cs2, verify that all node cluster ports are up:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*# network interface show -vserver Cluster
          Logical      Status      Network      Current
Current Is
Vserver      Interfac Admin/Oper Address/Mask      Node
Port      Home
-----
-----
```

Cluster				
		node1_clus1	up/up	169.254.3.4/16
e0b	false	node1_clus2	up/up	169.254.3.5/16
e0b	true	node2_clus1	up/up	169.254.3.8/16
e0b	false	node2_clus2	up/up	169.254.3.9/16
e0b	true			

10. On switch C1, shut down the ports connected to the cluster ports of the nodes in order to fail over the cluster LIFs.

```
(C1) # configure
(C1) (Config) # interface 0/1-0/12
(C1) (Interface 0/1-0/12) # shutdown
(C1) (Interface 0/1-0/12) # exit
(C1) (Config) # exit
```

11. Move the node cluster ports from the old switch C1 to the new switch cs1, using appropriate cabling supported by Cisco 9336C-FX2 and 9336C-FX2-T.

12. Verify the final configuration of the cluster:

```
network port show -ipspace Cluster
```

Each port should display **up** for **Link** and **healthy** for **Health** Status.

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e3a      Cluster      Cluster          up    9000  auto/100000
healthy  false
e3b      Cluster      Cluster          up    9000  auto/100000
healthy  false

Node: node2

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e3a      Cluster      Cluster          up    9000  auto/100000
healthy  false
e3b      Cluster      Cluster          up    9000  auto/100000
healthy  false
```

13. The cluster ports on each node are now connected to cluster switches in the following way, from the nodes' perspective:

```
network device-discovery show -protocol
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp

Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface
Platform

-----
-----
```

Node/	Protocol	Port	Device (LLDP: ChassisID)	Interface
node1	C9336C-FX2	/cdp		
		e3a	cs1 (b8:ce:f6:19:1a:7e)	Ethernet1/1/1
		e3b	cs2 (b8:ce:f6:19:1b:96)	Ethernet1/1/2
node2	C9336C-FX2	/cdp		
		e3a	cs1 (b8:ce:f6:19:1a:7e)	Ethernet1/1/1
		e3b	cs2 (b8:ce:f6:19:1b:96)	Ethernet1/1/2

```
C9336C-FX2
C9336C-FX2
C9336C-FX2
C9336C-FX2
```

14. On switches cs1 and cs2, verify that all node cluster ports are up:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore

Health                                         Speed (Mbps)  Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up      9000  auto/10000
healthy  false
e0b      Cluster      Cluster      up      9000  auto/10000
healthy  false

Node: node2

Ignore

Health                                         Speed (Mbps)  Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up      9000  auto/10000
healthy  false
e0b      Cluster      Cluster      up      9000  auto/10000
healthy  false
```

15. Verify that both nodes each have one connection to each switch:

```
network device-discovery show -protocol
```

Show example

The following example shows the appropriate results for both switches:

```
cluster1::*> network device-discovery show -protocol cdp
Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface
Platform

-----
-----
node1      /cdp
          e0a    cs1  (b8:ce:f6:19:1b:42)    Ethernet1/1/1  N9K-
C9336C-FX2
          e0b    cs2  (b8:ce:f6:19:1b:96)    Ethernet1/1/2  N9K-
C9336C-FX2

node2      /cdp
          e0a    cs1  (b8:ce:f6:19:1b:42)    Ethernet1/1/1  N9K-
C9336C-FX2
          e0b    cs2  (b8:ce:f6:19:1b:96)    Ethernet1/1/2  N9K-
C9336C-FX2
```

Step 3: Verify the configuration

1. Enable auto-revert on the cluster LIFs:

```
cluster1::*> network interface modify -vserver Cluster -lif * -auto-revert
true
```

2. On switch cs2, shut down and restart all cluster ports to trigger an auto-revert of all cluster LIFs that are not on their home ports.

```
cs2> enable
cs2# configure
cs2(config)# interface eth1/1-1/2
cs2(config-if-range)# shutdown
```

(Wait for 5-10 seconds before re-enabling the ports)

```
cs2(config-if-range)# no shutdown
```

(After executing the no shutdown command, the nodes detect the change and begin to auto-revert the cluster LIFs to their home ports)

```
cs2(config-if-range)# exit
cs2(config)# exit
cs2#
```

3. Verify that the cluster LIFs have reverted to their home ports (this might take a minute):

```
network interface show -vserver Cluster
```

If any of the cluster LIFs have not reverted to their home port, manually revert them. You must connect to each node-mgmt LIF or SP/BMC system console of the local node that owns the LIF:

```
network interface revert -vserver Cluster -lif *
```

4. Verify that the cluster is healthy:

```
cluster show
```

5. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```



Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

		Source	Destination
Packet			
Node	Date	LIF	LIF
Loss			

node1			
	3/5/2022 19:21:18 -06:00	node1_clus2	node2_clus1
none			
	3/5/2022 19:21:20 -06:00	node1_clus2	node2_clus2
none			
node2			
	3/5/2022 19:21:18 -06:00	node2_clus2	node1_clus1
none			
	3/5/2022 19:21:20 -06:00	node2_clus2	node1_clus2
none			

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node node2
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1      e0a
Cluster node1_clus2 169.254.49.125 node1      e0b
Cluster node2_clus1 169.254.47.194 node2      e0a
Cluster node2_clus2 169.254.19.183 node2      e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:

Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)
.....
Detected 9000 byte MTU on 4 path(s):
  Local 169.254.19.183 to Remote 169.254.209.69
  Local 169.254.19.183 to Remote 169.254.49.125
  Local 169.254.47.194 to Remote 169.254.209.69
  Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

6. Change the privilege level back to admin:

```
set -privilege admin
```

7. If you suppressed automatic case creation, re-enable it by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=END
```

What's next?

After you've migrated your switches, you can [configure switch health monitoring](#).

Migrate from older Cisco switches to Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches

You can perform a nondisruptive migration from older Cisco cluster switches to Cisco Nexus 9336C-FX2 and 9336C-FX2-T cluster network switches.

Review requirements

Ensure that:

- You have verified the switch serial number to ensure that the correct switch is migrated.
- Some of the ports on Nexus 9336C-FX2 switches are configured to run at 10GbE or 40GbE.
- The 10GbE and 40GbE connectivity from nodes to Nexus 9336C-FX2 cluster switches have been planned, migrated, and documented.
- The cluster is fully functioning (there should be no errors in the logs or similar issues).
- Initial customization of the Cisco Nexus 9336C-FX2 switches is complete, so that:
 - 9336C-FX2 switches are running the latest recommended version of software.
 - Confirm that Reference Configuration Files (RCFs) have been fully applied to any new switches before migrating the LIFs to the new switches.
 - Check the running and startup configurations on both switches prior to shifting network traffic.
 - Any site customization, such as DNS, NTP, SMTP, SNMP, and SSH, are configured on the new switches.
- You have access to the switch compatibility table on the [Cisco Ethernet Switches](#) page for the supported ONTAP, NX-OS, and RCF versions.
- You have reviewed the appropriate software and upgrade guides available on the Cisco web site for the Cisco switch upgrade and downgrade procedures at [Cisco Nexus 9000 Series Switches Support](#) page.

 If you are changing the port speed of the e0a and e1a cluster ports on AFF A800 or AFF C800 systems, you might observe malformed packets being received after the speed conversion. See [Bug 1570339](#) and the Knowledge Base article [CRC errors on T6 ports after converting from 40GbE to 100GbE](#) for guidance.

Migrate the switches

About the examples


The examples in this procedure use two nodes. These nodes use two 10GbE cluster interconnect ports e0a and e0b. See the [Hardware Universe](#) to verify the correct cluster ports on your platforms. See [What additional information do I need to install my equipment that is not in HWU?](#) for more information about switch installation requirements.

 The command outputs might vary depending on the different releases of ONTAP.

The examples in this procedure use the following switch and node nomenclature:

- The names of the existing two Cisco switches are **cs1** and **cs2**
- The new Nexus 9336C-FX2 cluster switches are **cs1-new** and **cs2-new**.
- The node names are **node1** and **node2**.
- The cluster LIF names are **node1_clus1** and **node1_clus2** for node 1, and **node2_clus1** and **node2_clus2** for node 2.
- The **cluster1::>*** prompt indicates the name of the cluster.

During this procedure, refer to the following example:



About this task

The procedure requires the use of both ONTAP commands and [Nexus 9000 Series Switches](#) commands; ONTAP commands are used, unless otherwise indicated.

This procedure covers the following scenario:

- Switch cs2 is replaced by switch cs2-new first.
 - Shut down the ports to the cluster nodes. All ports must be shut down simultaneously to avoid cluster instability.
 - All cluster LIFs fail over to the new switch cs2-new.
 - Cabling between the nodes and cs2 are then disconnected from cs2 and reconnected to cs2-new.
- Switch cs1 is replaced by switch cs1-new.
 - Shut down the ports to the cluster nodes. All ports must be shut down simultaneously to avoid cluster instability.
 - All cluster LIFs fail over to the new switch cs1-new.
 - Cabling between the nodes and cs1 are then disconnected from cs1 and reconnected to cs1-new.

i No operational inter-switch link (ISL) is needed during this procedure. This is by design because RCF version changes can affect ISL connectivity temporarily. To ensure non-disruptive cluster operations, the following procedure fails over all of the cluster LIFs to the operational partner switch while performing the steps on the target switch.

Step 1: Prepare for migration

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message: `system node autosupport invoke -node * -type all -message MAINT=xh`

where x is the duration of the maintenance window in hours.



The AutoSupport message notifies technical support of this maintenance task so that automatic case creation is suppressed during the maintenance window.

2. Change the privilege level to advanced, entering **y** when prompted to continue:

```
set -privilege advanced
```

The advanced prompt (***>**) appears.

Step 2: Configure ports and cabling

1. On the new switches, confirm that the ISL is cabled and healthy between the switches cs1-new and cs2-new:

```
show port-channel summary
```

Show example

```
cs1-new# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        S - Suspended      r - Module-removed
        b - BFD Session Wait
        S - Switched       R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
-----
```

Group	Port- Channel	Type	Protocol	Member Ports
1	Po1 (SU)	Eth	LACP	Eth1/35 (P) Eth1/36 (P)

```
cs2-new# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        S - Suspended      r - Module-removed
        b - BFD Session Wait
        S - Switched       R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
-----
```

Group	Port- Channel	Type	Protocol	Member Ports
1	Po1 (SU)	Eth	LACP	Eth1/35 (P) Eth1/36 (P)

2. Display the cluster ports on each node that are connected to the existing cluster switches:

```
network device-discovery show
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/      Local   Discovered
Protocol   Port    Device (LLDP: ChassisID)  Interface
Platform

-----
-----
node1      /cdp
          e0a    cs1                      Ethernet1/1      N5K-
C5596UP
          e0b    cs2                      Ethernet1/2      N5K-
C5596UP
node2      /cdp
          e0a    cs1                      Ethernet1/1      N5K-
C5596UP
          e0b    cs2                      Ethernet1/2      N5K-
C5596UP
```

3. Determine the administrative or operational status for each cluster port.

- a. Verify that all the cluster ports are up with a healthy status:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore                                         Speed (Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper
Status   Status
-----  -----
-----  -----
e0a      Cluster      Cluster          up    9000  auto/10000
healthy  false
e0b      Cluster      Cluster          up    9000  auto/10000
healthy  false

Node: node2

Ignore                                         Speed (Mbps)
Health   Health
Port      IPspace      Broadcast Domain Link MTU Admin/Oper
Status   Status
-----  -----
-----  -----
e0a      Cluster      Cluster          up    9000  auto/10000
healthy  false
e0b      Cluster      Cluster          up    9000  auto/10000
healthy  false
```

b. Verify that all the cluster interfaces (LIFs) are on their home ports:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster

          Logical      Status      Network      Current
Current  Is
Vserver   Interface   Admin/Oper  Address/Mask   Node
Port     Home
-----  -----
-----  -----
Cluster
          node1_clus1  up/up      169.254.209.69/16  node1
e0a      true
          node1_clus2  up/up      169.254.49.125/16  node1
e0b      true
          node2_clus1  up/up      169.254.47.194/16  node2
e0a      true
          node2_clus2  up/up      169.254.19.183/16  node2
e0b      true
```

c. Verify that the cluster displays information for both cluster switches:

```
system cluster-switch show -is-monitoring-enabled-operational true
```

Show example

```
cluster1::*> system cluster-switch show -is-monitoring-enabled
-operational true
Switch Type Address
Model
-----
-----
cs1 cluster-network 10.233.205.92
N5K-C5596UP
    Serial Number: FOXXXXXXXGS
    Is Monitored: true
    Reason: None
    Software Version: Cisco Nexus Operating System (NX-OS)
    Software, Version
        9.3(4)
    Version Source: CDP

cs2 cluster-network 10.233.205.93
N5K-C5596UP
    Serial Number: FOXXXXXXXGD
    Is Monitored: true
    Reason: None
    Software Version: Cisco Nexus Operating System (NX-OS)
    Software, Version
        9.3(4)
    Version Source: CDP
```

4. Disable auto-revert on the cluster LIFs.

By disabling auto-revert for this procedure, the cluster LIFs will not automatically move back to their home port. They remain on the current port while it continues to be up and operational.

```
network interface modify -vserver Cluster -lif * -auto-revert false
```



Disabling auto-revert ensures ONTAP only fails over the cluster LIFs when the switch ports are shutdown later.

5. On cluster switch cs2, shut down the ports connected to the cluster ports of **all** the nodes in order to fail over the cluster LIFs:

```
cs2# configure
cs2(config)# interface eth1/1-1/2
cs2(config-if-range)# shutdown
cs2(config-if-range)# exit
cs2(config)# exit
cs2#
```

6. Verify that the cluster LIFs have failed over to the ports hosted on cluster switch cs1. This might take a few seconds.

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
      Logical          Status      Network      Current
Current Is
Vserver      Interface      Admin/Oper Address/Mask      Node
Port        Home
-----  -----  -----  -----  -----
-----  -----
Cluster
      node1_clus1      up/up      169.254.3.4/16      node1
e0a        true
      node1_clus2      up/up      169.254.3.5/16      node1
e0a        false
      node2_clus1      up/up      169.254.3.8/16      node2
e0a        true
      node2_clus2      up/up      169.254.3.9/16      node2
e0a        false
```

7. Verify that the cluster is healthy:

```
cluster show
```

Show example

```
cluster1::*> cluster show
  Node      Health  Eligibility  Epsilon
-----  -----  -----  -----
  node1    true    true        false
  node2    true    true        false
```

8. If the cluster LIFs have failed over to switch cs1 and the cluster is healthy, go to [Step. 10](#). If some cluster LIFs are not healthy or the cluster is unhealthy, you can roll back the connectivity to the switch cs2, as follows:

a. Bring up the ports connected to the cluster ports of **all** the nodes:

```
cs2# configure
cs2(config) # interface eth1/1-1/2
cs2(config-if-range) # no shutdown
cs2(config-if-range) # exit
cs2(config) # exit
cs2#
```

b. Verify that the cluster LIFs have failed over to the ports hosted on cluster switch cs1. This might take a few seconds.

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
      Logical          Status        Network          Current
      Current  Is
      Vserver      Interface      Admin/Oper  Address/Mask      Node
      Port        Home
      -----
      -----
      Cluster
      node1_clus1    up/up      169.254.3.4/16    node1
      e0a      true
      node1_clus2    up/up      169.254.3.5/16    node1
      e0a      false
      node2_clus1    up/up      169.254.3.8/16    node2
      e0a      true
      node2_clus2    up/up      169.254.3.9/16    node2
      e0a      false
```

c. Verify that the cluster is healthy:


```
cluster show
```

Show example

```
cluster1::*> cluster show
Node      Health  Eligibility  Epsilon
-----
node1    true    true        false
node2    true    true        false
```

9. Once you have restored LIF and cluster health, restart the process from [Step 4](#).
10. Move all cluster node connection cables from the old cs2 switch to the new cs2-new switch.

Cluster node connection cables moved to the cs2-new switch



11. Confirm the health of the network connections moved to cs2-new:

```
network port show -ipspace Cluster
```

Show example

All cluster ports that were moved should be up.

12. Check neighbor information on the cluster ports:

```
network device-discovery show -protocol cdp
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp

Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface      Platform
-----  -----  -----
-----  -----
node1      /cdp
          e0a    cs1
          e0b    cs2-new
C5596UP
          e0a    cs1
          e0b    cs2-new
C9336C-FX2
          /cdp
          e0a    cs1
          e0b    cs2-new
C5596UP
          e0a    cs1
          e0b    cs2-new
C9336C-FX2
```

Verify that the moved cluster ports see the cs2-new switch as the neighbor.

13. Confirm the switch port connections from switch cs2-new's perspective:

```
cs2-new# show interface brief
cs2-new# show cdp neighbors
```

14. On cluster switch cs1, shut down the ports connected to the cluster ports of **all** the nodes in order to fail over the cluster LIFs.

```
cs1# configure
cs1(config)# interface eth1/1-1/2
cs1(config-if-range)# shutdown
cs1(config-if-range)# exit
cs1(config)# exit
cs1#
```

All cluster LIFs fail over to the cs2-new switch.

15. Verify that the cluster LIFs have failed over to the ports hosted on switch cs2-new. This might take a few seconds:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
          Logical      Status      Network      Current
Current Is
Vserver      Interfac Admin/Oper Address/Mask      Node
Port      Home
-----
-----
Cluster
          node1_clus1  up/up      169.254.3.4/16      node1
e0b      false
          node1_clus2  up/up      169.254.3.5/16      node1
e0b      true
          node2_clus1  up/up      169.254.3.8/16      node2
e0b      false
          node2_clus2  up/up      169.254.3.9/16      node2
e0b      true
```

16. Verify that the cluster is healthy:


```
cluster show
```

Show example

```
cluster1::*> cluster show
Node      Health  Eligibility  Epsilon
-----
node1    true    true        false
node2    true    true        false
```

17. Move the cluster node connection cables from cs1 to the new cs1-new switch.

Cluster node connection cables moved to the cs1-new switch



18. Confirm the health of the network connections moved to cs1-new:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up       9000  auto/10000
healthy  false
e0b      Cluster      Cluster      up       9000  auto/10000
healthy  false

Node: node2

Ignore                                         Speed (Mbps)  Health
Health
Port      IPspace      Broadcast  Domain  Link  MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster      up       9000  auto/10000
healthy  false
e0b      Cluster      Cluster      up       9000  auto/10000
healthy  false
```

All cluster ports that were moved should be up.

19. Check neighbor information on the cluster ports:

```
network device-discovery show
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/      Local   Discovered
Protocol   Port    Device (LLDP: ChassisID)  Interface
Platform

-----
-----
node1      /cdp
           e0a    cs1-new
C9336C-FX2
           e0b    cs2-new
C9336C-FX2

node2      /cdp
           e0a    cs1-new
C9336C-FX2
           e0b    cs2-new
C9336C-FX2
```

Verify that the moved cluster ports see the cs1-new switch as the neighbor.

20. Confirm the switch port connections from switch cs1-new's perspective:

```
cs1-new# show interface brief
cs1-new# show cdp neighbors
```

21. Verify that the ISL between cs1-new and cs2-new is still operational:

```
show port-channel summary
```

Show example

```
cs1-new# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
      I - Individual    H - Hot-standby (LACP only)
      s - Suspended      r - Module-removed
      b - BFD Session Wait
      S - Switched      R - Routed
      U - Up (port-channel)
      p - Up in delay-lacp mode (member)
      M - Not in use. Min-links not met
-----
-----
Group Port-      Type      Protocol Member Ports
      Channel
-----
-----
1      Po1 (SU)      Eth       LACP      Eth1/35 (P)   Eth1/36 (P)

cs2-new# show port-channel summary
Flags: D - Down          P - Up in port-channel (members)
      I - Individual    H - Hot-standby (LACP only)
      s - Suspended      r - Module-removed
      b - BFD Session Wait
      S - Switched      R - Routed
      U - Up (port-channel)
      p - Up in delay-lacp mode (member)
      M - Not in use. Min-links not met
-----
-----
Group Port-      Type      Protocol Member Ports
      Channel
-----
-----
1      Po1 (SU)      Eth       LACP      Eth1/35 (P)   Eth1/36 (P)
```

Step 3: Verify the configuration

1. Enable auto-revert on the cluster LIFs.

```
network interface modify -vserver Cluster -lif * -auto-revert true
```

2. On switch cs2, shut down and restart all cluster ports to trigger an auto-revert of all cluster LIFs that are not on their home ports.

```
cs2> enable
cs2# configure
cs2(config)# interface eth1/1-1/2
cs2(config-if-range)# shutdown
```

(Wait for 5-10 seconds before re-enabling the ports)

```
cs2(config-if-range)# no shutdown
```

(After executing the no shutdown command, the nodes detect the change and begin to auto-revert the cluster LIFs to their home ports)

```
cs2(config-if-range)# exit
cs2(config)# exit
cs2#
```

3. Verify that the cluster LIFs have reverted to their home ports (this might take a minute):

```
network interface show -vserver Cluster
```

If any of the cluster LIFs have not reverted to their home port, manually revert them. You must connect to each node-mgmt LIF or SP/BMC system console of the local node that owns the LIF:

```
network interface revert -vserver Cluster -lif *
```

4. Verify that the cluster is healthy:

```
cluster show
```

5. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```



Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

		Source	Destination
Packet			
Node	Date	LIF	LIF
Loss			

node1			
	3/5/2022 19:21:18 -06:00	node1_clus2	node2_clus1
none			
	3/5/2022 19:21:20 -06:00	node1_clus2	node2_clus2
none			
node2			
	3/5/2022 19:21:18 -06:00	node2_clus2	node1_clus1
none			
	3/5/2022 19:21:20 -06:00	node2_clus2	node1_clus2
none			

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node node2
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1      e0a
Cluster node1_clus2 169.254.49.125 node1      e0b
Cluster node2_clus1 169.254.47.194 node2      e0a
Cluster node2_clus2 169.254.19.183 node2      e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:

Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)
.....
Detected 9000 byte MTU on 4 path(s):
  Local 169.254.19.183 to Remote 169.254.209.69
  Local 169.254.19.183 to Remote 169.254.49.125
  Local 169.254.47.194 to Remote 169.254.209.69
  Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

6. If you suppressed automatic case creation, reenable it by invoking an AutoSupport message: system node autosupport invoke -node * -type all -message MAINT=END

What's next?

After you've migrated the switches, you can [configure switch health monitoring](#).

Migrate to two-node switched cluster

If you have an existing two-node *switchless* cluster environment, you can migrate to a two-node *switched* cluster environment using Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches.

The migration process works for all nodes using optical or Twinax ports, but is not supported on this switch if nodes are using onboard 10Gb BASE-T RJ45 ports for the cluster-network ports.

Review requirements

What you'll need

- For the two-node switchless configuration:
 - The two-node switchless configuration is properly set up and functioning.

- All cluster ports are in the **up** state.
- All cluster logical interfaces (LIFs) are in the **up** state and on their home ports.
- See [Hardware Universe](#) for all supported ONTAP versions.
- For the Cisco Nexus 9336C-FX2 switch configuration:
 - Both switches have management network connectivity.
 - There is console access to the cluster switches.
 - Nexus 9336C-FX2 node-to-node switch and switch-to-switch connections use Twinax or fiber cables.
- See [Hardware Universe](#) for more information about cabling.
- Inter-Switch Link (ISL) cables are connected to ports 1/35 and 1/36 on both 9336C-FX2 switches.
- Initial customization of both the 9336C-FX2 switches are completed, so that:
 - 9336C-FX2 switches are running the latest version of software.
 - Reference Configuration Files (RCFs) are applied to the switches. Any site customization, such as SMTP, SNMP, and SSH, is configured on the new switches.

About the examples

The examples in this procedure use the following cluster switch and node nomenclature:

- The names of the 9336C-FX2 switches are cs1 and cs2.
- The names of the cluster SVMs are node1 and node2.
- The names of the LIFs are node1_clus1 and node1_clus2 on node 1, and node2_clus1 and node2_clus2 on node 2 respectively.
- The `cluster1::*` prompt indicates the name of the cluster.
- The cluster ports used in this procedure are e0a and e0b.

See [Hardware Universe](#) for information about the cluster ports for your platforms. See [What additional information do I need to install my equipment that is not in HWU?](#) for more information about switch installation requirements.

Migrate the switches

Step 1: Prepare for migration

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=xh
```

where x is the duration of the maintenance window in hours.



The AutoSupport message notifies technical support of this maintenance task so that automatic case creation is suppressed during the maintenance window.

2. Change the privilege level to advanced, entering `y` when prompted to continue:

```
set -privilege advanced
```

The advanced prompt (*>) appears.

Step 2: Configure ports and cabling

1. Disable all node-facing ports (not ISL ports) on both the new cluster switches cs1 and cs2.

Do not disable the ISL ports.

Show example

The following example shows that node-facing ports 1 through 34 are disabled on switch cs1:

```
cs1# config
Enter configuration commands, one per line. End with CNTL/Z.
cs1(config)# interface e1/1/1-4, e1/2/1-4, e1/3/1-4, e1/4/1-4,
e1/5/1-4, e1/6/1-4, e1/7-34
cs1(config-if-range)# shutdown
```

2. Verify that the ISL and the physical ports on the ISL between the two 9336C-FX2 switches cs1 and cs2 are up on ports 1/35 and 1/36:

```
show port-channel summary
```

Show example

The following example shows that the ISL ports are up on switch cs1:

```
cs1# show port-channel summary

Flags:  D - Down          P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        S - Suspended      r - Module-removed
        b - BFD Session Wait
        S - Switched       R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
-----
-----
Group Port-      Type      Protocol Member Ports
      Channel
-----
-----
1      Po1 (SU)    Eth       LACP      Eth1/35 (P)  Eth1/36 (P)
```

The following example shows that the ISL ports are up on switch cs2:

```
(cs2)# show port-channel summary

Flags:  D - Down          P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        S - Suspended      r - Module-removed
        b - BFD Session Wait
        S - Switched       R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met
-----
-----
Group Port-      Type      Protocol Member Ports
      Channel
-----
-----
1      Po1 (SU)    Eth       LACP      Eth1/35 (P)  Eth1/36 (P)
```

3. Display the list of neighboring devices:

```
show cdp neighbors
```

This command provides information about the devices that are connected to the system.

Show example

The following example lists the neighboring devices on switch cs1:

```
cs1# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
S - Switch, H - Host, I - IGMP, r - Repeater,
V - VoIP-Phone, D - Remotely-Managed-Device,
s - Supports-STP-Dispute

Device-ID      Local Intrfce  Hldtme Capability  Platform
Port ID
cs2           Eth1/35      175      R S I s      N9K-C9336C
Eth1/35
cs2           Eth1/36      175      R S I s      N9K-C9336C
Eth1/36

Total entries displayed: 2
```

The following example lists the neighboring devices on switch cs2:

```
cs2# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
S - Switch, H - Host, I - IGMP, r - Repeater,
V - VoIP-Phone, D - Remotely-Managed-Device,
s - Supports-STP-Dispute

Device-ID      Local Intrfce  Hldtme Capability  Platform
Port ID
cs1           Eth1/35      177      R S I s      N9K-C9336C
Eth1/35
cs1           Eth1/36      177      R S I s      N9K-C9336C
Eth1/36

Total entries displayed: 2
```

4. Verify that all cluster ports are up:

```
network port show -ipspace Cluster
```

Each port should display up for Link and healthy for Health Status.

Show example

```
cluster1::*> network port show -ipspace Cluster
```

Node: node1

Port	IPspace	Broadcast	Domain	Link	MTU	Speed (Mbps)	Health	Admin/Oper	Status
e0a	Cluster	Cluster		up	9000	auto/10000			
healthy									
e0b	Cluster	Cluster		up	9000	auto/10000			
healthy									

Node: node2

Port	IPspace	Broadcast	Domain	Link	MTU	Speed (Mbps)	Health	Admin/Oper	Status
e0a	Cluster	Cluster		up	9000	auto/10000			
healthy									
e0b	Cluster	Cluster		up	9000	auto/10000			
healthy									

4 entries were displayed.

5. Verify that all cluster LIFs are up and operational:

```
network interface show -vserver Cluster
```

Each cluster LIF should display true for Is Home and have a Status Admin/Oper of up/up.

Show example

```
cluster1::*> network interface show -vserver Cluster

          Logical      Status      Network      Current
Current Is
Vserver      Interface  Admin/Oper  Address/Mask      Node
Port      Home
-----
-----
Cluster
      node1_clus1  up/up      169.254.209.69/16  node1
e0a      true
      node1_clus2  up/up      169.254.49.125/16  node1
e0b      true
      node2_clus1  up/up      169.254.47.194/16  node2
e0a      true
      node2_clus2  up/up      169.254.19.183/16  node2
e0b      true
4 entries were displayed.
```

6. Disable auto-revert on all of the cluster LIFs:

```
network interface modify -vserver Cluster -lif * -auto-revert false
```

Show example

```
cluster1::*> *network interface modify -vserver Cluster -lif * -auto
-revert false*

          Logical
Vserver      Interface      Auto-revert
-----
Cluster
      node1_clus1  false
      node1_clus2  false
      node2_clus1  false
      node2_clus2  false

4 entries were displayed.
```

7. Disconnect the cable from cluster port e0a on node1, and then connect e0a to port 1 on cluster switch cs1, using the appropriate cabling supported by the 9336C-FX2 switches.

The [Hardware Universe - Switches](#) contains more information about cabling.

[Hardware Universe - Switches](#)

8. Disconnect the cable from cluster port e0a on node2, and then connect e0a to port 2 on cluster switch cs1, using the appropriate cabling supported by the 9336C-FX2 switches.
9. Enable all node-facing ports on cluster switch cs1.

Show example

The following example shows that ports 1/1 through 1/34 are enabled on switch cs1:

```
cs1# config
Enter configuration commands, one per line. End with CNTL/Z.
cs1(config)# interface e1/1/1-4, e1/2/1-4, e1/3/1-4, e1/4/1-4,
e1/5/1-4, e1/6/1-4, e1/7-34
cs1(config-if-range)# no shutdown
```

10. Verify that all cluster LIFs are up and operational:

```
network interface show -vserver Cluster
```

Show example

The following example shows that all of the LIFs are up on node1 and node2:

```
cluster1::*> network interface show -vserver Cluster

      Logical      Status      Network      Current
Current Is
Vserver  Interface  Admin/Oper Address/Mask      Node      Port
Home

-----
-----
Cluster
      node1_clus1  up/up      169.254.209.69/16  node1    e0b
false
      node1_clus2  up/up      169.254.49.125/16  node1    e0b
true
      node2_clus1  up/up      169.254.47.194/16  node2    e0b
false
      node2_clus2  up/up      169.254.19.183/16  node2    e0b
true

4 entries were displayed.
```

11. Display information about the status of the nodes in the cluster:

```
cluster show
```

Show example

The following example displays information about the health and eligibility of the nodes in the cluster:

```
cluster1::*> cluster show

      Node      Health  Eligibility  Epsilon
-----
node1          true    true        false
node2          true    true        false

2 entries were displayed.
```

12. Disconnect the cable from cluster port e0b on node1, and then connect e0b to port 1 on cluster switch cs2, using the appropriate cabling supported by the 9336C-FX2 switches.
13. Disconnect the cable from cluster port e0b on node2, and then connect e0b to port 2 on cluster switch cs2,

using the appropriate cabling supported by the 9336C-FX2 switches.

14. Enable all node-facing ports on cluster switch cs2.

Show example

The following example shows that ports 1/1 through 1/34 are enabled on switch cs2:

```
cs2# config
Enter configuration commands, one per line. End with CNTL/Z.
cs2(config)# interface e1/1/1-4, e1/2/1-4, e1/3/1-4, e1/4/1-4,
e1/5/1-4, e1/6/1-4, e1/7-34
cs2(config-if-range)# no shutdown
```

15. Verify that all cluster ports are up:

```
network port show -ipspace Cluster
```

Show example

The following example shows that all of the cluster ports are up on node1 and node2:

```
cluster1::*> network port show -ipspace Cluster

Node: node1

Ignore

Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster          up    9000  auto/10000
healthy  false
e0b      Cluster      Cluster          up    9000  auto/10000
healthy  false

Node: node2

Ignore

Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status

-----
-----
e0a      Cluster      Cluster          up    9000  auto/10000
healthy  false
e0b      Cluster      Cluster          up    9000  auto/10000
healthy  false

4 entries were displayed.
```

Step 3: Verify the configuration

1. Enable auto-revert on the cluster LIFs.

```
network interface modify -vserver Cluster -lif * -auto-revert true
```

2. On switch cs2, shut down and restart all cluster ports to trigger an auto-revert of all cluster LIFs that are not on their home ports.

```
cs2> enable
cs2# configure
cs2(config)# interface eth1/1-1/2
cs2(config-if-range)# shutdown
```

(Wait for 5-10 seconds before re-enabling the ports)

```
cs2(config-if-range)# no shutdown
```

(After executing the no shutdown command, the nodes detect the change and begin to auto-revert the cluster LIFs to their home ports)

```
cs2(config-if-range)# exit
cs2(config)# exit
cs2#
```

3. Verify that the cluster LIFs have reverted to their home ports (this might take a minute):

```
network interface show -vserver Cluster
```

If any of the cluster LIFs have not reverted to their home port, manually revert them. You must connect to each node-mgmt LIF or SP/BMC system console of the local node that owns the LIF:

```
network interface revert -vserver Cluster -lif *
```

4. Verify that all interfaces display true for Is_Home:

```
network interface show -vserver Cluster
```



This might take several minutes to complete.

Show example

The following example shows that all LIFs are up on node1 and node2 and that `Is Home` results are true:

```
cluster1::*> network interface show -vserver Cluster

      Logical          Status        Network        Current
Current Is
Vserver   Interface    Admin/Oper Address/Mask      Node      Port
Home
-----
-----
Cluster
true      node1_clus1  up/up      169.254.209.69/16  node1    e0a
true      node1_clus2  up/up      169.254.49.125/16  node1    e0b
true      node2_clus1  up/up      169.254.47.194/16  node2    e0a
true      node2_clus2  up/up      169.254.19.183/16  node2    e0b

4 entries were displayed.
```

5. Verify that both nodes each have one connection to each switch:

```
show cdp neighbors
```

Show example

The following example shows the appropriate results for both switches:

```
(cs1) # show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device-ID          Local Intrfce  Hldtme Capability  Platform
Port ID
node1              Eth1/1       133      H             FAS2980
e0a
node2              Eth1/2       133      H             FAS2980
e0a
cs2                Eth1/35      175      R S I s      N9K-C9336C
Eth1/35
cs2                Eth1/36      175      R S I s      N9K-C9336C
Eth1/36

Total entries displayed: 4

(cs2) # show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device-ID          Local Intrfce  Hldtme Capability  Platform
Port ID
node1              Eth1/1       133      H             FAS2980
e0b
node2              Eth1/2       133      H             FAS2980
e0b
cs1                Eth1/35      175      R S I s      N9K-C9336C
Eth1/35
cs1                Eth1/36      175      R S I s      N9K-C9336C
Eth1/36

Total entries displayed: 4
```

6. Display information about the discovered network devices in your cluster:

```
network device-discovery show -protocol cdp
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/      Local  Discovered
Protocol    Port   Device (LLDP: ChassisID)  Interface
Platform

-----
-----
node2      /cdp
          e0a    cs1          0/2          N9K-
C9336C
          e0b    cs2          0/2          N9K-
C9336C
node1      /cdp
          e0a    cs1          0/1          N9K-
C9336C
          e0b    cs2          0/1          N9K-
C9336C

4 entries were displayed.
```

7. Verify that the settings are disabled:

```
network options switchless-cluster show
```



It might take several minutes for the command to complete. Wait for the '3 minute lifetime to expire' announcement.

The false output in the following example shows that the configuration settings are disabled:

```
cluster1::*> network options switchless-cluster show
Enable Switchless Cluster: false
```

8. Verify the status of the node members in the cluster:

```
cluster show
```

Show example

The following example shows information about the health and eligibility of the nodes in the cluster:

```
cluster1::*> cluster show

Node          Health  Eligibility  Epsilon
-----
node1        true    true          false
node2        true    true          false
```

9. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
                                         Source          Destination
Packet
Node    Date          LIF          LIF
Loss
-----
-----
node1
  3/5/2022 19:21:18 -06:00  node1_clus2      node2-clus1
none
  3/5/2022 19:21:20 -06:00  node1_clus2      node2_clus2
none
node2
  3/5/2022 19:21:18 -06:00  node2_clus2      node1_clus1
none
  3/5/2022 19:21:20 -06:00  node2_clus2      node1_clus2
none
```

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node local
Host is node2
Getting addresses from network interface table...
Cluster node1_clus1 169.254.209.69 node1 e0a
Cluster node1_clus2 169.254.49.125 node1 e0b
Cluster node2_clus1 169.254.47.194 node2 e0a
Cluster node2_clus2 169.254.19.183 node2 e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:

Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)

Detected 9000 byte MTU on 4 path(s):
Local 169.254.47.194 to Remote 169.254.209.69
Local 169.254.47.194 to Remote 169.254.49.125
Local 169.254.19.183 to Remote 169.254.209.69
Local 169.254.19.183 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

10. Change the privilege level back to admin:

```
set -privilege admin
```

11. If you suppressed automatic case creation, reenable it by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=END
```

What's next?

After you've migrated your switches, you can [configure switch health monitoring](#).

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.