



Apply StorageGRID hotfix

StorageGRID 11.8

NetApp
May 17, 2024

This PDF was generated from <https://docs.netapp.com/us-en/storagegrid-118/maintain/storagegrid-hotfix-procedure.html> on May 17, 2024. Always check docs.netapp.com for the latest.

Table of Contents

- Apply StorageGRID hotfix 1
 - StorageGRID hotfix procedure: Overview 1
 - How your system is affected when you apply a hotfix 2
 - Obtain required materials for hotfix 3
 - Download hotfix file 3
 - Check system's condition before applying hotfix 4
 - Apply hotfix. 4

Apply StorageGRID hotfix

StorageGRID hotfix procedure: Overview

You might need to apply a hotfix to your StorageGRID system if issues with the software are detected and resolved between feature releases.

StorageGRID hotfixes contain software changes that are made available outside of a feature or patch release. The same changes are included in a future release. In addition, each hotfix release contains a roll-up of all previous hotfixes within the feature or patch release.

Considerations for applying a hotfix

You can't apply a StorageGRID hotfix when another maintenance procedure is running. For example, you can't apply a hotfix while a decommission, expansion, or recovery procedure is running.



If a node or site decommission procedure is paused, you can safely apply a hotfix. In addition, you might be able to apply a hotfix during the final stages of a StorageGRID upgrade procedure. See the instructions for upgrading StorageGRID software for details.

After you upload the hotfix in the Grid Manager, the hotfix is applied automatically to the primary Admin Node. Then, you can approve the application of the hotfix to the rest of the nodes in your StorageGRID system.

If a hotfix fails to be applied to one or more nodes, the reason for the failure appears in the Details column of the hotfix progress table. You must resolve whatever issues caused the failures and then retry the entire process. Nodes with a previously successful application of the hotfix will be skipped in subsequent applications. You can safely retry the hotfix process as many times as required until all nodes have been updated. The hotfix must be successfully installed on all grid nodes in order for the application to be complete.

While grid nodes are updated with the new hotfix version, the actual changes in a hotfix might only affect specific services on specific types of nodes. For example, a hotfix might only affect the LDR service on Storage Nodes.

How hotfixes are applied for recovery and expansion

After a hotfix has been applied to your grid, the primary Admin Node automatically installs the same hotfix version to any nodes restored by recovery operations or added in an expansion.

However, if you need to recover the primary Admin Node, you must manually install the correct StorageGRID release and then apply the hotfix. The final StorageGRID version of the primary Admin Node must match the version of the other nodes in the grid.

The following example illustrates how to apply a hotfix when recovering the primary Admin Node:

1. Assume the grid is running a StorageGRID 11.A.B version with the latest hotfix. The "grid version" is 11.A.B.y.
2. The primary Admin Node fails.
3. You redeploy the primary Admin Node using StorageGRID 11.A.B, and perform the recovery procedure.



As required to match the grid version, you can use a minor release when deploying the node; you don't need to deploy the major release first.

4. You then apply hotfix 11.A.B.y to the primary Admin Node.

For more information, see [Configure replacement primary Admin Node](#).

How your system is affected when you apply a hotfix

You must understand how your StorageGRID system will be affected when you apply a hotfix.

StorageGRID hotfixes are non-disruptive

The StorageGRID system can ingest and retrieve data from client applications throughout the hotfix process. If you approve all nodes of the same type to hotfix (for example, Storage Nodes), the nodes are brought down one at a time, so there is no time when all grid nodes or all grid nodes of a certain type are unavailable.

To allow for continued availability, ensure that your ILM policy contains rules that specify storing multiple copies of each object. You must also ensure that all external S3 or Swift clients are configured to send requests to one of the following:

- A high availability (HA) group virtual IP address
- A high availability third-party load balancer
- Multiple Gateway Nodes for each client
- Multiple Storage Nodes for each client

Client applications might experience short-term disruptions

The StorageGRID system can ingest and retrieve data from client applications throughout the hotfix process; however, client connections to individual Gateway Nodes or Storage Nodes might be disrupted temporarily if the hotfix needs to restart services on those nodes. Connectivity will be restored after the hotfix process completes and services resume on the individual nodes.

You might need to schedule downtime to apply a hotfix if loss of connectivity for a short period is not acceptable. You can use selective approval to schedule when certain nodes are updated.



You can use multiple gateways and high availability (HA) groups to provide automatic failover during the hotfix process. See the instructions for [configuring high availability groups](#).

Alerts and SNMP notifications might be triggered

Alerts and SNMP notifications might be triggered when services are restarted and when the StorageGRID system is operating as a mixed-version environment (some grid nodes running an earlier version, while others have been upgraded to a later version). In general, these alerts and notifications will clear when the hotfix completes.

Configuration changes are restricted

When applying a hotfix to StorageGRID:

- Don't make any grid configuration changes (for example, specifying Grid Network subnets or approving pending grid nodes) until the hotfix has been applied to all nodes.
- Don't update the ILM configuration until the hotfix has been applied to all nodes.

Obtain required materials for hotfix

Before applying a hotfix, you must obtain all required materials.

Item	Notes
StorageGRID hotfix file	You must download the StorageGRID hotfix file.
<ul style="list-style-type: none"> • Network port • Supported web browser • SSH client (for example, PuTTY) 	
Recovery Package (.zip) file	Before applying a hotfix, download the most recent Recovery Package file in case any problems occur during the hotfix. Then, after the hotfix has been applied, download a new copy of the Recovery Package file and save it in a safe location. The updated Recovery Package file allows you to restore the system if a failure occurs.
Passwords.txt file	Optional and used only if you are applying a hotfix manually using the SSH client. The Passwords.txt file is part of the Recovery Package .zip file.
Provisioning passphrase	The passphrase is created and documented when the StorageGRID system is first installed. The provisioning passphrase is not listed in the Passwords.txt file.
Related documentation	readme.txt file for the hotfix. This file is included on the hotfix download page. Be sure to review the readme file carefully before applying the hotfix.

Download hotfix file

You must download the hotfix file before you can apply the hotfix.

Steps

1. Go to [NetApp Downloads: StorageGRID](#).
2. Select the down arrow under **Available Software** to see a list of hotfixes that are available to download.



Hotfix file versions have the form: 11.4.x.y.

3. Review the changes that are included in the update.



If you have just [recovered the primary Admin Node](#) and you need to apply a hotfix, select the same hotfix version that is installed on the other grid nodes.

- a. Select the hotfix version you want to download, and select **Go**.
- b. Sign in using the username and password for your NetApp account.
- c. Read and accept the End User License Agreement.

The download page for the version you selected appears.

- d. Download the hotfix `readme.txt` file to view a summary of the changes included in the hotfix.

4. Select the download button for the hotfix, and save the file.



Don't change the name of this file.



If you are using a macOS device, the hotfix file might be automatically saved as a `.txt` file. If it is, you must rename the file without the `.txt` extension.

5. Select a location for the download, and select **Save**.

Check system's condition before applying hotfix

You must verify the system is ready to accommodate the hotfix.

1. Sign in to the Grid Manager using a [supported web browser](#).
2. If possible, ensure that the system is running normally and that all grid nodes are connected to the grid.

Connected nodes have green check marks  on the Nodes page.

3. Check for and resolve any current alerts, if possible.
4. Ensure no other maintenance procedures are in progress, such as an upgrade, recovery, expansion, or decommission procedure.

You should wait for any active maintenance procedures to complete before applying a hotfix.

You can't apply a StorageGRID hotfix when another maintenance procedure is running. For example, you can't apply a hotfix while a decommission, expansion, or recovery procedure is running.



If a node or site [decommission procedure is paused](#), you can safely apply a hotfix. In addition, you might be able to apply a hotfix during the final stages of a StorageGRID upgrade procedure. See the instructions for [upgrading StorageGRID software](#).

Apply hotfix

The hotfix is first applied automatically to the primary Admin Node. Then, you must approve the application of the hotfix to other grid nodes until all nodes are running the same software version. You can customize the approval sequence by selecting to

approve individual grid nodes, groups of grid nodes, or all grid nodes.

Before you begin

- You have reviewed the [considerations for applying a hotfix](#).
- You have the provisioning passphrase.
- You have Root access or the Maintenance permission.

About this task

- You can delay applying a hotfix to a node, but the hotfix process is not complete until you apply the hotfix to all nodes.
- You can't perform a StorageGRID software upgrade or a SANtricity OS update until you have completed the hotfix process.

Steps

1. Sign in to the Grid Manager using a [supported web browser](#).
2. Select **MAINTENANCE** > **System** > **Software update**.

The Software Update page appears.

Software update

You can upgrade StorageGRID software, apply a hotfix, or upgrade the SANtricity OS software on StorageGRID storage appliances. NetApp recommends you apply the latest hotfix before and after each software upgrade. Some hotfixes are required to prevent data loss.

StorageGRID upgrade Upgrade to the next StorageGRID version and apply the latest hotfix for that version. Upgrade →	StorageGRID hotfix Apply a hotfix to your current StorageGRID software version. Apply hotfix →	SANtricity OS update Update the SANtricity OS software on your StorageGRID storage appliances. Update →
--	---	--

3. Select **Apply hotfix**.

The StorageGRID Hotfix page appears.

StorageGRID Hotfix

Before starting the hotfix process, you must confirm that there are no active alerts and that all grid nodes are online and available.

When the primary Admin Node is updated, services are stopped and restarted. Connectivity might be interrupted until the services are back online.

Hotfix file

Hotfix file ?

Browse

Passphrase

Provisioning Passphrase ?

Start

4. Select the hotfix file you downloaded from the NetApp Support Site.

- a. Select **Browse**.
- b. Locate and select the file.

`hotfix-install-version`

- c. Select **Open**.

The file is uploaded. When the upload is finished, the file name is shown in the Details field.



Don't change the file name because it is part of the verification process.

5. Enter the provisioning passphrase in the text box.

The **Start** button becomes enabled.

6. Select **Start**.

A warning appears stating that your browser's connection might be lost temporarily as services on the primary Admin Node are restarted.

7. Select **OK** to start applying the hotfix to the primary Admin Node.

When the hotfix starts:

- a. The hotfix validations are run.



If any errors are reported, resolve them, re-upload the hotfix file, and select **Start** again.

- b. The hotfix installation progress table appears.

This table shows all nodes in your grid and the current stage of the hotfix installation for each node. The nodes in the table are grouped by type (Admin Nodes, Gateway Nodes, Storage Nodes, and

Archive Nodes).

- c. The progress bar reaches completion, and then the primary Admin Node is shown as "Complete."

Hotfix Installation Progress

Approve All Remove All

Admin Nodes - 1 out of 1 completed

Search

Site	Name	Progress	Stage	Details	Action
Vancouver	VTC-ADM1-101-191	<div></div>	Complete		

8. Optionally, sort the lists of nodes in each grouping in ascending or descending order by **Site**, **Name**, **Progress**, **Stage**, or **Details**. Or, enter a term in the **Search** box to search for specific nodes.
9. Approve the grid nodes that are ready to be updated. Approved nodes of the same type are upgraded one at a time.



Don't approve the hotfix for a node unless you are sure the node is ready to be updated. When the hotfix is applied to a grid node, some services on that node might be restarted. These operations might cause service interruptions for clients that are communicating with the node.

- Select one or more **Approve** buttons to add one or more individual nodes to the hotfix queue.
- Select the **Approve All** button within each grouping to add all nodes of the same type to the hotfix queue. If you have entered search criteria in the **Search** box, the **Approve All** button applies to all the nodes selected by the search criteria.



The **Approve All** button at the top of the page approves all nodes listed on the page, while the **Approve All** button at the top of a table grouping only approves all nodes in that group. If the order in which nodes are upgraded is important, approve nodes or groups of nodes one at a time and wait until the upgrade is complete on each node before approving the next node(s).

- Select the top-level **Approve All** button at the top of the page to add all nodes in the grid to the hotfix queue.



You must complete the StorageGRID hotfix before you can start a different software update. If you are unable to complete the hotfix, contact technical support.

- Select **Remove** or **Remove All** to remove a node or all nodes from the hotfix queue.

When the Stage progresses beyond "Queued," the **Remove** button is hidden and you can no longer remove the node from the hotfix process.

Storage Nodes - 1 out of 9 completed
Approve All
Remove All

Site	Name	Progress	Stage	Details	Action
Raleigh	RAL-S1-101-196		Queued		Remove
Raleigh	RAL-S2-101-197		Complete		
Raleigh	RAL-S3-101-198		Queued		Remove
Sunnyvale	SVL-S1-101-199		Queued		Remove
Sunnyvale	SVL-S2-101-93		Waiting for you to approve		Approve
Sunnyvale	SVL-S3-101-94		Waiting for you to approve		Approve
Vancouver	VTC-S1-101-193		Waiting for you to approve		Approve
Vancouver	VTC-S2-101-194		Waiting for you to approve		Approve
Vancouver	VTC-S3-101-195		Waiting for you to approve		Approve

10. Wait while the hotfix is applied to each approved grid node.

When the hotfix has been successfully installed on all nodes, the Hotfix Installation Progress table closes. A green banner shows the date and time the hotfix was completed.

11. If the hotfix could not be applied to any nodes, review the error for each node, resolve the issue, and repeat these steps.

The procedure is not complete until the hotfix is successfully applied to all nodes. You can safely retry the hotfix process as many times as required until it is complete.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.