

TR-4871: Configure StorageGRID for backup and recovery with Commvault

How to enable StorageGRID in your environment

NetApp July 05, 2024

This PDF was generated from https://docs.netapp.com/us-en/storagegrid-enable/technicalreports/commvault/index.html on July 05, 2024. Always check docs.netapp.com for the latest.

Table of Contents

TR-4871: Configure StorageGRID for backup and recovery with Commvault		1
Backup and recover data using StorageGRID and Commvault		1
Tested solution overview	3	3
StorageGRID sizing guidance		5
Run a data protection job	7	7
Bucket consistency level recommendation	18	5

TR-4871: Configure StorageGRID for backup and recovery with Commvault

Backup and recover data using StorageGRID and Commvault

Commvault and NetApp have partnered to create a joint data protection solution combining Commvault Complete Backup and Recovery for NetApp software with NetApp StorageGRID software for cloud storage. Commvault Complete Backup and Recovery and NetApp StorageGRID provide unique, easy-to-use solutions that work together to help you meet demands of rapid data growth and increasing regulations around the world.

Many organizations want to migrate their storage to the cloud, scale their systems, and automate their policy for long-term retention of data. Cloud-based object storage is known for its resilience, ability to scale, and operational and cost efficiencies that make it a natural choice as a target for your backup. Commvault and NetApp jointly certified their combined solution in 2014 and since then have engineered deeper integration between their two solutions. Customers of all types around the world have adopted the Commvault Complete Backup and Recovery and StorageGRID combined solution.

About Commvault and StorageGRID

Commvault Complete Backup and Recovery software is an enterprise-level, integrated data and information management solution, built from the ground up on a single platform and with a unified code base. All of its functions share back-end technologies, bringing the unparalleled advantages and benefits of a fully integrated approach to protecting, managing, and accessing your data. The software contains modules to protect, archive, analyze, replicate, and search your data. The modules share a common set of back-end services and advanced capabilities that seamlessly interact with each other. The solution addresses all aspects of data management in your enterprise, while providing infinite scalability and unprecedented control of data and information.

NetApp StorageGRID as a Commvault cloud tier is an enterprise hybrid-cloud object-storage solution. You can deploy it across many sites, either on a purpose-built appliance or as a software-defined deployment. StorageGRID enables you to establish data management policies that determine how data is stored and protected. StorageGRID collects the information you need to develop and enforce policies. It examines a wide range of characteristics and needs, including performance, durability, availability, geographic location, longevity, and cost. Data is fully maintained and protected as it moves between locations and as it ages.

The StorageGRID intelligent policy engine helps you choose either of the following options:

- To use erasure coding to back up data across multiple sites for resilience.
- To copy objects to remote sites to minimize WAN latency and cost.

When StorageGRID stores an object, you access it as one object, regardless of where it is or how many copies exist. This behavior is crucial for disaster recovery, because with it, even if one backup copy of your data is corrupted, StorageGRID is able to restore your data.

Retaining backup data in your primary storage can be expensive. When you use NetApp StorageGRID, you free up space on your primary storage by migrating inactive backup data into StorageGRID while you benefit from the numerous capabilities of StorageGRID. The value of backup data changes over time, as does the cost

of storing it. StorageGRID can minimize the cost of your primary storage while increasing the durability of your data.

Key features

Key features of the Commvault software platform include:

- A complete data protection solution supporting all major operating systems, applications, and databases on virtual and physical servers, NAS systems, cloud-based infrastructures, and mobile devices.
- Simplified management through a single console: You can view, manage, and access all functions and all data and information across the enterprise.
- Multiple protection methods including data backup and archiving, snapshot management, data replication, and content indexing for e-discovery.
- Efficient storage management using deduplication for disk and cloud storage.
- Integration with NetApp storage arrays such as AFF, FAS, NetApp HCI, and E-Series arrays and NetApp SolidFire[®] scale-out storage systems. Integration also with NetApp Cloud Volumes ONTAP software to automate the creation of indexed, application-aware NetApp Snapshot[™] copies across the NetApp storage portfolio.
- Complete virtual infrastructure management that supports leading on-premises virtual hypervisors and public cloud hyperscaler platforms.
- Advanced security capabilities to limit access to critical data, provide granular management capabilities, and provide single-sign-on access for Active Directory users.
- Policy-based data management that allows you to manage your data based on business needs—not physical location.
- A cutting-edge end-user experience, empowering your users to protect, find, and recover their own data.
- API-driven automation, allowing you to use third-party tools like vRealize Automation or Service Now to manage your data protection and recovery operations.

For details on supported workloads, visit CommVault's supported technologies.

Backup options

When you implement Commvault Complete Backup and Recovery software with cloud storage, you have two backup options:

- Back up to a primary disk target and also back up an auxiliary copy to cloud storage.
- Back up to cloud storage as the primary target.

In the past, cloud or object storage was considered to be too low-performing to be used for primary backup. The use of a primary disk target allowed customers to have faster backup and restore processes and to keep an auxiliary copy on the cloud as a cold backup. StorageGRID represents the next generation of object storage. StorageGRID is capable of high performance and massive throughput as well as performance and flexibility beyond what other object-storage vendors offer.

The following table lists the benefits of each backup option with StorageGRID:

	Primary Backup to Disk and an Auxiliary Copy to StorageGRID	Primary Backup to StorageGRID
Performance	Fastest recovery time, using live mount or live recovery: best for Tier0/Tier1 workloads.	Cannot be used for live mount or live recovery operations. Ideal for streaming restore operation and for long-term retention.
Deployment architecture	Uses all flash or a spinning disk as a first backup landing tier. StorageGRID is used as a secondary tier.	Simplifies the deployment by using StorageGRID as the all-inclusive backup target.
Advanced features (live restore)	Supported	Not supported

Where to find additional information

To learn more about the information that is described in this document, review the following documents and/or websites:

- StorageGRID 11.8 Documentation Center https://docs.netapp.com/us-en/storagegrid-118/
- NetApp Product Documentation https://docs.netapp.com
- Commvault documentation
 https://documentation.commvault.com/2024/essential/index.html

Tested solution overview

The tested solution combines Commvault and NetApp solutions to make a powerful joint solution.

Solution setup

In the lab setup, the StorageGRID environment consisted of four NetApp StorageGRID SG5712 appliances, one virtual primary Admin node and one virtual Gateway node. The SG5712 appliance is the entry level option—a baseline configuration. Choosing higher performance appliance options such as the NetApp StorageGRID SG5760 or SG6060 can provide significant performance benefits. Consult your NetApp StorageGRID solution architect for sizing assistance.

For its data protection policy, StorageGRID uses an integrated lifecycle management (ILM) policy to manage and protect data. ILM rules are evaluated in a policy from top to bottom. We implemented the ILM policy shown in the following table:

ILM Rule	Qualifiers	Ingest Behavior
Erasure Coding 2+1	Objects over 200KB	Balanced
2 Сору	All objects	Dual Commit

The ILM 2 Copy rule is the default rule. The Erasure Coding 2+1 rule was applied for this testing to any object 200KB or larger. The default rule was applied to objects smaller than 200KB. Application of the rules in this way is a StorageGRID best practice.

For technical details about this test environment, read the Solution Design and Best Practices section in the NetApp Scale-out Data Protection with Commvault technical report.

StorageGRID hardware specifications

The following table describes the NetApp StorageGRID hardware used in this testing. The StorageGRID SG5712 appliance with 10Gbps networking is the entry-level option and represents a baseline configuration. Optionally the SG5712 can be configured for 25Gbps networking.

Hardware	Quantity	Disk	Usable Capacity	Network
StorageGRID SG5712 appliances	4	48 x 4TB (near-line SAS HDD)	136TB	10Gbps

Choosing higher-performance appliance options such as the NetApp StorageGRID SG5760, SG6060, or all flash SGF6112 appliances can provide significant performance benefits. Consult your NetApp StorageGRID solution architect for sizing assistance.

Commvault and StorageGRID software requirements

The following tables list the software requirements for the Commvault and NetApp StorageGRID software installed on VMware software for our testing. Four MediaAgent data transmission managers and one CommServe server were installed. In the test, 10Gbps networking was implemented for the VMware infrastructure. The following table

The following table lists Commvault software total system requirements:

Component	Quantity	Datastore	Size	Total	Total Required IOPS
CommServe Server	1	OS	500GB	500GB	n/a
		SQL	500GB	500GB	n/a
MediaAgent	4	Virtual CPU (vCPU)	16	64	n/a
		RAM	128GB	512	n/a
		OS	500GB	2TB	n/a
		Index Cache	2TB	8TB	200+
		DDB	2TB	8TB	200-80,000K

In the test environment, one virtual primary Admin node and one virtual Gateway node were deployed on VMware on a NetApp E-Series E2812 storage array. Each node was on a separate server with the minimum production environment requirements described in the following table:

The following table list requirements for StorageGRID virtual Admin nodes and Gateway nodes:

Node type	Quantity	vCPU	RAM	Storage
Gateway node	1	8	24GB	100GB LUN for the OS
Admin node	1	8	24GB	100GB LUN for the OS 200GB LUN for Admin node tables 200GB LUN for the Admin node audit log

StorageGRID sizing guidance

Consult your NetApp data protection specialists for specific sizing for your environment. NetApp data protection specialists can use the Commvault Total Backup Storage Calculator tool to estimate the backup infrastructure requirements. The tool requires Commvault Partner Portal access. Sign up for access, if needed.

Commvault sizing inputs

The following tasks can be used to perform discovery for sizing of the data protection solution:

- Identify the system or application/database workloads and corresponding front-end capacity (in terabytes [TB]) that will need to be protected.
- Identify the VM/file workload and similar front-end capacity (TB) that will need to be protected.
- Identify short-term and long-term retention requirements.
- Identify the daily % change rate for the datasets/workloads identified.
- Identify projected data growth over the next 12, 24, and 36 months.
- Define the RTO and RPO for data protection/recovery according to business needs.

When this information is available, the backup infrastructure sizing can be done resulting in a breakdown of required storage capacities.

StorageGRID sizing guidance

Before you perform NetApp StorageGRID sizing, consider these aspects of your workload:

- Usable capacity
- WORM mode

- Average object size
- Performance requirements
- ILM policy applied

The amount of usable capacity needs to accommodate the size of the backup workload you have tiered to StorageGRID and the retention schedule.

Will WORM mode be enabled or not? With WORM enabled in Commvault, this will configure object lock on StorageGRID. This will increase the object storage capacity required. The amount of capacity required will vary based on the retention duration and number of object changes with each backup.

Average object size is an input parameter that helps with sizing for performance in a StorageGRID environment. The average object sizes used for a Commvault workload depend on the type of backup.

The following table lists average object sizes by type of backup and describes what the restore process reads from the object store:

Васкир Туре	Average Object Size	Restore Behavior
Make an auxiliary copy in StorageGRID	32MB	Full read of 32MB object
Direct the backup to StorageGRID (deduplication enabled)	8MB	1MB random-range read
Direct the backup to StorageGRID (deduplication disabled)	32MB	Full read of 32MB object

In addition, understanding your performance requirements for full backups and incremental backups helps you determine sizing for the StorageGRID storage nodes. StorageGRID information lifecycle management (ILM) policy data protection methods determine the capacity needed to store Commvault backups and affect the sizing of the grid.

StorageGRID ILM replication is one of two mechanisms used by StorageGRID to store object data. When StorageGRID assigns objects to an ILM rule that replicates data, the system creates exact copies of the objects' data and stores the copies on storage nodes.

Erasure coding is the second method used by StorageGRID to store object data. When StorageGRID assigns objects to an ILM rule that is configured to create erasure-coded copies, it slices object data into data fragments. It then computes additional parity fragments and stores each fragment on a different storage node. When an object is accessed, it is reassembled using the stored fragments. If a data fragment or a parity fragment becomes corrupt or is lost, the erasure-coding algorithm can re-create that fragment using a subset of the remaining data and parity fragments.

The two mechanisms require different amounts of storage, as these examples demonstrate:

- If you store two replicated copies, your storage overhead doubles.
- If you store a 2+1 erasure-coded copy, your storage overhead increases by 1.5 times.

For the solution tested, an entry-level StorageGRID deployment on a single site was used:

• Admin node: VMware virtual machine (VM)

- Load balancer: VMware VM
- Storage nodes: 4x SG5712 with 4TB drives
- Primary Admin node and Gateway node: VMware VMs with the minimum production workload requirements



StorageGRID also supports third-party load balancers.

StorageGRID is typically deployed in two or more sites with data protection policies that replicate data to protect against node and site-level failures. By backing up your data to StorageGRID, your data is protected by multiple copies or by erasure coding that separates and reassembles data dependably through an algorithm.

You can use the sizing tool Fusion to size your grid.

Scaling

You can expand a NetApp StorageGRID system by adding storage to storage nodes, adding new grid nodes to an existing site, or adding a new data center site. You can perform expansions without interrupting the operation of your current system.

StorageGRID scales performance by using either higher performance nodes for storage nodes or the physical appliance which runs the load balancer and the admin nodes or by simply adding additional nodes.



For more information about expanding the StorageGRID system, see StorageGRID 11.8 Expansion Guide.

Run a data protection job

To configure StorageGRID with Commvault Complete Backup and Recovery for NetApp, the following steps were performed to add StorageGRID as a cloud library within the Commvault software.

Step 1: Configure Commvault with StorageGRID

Steps

1. Log in to the Commvault Command Center. On the left panel, click Storage > Cloud > Add to see and respond to the Add Cloud dialog box:

Add cloud

Name				
Туре	NetApp StorageGRI	D		•
MediaAgent	Select MediaAgent		•	+
Server host	<ip-address-or-host-< td=""><td>name>:<port></port></td><td></td><td></td></ip-address-or-host-<>	name>: <port></port>		
Bucket	<name-of-the-bucke< td=""><td>t-in-SG></td><td></td><td></td></name-of-the-bucke<>	t-in-SG>		
Credentials				
Use saved credentials Name	Select credentials		*	+
Use deduplication				
Deduplication DB location				(f)
		Cancel	Sa	ve

×

- 2. For Type, select NetApp StorageGRID.
- 3. For MediaAgent, select all that are associated with the cloud library.
- 4. For Server Host, enter the IP address or the host name of the StorageGRID endpoint and the port number.

Follow the steps in StorageGRID documentation on how to configure a load balancer endpoint (port). Make sure you have an HTTPS port with a self-signed certificate and the IP address or the domain name of the StorageGRID endpoint.

- 5. If you want to use deduplication, turn on this option and provide the path to the deduplication database location.
- 6. Click Save.

Step 2: Create a backup plan with StorageGRID as the primary target

Steps

1. On the left panel, select Manage > Plans to see and respond to the Create Server Backup Plan dialog box.

Create server backup plan o

Plan name

Backup destinations

Add copy

×

Name	Storage	Retention period 🕹	
Primary	storageGRID final test	30	
Primary RPO (1)			
Backup frequency	Runs every 4	Hours V	
Add full backup			
Backup window	Monday through	n Sunday : All day	
Full backup window	Monday through	n Sunday : All day	
Folders to backup 🕚			~
Snapshot options 0			~
Database options 🕚			~
Override restrictions			~
		Cancel	e

- 2. Enter a plan name.
- 3. Select the StorageGRID Simple Storage Service (S3) storage backup destination that you created earlier.
- 4. Enter the backup retention period and recovery point objective (RPO) that you want.
- 5. Click Save.

Step 3: Start a backup job to protect your workloads

Steps

- 1. On the Commvault Command Center, navigate to Protect > Virtualization.
- 2. Add a VMware vCenter Server hypervisor.
- 3. Click the hypervisor that you just added.
- 4. Click Add VM group to respond to the Add VM Group dialog box so that you can see the vCenter environment that you plan to protect.

Add VM group 🛛			×
Name			
Browse and select VMs	Hosts and clusters		-
	Q Search VMs		
		Select all	Clear all
🔻 🗆 🛗 GDL1			
> D DAD			
🔻 🗌 🕅 SG			
▶ 🔲 🗎 10.193.92.169			
► 🗌 📕 10.193.92.170			
► 🔲 📕 10.193.92.171			
► 🗌 🖬 10.193.92.203			
▶ 🔲 🖩 10.193.92.227			
▶ □			
10.193.92.98			
► 🗌 📕 10.193.92.99			
🕨 🗌 🥑 Ahmad			
🕨 🗌 😂 Arpita			
	fore screwing around :)		
🕨 🗌 🦁 Baremetal-VM			
CVLT HCI POD			
DO-NOT-TOUC	:H		
🕨 🗌 😂 Felix			
Image: Second			
DisephKj			
NAS Bridge Mi	gration Test		
► 🗌 🥏 steve			
Pahoo Japan T Solution Constant Consta	est		
GroupA-GW1			
□ ∰ John			
Backup configuration	1		
Use backup plan			
Plan	to SG- No dedup		*
		Cancel	Save

- 5. Select a datastore, a VM, or a collection of VMs, and enter a name for it.
- 6. Select the backup plan that you created in the previous task.
- 7. Click Save to see the VM group you created.
- 8. In the upper-right corner of the VM group window, select Backup:

COMMVAULT Command Center	Q Search or type / for	a command					a t	🛓 admin 🗸
Filter navigation	Hypervisors	VM groups	Virtual machines					
🏋 Guided setup	VM groups / -DSN-server							
Le Dashboard	Overview	Configuration					Backup	View jobs
Virtualization								
File servers	VMs					Content		Manage
> Databases	0		0	0		DNS-server-Bootcamp		
Laptops	PROTECTED		NOT PROTECTED	BACKED UP WITH ERRO	8			
Cloud apps								
🕏 Activate	Summary							
Orchestrate	Hypervisor name			enenglab.netapp.com-retry				
🚔 Jobs	Region		Not set		Edit			
Reports	Data management							
Monitoring								
😂 Storage								
韮 Manage								
🔅 Developer tools								edbaci
Web console								 Feedback

9. Select Full as the backup level, (optionally) request an email when the backup is finished, then click OK to have your backup job start:

Select backup level

Full

Incremental

Synthetic full

When the job completes, notify me via email

Cancel

ОК

×

10. Navigate to the job summary page to view the job metrics:

COMMVAULT Command Center	Q Search or type / for a command					🏴 🛓 admin
Filter navigation	Active jobs /					
🛠 Guided setup	Job 21531 - [Backup]					Suspend Kill More actions 🔻
🕼 Dashboard	Job summary			Job details		
Protect	Туре	Backup		Agent	Virtual Server	
Activate	Backup type	Full		Media agent	MA_win-jmt87h11uo3	
Orchestrate	Current phase	Backup		Size of application	12.87 GB	
🚔 Jobs	Status	Running		Data transferred on network	7.27 GB	
Reports	Progress	61%		Transfer time	40 min 0 sec	More 🗸
🛛 Monitoring	Source client computer	sg-vc-gdl1.rtp.openenglab.netapp.com-retry				indic +
🥃 Storage	Subclient	testvms-DSN-server				
茎 Manage	Last update time	Jul 13, 2020 4:29:41 PM				
🐼 Developer tools	Start time	Jul 14, 2020 12:40:38 AM				
Web console	Job started from	Scheduled				
Console	Storage policy	to-sg-head-test				
	Encryption enabled	No				
			^			
	Events VM list					
	Events (All -)					۵
			No data	available		

Bucket consistency level recommendation

NetApp StorageGRID allows the end user to select the consistency level for operations performed on the objects in Simple Storage Service (S3) buckets.

Commvault MediaAgents are the data movers in a Commvault environment. In most cases, MediaAgents are configured to write locally into a primary StorageGRID site. For this reason, a high consistency level within a local primary site is recommended. Use the following guidelines when you set the consistency level on Commvault buckets created in StorageGRID.



If you have a Commvault version earlier than 11.0.0 - Service Pack 16, consider upgrading Commvault to the newest version. If that is not an option, be sure to follow the guidelines for your version.

- Commvault versions earlier than 11.0.0 Service Pack 16.* In versions earlier than 11.0.0 Service Pack 16, Commvault performs S3 HEAD and GET operations on non-existent objects as part of restore and pruning process. Set the bucket consistency level to Strong-site to achieve the optimal consistency level for Commvault backups to StorageGRID.
- Commvault versions 11.0.0 Service Pack 16 and later.* In versions 11.0.0 Service Pack 16 and later, the number of S3 HEAD and GET operations performed on non-existent objects are minimized. Set the default bucket consistency level to Read-after-new-write to ensure high consistency level in the Commvault and StorageGRID environment.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.