



Replication

Amazon FSx for NetApp ONTAP

NetApp

February 17, 2026

This PDF was generated from <https://docs.netapp.com/us-en/workload-fsx-ontap/cascade-replication.html> on February 17, 2026. Always check docs.netapp.com for the latest.

Table of Contents

Replication	1
Replicate data protection volumes in NetApp Workload Factory	1
Reverse a replication relationship in NetApp Workload Factory	3
Change the replication schedule of a source volume	4
Limit the max transfer rate of a replication relationship	4
Update snapshot data in a replication relationship	5
Pause and resume a replication relationship in NetApp Workload Factory	5
Pause a replication relationship	6
Resume a paused replication relationship	6
Stop a replication relationship in NetApp Workload Factory	7
Delete a replication relationship in NetApp Workload Factory	7

Replication

Replicate data protection volumes in NetApp Workload Factory

Replicate data protection volumes, or cascade the replication of volume data, to extend data protection to tertiary systems or migrate your data.

About this task

NetApp Workload Factory supports replicating data protection volumes, also called *cascade deployments*. A *cascade deployment* consists of a chain of relationships in which a source volume is mirrored to a secondary volume (first hop), and the secondary volume is mirrored to a tertiary volume (second hop). If the secondary volume becomes unavailable, you can synchronize the relationship between the primary and tertiary volumes without performing a new baseline transfer.

This feature is supported for FSx for ONTAP file systems with ONTAP version 9.6 and higher. Refer to [ONTAP documentation for compatible ONTAP versions](#).

Learn more about [how cascade deployments work](#).

Before you begin

Consider the following before you begin:

- Be aware that volumes that are part of a cascade configuration can take longer to resynchronize.
- If the source volume of the relationship is a data protection volume and is a target of another relationship, reversing the replication relationship isn't supported.
- One replica of a data protection volume (or a second hop) is supported. It isn't considered best practice to create a second replica of a data protection volume (or a third hop).

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system that contains the volume(s) to replicate and then select **Manage**.
5. From the file system overview, select the **Volumes** tab.
6. In the Volumes table, select one or more data protection volumes (DP/replicated volumes), and then select **Replicate data**.
7. On the Replicate data page, under Replication target, provide the following:
 - a. **FSx for ONTAP file system**: Select credentials, region, and FSx for ONTAP file system name for the target FSx for ONTAP file system.
 - b. **Storage VM name**: Select the storage VM from the dropdown menu.
 - c. **Volume name**: The target volume name is generated automatically with the following format {OriginalVolumeName}_copy. You can use the auto-generated volume name or enter another volume name.
 - d. **Use case**: Select one of the following use cases for the replication. Depending on the selected use

case, Workload Factory fills in the form with recommended values in accordance with best practices. You can accept the recommended values or make changes as you complete the form.

- Migration: transfers your data to the target FSx for ONTAP file system
- Hot disaster recovery: ensures high availability and rapid disaster recovery for critical workloads
- Cold or archive disaster recovery:
 - Cold disaster recovery: uses longer recovery time objectives (RTO) and recovery point objects (RPO) to lower costs
 - Archive: replicates data for long-term storage and compliance
- Other

e. **Tiering policy:** Select the tiering policy for the data stored in the target volume. The tiering policy defaults to the recommended tiering policy for the use case you selected.

Balanced (Auto) is the default tiering policy when creating a volume using the Workload Factory console. For more information about volume tiering policies, refer to [Volume storage capacity](#) in AWS FSx for NetApp ONTAP documentation. Note that Workload factory uses use-case based names in the Workload Factory console for tiering policies and includes FSx for ONTAP tiering policy names in parentheses.

If you selected the migration use case, Workload Factory automatically selects to copy the tiering policy of source volume to the target volume. You can deselect to copy the tiering policy and select a tiering policy which applies to the volume selected for replication.

f. **Max transfer rate:** Select **Limited** and enter the max transfer limit in MB/s. Alternatively, select **Unlimited**.

Without a limit, network and application performance may decline. Alternatively, we recommend an unlimited transfer rate for FSx for ONTAP file systems for critical workloads, for example, those that are used primarily for disaster recovery.

8. Under Replication settings, provide the following:

- a. **Replication interval:** Select the frequency that snapshots are transferred from the source volume to the target volume.
- b. **Long-term retention:** Optionally, enable snapshots for long-term retention. Long-term retention enables business services to continue operating even through a complete site failure, supporting applications to fail over transparently using a secondary copy.

Replications without long-term retention use the *MirrorAllSnapshots* policy. Enabling long-term retention assigns the *MirrorAndVault* policy to the replication.

If you enable long-term retention, then select an existing policy or create a new policy to define the snapshots to replicate and the number to retain.



Matching source and target labels are required for long-term retention. If desired, Workload factory can create missing labels for you.

- **Choose an existing policy:** select an existing policy from the dropdown menu.
- **Create a new policy:** provide the following:
 - **Policy name:** Enter a policy name.
 - **Optional:** Enable immutable snapshots.

- Select **Enable immutable snapshots** to prevent snapshots taken in this policy from being deleted during the retention period.
- Set the **Retention period** in number of hours, days, months, or years.
- **Snapshot policies:** In the table, select the snapshot policy frequency and the number of copies to retain. You can select more than one snapshot policy.

9. Select **Create**.

Result

The replicated volume or volumes replicate and appear in the **Replication relationships** tab in the target FSx for ONTAP file system.

Reverse a replication relationship in NetApp Workload Factory

Reverse a replication relationship in NetApp Workload Factory so that the target volume becomes the source volume.

Reverse operations are supported for the following:

- Two FSx for ONTAP file systems
- One FSx for ONTAP file system and one on-premises ONTAP system

After you stop replication and make changes to the target volume, you can replicate those changes back to the source volume. This process is common in a disaster recovery scenario in which you operate on the target volume for a while and want to switch roles of the volumes.

About this task

When you reverse and resume a replication, it switches the source and target roles of your volumes; the target volume becomes the new source volume, and the source volume becomes the new target volume. The reverse operation also overwrites the contents of the new target volume with the contents of the new source volume. If you reverse a replication twice, the original replication direction re-establishes.

NOTE:

- Any data written to the original source volume between the last data replication and the time that the source volume is disabled is not preserved.
- Reversing replication isn't available when replicating storage VM data and configuration settings.

Before you begin

Make sure that you know the current and future roles of your source and target volumes because changes on the new target volume are overwritten with the new source volume. If used incorrectly, you can experience unintended data loss.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.

4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to reverse.
7. Select **Reverse relationship**.
8. In the Reverse relationship dialog, select **Reverse**.

Change the replication schedule of a source volume

Change the replication schedule of the source volume in a replication relationship in NetApp Workload Factory.

Choose how frequently snapshots from the source volume are transferred to the replicated volume to match your required point objectives (RPOs).

When an on-premises ONTAP cluster is the target for the replication relationship, changing the replication schedule isn't supported.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship schedule to change.
7. Select **Edit replication interval**.
8. In the Edit replication interval dialog, select the frequency of snapshot transfer from the source volume. You may select between the following frequencies:
 - Every 5 minutes
 - Hourly
 - Every 8 hours
 - Daily
 - Weekly
9. Select **Apply**.

Limit the max transfer rate of a replication relationship

Limit the max transfer rate of a replication relationship in NetApp Workload Factory. An unlimited transfer rate might negatively impact the performance of other applications and your network.

About this task

Limiting the max transfer rate is optional but recommended. Without a limit, network and application performance might decline.

Alternatively, we recommend an unlimited transfer rate for FSx for ONTAP file systems for critical workloads, for example, those that are used primarily for disaster recovery.

Before you begin

Consider how much bandwidth to allocate for replication.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to limit the max transfer rate for.
7. Select **Edit max transfer rate**.
8. In the Edit max transfer rate dialog, select **Limited** and enter the max transfer limit in MB/s.

Alternatively, select **Unlimited**.

9. Select **Apply**.

Update snapshot data in a replication relationship

A replication relationship has a set replication schedule, but you can manually update snapshot data transferred between source and target volumes in NetApp Workload Factory at any time.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to update.
7. Select **Update now**.
8. In the Update dialog, select **Update now**.

Pause and resume a replication relationship in NetApp Workload Factory

Pause a replication relationship to stop scheduled replication updates from the source volume to the target volume. The target volume transitions from read-only to read/write. Both volumes continue to share the latest replication snapshot as a new baseline for later resynchronization.

About this task

When paused, the replication relationship between source and target volume continues to exist. Data transfers pause and the volumes become independent. To re-enable the transfer of changes from source volume to destination volume, resume the replication.

When you resume a replication, all the changes to the target volume are undone and NetApp Workload Factory re-enables the replication. The target volume transitions from read/write to read-only, and receives updates from the source volume at the scheduled replication interval again. When you resume a replication relationship, the target volume reverts back to the latest initial replication snapshot, at which point, the volume replication process starts over.

Before you begin

If you pause when a transfer is in progress, the transfer is not affected, and the relationship becomes "Quiescing" until the transfer completes. If the current transfer aborts, it is now a future transfer and will not restart.

Pause a replication relationship

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to pause.
7. Select **Pause (Quiesce)**.
8. In the **Quiesce relationship** dialog, select **Quiesce**.

Result

The relationship pauses and its status shows as "Paused".

Resume a paused replication relationship

When you resume a replication relationship, any changes to the destination volume while the replication was stopped are deleted.



Any data written to the original source volume between the last data replication and the time that the source volume is disabled is not preserved.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to resume.

7. Select **Resume**.
8. In the Resume relationship dialog, select **Resume**.

Result

The relationship resumes and its status shows as "Replicated".

Stop a replication relationship in NetApp Workload Factory

Stop a replication relationship in NetApp Workload Factory. When you stop a replication relationship, scheduled replication updates from the source volume to the target volume pause. The target volume transitions from read-only to read/write.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to stop.
7. Select **Break**.
8. In the Break replication dialog, select **Break**.

Result

The replication status of the volume changes to **Broken**. The target volume becomes writable.

Delete a replication relationship in NetApp Workload Factory

Delete a replication relationship in NetApp Workload Factory. When you delete a replication relationship, it removes the replication relationship between the source and target volume. After the replication relationship deletes, both volumes continue to exist independently with the current data they contain.

When you delete a replication relationship, FSx for ONTAP also deletes the common replication snapshots of the source and target volume.

Steps

1. Log in using one of the [console experiences](#).
2. Select the menu and then select **Storage**.
3. From the Storage menu, select **FSx for ONTAP**.
4. From **FSx for ONTAP**, select the actions menu of the file system to update and then select **Manage**.
5. From the file system overview, select the **Replication relationships** tab.
6. In the Replication relationships tab, select the actions menu of the replication relationship to delete.

7. Select **Delete**.
8. In the Delete relationship dialog, select **Delete**.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—with prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.