



View risks that can be automatically mitigated using Unified Manager or Ansible Playbook

Active IQ Digital Advisor

netapp-manishc, Farheen Viquas
January 15, 2021

Table of Contents

View risks that can be automatically mitigated using Unified Manager or Ansible Playbook 1



View risks that can be automatically mitigated using Unified Manager or Ansible Playbook



You can analyze your storage system by viewing the actions and risks, and mitigate them using Active IQ Unified Manager or Ansible Playbook.



Steps

1. Click **View All Actions** on the dashboard.
2. Click **Actions** to view the risks associated with the actions, click **Risks** to view all the risks, or click **Affected Systems** to view the systems that require attention.

If the risk can be mitigated using Active IQ Unified Manager, the  icon is highlighted and if the risk can be mitigated using Ansible Playbook, the  icon is highlighted.

To mitigate the risk using Unified Manager	To mitigate the risk using Ansible Playbook
<ol style="list-style-type: none">1. Click the  icon.2. Click Fix It to launch Active IQ Unified Manager.3. Click Install to install Active IQ Unified Manager 9.7 or later to use the Fix It option.4. Click Upgrade to upgrade to Active IQ Unified Manager 9.7 or later to use the Fix It option.	<ol style="list-style-type: none">1. Click the  icon.2. Click Download to download the AFF and FAS firmware Ansible Automation package.



A SupportEdge Advisor or SupportEdge Expert contract is required to use the **Fix It** option and the Ansible Playbook features.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.