



availability events

ONTAP EMS reference

NetApp
May 13, 2026

Table of Contents

- availability events 1
- availability.zone events 1
- availability.zone.full 1
- availability.zone.nearlyFull 1
- availability.zone.ok 2
- availability.zone.overalloc 2

availability events

availability.zone events

availability.zone.full

Severity

ALERT

Description

This message occurs when the storage availability zone space usage has exceeded the full threshold value. If physical space usage surpasses 100%, the storage availability zone will be overallocated.

Corrective Action

Create space by increasing the storage availability zone size, by deleting data or by deleting Snapshot copies.

Syslog Message

Physical space used (%s%%) by storage availability zone (%s) exceeds the full threshold (%d%%).

Parameters

percent_full (STRING): Physical used space of the storage availability zone, as a percent.

pod_uuid (STRING): UUID of the storage availability zone.

percent_threshold (INT): Threshold percentage of physical used space which triggers the storage full condition.

availability.zone.nearlyFull

Severity

ERROR

Description

This message occurs when the storage availability zone space usage has exceeded the nearly full threshold value.

Corrective Action

Create space by increasing the storage availability zone size, by deleting data or by deleting Snapshot copies.

Syslog Message

Physical space used (%s%%) by storage availability zone (%s) exceeds the nearly full threshold (%d%%).

Parameters

percent_full (STRING): Physical used space of the storage availability zone, as a percent.

pod_uuid (STRING): UUID of the storage availability zone.

percent_threshold (INT): Threshold percentage of physical used space which triggers the storage nearly full condition.

availability.zone.ok

Severity

NOTICE

Description

This message occurs when the storage availability zone space usage level is below the nearly full threshold value.

Corrective Action

(None).

Syslog Message

Physical space used (%s%%) by storage availability zone (%s) is below nearly full threshold (%d%%).

Parameters

percent_full (STRING): Physical used space of the storage availability zone, as a percent.

pod_uuid (STRING): UUID of the storage availability zone.

percent_threshold (INT): Threshold percentage of physical used space which triggers the storage nearly full condition.

availability.zone.overalloc

Severity

EMERGENCY

Description

This message occurs when the storage availability zone space usage has exceeded the storage availability zone size. Once the physical use is beyond 100%, it may cause the availability zone to be taken offline.

Corrective Action

Create space by increasing the storage availability zone size, by deleting data or by deleting Snapshot copies.

Syslog Message

Physical space used (%s%%) by the storage availability zone (%s) exceeds maximum space in the storage availability zone.

Parameters

percent_full (STRING): Physical used space of the storage availability zone, as a percent.

pod_uuid (STRING): UUID of the storage availability zone.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.