



An access control LUN is presented to ONTAP

ONTAP FlexArray

netapp-chikkusu
July 28, 2021

Table of Contents

- An access control LUN is presented to ONTAP 1
- Storage errors show message 1
- Explanation 1
- Troubleshooting and problem resolution 1

An access control LUN is presented to ONTAP

ONTAP does not support access control array LUNs. The `storage errors show` output alerts you if an access control LUN is being presented.

Storage errors show message

```
NAME (UID): This array LUN is an access control LUN. It is not supported
and should be masked off or disabled.
```

Explanation

ONTAP supports only storage array LUNs. When an array LUN, for example, an E-Series access control LUN is presented to ONTAP, the `storage array config show` output looks normal; it shows the access control LUN in a LUN group, as the following example shows. The warning message at the bottom of the screen indicates the problem. You need to run `storage errors show` to find out that the problem is that an access control LUN was presented and which LUN it is.

```
mssystem1::> storage array config show
```

Node	LUN Group	LUN Count	Array Name	Array Target Port	Initiator
mssystem1	0	1	NETAPP_INF_1	20:1A:00:a0:b8:0f:ee:04 20:2A:00:a0:b8:0f:ee:04	0a 0c

```
Warning: Configuration errors were detected. Use 'storage errors show'
for detailed information.
```

Troubleshooting and problem resolution

1. On the storage array, mask off the access control LUN.
2. In ONTAP, run `storage errors show` again to confirm that the access control LUN is no longer being presented to ONTAP.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.