



Booting to ONTAP on replacement controller modules in MetroCluster IP configurations

ONTAP MetroCluster

Thom Illingworth, Paula Carrigan
June 24, 2021

Table of Contents

Booting to ONTAP on replacement controller modules in MetroCluster IP configurations. 1

Booting to ONTAP on replacement controller modules in MetroCluster IP configurations

You must boot the replacement nodes at the disaster site to the ONTAP operating system.

About this task

This task begins with the nodes at the disaster site in Maintenance mode.

Steps

1. On one of the replacement nodes, exit to the LOADER prompt: `halt`
2. Display the boot menu: `boot_ontap menu`
3. From the boot menu, select option 6, **Update flash from backup config**.

The system boots twice. You should respond `yes` when prompted to continue. After the second boot, you should respond `y` when prompted about the system ID mismatch.



If you did not clear the NVRAM contents of a used replacement controller module, then you might see the following panic message: `PANIC: NVRAM contents are invalid...` If this occurs, boot the system to the ONTAP prompt again (`boot_ontap menu`). You then need to perform a root recovery. Contact technical support for assistance.

- Confirmation to continue prompt:

```
Selection (1-9)? 6
```

```
This will replace all flash-based configuration with the last backup  
to  
disks. Are you sure you want to continue?: yes
```

- System ID mismatch prompt:

```
WARNING: System ID mismatch. This usually occurs when replacing a  
boot device or NVRAM cards!  
Override system ID? {y|n} y
```

4. From the surviving site, verify that the correct partner system IDs have been applied to the nodes:

```
metrocluster node show -fields node-systemid,ha-partner-systemid,dr-partner-  
systemid,dr-auxiliary-systemid
```

In this example, the following new system IDs should appear in the output:

- `Node_A_1: 1574774970`
- `Node_A_2: 1574774991`

The "ha-partner-systemid" column should show the new system IDs.

```
metrocluster node show -fields node-systemid,ha-partner-systemid,dr-
partner-systemid,dr-auxiliary-systemid

dr-group-id cluster      node      node-systemid ha-partner-systemid dr-
partner-systemid dr-auxiliary-systemid
-----
-----
1              Cluster_A  Node_A_1  1574774970    1574774991
4068741254          4068741256
1              Cluster_A  Node_A_2  1574774991    1574774970
4068741256          4068741254
1              Cluster_B  Node_B_1  -              -
-
1              Cluster_B  Node_B_2  -              -
-
4 entries were displayed.
```

- 5. If the partner system IDs were not correctly set, you must manually set the correct value:
 - a. Halt and display the LOADER prompt on the node.
 - b. Verify the partner-sysID bootarg's current value:

```
printenv
```

- c. Set the value to the correct partner system ID:

```
setenv partner-sysid partner-sysID
```

- d. Boot the node:

```
boot_ontap
```

- e. Repeat these substeps on the other node, if necessary.

- 6. Confirm that the replacement nodes at the disaster site are ready for switchback:

```
metrocluster node show
```

The replacement nodes should be in waiting for switchback recovery mode. If they are in normal mode instead, you can reboot the replacement nodes. After that boot, the nodes should be in waiting for switchback recovery mode.

The following example shows that the replacement nodes are ready for switchback:

```

cluster_B::> metrocluster node show
DR
Group Cluster Node          Configuration  DR
State          Mirroring Mode
-----
1      cluster_B
      node_B_1      configured   enabled   switchover
completed
      node_B_2      configured   enabled   switchover
completed
      cluster_A
      node_A_1      configured   enabled   waiting for
switchback recovery
      node_A_2      configured   enabled   waiting for
switchback recovery
4 entries were displayed.

cluster_B::>

```

7. Verify the MetroCluster connection configuration settings:

```
metrocluster configuration-settings connection show
```

The configuration state should indicate completed.

```

cluster_B::*> metrocluster configuration-settings connection show
DR
Group Cluster Node          Source          Destination
Config State  Network Address Network Address Partner Type
-----
1      cluster_B
      node_B_2
      Home Port: e5a
      172.17.26.13  172.17.26.12  HA Partner
completed
      Home Port: e5a
      172.17.26.13  172.17.26.10  DR Partner
completed
      Home Port: e5a
      172.17.26.13  172.17.26.11  DR Auxiliary
completed
      Home Port: e5b
      172.17.27.13  172.17.27.12  HA Partner
completed

```

```

        Home Port: e5b
        172.17.27.13      172.17.27.10      DR Partner
completed

        Home Port: e5b
        172.17.27.13      172.17.27.11      DR Auxiliary
completed

node_B_1
    Home Port: e5a
    172.17.26.12      172.17.26.13      HA Partner
completed

    Home Port: e5a
    172.17.26.12      172.17.26.11      DR Partner
completed

    Home Port: e5a
    172.17.26.12      172.17.26.10      DR Auxiliary
completed

    Home Port: e5b
    172.17.27.12      172.17.27.13      HA Partner
completed

    Home Port: e5b
    172.17.27.12      172.17.27.11      DR Partner
completed

    Home Port: e5b
    172.17.27.12      172.17.27.10      DR Auxiliary
completed
cluster_A
    node_A_2
        Home Port: e5a
        172.17.26.11      172.17.26.10      HA Partner
completed

        Home Port: e5a
        172.17.26.11      172.17.26.12      DR Partner
completed

        Home Port: e5a
        172.17.26.11      172.17.26.13      DR Auxiliary
completed

        Home Port: e5b
        172.17.27.11      172.17.27.10      HA Partner
completed

        Home Port: e5b
        172.17.27.11      172.17.27.12      DR Partner
completed

        Home Port: e5b
        172.17.27.11      172.17.27.13      DR Auxiliary
completed
node_A_1

```

```
Home Port: e5a
172.17.26.10 172.17.26.11 HA Partner
completed
Home Port: e5a
172.17.26.10 172.17.26.13 DR Partner
completed
Home Port: e5a
172.17.26.10 172.17.26.12 DR Auxiliary
completed
Home Port: e5b
172.17.27.10 172.17.27.11 HA Partner
completed
Home Port: e5b
172.17.27.10 172.17.27.13 DR Partner
completed
Home Port: e5b
172.17.27.10 172.17.27.12 DR Auxiliary
completed
24 entries were displayed.

cluster_B::*>
```

8. Repeat the previous steps on the other node at the disaster site.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.