



Manage Vscan scanner-pool configuration

ONTAP 9.10.1 REST API Documentation

NetApp
April 02, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9101/ontap/protocols_vscan_svm.uuid_scanner-pools_endpoint_overview.html on April 02, 2024. Always check docs.netapp.com for the latest.

Table of Contents

- Manage Vscan scanner-pool configuration 1
 - Protocols Vscan svm.uuid scanner-pools endpoint overview 1
 - Retrieve a Vscan scanner-pool configuration for an SVM 7
 - Create a Vscan scanner-pool configuration for an SVM 14
 - Delete a Vscan scanner-pool configuration 24
 - Retrieve the Vscan scanner-pool configuration for an SVM 26
 - Update the Vscan scanner-pool configuration for an SVM 32

Manage Vscan scanner-pool configuration

Protocols Vscan svm.uuid scanner-pools endpoint overview

Overview

A scanner-pool defines the Vscan servers and privileged users that can connect to SVMs and a scanner policy or role determines whether a scanner-pool is active. You can configure a scanner-pool to be used on the local cluster or any other cluster in an MCC/DR setup.

Examples

Retrieving all fields for all scanner-pools of an SVM

```
# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/vscan/<svm-uuid>/scanner-
pools?fields=*&return_records=true&return_timeout=15" -H "accept:
application/json"

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "0e2f7c91-f227-11e8-9601-0050568ecc06"
      },
      "name": "scanner-1",
      "servers": [
        "1.1.1.1",
        "10.72.204.27"
      ],
      "privileged_users": [
        "cifs\\u1",
        "cifs\\u2"
      ],
      "role": "primary"
    },
    {
      "svm": {
        "uuid": "0e2f7c91-f227-11e8-9601-0050568ecc06"
      },
      "name": "scanner-2",
      "servers": [
        "1.1.1.1",
        "10.72.204.27"
      ],
      "privileged_users": [
        "cifs\\u1",
        "cifs\\u2"
      ],
      "role": "secondary"
    }
  ],
  "num_records": 2
}
```

Retrieving all scanner-pools with *role* set as *secondary*

```
# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/vscan/<svm-uuid>/scanner-
pools?role=secondary&fields=*&return_records=true&return_timeout=15" -H
"accept: application/json"

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "0e2f7c91-f227-11e8-9601-0050568ecc06",
        "name": "vs1"
      },
      "name": "scanner-2",
      "servers": [
        "1.1.1.1",
        "10.72.204.27"
      ],
      "privileged_users": [
        "cifs\\u1",
        "cifs\\u2"
      ],
      "role": "secondary",
      "cluster": {
        "uuid": "0933f9b5-f226-11e8-9601-0050568ecc06",
        "name": "Cluster3"
      }
    }
  ],
  "num_records": 1
}
```

Retrieving the specified scanner-pool associated with an SVM

```
# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/vscan/0e2f7c91-f227-11e8-9601-0050568ecc06/scanner-pools/scanner-1?fields=*" -H "accept: application/json"

# The response:
{
  "svm": {
    "uuid": "0e2f7c91-f227-11e8-9601-0050568ecc06",
    "name": "vs1"
  },
  "name": "scanner-1",
  "servers": [
    "1.1.1.1",
    "10.72.204.27"
  ],
  "privileged_users": [
    "cifs\\u1",
    "cifs\\u2"
  ],
  "role": "primary",
  "cluster": {
    "uuid": "0933f9b5-f226-11e8-9601-0050568ecc06",
    "name": "Cluster3"
  }
}
```

Creating a scanner-pool for an SVM with all fields specified

```

# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/

# The call:
curl -X POST "https://<mgmt-ip>/api/protocols/vscan/b103be27-17b8-11e9-
b451-0050568ecd85/scanner-pools?return_records=true" -H "accept:
application/json" -H "Content-Type: application/json" -d "{ \"cluster\": {
\"name\": \"Cluster1\", \"uuid\": \"ab746d77-17b7-11e9-b450-0050568ecd85\"
}, \"name\": \"test-scanner\", \"privileged_users\": [ \"cifs\\\\u1\",
\"cifs\\\\u2\" ], \"role\": \"primary\", \"servers\": [ \"1.1.1.1\",
\"10.72.204.27\" ]}"

# The response:
{
  "num_records": 1,
  "records": [
    {
      "name": "test-scanner",
      "servers": [
        "1.1.1.1",
        "10.72.204.27"
      ],
      "privileged_users": [
        "cifs\\u1",
        "cifs\\u2"
      ],
      "role": "primary",
      "cluster": {
        "uuid": "ab746d77-17b7-11e9-b450-0050568ecd85",
        "name": "Cluster1"
      }
    }
  ]
}

```

Creating a scanner-pool for an SVM with an unspecified role and cluster

```

# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/

# The call:
curl -X POST "https://<mgmt-ip>/api/protocols/vscan/b103be27-17b8-11e9-
b451-0050568ecd85/scanner-pools" -H "accept: application/json" -H
"Content-Type: application/json" -d "{ \"name\": \"test-scanner-1\",
\"privileged_users\": [ \"cifs\\\\u1\", \"cifs\\\\u2\" ], \"servers\": [
\"1.1.1.1\", \"10.72.204.27\" ]}"

# The response:
{
  "num_records": 1,
  "records": [
    {
      "name": "test-scanner-1",
      "servers": [
        "1.1.1.1",
        "10.72.204.27"
      ],
      "privileged_users": [
        "cifs\\u1",
        "cifs\\u2"
      ]
    }
  ]
}

```

Updating a scanner-pool for an SVM with all of the fields specified

```

# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/{name}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/protocols/vscan/0e2f7c91-f227-11e8-
9601-0050568ecc06/scanner-pools/test-scanner-1" -H "accept:
application/json" -H "Content-Type: application/json" -d "{ \"cluster\": {
\"name\": \"Cluster3\", \"uuid\": \"0933f9b5-f226-11e8-9601-0050568ecc06\"
}, \"privileged_users\": [ \"cifs\\\\u1\", \"cifs\\\\u2\" ], \"role\":
\"secondary\", \"servers\": [ \"1.1.1.1\", \"10.72.204.27\" ]}"

```

Updating the "role" of a scanner-pool for an SVM


```
# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/{name}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/protocols/vscan/0e2f7c91-f227-11e8-9601-0050568ecc06/scanner-pools/test-scanner-1" -H "accept: application/json" -H "Content-Type: application/json" -d "{ \"cluster\": { \"name\": \"Cluster3\", \"uuid\": \"0933f9b5-f226-11e8-9601-0050568ecc06\" }, \"role\": \"primary\"}"
```

Deleting a scanner-pool for a specified SVM

```
# The API:
/api/protocols/vscan/{svm.uuid}/scanner-pools/{name}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/protocols/vscan/0e2f7c91-f227-11e8-9601-0050568ecc06/scanner-pools/test-scanner-1" -H "accept: application/json"
```

Retrieve a Vscan scanner-pool configuration for an SVM

GET /protocols/vscan/{svm.uuid}/scanner-pools

Introduced In: 9.6

Retrieves the Vscan scanner-pool configuration of an SVM.

Related ONTAP commands

- `vserver vscan scanner-pool show`
- `vserver vscan scanner-pool privileged-users show`
- `vserver vscan scanner-pool servers show`

Learn more

- [DOC /protocols/vscan/{svm.uuid}/scanner-pools](#)

Parameters

| Name | Type | In | Required | Description |
|------|--------|-------|----------|----------------|
| name | string | query | False | Filter by name |

| Name | Type | In | Required | Description |
|------------------|---------------|-------|----------|---|
| svm.name | string | query | False | Filter by svm.name • Introduced in: 9.10 |
| role | string | query | False | Filter by role |
| servers | string | query | False | Filter by servers |
| privileged_users | string | query | False | Filter by privileged_users |
| cluster.name | string | query | False | Filter by cluster.name |
| cluster.uuid | string | query | False | Filter by cluster.uuid |
| svm.uuid | string | path | True | UUID of the SVM to which this object belongs. |
| fields | array[string] | query | False | Specify the fields to return. |
| max_records | integer | query | False | Limit the number of records returned. |
| return_records | boolean | query | False | The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1 |

| Name | Type | In | Required | Description |
|----------------|---------------|-------|----------|--|
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> • Default value: 1 • Max value: 120 • Min value: 0 |
| order_by | array[string] | query | False | Order results by specified fields and optional [asc |

Response

Status: 200, Ok

| Name | Type | Description |
|-------------|---|-------------------|
| _links | _links | |
| num_records | integer | Number of records |
| records | array[vscan_scanner_pool] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "name": "scanner-1",
    "privileged_users": [
      "cifs\\u1",
      "cifs\\u2"
    ],
    "role": "primary",
    "servers": [
      "1.1.1.1",
      "10.72.204.27",
      "vmwin204-27.fsct.nb"
    ],
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

Error

Status: Default, Error

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

cluster_reference

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

svm

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

vscan_scanner_pool

Scanner pool is a set of attributes which are used to validate and manage connections between clustered ONTAP and external virus-scanning server, or "Vscan server".

| Name | Type | Description |
|---------|-----------------------------------|-------------|
| cluster | cluster_reference | |

| Name | Type | Description |
|------------------|---------------|---|
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-", and ".". |
| privileged_users | array[string] | <p>Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remedying and quarantining operations.</p> <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |
| role | string | <p>Specifies the role of the scanner pool. The possible values are:</p> <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | <p>Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP.</p> <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Create a Vscan scanner-pool configuration for an SVM

POST /protocols/vscan/{svm.uuid}/scanner-pools

Introduced In: 9.6

Creates a Vscan scanner-pool configuration for a specified SVM. You can create a scanner-pool with all fields specified or only mandatory fields specified.

Important notes:

- A scanner-pool must have servers and privileged users specified.
- If the role or cluster is not specified, the scanner-pool is created on the local cluster with the role set as primary. *^Only one of the fields cluster-uuid or cluster-name is required.

Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the Vscan configuration.
- `name` - Scanner-pool name.
- `privileged_users` - List of privileged users.
- `servers` - List of server IP addresses or FQDNs.

Recommended optional properties

- `role` - Setting a role for a scanner-pool is recommended.

- `cluster` - Passing the cluster name or UUID (or both) in a multi-cluster environment is recommended.

Default property values

If not specified in POST, the following default property values are assigned:

- `role` - *primary*
- `cluster.name` - Local cluster name.
- `cluster.uuid` - Local cluster UUID.

Related ONTAP commands

- `vserver vscan scanner-pool create`
- `vserver vscan scanner-pool apply-policy`
- `vserver vscan scanner-pool privileged-users add`
- `vserver vscan scanner-pool servers add`

Learn more

- [DOC /protocols/vscan/{svm.uuid}/scanner-pools](#)

Parameters

| Name | Type | In | Required | Description |
|-----------------------------|---------|-------|----------|--|
| <code>return_records</code> | boolean | query | False | The default is false. If set to true, the records are returned. <ul style="list-style-type: none"> • Default value: |
| <code>svm.uuid</code> | string | path | True | UUID of the SVM to which this object belongs. |

Request Body

| Name | Type | Description |
|----------------------|-----------------------------------|-------------|
| <code>cluster</code> | cluster_reference | |

| Name | Type | Description |
|------------------|---------------|--|
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-" and ".". |
| privileged_users | array[string] | Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remedying and quarantining operations. <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |
| role | string | Specifies the role of the scanner pool. The possible values are: <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP. <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

Example request

```
{
  "cluster": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "cluster1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "scanner-1",
  "privileged_users": [
    "cifs\\u1",
    "cifs\\u2"
  ],
  "role": "primary",
  "servers": [
    "1.1.1.1",
    "10.72.204.27",
    "vmwin204-27.fsct.nb"
  ],
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Response

Status: 201, Created

| Name | Type | Description |
|-------------|------------------------|-------------------|
| _links | _links | |
| num_records | integer | Number of records |

| Name | Type | Description |
|---------|---|-------------|
| records | array[vscan_scanner_pool] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "name": "scanner-1",
    "privileged_users": [
      "cifs\\u1",
      "cifs\\u2"
    ],
    "role": "primary",
    "servers": [
      "1.1.1.1",
      "10.72.204.27",
      "vmwin204-27.fsct.nb"
    ],
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|--|
| 10027086 | The specified list of servers contain one or more entries that cannot be resolved |
| 10027258 | The specified cluster_name does not exist |
| 10027256 | The specified cluster_uuid does not exist |
| 10027257 | The specified cluster_name and cluster_uuid are valid but belong to different clusters |
| 10027248 | Scanner-pool created successfully but failed to activate |
| 10027107 | The list of privileged users or list of servers specified is empty |
| 10027108 | The list of privileged users specified contains an invalid entry |
| 10027063 | Attempting to modify a scanner-pool on an administrative SVM with a data SVM |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

cluster_reference

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

svm

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

vscan_scanner_pool

Scanner pool is a set of attributes which are used to validate and manage connections between clustered ONTAP and external virus-scanning server, or "Vscan server".

| Name | Type | Description |
|---------|-----------------------------------|---|
| cluster | cluster_reference | |
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-" and ".". |

| Name | Type | Description |
|------------------|---------------------|---|
| privileged_users | array[string] | <p>Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remedying and quarantining operations.</p> <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |
| role | string | <p>Specifies the role of the scanner pool. The possible values are:</p> <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | <p>Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP.</p> <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Delete a Vscan scanner-pool configuration

```
DELETE /protocols/vscan/{svm.uuid}/scanner-pools/{name}
```

Introduced In: 9.6

Deletes a Vscan scanner-pool configuration.

Important notes:

- The Vscan scanner-pool DELETE endpoint deletes all of the Vscan scanner-pools for a specified SVM.
- If a Vscan is enabled, it requires at least one scanner-pool to be in the active state. Therefore, disable Vscan on the specified SVM so all the scanner-pools configured on that SVM can be deleted.

Related ONTAP commands

- `vserver vscan scanner-pool delete`

Learn more

- [DOC /protocols/vscan/{svm.uuid}/scanner-pools](#)

Parameters

| Name | Type | In | Required | Description |
|------|--------|------|----------|-------------|
| name | string | path | True | |

| Name | Type | In | Required | Description |
|----------|--------|------|----------|---|
| svm.uuid | string | path | True | UUID of the SVM to which this object belongs. |

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 10027070 | Attempting to delete a scanner-pool but it is the only active scanner-pool for a Vscan enabled on the SVM |
| 10027064 | Attempting to delete a scanner-pool with a data SVM which was created with an administrative SVM |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Retrieve the Vscan scanner-pool configuration for an SVM

```
GET /protocols/vscan/{svm.uuid}/scanner-pools/{name}
```

Introduced In: 9.6

Retrieves the configuration of a specified scanner-pool of an SVM.

Related ONTAP commands

- `vserver vscan scanner-pool show`
- `vserver vscan scanner-pool privileged-users show`
- `vserver vscan scanner-pool servers show`

Learn more

- [DOC /protocols/vscan/{svm.uuid}/scanner-pools](#)

Parameters

| Name | Type | In | Required | Description |
|----------|---------------|-------|----------|---|
| name | string | path | True | |
| svm.uuid | string | path | True | UUID of the SVM to which this object belongs. |
| fields | array[string] | query | False | Specify the fields to return. |

Response

Status: 200, Ok

| Name | Type | Description |
|------------------|-----------------------------------|---|
| cluster | cluster_reference | |
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-" and ".". |
| privileged_users | array[string] | <p>Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remediating and quarantining operations.</p> <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |

| Name | Type | Description |
|---------|---------------|--|
| role | string | <p>Specifies the role of the scanner pool. The possible values are:</p> <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | <p>Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP.</p> <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

Example response

```
{
  "cluster": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "cluster1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "scanner-1",
  "privileged_users": [
    "cifs\\u1",
    "cifs\\u2"
  ],
  "role": "primary",
  "servers": [
    "1.1.1.1",
    "10.72.204.27",
    "vmwin204-27.fsct.nb"
  ],
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Error

Status: Default, Error

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

cluster_reference

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

svm

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|-------------------|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |

| Name | Type | Description |
|--------|--------|---|
| target | string | The target parameter that caused the error. |

Update the Vscan scanner-pool configuration for an SVM

PATCH /protocols/vscan/{svm.uuid}/scanner-pools/{name}

Introduced In: 9.6

Updates the Vscan scanner-pool configuration of an SVM.

Important notes:

- Along with servers and privileged-users, the role of a scanner-pool can also be updated with the cluster on which a scanner-pool is allowed.
- If role is specified and cluster isn't, then role is applied to the local cluster.

Related ONTAP commands

- `vserver vscan scanner-pool modify`
- `vserver vscan scanner-pool apply-policy`
- `vserver vscan scanner-pool privileged-users add`
- `vserver vscan scanner-pool privileged-users remove`
- `vserver vscan scanner-pool servers remove`
- `vserver vscan scanner-pool servers add`

Learn more

- [DOC /protocols/vscan/{svm.uuid}/scanner-pools](#)

Parameters

| Name | Type | In | Required | Description |
|----------|--------|------|----------|---|
| name | string | path | True | |
| svm.uuid | string | path | True | UUID of the SVM to which this object belongs. |

Request Body

| Name | Type | Description |
|------------------|-----------------------------------|---|
| cluster | cluster_reference | |
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-" and ".". |
| privileged_users | array[string] | <p>Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remedying and quarantining operations.</p> <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |
| role | string | <p>Specifies the role of the scanner pool. The possible values are:</p> <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | <p>Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP.</p> <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

Example request

```
{
  "cluster": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "cluster1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "scanner-1",
  "privileged_users": [
    "cifs\\u1",
    "cifs\\u2"
  ],
  "role": "primary",
  "servers": [
    "1.1.1.1",
    "10.72.204.27",
    "vmwin204-27.fsct.nb"
  ],
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|--|
| 10027258 | The specified cluster_name does not exist |
| 10027256 | The specified cluster_uuid does not exist |
| 10027257 | The specified cluster_name and cluster_uuid are valid but belong to different clusters |
| 10027248 | Scanner-pool updated successfully but failed to apply the specified role |
| 10027107 | The list of privileged users or list of servers specified is empty |
| 10027108 | The list of privileged users specified contains an invalid entry |
| 10027063 | Attempting to modify a scanner-pool on an administrative SVM with a data SVM |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

cluster_reference

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

svm

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

vscan_scanner_pool

Scanner pool is a set of attributes which are used to validate and manage connections between clustered ONTAP and external virus-scanning server, or "Vscan server".

| Name | Type | Description |
|---------|-----------------------------------|---|
| cluster | cluster_reference | |
| name | string | Specifies the name of the scanner pool. Scanner pool name can be up to 256 characters long and is a string that can only contain any combination of ASCII-range alphanumeric characters a-z, A-Z, 0-9), "_", "-" and ".". |

| Name | Type | Description |
|------------------|---------------------|--|
| privileged_users | array[string] | Specifies a list of privileged users. A valid form of privileged user-name is "domain-name\user-name". Privileged user-names are stored and treated as case-insensitive strings. Virus scanners must use one of the registered privileged users for connecting to clustered Data ONTAP for exchanging virus-scanning protocol messages and to access file for scanning, remedying and quarantining operations. <ul style="list-style-type: none"> • example: ["cifs\u1", "cifs\u2"] • Introduced in: 9.6 |
| role | string | Specifies the role of the scanner pool. The possible values are: <ul style="list-style-type: none"> • primary - Always active. • secondary - Active only when none of the primary external virus-scanning servers are connected. • idle - Always inactive. |
| servers | array[string] | Specifies a list of IP addresses or FQDN for each Vscan server host names which are allowed to connect to clustered ONTAP. <ul style="list-style-type: none"> • example: ["1.1.1.1", "10.72.204.27", "vmwin204-27.fsct.nb"] • Introduced in: 9.6 |
| svm | svm | |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.