



## Storage

### ONTAP 9.11.1 REST API reference

NetApp  
April 02, 2024

# Table of Contents

- Storage ..... 1
  - Storage overview ..... 1
  - Retrieve or create a collection of storage aggregates ..... 1
  - Retrieve a collection of cloud stores used by an aggregate ..... 101
  - Attach an object store to an aggregate or add a second object store as a mirror ..... 108
  - Remove a cloud target from an aggregate ..... 116
  - Retrieve the cloud store for an aggregate ..... 119
  - Update a cloud store ..... 124
  - Manage storage aggregate plexes ..... 131
  - Manage storage aggregates ..... 151
  - Storage aggregate metrics ..... 247
  - Manage storage bridges ..... 261
  - Manage disks ..... 300
  - Manage storage file clones ..... 359
  - Manage storage file moves ..... 429
  - Manage FlexCache volumes ..... 479
  - Manage storage FlexCache origin volumes ..... 532
  - Manage storage pools ..... 561
  - Manage specific storage pools ..... 590
  - Manage storage ports ..... 627
  - Manage QoS policies ..... 654
  - Manage QoS workloads ..... 691
  - Manage storage qtrees ..... 703
  - Storage quota ..... 769
    - Manage storage quota reports ..... 770
    - Manage storage quota policy rules ..... 812
  - Manage shelves ..... 878
  - Manage Snapshot copy policies ..... 948
  - Manage Snapshot copy policies and schedules ..... 980
  - Manage storage switches ..... 1006
  - Manage storage tape devices ..... 1035
  - Manage volume efficiency policies ..... 1068

# Storage

## Storage overview

### Overview

The ONTAP storage APIs can be used to manage physical and logical storage. This includes management of aggregates, volumes, LUNs, qtrees, snapshots, quotas, and storage efficiency.

## Retrieve or create a collection of storage aggregates

### Storage aggregates endpoint overview

#### Retrieving storage aggregate information

The Storage Aggregate GET API retrieves all data aggregates in the cluster. System owned root aggregates are not included in the output. This API also supports specific queries, in addition to queries on aggregate body properties, which affect the output of the API. The parameters for these queries are "recommend" and "show\_spare". Using the "recommend" query returns the list of aggregates that are recommended for creation in the cluster. The "show\_spare" query returns a response outside of the records body, which includes the groups of usable spares in the cluster. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices.

The collection GET returns the aggregate identifiers, UUID and name, and the node on which the aggregate resides. The instance GET, by default, returns all of the properties defined in the aggregates object, except advanced properties. The properties "space.footprint", "is\_spare\_low", "space.block\_storage.inactive\_user\_data", "space.block\_storage.inactive\_user\_data\_percent", "inode\_attributes.version", "inode\_attributes.files\_private\_used", "inode\_attributes.file\_private\_capacity" and "inode\_attributes.file\_public\_capacity" are considered advanced properties and only returned when requested using the "fields" query parameter. Performance "metric" and "statistics" for aggregates are also only returned when requested. The "statistics" property accounts for the cumulative raw values collected by ONTAP for an aggregate, while the "metric" property displays the incremental average for latency and incremental changes in IOPs and throughput over the last 15 seconds. Any external application can use the raw statistics to derive its own incremental performance metrics. The collection GET does not support queries in conjunction with the "order\_by" parameter.

#### Creating storage aggregates

When the POST command is issued with no properties, the system evaluates the cluster attached storage, determines the optimal aggregate layout and configures the aggregates. This layout is completely controlled by the system. To view the recommended optimal layout rather than creating it, use the GET endpoint, setting the "recommend" query to 'true'. This response will also include any warnings related to any inefficiencies in the storage configuration. Recommended aggregate creation is not supported on ONTAP Cloud and MetroCluster with Fibre Channel (FC). Alternatively, POST can be used with specific properties to create an aggregate as requested. At a minimum, the aggregate name, disk count, and the node where it should reside are required if any properties are provided.

When using POST with input properties, three properties are required. These are:

- name
- node.name or node.uuid

- `block_storage.primary.disk_count`

### Remaining properties are optional

The following properties can be specified in POST:

- `name` - Name of the aggregate.
- `node.name` and `node.uuid` - Node on which the aggregate will be created.
- `block_storage.primary.disk_count` - Number of disks to be used to create the aggregate.
- `block_storage.mirror.enabled` - Specifies whether or not the aggregate should be created using SyncMirror.
- `block_storage.primary.checksum_style` - Checksum style of the disks to be use for the aggregate.
- `block_storage.primary.disk_class` - Class of disks to be use to for the aggregate.
- `block_storage.primary.raid_size` - Desired RAID size of the aggregate.
- `block_storage.primary.raid_type` - Desired RAID type of the aggregate.
- `snaplock_type` - SnapLock type to use on the aggregate.
- `data_encryption.software_encryption_enabled` - Enable or disable NAE (NetApp Aggregate Encryption) on the aggregate.
- `simulate` - Simulate the creation of the aggregate with specified input parameters. If the `simulate` field is specified, the response includes information on the proposed aggregate disk layout, any associated warnings, along with the proposed final size of the aggregate.

---

## Examples

### Retrieving a list of aggregates from the cluster

The following example shows the response with a list of data aggregates in the cluster:

```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates" -H "accept:
application/json"

# The response:
{
  "records": [
    {
      "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
      "name": "test1",
      "node": {
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
        "name": "node-1",
      },
    },
    {
      "uuid": "4a7e4139-ca7a-420b-9a11-3f040d2189fd",
      "name": "test4",
      "node": {
        "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
        "name": "node-2",
      },
    }
  ],
  "num_records": 2,
}

```

### Retrieving a list of aggregates recommended for creation from the cluster

The following example shows the response with a list of recommended data aggregates in the cluster.



Each aggregate UUID provided in this response is not guaranteed to be the same UUID for the aggregate if it is created.

```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-
ip>/api/storage/aggregates?recommend=true&fields=*" -H "accept:
application/json"

```

```

# The response:
{
  "records": [
    {
      "uuid": "795bf7c2-fa4b-11e8-ba65-005056bbe5c1",
      "name": "node_2_SSD_1",
      "node": {
        "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
        "name": "node-2",
      },
      "space": {
        "block_storage": {
          "size": 1116180480
        }
      },
      "block_storage": {
        "primary": {
          "disk_count": 22,
          "disk_class": "solid_state",
          "raid_type": "raid_dp",
          "disk_type": "ssd",
          "raid_size": 24,
          "simulated_raid_groups": [
            {
              "name": "node_2_SSD_1/plex0/rg0",
              "raid_type": "raid_dp",
              "parity_disk_count": 2,
              "data_disk_count": 9,
              "usable_size": 12309487,
              "is_partition": true
            },
            {
              "name": "node_2_SSD_1/plex1/rg0",
              "raid_type": "raid_dp",
              "parity_disk_count": 2,
              "data_disk_count": 9,
              "usable_size": 12309487,
              "is_partition": false
            }
          ]
        },
        "hybrid_cache": {
          "enabled": true,
          "storage_pools": [
            {
              "allocation_units_count": 1,

```

```

        "storage_pool": {
            "name": "sp1",
            "uuid": "1511d084-7290-11ec-ae5b-005056bb2afa",
            "_links": {
                "self": {
                    "href": "/api/storage/pools/1511d084-7290-
11ec-ae5b-005056bb2afa"
                }
            }
        },
        {
            "allocation_units_count": 1,
            "storage_pool": {
                "name": "sp2",
                "uuid": "342d234f-7291-11ec-ae5b-005056bb2afa",
                "_links": {
                    "self": {
                        "href": "/api/storage/pools/342d234f-7291-
11ec-ae5b-005056bb2afa"
                    }
                }
            }
        }
    ]
},
"mirror": {
    "enabled": true
}
},
{
    "uuid": "795c0a15-fa4b-11e8-ba65-005056bbe5c1",
    "name": "node_1_SSD_1",
    "node": {
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
        "name": "node-1",
    },
    "space": {
        "block_storage": {
            "size": 352477184
        }
    },
    "block_storage": {
        "primary": {
            "disk_count": 22,

```

```

    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "disk_type": "ssd",
    "raid_size": 24,
    "simulated_raid_groups": [
      {
        "name": "node_1_SSD_1/plex0/rg0",
        "raid_type": "raid_dp",
        "parity_disk_count": 2,
        "data_disk_count": 9,
        "usable_size": 12309487,
        "is_partition": true
      },
      {
        "name": "node_1_SSD_1/plex1/rg0",
        "raid_type": "raid_dp",
        "parity_disk_count": 2,
        "data_disk_count": 9,
        "usable_size": 12309487,
        "is_partition": false
      }
    ]
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {
    "enabled": true
  }
},
}
],
"recommendation_spares" [
  {
    "node": {
      "uuid": "795bf7c2-fa4b-11e8-ba65-005056bbe5c1",
      "name": "node-2",
      "_links": {
        "self" {
          "href": "/api/cluster/nodes/795bf7c2-fa4b-11e8-ba65-005056bbe5c1"
        }
      }
    }
  },
  "disk_class": "solid-state",
  "size": "2856845312",

```



```

    "is_partition": true,
    "disk_type": "ssd",
    "syncmirror_pool": "pool10",
    "usable": 1
  }
],
"num_records": 2,
"warnings": [
  {
    "name": "node_1_SSD_1",
    "warning": {
      "code": 19726347,
      "message": "Unable to use all attached capacity on node \"node_1\".
3 local/remote pool disks not usable for mirroring.",
      "arguments": [
        "node_1",
        "3"
      ]
    },
    "action": {
      "code": 19726348,
      "message": "Contact technical support."
    }
  },
  {
    "name": "node_2_SSD_1",
    "warning": {
      "code": 19726347,
      "message": "Unable to use all attached capacity on node \"node_2\".
3 local/remote pool disks not usable for mirroring.",
      "arguments": [
        "node_2",
        "3"
      ]
    },
    "action": {
      "code": 19726348,
      "message": "Contact technical support."
    }
  }
],
"_links": {
  "self": {
    "href": "/api/storage/aggregates?recommend=true&fields=*"
  }
}
}

```

```
}
```

### Retrieving the usable spare information for the cluster

The following example shows the response from retrieving usable spare information according to ONTAP best practices.

```
# The API:
/api/storage/aggregates?show_spares=true

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates?show_spares=true" -H
"accept: application/json"

# The response:
{
  "records": [],
  "num_records": 0,
  "spares": [
    {
      "node": {
        "uuid": "0cdd84fa-b99c-11eb-b0ed-005056bb4fc2",
        "name": "node-2",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0cdd84fa-b99c-11eb-b0ed-
005056bb4fc2"
          }
        }
      },
      "disk_class": "solid_state",
      "disk_type": "ssd",
      "size": 3720609792,
      "checksum_style": "block",
      "syncmirror_pool": "pool0",
      "is_partitioned": true,
      "usable": 12,
      "layout_requirements": [
        {
          "raid_type": "raid_dp",
          "default": true,
          "aggregate_min_disks": 3,
          "raid_group": {
            "min": 3,
            "max": 28,
            "default": 24
          }
        }
      ]
    }
  ]
}
```

```

    }
  },
  {
    "raid_type": "raid4",
    "default": false,
    "aggregate_min_disks": 2,
    "raid_group": {
      "min": 2,
      "max": 14,
      "default": 8
    }
  },
  {
    "raid_type": "raid_tec",
    "default": false,
    "aggregate_min_disks": 7,
    "raid_group": {
      "min": 4,
      "max": 29,
      "default": 25
    }
  }
]
},
{
  "node": {
    "uuid": "0cdd84fa-b99c-11eb-b0ed-005056bb4fc2",
    "name": "node-2",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0cdd84fa-b99c-11eb-b0ed-005056bb4fc2"
      }
    }
  },
  "disk_class": "solid_state",
  "disk_type": "ssd_nvme",
  "size": 8583380992,
  "checksum_style": "block",
  "syncmirror_pool": "pool0",
  "is_partitioned": false,
  "usable": 5,
  "layout_requirements": [
    {
      "raid_type": "raid_dp",
      "default": true,

```

```

    "aggregate_min_disks": 3,
    "raid_group": {
      "min": 3,
      "max": 28,
      "default": 24
    }
  },
  {
    "raid_type": "raid4",
    "default": false,
    "aggregate_min_disks": 2,
    "raid_group": {
      "min": 2,
      "max": 14,
      "default": 8
    }
  },
  {
    "raid_type": "raid_tec",
    "default": false,
    "aggregate_min_disks": 7,
    "raid_group": {
      "min": 4,
      "max": 29,
      "default": 25
    }
  }
]
}
],
"_link": {
  "self": {
    "href": "/api/storage/aggregates?show_spare=true"
  }
}
}

```

### Retrieving the total spare count information for the cluster

The following example shows the response from retrieving total spare count information, under advanced privilege.

```

# The API:
/api/storage/aggregates?show_spare=true&fields=**

# The call:

```

```
curl -X GET "https://<mgmt-  
ip>/api/storage/aggregates?show_spare=true&fields=*" -H "accept:  
application/json"  
  
# The response:  
{  
  "records": [],  
  "num_records": 0,  
  "spares": [  
    {  
      "node": {  
        "uuid": "0cdd84fa-b99c-11eb-b0ed-005056bb4fc2",  
        "name": "node-2",  
        "_links": {  
          "self": {  
            "href": "/api/cluster/nodes/0cdd84fa-b99c-11eb-b0ed-  
005056bb4fc2"  
          }  
        }  
      },  
      "disk_class": "solid_state",  
      "disk_type": "ssd",  
      "size": 3720609792,  
      "checksum_style": "block",  
      "syncmirror_pool": "pool0",  
      "is_partitioned": true,  
      "usable": 12,  
      "total": 14,  
      "layout_requirements": [  
        {  
          "raid_type": "raid_dp",  
          "default": true,  
          "aggregate_min_disks": 3,  
          "raid_group": {  
            "min": 3,  
            "max": 28,  
            "default": 24  
          }  
        },  
        {  
          "raid_type": "raid4",  
          "default": false,  
          "aggregate_min_disks": 2,  
          "raid_group": {  
            "min": 2,  
            "max": 14,  

```

```

        "default": 8
    }
},
{
    "raid_type": "raid_tec",
    "default": false,
    "aggregate_min_disks": 7,
    "raid_group": {
        "min": 4,
        "max": 29,
        "default": 25
    }
}
],
{
    "node": {
        "uuid": "0cdd84fa-b99c-11eb-b0ed-005056bb4fc2",
        "name": "node-2",
        "_links": {
            "self": {
                "href": "/api/cluster/nodes/0cdd84fa-b99c-11eb-b0ed-005056bb4fc2"
            }
        }
    },
    "disk_class": "solid_state",
    "disk_type": "ssd_nvme",
    "size": 8583380992,
    "checksum_style": "block",
    "syncmirror_pool": "pool0",
    "is_partitioned": false,
    "usable": 5,
    "total": 6,
    "layout_requirements": [
        {
            "raid_type": "raid_dp",
            "default": true,
            "aggregate_min_disks": 3,
            "raid_group": {
                "min": 3,
                "max": 28,
                "default": 24
            }
        }
    ],
}
{

```

```

    "raid_type": "raid4",
    "default": false,
    "aggregate_min_disks": 2,
    "raid_group": {
      "min": 2,
      "max": 14,
      "default": 8
    }
  },
  {
    "raid_type": "raid_tec",
    "default": false,
    "aggregate_min_disks": 7,
    "raid_group": {
      "min": 4,
      "max": 29,
      "default": 25
    }
  }
]
}
],
"_link": {
  "self": {
    "href": "/api/storage/aggregates?show_spare=true&fields=**"
  }
}
}

```

### Simulating the creation of an aggregate using defined parameters

The following example shows the response in the simulation of a manual aggregate creation:

```

# The API:
/api/storage/aggregates

# The call
curl -X POST "https://<mgmt-ip>/api/storage/aggregates" -H "accept:
application/json" -d "{\"name\": \"node_2_SSD_1\", \"node\":
{ \"name\": \"node-2\", \"block_storage\": { \"primary\": { \"disk_count\":
\"12\" } }, \"simulate\": \"true\"}"

# The response:
{
  "records": [
    {

```

```

"uuid": "795bf7c2-fa4b-11e8-ba65-005056bbe5c1",
"name": "node_2_SSD_1",
"node": {
  "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
  "name": "node-2",
},
"space": {
  "block_storage": {
    "size": 1116180480
  }
},
"block_storage": {
  "primary": {
    "disk_count": 12,
    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "disk_type": "ssd",
    "raid_size": 24,
    "simulated_raid_groups": [
      {
        "name": "node_2_SSD_1/plex0/rg0",
        "raid_type": "raid_dp",
        "parity_disk_count": 2,
        "data_disk_count": 10,
        "usable_size": 558090240,
        "is_partition": true
      },
    ]
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {
    "enabled": false
  }
}
"_links": {
  "self": {
    "href": "/api/storage/aggregates?recommend=true&fields=*"
  }
}
},
"num_records": 1,
"warnings": [
  {

```



```
  "name": "node-2"
  "warning": {
    "code": 19726347,
    "message": "Number of unassigned disks attached to node \"node-2\":
6.",
    "arguments": [
      "node-2",
      "6"
    ]
  }
}
```

## Retrieve a collection of aggregates for an entire cluster

GET /storage/aggregates

**Introduced In:** 9.6

Retrieves the collection of aggregates for the entire cluster.

### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `metric.*`
- `space.block_storage.inactive_user_data`
- `space.block_storage.inactive_user_data_percent`
- `space.footprint`
- `is_spare_low`
- `statistics.*`

### Related ONTAP commands

- `storage aggregate show`

### Parameters

| Name  | Type    | In    | Required | Description   |
|---|---------|-------|----------|---|
| recommend   | boolean | query | False    | If set to 'true', it queries the system for the recommended optimal layout for creating new aggregates. The default setting is 'false'.     |
| show_spares   | boolean | query | False    | If set to 'true', the spares object is returned instead of records to show the spare groups in the cluster. The default setting is 'false'. |
| recommendation_spares.checksum_style                          | string  | query | False    | Filter by recommendation_spares.checksum_style<br><br>• Introduced in: 9.10   |
| recommendation_spares.is_partition                            | boolean | query | False    | Filter by recommendation_spares.is_partition<br><br>• Introduced in: 9.10   |
| recommendation_spares.disk_class                              | string  | query | False    | Filter by recommendation_spares.disk_class<br><br>• Introduced in: 9.10   |
| recommendation_spares.layout_requirements.aggregate_min_disks | integer | query | False    | Filter by recommendation_spares.layout_requirements.aggregate_min_disks<br><br>• Introduced in: 9.10  |

| Name   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| recommendation_spaces.layout_requirements.default            | boolean | query | False    | Filter by recommendation_spaces.layout_requirements.default<br><br>• Introduced in: 9.10            |
| recommendation_spaces.layout_requirements.raid_group.max     | integer | query | False    | Filter by recommendation_spaces.layout_requirements.raid_group.max<br><br>• Introduced in: 9.10     |
| recommendation_spaces.layout_requirements.raid_group.default | integer | query | False    | Filter by recommendation_spaces.layout_requirements.raid_group.default<br><br>• Introduced in: 9.10 |
| recommendation_spaces.layout_requirements.raid_group.min     | integer | query | False    | Filter by recommendation_spaces.layout_requirements.raid_group.min<br><br>• Introduced in: 9.10     |
| recommendation_spaces.layout_requirements.raid_type          | string  | query | False    | Filter by recommendation_spaces.layout_requirements.raid_type<br><br>• Introduced in: 9.10          |
| recommendation_spaces.disk_type                              | string  | query | False    | Filter by recommendation_spaces.disk_type<br><br>• Introduced in: 9.10                              |

| Name                                  | Type    | In    | Required | Description  |
|---------------------------------------|---------|-------|----------|--|
| recommendation_spares.node.uuid       | string  | query | False    | Filter by recommendation_spares.node.uuid<br><br>• Introduced in: 9.10       |
| recommendation_spares.node.name       | string  | query | False    | Filter by recommendation_spares.node.name<br><br>• Introduced in: 9.10       |
| recommendation_spares.total           | integer | query | False    | Filter by recommendation_spares.total<br><br>• Introduced in: 9.11           |
| recommendation_spares.size            | integer | query | False    | Filter by recommendation_spares.size<br><br>• Introduced in: 9.10            |
| recommendation_spares.usable          | integer | query | False    | Filter by recommendation_spares.usable<br><br>• Introduced in: 9.10          |
| recommendation_spares.syncmirror_pool | string  | query | False    | Filter by recommendation_spares.syncmirror_pool<br><br>• Introduced in: 9.10 |
| inactive_data_reporting.start_time    | string  | query | False    | Filter by inactive_data_reporting.start_time<br><br>• Introduced in: 9.8     |

| Name                            | Type    | In    | Required | Description   |
|---------------------------------|---------|-------|----------|---|
| inactive_data_reporting.enabled | boolean | query | False    | Filter by inactive_data_reporting.enabled<br><br>• Introduced in: 9.8 |
| uuid                            | string  | query | False    | Filter by uuid  |
| node.uuid                       | string  | query | False    | Filter by node.uuid   |
| node.name                       | string  | query | False    | Filter by node.name   |
| volume-count                    | integer | query | False    | Filter by volume-count<br><br>• Introduced in: 9.11                   |
| sidl_enabled                    | boolean | query | False    | Filter by sidel_enabled<br><br>• Introduced in: 9.11                  |
| create_time                     | string  | query | False    | Filter by create_time   |
| statistics.timestamp            | string  | query | False    | Filter by statistics.timestamp<br><br>• Introduced in: 9.7            |
| statistics.iops_raw.other       | integer | query | False    | Filter by statistics.iops_raw.other<br><br>• Introduced in: 9.7       |
| statistics.iops_raw.read        | integer | query | False    | Filter by statistics.iops_raw.read<br><br>• Introduced in: 9.7        |

| Name                         | Type    | In    | Required | Description  |
|------------------------------|---------|-------|----------|--|
| statistics.iops_raw.write    | integer | query | False    | Filter by statistics.iops_raw.write<br><br>• Introduced in: 9.7    |
| statistics.iops_raw.total    | integer | query | False    | Filter by statistics.iops_raw.total<br><br>• Introduced in: 9.7    |
| statistics.status            | string  | query | False    | Filter by statistics.status<br><br>• Introduced in: 9.7            |
| statistics.latency_raw.other | integer | query | False    | Filter by statistics.latency_raw.other<br><br>• Introduced in: 9.7 |
| statistics.latency_raw.read  | integer | query | False    | Filter by statistics.latency_raw.read<br><br>• Introduced in: 9.7  |
| statistics.latency_raw.write | integer | query | False    | Filter by statistics.latency_raw.write<br><br>• Introduced in: 9.7 |
| statistics.latency_raw.total | integer | query | False    | Filter by statistics.latency_raw.total<br><br>• Introduced in: 9.7 |

| Name                            | Type    | In    | Required | Description   |
|---------------------------------|---------|-------|----------|---|
| statistics.throughput_raw.other | integer | query | False    | Filter by statistics.throughput_raw.other<br><br>• Introduced in: 9.7 |
| statistics.throughput_raw.read  | integer | query | False    | Filter by statistics.throughput_raw.read<br><br>• Introduced in: 9.7  |
| statistics.throughput_raw.write | integer | query | False    | Filter by statistics.throughput_raw.write<br><br>• Introduced in: 9.7 |
| statistics.throughput_raw.total | integer | query | False    | Filter by statistics.throughput_raw.total<br><br>• Introduced in: 9.7 |
| name                            | string  | query | False    | Filter by name  |
| metric.iops.other               | integer | query | False    | Filter by metric.iops.other<br><br>• Introduced in: 9.7               |
| metric.iops.read                | integer | query | False    | Filter by metric.iops.read<br><br>• Introduced in: 9.7                |
| metric.iops.write               | integer | query | False    | Filter by metric.iops.write<br><br>• Introduced in: 9.7               |

| Name                 | Type    | In    | Required | Description  |
|----------------------|---------|-------|----------|--|
| metric.iops.total    | integer | query | False    | Filter by metric.iops.total<br><br>• Introduced in: 9.7    |
| metric.timestamp     | string  | query | False    | Filter by metric.timestamp<br><br>• Introduced in: 9.7     |
| metric.latency.other | integer | query | False    | Filter by metric.latency.other<br><br>• Introduced in: 9.7 |
| metric.latency.read  | integer | query | False    | Filter by metric.latency.read<br><br>• Introduced in: 9.7  |
| metric.latency.write | integer | query | False    | Filter by metric.latency.write<br><br>• Introduced in: 9.7 |
| metric.latency.total | integer | query | False    | Filter by metric.latency.total<br><br>• Introduced in: 9.7 |
| metric.duration      | string  | query | False    | Filter by metric.duration<br><br>• Introduced in: 9.7      |
| metric.status        | string  | query | False    | Filter by metric.status<br><br>• Introduced in: 9.7        |



| Name                         | Type    | In    | Required | Description   |
|------------------------------|---------|-------|----------|---|
| metric.throughput.other      | integer | query | False    | Filter by metric.throughput.other<br><br>• Introduced in: 9.7       |
| metric.throughput.read       | integer | query | False    | Filter by metric.throughput.read<br><br>• Introduced in: 9.7        |
| metric.throughput.write      | integer | query | False    | Filter by metric.throughput.write<br><br>• Introduced in: 9.7       |
| metric.throughput.total      | integer | query | False    | Filter by metric.throughput.total<br><br>• Introduced in: 9.7       |
| snapshot.max_files_available | integer | query | False    | Filter by snapshot.max_files_available<br><br>• Introduced in: 9.10 |
| snapshot.max_files_used      | integer | query | False    | Filter by snapshot.max_files_used<br><br>• Introduced in: 9.10      |
| snapshot.files_used          | integer | query | False    | Filter by snapshot.files_used<br><br>• Introduced in: 9.10          |

| Name                                | Type    | In    | Required | Description  |
|-------------------------------------|---------|-------|----------|--|
| snapshot.files_total                | integer | query | False    | Filter by snapshot.files_total<br><br>• Introduced in: 9.10  |
| home_node.uuid                      | string  | query | False    | Filter by home_node.uuid   |
| home_node.name                      | string  | query | False    | Filter by home_node.name   |
| is_spare_low                        | boolean | query | False    | Filter by is_spare_low<br><br>• Introduced in: 9.11  |
| inode_attributes.max_files_possible | integer | query | False    | Filter by inode_attributes.max_files_possible<br><br>• Introduced in: 9.11                                 |
| inode_attributes.files_private_used | integer | query | False    | Filter by inode_attributes.files_private_used<br><br>• Introduced in: 9.11                                 |
| inode_attributes.files_total        | integer | query | False    | Filter by inode_attributes.files_total<br><br>• Introduced in: 9.11  |
| inode_attributes.used_percent       | integer | query | False    | Filter by inode_attributes.used_percent<br><br>• Introduced in: 9.11<br>• Max value: 100<br>• Min value: 0 |

| Name                                   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| inode_attributes.version               | integer | query | False    | Filter by inode_attributes.version<br><br>• Introduced in: 9.11               |
| inode_attributes.max_files_available   | integer | query | False    | Filter by inode_attributes.max_files_available<br><br>• Introduced in: 9.11   |
| inode_attributes.file_private_capacity | integer | query | False    | Filter by inode_attributes.file_private_capacity<br><br>• Introduced in: 9.11 |
| inode_attributes.files_used            | integer | query | False    | Filter by inode_attributes.files_used<br><br>• Introduced in: 9.11            |
| inode_attributes.max_files_used        | integer | query | False    | Filter by inode_attributes.max_files_used<br><br>• Introduced in: 9.11        |
| inode_attributes.file_public_capacity  | integer | query | False    | Filter by inode_attributes.file_public_capacity<br><br>• Introduced in: 9.11  |
| dr_home_node.name                      | string  | query | False    | Filter by dr_home_node.name   |
| dr_home_node.uuid                      | string  | query | False    | Filter by dr_home_node.uuid   |

| Name                            | Type    | In    | Required | Description   |
|---------------------------------|---------|-------|----------|---|
| space.encyclopedia.logical_used | integer | query | False    | Filter by space.encyclopedia.logical_used                             |
| space.encyclopedia.savings      | integer | query | False    | Filter by space.encyclopedia.savings                                  |
| space.encyclopedia.ratio        | number  | query | False    | Filter by space.encyclopedia.ratio                                    |
| space.snapshot.reserve_percent  | integer | query | False    | Filter by space.snapshot.reserve_percent<br><br>• Introduced in: 9.10 |
| space.snapshot.available        | integer | query | False    | Filter by space.snapshot.available<br><br>• Introduced in: 9.10       |
| space.snapshot.used_percent     | integer | query | False    | Filter by space.snapshot.used_percent<br><br>• Introduced in: 9.10    |
| space.snapshot.used             | integer | query | False    | Filter by space.snapshot.used<br><br>• Introduced in: 9.10            |
| space.snapshot.total            | integer | query | False    | Filter by space.snapshot.total<br><br>• Introduced in: 9.10           |
| space.footprint                 | integer | query | False    | Filter by space.footprint   |

| Name   | Type    | In    | Required | Description  |
|--|---------|-------|----------|--|
| space.encyency_wit hout_snapshots.logi cal_used            | integer | query | False    | Filter by space.encyency_wit hout_snapshots.logi cal_used  |
| space.encyency_wit hout_snapshots.savi ngs                 | integer | query | False    | Filter by space.encyency_wit hout_snapshots.savi ngs   |
| space.encyency_wit hout_snapshots.ratio                    | number  | query | False    | Filter by space.encyency_wit hout_snapshots.rati o   |
| space.cloud_storage .used                                  | integer | query | False    | Filter by space.cloud_storage .used  |
| space.encyency_wit hout_snapshots_flex clones.logical_used | integer | query | False    | Filter by space.encyency_wit hout_snapshots_flex clones.logical_used<br><br>• Introduced in: 9.9 |
| space.encyency_wit hout_snapshots_flex clones.savings      | integer | query | False    | Filter by space.encyency_wit hout_snapshots_flex clones.savings<br><br>• Introduced in: 9.9      |
| space.encyency_wit hout_snapshots_flex clones.ratio        | number  | query | False    | Filter by space.encyency_wit hout_snapshots_flex clones.ratio<br><br>• Introduced in: 9.9        |

| Name   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| space.block_storage.data_compaction_space_saved_percent      | integer | query | False    | Filter by space.block_storage.data_compaction_space_saved_percent<br><br>• Introduced in: 9.10      |
| space.block_storage.size                                     | integer | query | False    | Filter by space.block_storage.size  |
| space.block_storage.volume_deduplication_space_saved_percent | integer | query | False    | Filter by space.block_storage.volume_deduplication_space_saved_percent<br><br>• Introduced in: 9.10 |
| space.block_storage.used                                     | integer | query | False    | Filter by space.block_storage.used  |
| space.block_storage.data_compacted_count                     | integer | query | False    | Filter by space.block_storage.data_compacted_count<br><br>• Introduced in: 9.10                     |
| space.block_storage.data_compaction_space_saved              | integer | query | False    | Filter by space.block_storage.data_compaction_space_saved<br><br>• Introduced in: 9.10              |
| space.block_storage.volume_deduplication_shared_count        | integer | query | False    | Filter by space.block_storage.volume_deduplication_shared_count<br><br>• Introduced in: 9.10        |

| Name   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| space.block_storage.physical_used                    | integer | query | False    | Filter by space.block_storage.physical_used<br><br>• Introduced in: 9.9                     |
| space.block_storage.inactive_user_data_percent       | integer | query | False    | Filter by space.block_storage.inactive_user_data_percent<br><br>• Introduced in: 9.10       |
| space.block_storage.volume_deduplication_space_saved | integer | query | False    | Filter by space.block_storage.volume_deduplication_space_saved<br><br>• Introduced in: 9.10 |
| space.block_storage.aggregate_metadata_percent       | integer | query | False    | Filter by space.block_storage.aggregate_metadata_percent<br><br>• Introduced in: 9.11       |
| space.block_storage.aggregate_metadata               | integer | query | False    | Filter by space.block_storage.aggregate_metadata<br><br>• Introduced in: 9.11               |
| space.block_storage.available                        | integer | query | False    | Filter by space.block_storage.available   |

| Name  | Type    | In    | Required | Description  |
|---|---------|-------|----------|--|
| space.block_storage.physical_used_percent                   | integer | query | False    | Filter by space.block_storage.physical_used_percent<br><br>• Introduced in: 9.10                   |
| space.block_storage.inactive_user_data                      | integer | query | False    | Filter by space.block_storage.inactive_user_data   |
| space.block_storage.used_including_snapshot_reserve         | integer | query | False    | Filter by space.block_storage.used_including_snapshot_reserve<br><br>• Introduced in: 9.11         |
| space.block_storage.full_threshold_percent                  | integer | query | False    | Filter by space.block_storage.full_threshold_percent   |
| space.block_storage.used_including_snapshot_reserve_percent | integer | query | False    | Filter by space.block_storage.used_including_snapshot_reserve_percent<br><br>• Introduced in: 9.11 |
| space.block_storage.volume_footprints_percent               | integer | query | False    | Filter by space.block_storage.volume_footprints_percent<br><br>• Introduced in: 9.11               |
| state   | string  | query | False    | Filter by state  |



| Name  | Type    | In    | Required | Description  |
|---|---------|-------|----------|--|
| block_storage.uses_partitions                                   | boolean | query | False    | Filter by block_storage.uses_partitions<br><br>• Introduced in: 9.11                                   |
| block_storage.plexes.name                                       | string  | query | False    | Filter by block_storage.plexes.name  |
| block_storage.mirror.state                                      | string  | query | False    | Filter by block_storage.mirror.state   |
| block_storage.mirror.enabled                                    | boolean | query | False    | Filter by block_storage.mirror.enabled   |
| block_storage.hybrid_cache.storage_pools.allocation_units_count | integer | query | False    | Filter by block_storage.hybrid_cache.storage_pools.allocation_units_count<br><br>• Introduced in: 9.11 |
| block_storage.hybrid_cache.storage_pools.storage_pool.name      | string  | query | False    | Filter by block_storage.hybrid_cache.storage_pools.storage_pool.name<br><br>• Introduced in: 9.11      |
| block_storage.hybrid_cache.storage_pools.storage_pool.uuid      | string  | query | False    | Filter by block_storage.hybrid_cache.storage_pools.storage_pool.uuid<br><br>• Introduced in: 9.11      |
| block_storage.hybrid_cache.disk_count                           | integer | query | False    | Filter by block_storage.hybrid_cache.disk_count  |

| Name   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| block_storage.hybrid_cache.raid_type                                 | string  | query | False    | Filter by block_storage.hybrid_cache.raid_type  |
| block_storage.hybrid_cache.enabled                                   | boolean | query | False    | Filter by block_storage.hybrid_cache.enabled  |
| block_storage.hybrid_cache.size                                      | integer | query | False    | Filter by block_storage.hybrid_cache.size   |
| block_storage.hybrid_cache.used                                      | integer | query | False    | Filter by block_storage.hybrid_cache.used   |
| block_storage.primary.disk_type                                      | string  | query | False    | Filter by block_storage.primary.disk_type<br><br>• Introduced in: 9.7                                       |
| block_storage.primary.raid_size                                      | integer | query | False    | Filter by block_storage.primary.raid_size   |
| block_storage.primary.simulated_raid_groups.usable_size              | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.usable_size<br><br>• Introduced in: 9.10              |
| block_storage.primary.simulated_raid_groups.existing_data_disk_count | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.existing_data_disk_count<br><br>• Introduced in: 9.11 |

| Name   | Type    | In    | Required | Description   |
|--|---------|-------|----------|---|
| block_storage.primary.simulated_raid_groups.raid_type                  | string  | query | False    | Filter by block_storage.primary.simulated_raid_groups.raid_type<br><br>• Introduced in: 9.10                  |
| block_storage.primary.simulated_raid_groups.existing_parity_disk_count | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.existing_parity_disk_count<br><br>• Introduced in: 9.11 |
| block_storage.primary.simulated_raid_groups.name                       | string  | query | False    | Filter by block_storage.primary.simulated_raid_groups.name<br><br>• Introduced in: 9.10                       |
| block_storage.primary.simulated_raid_groups.added_parity_disk_count    | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.added_parity_disk_count<br><br>• Introduced in: 9.11    |
| block_storage.primary.simulated_raid_groups.is_partition               | boolean | query | False    | Filter by block_storage.primary.simulated_raid_groups.is_partition<br><br>• Introduced in: 9.10               |
| block_storage.primary.simulated_raid_groups.added_data_disk_count      | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.added_data_disk_count<br><br>• Introduced in: 9.11      |

| Name  | Type    | In    | Required | Description  |
|---|---------|-------|----------|--|
| block_storage.primary.simulated_raid_groups.parity_disk_count | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.parity_disk_count<br><br>• Introduced in: 9.10 |
| block_storage.primary.simulated_raid_groups.data_disk_count   | integer | query | False    | Filter by block_storage.primary.simulated_raid_groups.data_disk_count<br><br>• Introduced in: 9.10   |
| block_storage.primary.disk_class                              | string  | query | False    | Filter by block_storage.primary.disk_class   |
| block_storage.primary.raid_type                               | string  | query | False    | Filter by block_storage.primary.raid_type  |
| block_storage.primary.disk_count                              | integer | query | False    | Filter by block_storage.primary.disk_count   |
| block_storage.primary.checksum_style                          | string  | query | False    | Filter by block_storage.primary.checksum_style   |
| block_storage.storage_type                                    | string  | query | False    | Filter by block_storage.storage_type<br><br>• Introduced in: 9.11                                    |
| data_encryption.drive_protection_enabled                      | boolean | query | False    | Filter by data_encryption.drive_protection_enabled   |

| Name  | Type          | In    | Required | Description   |
|---|---------------|-------|----------|---|
| data_encryption.software_encryption_enabled | boolean       | query | False    | Filter by data_encryption.software_encryption_enabled   |
| snaplock_type                               | string        | query | False    | Filter by snaplock_type   |
| fields                                      | array[string] | query | False    | Specify the fields to return.   |
| max_records                                 | integer       | query | False    | Limit the number of records returned.   |
| return_records                              | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout                              | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Max value: 120</li> <li>• Min value: 0</li> <li>• Default value: 1</li> </ul> |
| order_by                                    | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                                       | Description   |
|-------------|--|---|
| _links      | <a href="#">_links</a>                     |   |
| error       | <a href="#">error</a>                      |   |
| num_records | integer                                    | Number of records   |
| records     | array[ <a href="#">aggregate</a> ]         |   |
| spares      | array[ <a href="#">aggregate_spare</a> ]   |   |
| warnings    | array[ <a href="#">aggregate_warning</a> ] | List of warnings and remediation advice for the aggregate recommendation. |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "block_storage": {
    "hybrid_cache": {
      "disk_count": 6,
      "raid_type": "raid_dp",
      "size": 1612709888,
      "storage_pools": {
        "storage_pool": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "storage_pool_1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      },
      "used": 26501122
    },
    "mirror": {
      "enabled": "",

```

```

    "state": "unmirrored"
  },
  "plexes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "plex0"
  },
  "primary": {
    "checksum_style": "block",
    "disk_class": "performance",
    "disk_count": 8,
    "disk_type": "fc",
    "raid_size": 16,
    "raid_type": "raid_dp",
    "simulated_raid_groups": {
      "raid_type": "raid_dp"
    }
  },
  "storage_type": "hdd"
},
"cloud_storage": {
  "stores": {
    "cloud_store": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "store1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "used": 0
  }
},
"create_time": "2018-01-01T12:00:00-04:00",
"dr_home_node": {
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"home_node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
}

```



```

    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"inactive_data_reporting": {
  "start_time": "2019-12-12T12:00:00-04:00"
},
"inode_attributes": {
  "file_private_capacity": 31136,
  "file_public_capacity": 31136,
  "files_private_used": 502,
  "files_total": 31136,
  "files_used": 97,
  "max_files_available": 31136,
  "max_files_possible": 2844525,
  "max_files_used": 97,
  "used_percent": 5,
  "version": 4
},
"is_spare_low": "",
"metric": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"duration": "PT15S",
"iops": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"latency": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"status": "ok",
"throughput": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},

```

```

"name": "node1_aggr_1",
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"recommendation_spare": {
  "checksum_style": "block",
  "disk_class": "solid_state",
  "disk_type": "fc",
  "is_partition": 1,
  "layout_requirements": {
    "aggregate_min_disks": 6,
    "raid_group": {
      "default": 16,
      "max": 28,
      "min": 5
    }
  },
  "raid_type": "raid_dp"
},
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 10156769280,
"syncmirror_pool": "pool0",
"total": 10,
"usable": 9
},
"snaplock_type": "non_snaplock",
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"space": {

```

```
"block_storage": {
  "aggregate_metadata": 2655,
  "aggregate_metadata_percent": 8,
  "available": 10156560384,
  "data_compacted_count": 1990000,
  "data_compaction_space_saved": 1996000,
  "data_compaction_space_saved_percent": 27,
  "full_threshold_percent": 0,
  "inactive_user_data": 304448,
  "inactive_user_data_percent": 0,
  "physical_used": 2461696,
  "physical_used_percent": 50,
  "size": 10156769280,
  "used": 2088960,
  "used_including_snapshot_reserve": 674685,
  "used_including_snapshot_reserve_percent": 35,
  "volume_deduplication_shared_count": 1990000,
  "volume_deduplication_space_saved": 1996000,
  "volume_deduplication_space_saved_percent": 27,
  "volume_footprints_percent": 14
},
"cloud_storage": {
  "used": 402743264
},
"efficiency": {
  "logical_used": 0,
  "ratio": 0,
  "savings": 0
},
"efficiency_without_snapshots": {
  "logical_used": 0,
  "ratio": 0,
  "savings": 0
},
"efficiency_without_snapshots_flexclones": {
  "logical_used": 0,
  "ratio": 0,
  "savings": 0
},
"footprint": 608896,
"snapshot": {
  "available": 2000,
  "reserve_percent": 20,
  "total": 5000,
  "used": 3000,
  "used_percent": 45
}
```

```

    }
  },
  "state": "online",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "uuid": "string",
  "volume-count": 0
},
"spares": {
  "checksum_style": "block",
  "disk_class": "solid_state",
  "disk_type": "fc",
  "is_partition": 1,
  "layout_requirements": {
    "aggregate_min_disks": 6,
    "raid_group": {
      "default": 16,
      "max": 28,
      "min": 5
    },
    "raid_type": "raid_dp"
  },
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",

```

```

    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "size": 10156769280,
  "syncmirror_pool": "pool0",
  "total": 10,
  "usable": 9
},
"warnings": {
  "action": {
    "arguments": {
    }
  },
  "warning": {
    "arguments": {
    }
  }
}
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 787092     | The target field cannot be specified for this operation.  |
| 918138     | Internal error. Failed to get encryption operation status.  |
| 8586225    | Encountered unexpected error in retrieving metrics and statistics for an aggregate.                             |
| 19726341   | Not enough eligible spare disks are available on the node.  |
| 19726344   | No recommendation can be made for this cluster.   |
| 19726357   | Aggregate recommendations are not supported on MetroCluster with Fibre Channel (FC).                            |
| 19726358   | Aggregate recommendations are not supported on ONTAP Cloud.   |
| 19726382   | Another provisioning operation is in progress on this cluster. Wait a few minutes, and try the operation again. |

| Error Code | Description   |
|------------|---|
| 19726386   | Encountered an error when retrieving licensing information on this cluster.   |
| 19726387   | No recommendation can be provided for this cluster within the license capacity.   |
| 19726401   | Aggregate recommendations are not supported when the DR group is not in the "normal" state.   |
| 19726402   | Internal error. Unable to determine the MetroCluster configuration state.   |
| 19726403   | Aggregate recommendation is not supported when there are no healthy target connections to remote storage.   |
| 19726404   | The recommended mirrored aggregate couldn't use all the attached capacity in one of the SyncMirror pools. Make sure that the remote and local storage is symmetrically wired. |
| 19726405   | Not all local and remote disks attached to the node have been auto-partitioned.   |
| 19726406   | Aggregate recommendations are not supported on this node because remote and local storage is not symmetrically wired.   |
| 19726540   | The next tag is not supported for recommended aggregates. Retry the operation with a higher "return_timeout" value.   |
| 196608055  | Aggregate recommendation is not supported on this node because it does not support NetApp Aggregate Encryption (NAE).   |
| 196608206  | Internal error. Failed to get encryption operation status.  |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

storage\_pool\_reference

Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |



| Name | Type   | Description |
|------|--------|-------------|
| uuid | string |             |

#### storage\_pools

| Name                   | Type                                   | Description                       |
|------------------------|--|-----------------------------------|
| allocation_units_count | integer                                | Allocation count of storage pool. |
| storage_pool           | <a href="#">storage_pool_reference</a> | Shared Storage Pool               |

#### hybrid\_cache

Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs.

| Name          | Type                                   | Description  |
|---------------|--|--|
| disk_count    | integer                                | Number of disks used in the cache tier of the aggregate. Only provided when <code>hybrid_cache.enabled</code> is 'true'. |
| enabled       | boolean                                | Specifies whether the aggregate uses HDDs with SSDs as a cache.  |
| raid_type     | string                                 | RAID type for SSD cache of the aggregate. Only provided when <code>hybrid_cache.enabled</code> is 'true'.                |
| size          | integer                                | Total usable space in bytes of SSD cache. Only provided when <code>hybrid_cache.enabled</code> is 'true'.                |
| storage_pools | array[ <a href="#">storage_pools</a> ] | List of storage pool properties and <code>allocation_units_count</code> for aggregate.                                   |
| used          | integer                                | Space used in bytes of SSD cache. Only provided when <code>hybrid_cache.enabled</code> is 'true'.                        |

#### mirror

| Name    | Type    | Description                       |
|---------|---------|-----------------------------------|
| enabled | boolean | Aggregate is SyncMirror protected |
| state   | string  |                                   |

plex\_reference

Plex

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

simulated\_raid\_groups

| Name                       | Type    | Description  |
|----------------------------|---------|--|
| added_data_disk_count      | integer | Number of added data disks in RAID group.                          |
| added_parity_disk_count    | integer | Number of added parity disks in RAID group.                        |
| data_disk_count            | integer | Number of data disks in RAID group.                                |
| existing_data_disk_count   | integer | Number of existing data disks in the RAID group.                   |
| existing_parity_disk_count | integer | Number of existing parity disks in the RAID group.                 |
| is_partition               | boolean | Indicates whether the disk is partitioned (true) or whole (false). |
| name                       | string  | Name of the raid group.  |
| parity_disk_count          | integer | Number of parity disks in RAID group.                              |
| raid_type                  | string  | RAID type of the aggregate.  |
| usable_size                | integer | Usable size of each disk, in bytes.                                |

primary

Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.

| Name                  | Type   | Description  |
|-----------------------|--|--|
| checksum_style        | string   | The checksum style used by the aggregate.  |
| disk_class            | string   | The class of disks being used by the aggregate.  |
| disk_count            | integer  | Number of disks used in the aggregate. This includes parity disks, but excludes disks in the hybrid cache. |
| disk_type             | string   | The type of disk being used by the aggregate.  |
| raid_size             | integer  | Option to specify the maximum number of disks that can be included in a RAID group.                        |
| raid_type             | string   | RAID type of the aggregate.  |
| simulated_raid_groups | array[ <a href="#">simulated_raid_groups</a> ] |  |

#### block\_storage

Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.

| Name         | Type                                    | Description   |
|--------------|---|---|
| hybrid_cache | <a href="#">hybrid_cache</a>            | Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs. |
| mirror       | <a href="#">mirror</a>                  |   |
| plexes       | array[ <a href="#">plex_reference</a> ] | Plex reference for each plex in the aggregate.  |
| primary      | <a href="#">primary</a>                 | Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.     |
| storage_type | string                                  | Type of aggregate.  |

| Name            | Type    | Description                               |
|-----------------|---------|---|
| uses_partitions | boolean | If true, aggregate is using shared disks. |

cloud\_store

Cloud store

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

cloud\_storage\_tier

| Name        | Type                        | Description   |
|-------------|-----------------------------|---|
| cloud_store | <a href="#">cloud_store</a> | Cloud store   |
| used        | integer                     | Capacity used in bytes in the cloud store by this aggregate. This is a cached value calculated every 5 minutes. |

cloud\_storage

Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.

| Name                       | Type  | Description  |
|----------------------------|---|--|
| attach_eligible            | boolean                                     | Specifies whether the aggregate is eligible for a cloud store to be attached.  |
| stores                     | array[ <a href="#">cloud_storage_tier</a> ] | Configuration information for each cloud storage portion of the aggregate.   |
| tiering_fullness_threshold | integer                                     | The percentage of space in the performance tier that must be used before data is tiered out to the cloud store. Only valid for PATCH operations. |

data\_encryption

| Name                        | Type    | Description   |
|-----------------------------|---------|---|
| drive_protection_enabled    | boolean | Specifies whether the aggregate uses self-encrypting drives with data protection enabled.         |
| software_encryption_enabled | boolean | Specifies whether NetApp aggregate encryption is enabled. All data in the aggregate is encrypted. |

dr\_home\_node

Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

home\_node

Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

inactive\_data\_reporting

| Name       | Type    | Description   |
|------------|---------|---|
| enabled    | boolean | Specifies whether or not inactive data reporting is enabled on the aggregate. |
| start_time | string  | Timestamp at which inactive data reporting was enabled on the aggregate.      |

inode\_attributes

| Name                  | Type    | Description   |
|-----------------------|---------|---|
| file_private_capacity | integer | Number of files that can currently be stored on disk for system metadata files. This number will dynamically increase as more system files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> .    |
| file_public_capacity  | integer | Number of files that can currently be stored on disk for user-visible files. This number will dynamically increase as more user-visible files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| files_private_used    | integer | Number of system metadata files used. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> .                                    |
| files_total           | integer | Maximum number of user-visible files that this referenced file system can currently hold. If the referenced file system is restricted or offline, a value of 0 is returned.   |

| Name                | Type    | Description  |
|---------------------|---------|--|
| files_used          | integer | Number of user-visible files used in the referenced file system. If the referenced file system is restricted or offline, a value of 0 is returned.   |
| max_files_available | integer | The count of the maximum number of user-visible files currently allowable on the referenced file system.   |
| max_files_possible  | integer | The largest value to which the maxfiles-available parameter can be increased by reconfiguration, on the referenced file system.  |
| max_files_used      | integer | The number of user-visible files currently in use on the referenced file system.   |
| used_percent        | integer | The percentage of disk space currently in use based on user-visible file count on the referenced file system.  |
| version             | integer | The inofile-version of the aggregate. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

#### iops

The rate of I/O operations observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |

| Name  | Type    | Description   |
|-------|---------|---|
| read  | integer | Performance metric for read I/O operations.                     |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations.                    |

#### latency

The round trip latency in microseconds observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput

The rate of throughput bytes per second observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |



| Name  | Type    | Description                                  |
|-------|---------|--|
| write | integer | Performance metric for write I/O operations. |

metric

The most recent sample of I/O metrics for the aggregate.

| Name                   | Type                    | Description   |
|------------------------|-------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a>  |   |
| duration               | string                  | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:  |
| iops                   | <a href="#">iops</a>    | The rate of I/O operations observed at the storage object.  |
| latency                | <a href="#">latency</a> | The round trip latency in microseconds observed at the storage object.  |
| status                 | string                  | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |

| Name       | Type                       | Description   |
|------------|----------------------------|---|
| throughput | <a href="#">throughput</a> | The rate of throughput bytes per second observed at the storage object. |
| timestamp  | string                     | The timestamp of the performance data.                                  |

node

Node where the aggregate currently resides.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

raid\_group

| Name    | Type    | Description                                      |
|---------|---------|--|
| default | integer | Default number of disks in a RAID group.         |
| max     | integer | Maximum number of disks allowed in a RAID group. |
| min     | integer | Minimum number of disks allowed in a RAID group. |

layout\_requirement

| Name                | Type                       | Description                                     |
|---------------------|----------------------------|---|
| aggregate_min_disks | integer                    | Minimum number of disks to create an aggregate. |
| default             | boolean                    | Indicates if this RAID type is the default.     |
| raid_group          | <a href="#">raid_group</a> |   |
| raid_type           | string                     | RAID type.                                      |

node

Node where the spares are assigned.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### aggregate\_spare

| Name                | Type  | Description   |
|---------------------|---|---|
| checksum_style      | string                                      | The checksum type that has been assigned to the spares.   |
| disk_class          | string                                      | Disk class of spares.   |
| disk_type           | string                                      | Type of disk.   |
| is_partition        | boolean                                     | Indicates whether a disk is partitioned (true) or whole (false)   |
| layout_requirements | array[ <a href="#">layout_requirement</a> ] | Available RAID protections and their restrictions.  |
| node                | <a href="#">node</a>                        | Node where the spares are assigned.   |
| size                | integer                                     | Usable size of each spare, in bytes.  |
| syncmirror_pool     | string                                      | SyncMirror spare pool.  |
| total               | integer                                     | Total number of spares in the bucket. The total spare count for each class of spares also includes reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 10</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.11</li> </ul> |

| Name   | Type    | Description  |
|--------|---------|--|
| usable | integer | Total number of usable spares in the bucket. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 9</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul> |

#### snapshot

| Name                | Type    | Description                                 |
|---------------------|---------|---|
| files_total         | integer | Total files allowed in Snapshot copies      |
| files_used          | integer | Total files created in Snapshot copies      |
| max_files_available | integer | Maximum files available for Snapshot copies |
| max_files_used      | integer | Files in use by Snapshot copies             |

#### block\_storage

| Name                        | Type    | Description   |
|-----------------------------|---------|---|
| aggregate_metadata          | integer | Space used by different metafiles and internal operations inside the aggregate, in bytes. |
| aggregate_metadata_percent  | integer | Aggregate metadata as a percentage.   |
| available                   | integer | Space available in bytes.   |
| data_compacted_count        | integer | Amount of compacted data in bytes.  |
| data_compaction_space_saved | integer | Space saved in bytes by compacting the data.  |

| Name                                | Type    | Description  |
|-------------------------------------|---------|--|
| data_compaction_space_saved_percent | integer | Percentage saved by compacting the data.   |
| full_threshold_percent              | integer | The aggregate used percentage at which 'monitor.volume.full' EMS is generated.   |
| inactive_user_data                  | integer | The size that is physically used in the block storage and has a cold temperature, in bytes. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data</code> or <code>**</code> . |
| inactive_user_data_percent          | integer | The percentage of inactive user data in the block storage. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data_percent</code> or <code>**</code> .                          |
| physical_used                       | integer | Total physical used size of an aggregate in bytes.   |
| physical_used_percent               | integer | Physical used percentage.  |

| Name                                     | Type    | Description   |
|--|---------|---|
| size                                     | integer | Total usable space in bytes, not including WAFL reserve and aggregate Snapshot copy reserve.  |
| used                                     | integer | Space used or reserved in bytes. Includes volume guarantees and aggregate metadata.   |
| used_including_snapshot_reserve          | integer | Total used including the Snapshot copy reserve, in bytes.   |
| used_including_snapshot_reserve_percent  | integer | Total used including the Snapshot reserve as a percentage.  |
| volume_deduplication_shared_count        | integer | Amount of shared bytes counted by storage efficiency.   |
| volume_deduplication_space_saved         | integer | Amount of space saved in bytes by storage efficiency.   |
| volume_deduplication_space_saved_percent | integer | Percentage of space saved by storage efficiency.  |
| volume_footprints_percent                | integer | A summation of volume footprints inside the aggregate, as a percentage. A volume's footprint is the amount of space being used for the volume in the aggregate. |

#### cloud\_storage

| Name | Type    | Description   |
|------|---------|---|
| used | integer | Used space in bytes in the cloud store. Only applicable for aggregates with a cloud store tier. |

#### efficiency

Storage efficiency.

| Name         | Type    | Description  |
|--------------|---------|--------------|
| logical_used | integer | Logical used |

| Name    | Type    | Description   |
|---------|---------|---|
| ratio   | number  | Data reduction ratio (logical_used / used)                |
| savings | integer | Space saved by storage efficiencies (logical_used - used) |

efficiency\_without\_snapshots

Storage efficiency that does not include the savings provided by Snapshot copies.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

efficiency\_without\_snapshots\_flexclones

Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

snapshot

| Name            | Type    | Description                                      |
|-----------------|---------|--|
| available       | integer | Available space for Snapshot copies in bytes     |
| reserve_percent | integer | Percentage of space reserved for Snapshot copies |
| total           | integer | Total space for Snapshot copies in bytes         |

| Name         | Type    | Description                                      |
|--------------|---------|--|
| used         | integer | Space used by Snapshot copies in bytes           |
| used_percent | integer | Percentage of disk space used by Snapshot copies |

#### space

| Name                                     | Type   | Description  |
|--|--|--|
| block_storage                            | <a href="#">block_storage</a>                            |  |
| cloud_storage                            | <a href="#">cloud_storage</a>                            |  |
| efficiency                               | <a href="#">efficiency</a>                               | Storage efficiency.  |
| efficiency_without_snapshots             | <a href="#">efficiency_without_snapshots</a>             | Storage efficiency that does not include the savings provided by Snapshot copies.  |
| efficiency_without_snapshots_flex_clones | <a href="#">efficiency_without_snapshots_flex_clones</a> | Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes.  |
| footprint                                | integer  | A summation of volume footprints (including volume guarantees), in bytes. This includes all of the volume footprints in the <code>block_storage</code> tier and the <code>cloud_storage</code> tier. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <code>fields</code> query parameter containing either <code>footprint</code> or <code>**</code> . |
| snapshot                                 | <a href="#">snapshot</a>                                 |  |

#### iops\_raw

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.



| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### latency\_raw

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

The real time I/O statistics for the aggregate.

| Name        | Type                        | Description   |
|-------------|-----------------------------|---|
| iops_raw    | <a href="#">iops_raw</a>    | The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time. |
| latency_raw | <a href="#">latency_raw</a> | The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation. |

| Name           | Type                           | Description   |
|----------------|--------------------------------|---|
| status         | string                         | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.  |

#### aggregate

| Name                          | Type                          | Description  |
|-------------------------------|-------------------------------|--|
| <a href="#">_links</a>        | <a href="#">_links</a>        |  |
| <a href="#">block_storage</a> | <a href="#">block_storage</a> | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier. |

| Name                    | Type                    | Description  |
|-------------------------|-------------------------|--|
| cloud_storage           | cloud_storage           | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |
| create_time             | string                  | Timestamp of aggregate creation.   |
| data_encryption         | data_encryption         |  |
| dr_home_node            | dr_home_node            | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | home_node               | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | inactive_data_reporting |  |
| inode_attributes        | inode_attributes        |  |
| is_spare_low            | boolean                 | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| metric                  | metric                  | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                  | Aggregate name.  |
| node                    | node                    | Node where the aggregate currently resides.  |
| recommendation_spares   | array[aggregate_spare]  | Information on the aggregate's remaining hot spare disks.  |

| Name          | Type                       | Description  |
|---------------|----------------------------|--|
| sidl_enabled  | boolean                    | Specifies whether or not SIDL is enabled on the aggregate. |
| snaplock_type | string                     | SnapLock type.   |
| snapshot      | <a href="#">snapshot</a>   |  |
| space         | <a href="#">space</a>      |  |
| state         | string                     | Operational state of the aggregate.                        |
| statistics    | <a href="#">statistics</a> | The real time I/O statistics for the aggregate.            |
| uuid          | string                     | Aggregate UUID.  |
| volume-count  | integer                    | Number of volumes in the aggregate.                        |

#### action

| Name      | Type          | Description   |
|-----------|---------------|---|
| arguments | array[string] | Arguments present in the specified action message.                |
| code      | integer       | Corrective action code of the specified action.                   |
| message   | string        | Specifies the corrective action to be taken to resolve the issue. |

#### warning

| Name      | Type          | Description   |
|-----------|---------------|---|
| arguments | array[string] | Arguments present in the warning message encountered.               |
| code      | integer       | Warning code of the warning encountered.                            |
| message   | string        | Details of the warning encountered by the aggregate simulate query. |

## aggregate\_warning

| Name    | Type                    | Description                                  |
|---------|-------------------------|--|
| action  | <a href="#">action</a>  |  |
| name    | string                  | Name of the entity that returns the warning. |
| warning | <a href="#">warning</a> |  |

## Create a collection of aggregates for an entire cluster

POST /storage/aggregates

**Introduced In:** 9.6

Automatically creates aggregates based on an optimal layout recommended by the system. Alternatively, properties can be provided to create an aggregate according to the requested specification. This request starts a job and returns a link to that job. POST operations will be blocked while one or more nodes in the cluster are simulating or implementing automatic aggregate creation.

### Required properties

Properties are not required for this API. The following properties are only required if you want to specify properties for aggregate creation:

- `name` - Name of the aggregate.
- `node.name` or `node.uuid` - Node on which the aggregate will be created.
- `block_storage.primary.disk_count` - Number of disks to be used to create the aggregate.

### Default values

If not specified in POST, the following default values are assigned. The remaining unspecified properties will receive system dependent default values.

- `block_storage.mirror.enabled` - *false*
- `snaplock_type` - *non\_snaplock*

### Related ONTAP commands

- `storage aggregate auto-provision`
- `storage aggregate create`

### Example:

```
POST /api/storage/aggregates {"node": {"name": "node1"}, "name": "test",  
"block_storage": {"primary": {"disk_count": "10"}}
```

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| disk_size      | integer | query | False    | If set, POST only selects disks of the specified size.   |
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul> |
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"><li>• Default value:</li></ul>  |

## Request Body

| Name                    | Type                                    | Description  |
|-------------------------|---|--|
| _links                  | <a href="#">_links</a>                  |  |
| block_storage           | <a href="#">block_storage</a>           | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.   |
| cloud_storage           | <a href="#">cloud_storage</a>           | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |
| create_time             | string                                  | Timestamp of aggregate creation.   |
| data_encryption         | <a href="#">data_encryption</a>         |  |
| dr_home_node            | <a href="#">dr_home_node</a>            | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | <a href="#">home_node</a>               | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | <a href="#">inactive_data_reporting</a> |  |
| inode_attributes        | <a href="#">inode_attributes</a>        |  |
| is_spare_low            | boolean                                 | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| metric                  | <a href="#">metric</a>                  | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                                  | Aggregate name.  |
| node                    | <a href="#">node</a>                    | Node where the aggregate currently resides.  |



| Name                  | Type                                     | Description  |
|-----------------------|--|--|
| recommendation_spares | array[ <a href="#">aggregate_spare</a> ] | Information on the aggregate's remaining hot spare disks.  |
| sidl_enabled          | boolean                                  | Specifies whether or not SIDL is enabled on the aggregate. |
| snaplock_type         | string                                   | SnapLock type.   |
| snapshot              | <a href="#">snapshot</a>                 |  |
| space                 | <a href="#">space</a>                    |  |
| state                 | string                                   | Operational state of the aggregate.                        |
| statistics            | <a href="#">statistics</a>               | The real time I/O statistics for the aggregate.            |
| uuid                  | string                                   | Aggregate UUID.  |
| volume-count          | integer                                  | Number of volumes in the aggregate.                        |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "block_storage": {
    "hybrid_cache": {
      "disk_count": 6,
      "raid_type": "raid_dp",
      "size": 1612709888,
      "storage_pools": {
        "storage_pool": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "storage_pool_1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      },
      "used": 26501122
    },
    "mirror": {
      "enabled": "",
      "state": "unmirrored"
    },
    "plexes": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "plex0"
    },
    "primary": {
      "checksum_style": "block",
      "disk_class": "performance",
      "disk_count": 8,
      "disk_type": "fc",
      "raid_size": 16,
      "raid_type": "raid_dp",
      "simulated_raid_groups": {
```

```

    "raid_type": "raid_dp"
  }
},
"storage_type": "hdd"
},
"cloud_storage": {
  "stores": {
    "cloud_store": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "store1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "used": 0
  }
},
"create_time": "2018-01-01T12:00:00-04:00",
"dr_home_node": {
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"home_node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"inactive_data_reporting": {
  "start_time": "2019-12-12T12:00:00-04:00"
},
"inode_attributes": {
  "file_private_capacity": 31136,
  "file_public_capacity": 31136,
  "files_private_used": 502,
  "files_total": 31136,
  "files_used": 97,
  "max_files_available": 31136,
  "max_files_possible": 2844525,
  "max_files_used": 97,
  "used_percent": 5,

```

```

    "version": 4
  },
  "is_spare_low": "",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"name": "node1_aggr_1",
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"name": "node1",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"recommendation_spares": {
  "checksum_style": "block",
  "disk_class": "solid_state",
  "disk_type": "fc",
  "is_partition": 1,
  "layout_requirements": {
    "aggregate_min_disks": 6,
    "raid_group": {

```

```

    "default": 16,
    "max": 28,
    "min": 5
  },
  "raid_type": "raid_dp"
},
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 10156769280,
"syncmirror_pool": "pool0",
"total": 10,
"usable": 9
},
"snaplock_type": "non_snaplock",
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"space": {
  "block_storage": {
    "aggregate_metadata": 2655,
    "aggregate_metadata_percent": 8,
    "available": 10156560384,
    "data_compacted_count": 1990000,
    "data_compaction_space_saved": 1996000,
    "data_compaction_space_saved_percent": 27,
    "full_threshold_percent": 0,
    "inactive_user_data": 304448,
    "inactive_user_data_percent": 0,
    "physical_used": 2461696,
    "physical_used_percent": 50,
    "size": 10156769280,
    "used": 2088960,
    "used_including_snapshot_reserve": 674685,
    "used_including_snapshot_reserve_percent": 35,
    "volume_deduplication_shared_count": 1990000,
    "volume_deduplication_space_saved": 1996000,

```

```

    "volume_deduplication_space_saved_percent": 27,
    "volume_footprints_percent": 14
  },
  "cloud_storage": {
    "used": 402743264
  },
  "efficiency": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots_flexclones": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "footprint": 608896,
  "snapshot": {
    "available": 2000,
    "reserve_percent": 20,
    "total": 5000,
    "used": 3000,
    "used_percent": 45
  }
},
"state": "online",
"statistics": {
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput_raw": {
    "read": 200,
    "total": 1000,

```

```

    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"uuid": "string",
"volume-count": 0
}

```

## Response

Status: 202, Accepted

| Name | Type     | Description |
|------|----------|-------------|
| job  | job_link |             |

## Example response

```

{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "uuid": "string"
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 460770     | The aggregate create job failed to create the aggregate. |
| 786438     | Failed to create an aggregate on the node.               |
| 786439     | An aggregate already uses the specified name.            |

| <b>Error Code</b> | <b>Description</b>   |
|-------------------|--|
| 786446            | The node is not in cluster.  |
| 786468            | VLDB is offline.   |
| 786819            | The value is invalid for the specified option at the current privilege level.  |
| 786902            | RAID-TEC aggregate is not fully supported.   |
| 786911            | Not every node in the cluster has the Data ONTAP version required for the feature.   |
| 787069            | Node is setup for MetroCluster over IP configuration; creating an unmirrored aggregate is not supported in this configuration. |
| 787092            | The target field cannot be specified for this operation.   |
| 918138            | Internal error. Failed to get encryption operation status.   |
| 1114292           | The required SnapLock license is not installed.  |
| 2425736           | No matching node found for the target UUID.  |
| 19726341          | Not enough eligible spare disks are available on the node.   |
| 19726344          | No recommendation can be made for this cluster.  |
| 19726357          | Automatic aggregate creation is not supported on MetroCluster with Fibre Channel (FC).   |
| 19726358          | Automatic aggregate creation is not supported on ONTAP Cloud.  |
| 19726373          | Recommendation specified for creating aggregates is not current.   |
| 19726378          | Failed to create recommended aggregates on one or more nodes.  |
| 19726382          | Another provisioning operation is in progress on this cluster. Wait a few minutes, and try the operation again.                |
| 19726386          | Encountered an error when retrieving licensing information on this cluster.  |
| 19726387          | No recommendation can be provided for this cluster within the license capacity.  |
| 19726401          | Aggregate recommendations are not supported when the DR group is not in the "normal" state.                                    |
| 19726402          | Internal error. Unable to determine the MetroCluster configuration state.  |
| 19726403          | Aggregate recommendation is not supported when there are no healthy target connections to remote storage.                      |



| Error Code | Description   |
|------------|---|
| 196608055  | Aggregate recommendation is not supported on this node because it does not support NetApp Aggregate Encryption (NAE). |
| 196608206  | Internal error. Failed to get encryption operation status.  |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

storage\_pool\_reference

Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pools

| Name                   | Type                                   | Description                       |
|------------------------|--|-----------------------------------|
| allocation_units_count | integer                                | Allocation count of storage pool. |
| storage_pool           | <a href="#">storage_pool_reference</a> | Shared Storage Pool               |

hybrid\_cache

Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs.

| Name       | Type    | Description  |
|------------|---------|--|
| disk_count | integer | Number of disks used in the cache tier of the aggregate. Only provided when <code>hybrid_cache.enabled</code> is 'true'. |
| enabled    | boolean | Specifies whether the aggregate uses HDDs with SSDs as a cache.  |

| Name          | Type                                   | Description  |
|---------------|--|--|
| raid_type     | string                                 | RAID type for SSD cache of the aggregate. Only provided when hybrid_cache.enabled is 'true'. |
| size          | integer                                | Total usable space in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'. |
| storage_pools | array[ <a href="#">storage_pools</a> ] | List of storage pool properties and allocation_units_count for aggregate.                    |
| used          | integer                                | Space used in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'.         |

#### mirror

| Name    | Type    | Description                       |
|---------|---------|-----------------------------------|
| enabled | boolean | Aggregate is SyncMirror protected |
| state   | string  |                                   |

#### plex\_reference

##### Plex

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

#### simulated\_raid\_groups

| Name                    | Type    | Description                                 |
|-------------------------|---------|---|
| added_data_disk_count   | integer | Number of added data disks in RAID group.   |
| added_parity_disk_count | integer | Number of added parity disks in RAID group. |
| data_disk_count         | integer | Number of data disks in RAID group.         |

| Name                       | Type    | Description  |
|----------------------------|---------|--|
| existing_data_disk_count   | integer | Number of existing data disks in the RAID group.                   |
| existing_parity_disk_count | integer | Number of existing parity disks in the RAID group.                 |
| is_partition               | boolean | Indicates whether the disk is partitioned (true) or whole (false). |
| name                       | string  | Name of the raid group.  |
| parity_disk_count          | integer | Number of parity disks in RAID group.                              |
| raid_type                  | string  | RAID type of the aggregate.  |
| usable_size                | integer | Usable size of each disk, in bytes.                                |

#### primary

Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.

| Name                  | Type   | Description  |
|-----------------------|--|--|
| checksum_style        | string   | The checksum style used by the aggregate.  |
| disk_class            | string   | The class of disks being used by the aggregate.  |
| disk_count            | integer  | Number of disks used in the aggregate. This includes parity disks, but excludes disks in the hybrid cache. |
| disk_type             | string   | The type of disk being used by the aggregate.  |
| raid_size             | integer  | Option to specify the maximum number of disks that can be included in a RAID group.                        |
| raid_type             | string   | RAID type of the aggregate.  |
| simulated_raid_groups | array[ <a href="#">simulated_raid_groups</a> ] |  |

## block\_storage

Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.

| Name            | Type                                    | Description   |
|-----------------|---|---|
| hybrid_cache    | <a href="#">hybrid_cache</a>            | Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs. |
| mirror          | <a href="#">mirror</a>                  |   |
| plexes          | array[ <a href="#">plex_reference</a> ] | Plex reference for each plex in the aggregate.  |
| primary         | <a href="#">primary</a>                 | Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.     |
| storage_type    | string                                  | Type of aggregate.  |
| uses_partitions | boolean                                 | If true, aggregate is using shared disks.   |

## cloud\_store

Cloud store

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

## cloud\_storage\_tier

| Name        | Type                        | Description   |
|-------------|-----------------------------|---|
| cloud_store | <a href="#">cloud_store</a> | Cloud store   |
| used        | integer                     | Capacity used in bytes in the cloud store by this aggregate. This is a cached value calculated every 5 minutes. |

## cloud\_storage

Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.

| Name                       | Type  | Description  |
|----------------------------|---|--|
| attach_eligible            | boolean                                     | Specifies whether the aggregate is eligible for a cloud store to be attached.  |
| stores                     | array[ <a href="#">cloud_storage_tier</a> ] | Configuration information for each cloud storage portion of the aggregate.   |
| tiering_fullness_threshold | integer                                     | The percentage of space in the performance tier that must be used before data is tiered out to the cloud store. Only valid for PATCH operations. |

data\_encryption

| Name                        | Type    | Description   |
|-----------------------------|---------|---|
| drive_protection_enabled    | boolean | Specifies whether the aggregate uses self-encrypting drives with data protection enabled.         |
| software_encryption_enabled | boolean | Specifies whether NetApp aggregate encryption is enabled. All data in the aggregate is encrypted. |

dr\_home\_node

Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

home\_node

Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### inactive\_data\_reporting

| Name       | Type    | Description   |
|------------|---------|---|
| enabled    | boolean | Specifies whether or not inactive data reporting is enabled on the aggregate. |
| start_time | string  | Timestamp at which inactive data reporting was enabled on the aggregate.      |

#### inode\_attributes

| Name                  | Type    | Description   |
|-----------------------|---------|---|
| file_private_capacity | integer | Number of files that can currently be stored on disk for system metadata files. This number will dynamically increase as more system files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> .    |
| file_public_capacity  | integer | Number of files that can currently be stored on disk for user-visible files. This number will dynamically increase as more user-visible files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

| Name                | Type    | Description  |
|---------------------|---------|--|
| files_private_used  | integer | Number of system metadata files used. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| files_total         | integer | Maximum number of user-visible files that this referenced file system can currently hold. If the referenced file system is restricted or offline, a value of 0 is returned.  |
| files_used          | integer | Number of user-visible files used in the referenced file system. If the referenced file system is restricted or offline, a value of 0 is returned.   |
| max_files_available | integer | The count of the maximum number of user-visible files currently allowable on the referenced file system.   |
| max_files_possible  | integer | The largest value to which the maxfiles-available parameter can be increased by reconfiguration, on the referenced file system.  |
| max_files_used      | integer | The number of user-visible files currently in use on the referenced file system.   |
| used_percent        | integer | The percentage of disk space currently in use based on user-visible file count on the referenced file system.  |



| Name    | Type    | Description  |
|---------|---------|--|
| version | integer | The inofile-version of the aggregate. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

### iops

The rate of I/O operations observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### latency

The round trip latency in microseconds observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |

| Name  | Type    | Description   |
|-------|---------|---|
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations.                    |

### throughput

The rate of throughput bytes per second observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### metric

The most recent sample of I/O metrics for the aggregate.

| Name                   | Type                    | Description  |
|------------------------|-------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a>  |  |
| duration               | string                  | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops                   | <a href="#">iops</a>    | The rate of I/O operations observed at the storage object.   |
| latency                | <a href="#">latency</a> | The round trip latency in microseconds observed at the storage object.   |

| Name       | Type                       | Description   |
|------------|----------------------------|---|
| status     | string                     | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | <a href="#">throughput</a> | The rate of throughput bytes per second observed at the storage object.   |
| timestamp  | string                     | The timestamp of the performance data.  |

node

Node where the aggregate currently resides.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

raid\_group

| Name    | Type    | Description                              |
|---------|---------|--|
| default | integer | Default number of disks in a RAID group. |

| Name | Type    | Description                                      |
|------|---------|--|
| max  | integer | Maximum number of disks allowed in a RAID group. |
| min  | integer | Minimum number of disks allowed in a RAID group. |

#### layout\_requirement

| Name                | Type                       | Description                                     |
|---------------------|----------------------------|---|
| aggregate_min_disks | integer                    | Minimum number of disks to create an aggregate. |
| default             | boolean                    | Indicates if this RAID type is the default.     |
| raid_group          | <a href="#">raid_group</a> |   |
| raid_type           | string                     | RAID type.                                      |

#### node

Node where the spares are assigned.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### aggregate\_spare

| Name                | Type  | Description   |
|---------------------|---|---|
| checksum_style      | string                                      | The checksum type that has been assigned to the spares.         |
| disk_class          | string                                      | Disk class of spares.   |
| disk_type           | string                                      | Type of disk.   |
| is_partition        | boolean                                     | Indicates whether a disk is partitioned (true) or whole (false) |
| layout_requirements | array[ <a href="#">layout_requirement</a> ] | Available RAID protections and their restrictions.              |

| Name            | Type                 | Description  |
|-----------------|----------------------|--|
| node            | <a href="#">node</a> | Node where the spares are assigned.  |
| size            | integer              | Usable size of each spare, in bytes.   |
| syncmirror_pool | string               | SyncMirror spare pool.   |
| total           | integer              | Total number of spares in the bucket. The total spare count for each class of spares also includes reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 10</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.11</li> </ul>    |
| usable          | integer              | Total number of usable spares in the bucket. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 9</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul> |

#### snapshot

| Name                | Type    | Description                                 |
|---------------------|---------|---|
| files_total         | integer | Total files allowed in Snapshot copies      |
| files_used          | integer | Total files created in Snapshot copies      |
| max_files_available | integer | Maximum files available for Snapshot copies |
| max_files_used      | integer | Files in use by Snapshot copies             |

#### block\_storage

| Name                                | Type    | Description  |
|-------------------------------------|---------|--|
| aggregate_metadata                  | integer | Space used by different metafiles and internal operations inside the aggregate, in bytes.  |
| aggregate_metadata_percent          | integer | Aggregate metadata as a percentage.  |
| available                           | integer | Space available in bytes.  |
| data_compacted_count                | integer | Amount of compacted data in bytes.   |
| data_compaction_space_saved         | integer | Space saved in bytes by compacting the data.   |
| data_compaction_space_saved_percent | integer | Percentage saved by compacting the data.   |
| full_threshold_percent              | integer | The aggregate used percentage at which 'monitor.volume.full' EMS is generated.   |
| inactive_user_data                  | integer | The size that is physically used in the block storage and has a cold temperature, in bytes. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data</code> or <code>**</code> . |

| Name                                     | Type    | Description   |
|--|---------|---|
| inactive_user_data_percent               | integer | The percentage of inactive user data in the block storage. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data_percent</code> or <code>**</code> . |
| physical_used                            | integer | Total physical used size of an aggregate in bytes.  |
| physical_used_percent                    | integer | Physical used percentage.   |
| size                                     | integer | Total usable space in bytes, not including WAFL reserve and aggregate Snapshot copy reserve.  |
| used                                     | integer | Space used or reserved in bytes. Includes volume guarantees and aggregate metadata.   |
| used_including_snapshot_reserve          | integer | Total used including the Snapshot copy reserve, in bytes.   |
| used_including_snapshot_reserve_percent  | integer | Total used including the Snapshot reserve as a percentage.  |
| volume_deduplication_shared_count        | integer | Amount of shared bytes counted by storage efficiency.   |
| volume_deduplication_space_saved         | integer | Amount of space saved in bytes by storage efficiency.   |
| volume_deduplication_space_saved_percent | integer | Percentage of space saved by storage efficiency.  |

| Name                      | Type    | Description   |
|---------------------------|---------|---|
| volume_footprints_percent | integer | A summation of volume footprints inside the aggregate, as a percentage. A volume's footprint is the amount of space being used for the volume in the aggregate. |

#### cloud\_storage

| Name | Type    | Description   |
|------|---------|---|
| used | integer | Used space in bytes in the cloud store. Only applicable for aggregates with a cloud store tier. |

#### efficiency

Storage efficiency.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots

Storage efficiency that does not include the savings provided by Snapshot copies.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots\_flexclones

Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes.



| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### snapshot

| Name            | Type    | Description                                      |
|-----------------|---------|--|
| available       | integer | Available space for Snapshot copies in bytes     |
| reserve_percent | integer | Percentage of space reserved for Snapshot copies |
| total           | integer | Total space for Snapshot copies in bytes         |
| used            | integer | Space used by Snapshot copies in bytes           |
| used_percent    | integer | Percentage of disk space used by Snapshot copies |

#### space

| Name                                     | Type   | Description   |
|--|--|---|
| block_storage                            | <a href="#">block_storage</a>                            |   |
| cloud_storage                            | <a href="#">cloud_storage</a>                            |   |
| efficiency                               | <a href="#">efficiency</a>                               | Storage efficiency.   |
| efficiency_without_snapshots             | <a href="#">efficiency_without_snapshots</a>             | Storage efficiency that does not include the savings provided by Snapshot copies.                       |
| efficiency_without_snapshots_flex_clones | <a href="#">efficiency_without_snapshots_flex_clones</a> | Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes. |

| Name      | Type                     | Description   |
|-----------|--------------------------|---|
| footprint | integer                  | A summation of volume footprints (including volume guarantees), in bytes. This includes all of the volume footprints in the block_storage tier and the cloud_storage tier. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or **. |
| snapshot  | <a href="#">snapshot</a> |   |

#### iops\_raw

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### latency\_raw

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

The real time I/O statistics for the aggregate.

| Name           | Type                           | Description   |
|----------------|--------------------------------|---|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| latency_raw    | <a href="#">latency_raw</a>    | The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.   |
| status         | string                         | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.  |

aggregate

| Name                    | Type                                    | Description  |
|-------------------------|---|--|
| _links                  | <a href="#">_links</a>                  |  |
| block_storage           | <a href="#">block_storage</a>           | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.   |
| cloud_storage           | <a href="#">cloud_storage</a>           | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |
| create_time             | string                                  | Timestamp of aggregate creation.   |
| data_encryption         | <a href="#">data_encryption</a>         |  |
| dr_home_node            | <a href="#">dr_home_node</a>            | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | <a href="#">home_node</a>               | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | <a href="#">inactive_data_reporting</a> |  |
| inode_attributes        | <a href="#">inode_attributes</a>        |  |
| is_spare_low            | boolean                                 | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or **. |
| metric                  | <a href="#">metric</a>                  | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                                  | Aggregate name.  |

| Name                  | Type                                     | Description  |
|-----------------------|--|--|
| node                  | <a href="#">node</a>                     | Node where the aggregate currently resides.                |
| recommendation_spares | array[ <a href="#">aggregate_spare</a> ] | Information on the aggregate's remaining hot spare disks.  |
| sidl_enabled          | boolean                                  | Specifies whether or not SIDL is enabled on the aggregate. |
| snaplock_type         | string                                   | SnapLock type.   |
| snapshot              | <a href="#">snapshot</a>                 |  |
| space                 | <a href="#">space</a>                    |  |
| state                 | string                                   | Operational state of the aggregate.                        |
| statistics            | <a href="#">statistics</a>               | The real time I/O statistics for the aggregate.            |
| uuid                  | string                                   | Aggregate UUID.  |
| volume-count          | integer                                  | Number of volumes in the aggregate.                        |

#### job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a collection of cloud stores used by an aggregate

GET /storage/aggregates/{aggregate.uuid}/cloud-stores

**Introduced In:** 9.6

Retrieves the collection of cloud stores used by an aggregate.

### Related ONTAP commands

- `storage aggregate object-store show`

### Parameters

| Name                           | Type    | In    | Required | Description  |
|--------------------------------|---------|-------|----------|--|
| aggregate.uuid                 | string  | path  | True     | Aggregate UUID   |
| unavailable_reason.<br>message | string  | query | False    | Filter by<br>unavailable_reason.<br>message<br><br>• Introduced in:<br>9.7 |
| primary                        | boolean | query | False    | Filter by primary  |
| aggregate.name                 | string  | query | False    | Filter by<br>aggregate.name<br><br>• Introduced in:<br>9.9                 |
| mirror_degraded                | boolean | query | False    | Filter by<br>mirror_degraded   |

| Name                        | Type          | In    | Required | Description   |
|-----------------------------|---------------|-------|----------|---|
| used                        | integer       | query | False    | Filter by used  |
| unreclaimed_space_threshold | integer       | query | False    | Filter by unreclaimed_space_threshold   |
| availability                | string        | query | False    | Filter by availability  |
| target.uuid                 | string        | query | False    | Filter by target.uuid   |
| target.name                 | string        | query | False    | Filter by target.name   |
| fields                      | array[string] | query | False    | Specify the fields to return.   |
| max_records                 | integer       | query | False    | Limit the number of records returned.   |
| return_records              | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout              | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by                    | array[string] | query | False    | Order results by specified fields and optional [asc   |



## Response

Status: 200, Ok

| Name        | Type                                 | Description       |
|-------------|--------------------------------------|-------------------|
| _links      | <a href="#">_links</a>               |                   |
| num_records | integer                              | Number of records |
| records     | array[ <a href="#">cloud_store</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "aggregate": {
      "name": "aggr1"
    },
    "availability": "available",
    "target": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "target1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "unavailable_reason": {
      "message": "string"
    },
    "unreclaimed_space_threshold": 20,
    "used": 0
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

Aggregate

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

target

Cloud target

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

unavailable\_reason

| Name    | Type   | Description                                    |
|---------|--------|--|
| message | string | Indicates why the object store is unavailable. |

cloud\_store

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name                        | Type                               | Description  |
|-----------------------------|------------------------------------|--|
| aggregate                   | <a href="#">aggregate</a>          | Aggregate  |
| availability                | string                             | Availability of the object store.  |
| mirror_degraded             | boolean                            | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool.   |
| primary                     | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.  |
| target                      | <a href="#">target</a>             | Cloud target   |
| unavailable_reason          | <a href="#">unavailable_reason</a> |  |
| unreclaimed_space_threshold | integer                            | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer                            | The amount of object space used. Calculated every 5 minutes and cached.  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |
| message   | string                                   | Error message     |

| Name   | Type   | Description                                 |
|--------|--------|---|
| target | string | The target parameter that caused the error. |

## Attach an object store to an aggregate or add a second object store as a mirror

POST /storage/aggregates/{aggregate.uuid}/cloud-stores

Introduced In: 9.6

Attaches an object store to an aggregate, or adds a second object store as a mirror.

### Required properties

- `target.uuid` or `target.name` - UUID or name of the cloud target.

### Recommended optional properties

- `primary` - *true* if the object store is primary or *false* if it is a mirror.
- `allow_flexgroups` - Allow attaching object store to an aggregate containing FlexGroup constituents.
- `check_only` - Validate only and do not add the cloud store.

### Default property values

- `primary` - *true*
- `allow_flexgroups` - *false*
- `check_only` - *false*

### Related ONTAP commands

- `storage aggregate object-store attach`
- `storage aggregate object-store mirror`

### Parameters

| Name           | Type   | In   | Required | Description    |
|----------------|--------|------|----------|----------------|
| aggregate.uuid | string | path | True     | Aggregate UUID |

| Name             | Type    | In    | Required | Description   |
|------------------|---------|-------|----------|---|
| allow_flexgroups | boolean | query | False    | This optional parameter allows attaching object store to an aggregate containing FlexGroup constituents. The default value is false. Mixing FabricPools and non-FabricPools within a FlexGroup is not recommended. All aggregates hosting constituents of a FlexGroup should be attached to the object store. |
| check_only       | boolean | query | False    | Validate only and do not add the cloud store.   |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul>  |

## Request Body

| Name         | Type                      | Description                       |
|--------------|---------------------------|-----------------------------------|
| _links       | <a href="#">_links</a>    |                                   |
| aggregate    | <a href="#">aggregate</a> | Aggregate                         |
| availability | string                    | Availability of the object store. |



| Name                        | Type                               | Description  |
|-----------------------------|------------------------------------|--|
| mirror_degraded             | boolean                            | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool.   |
| primary                     | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.  |
| target                      | <a href="#">target</a>             | Cloud target   |
| unavailable_reason          | <a href="#">unavailable_reason</a> |  |
| unreclaimed_space_threshold | integer                            | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer                            | The amount of object space used. Calculated every 5 minutes and cached.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregate": {
    "name": "aggr1"
  },
  "availability": "available",
  "target": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "target1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "unavailable_reason": {
    "message": "string"
  },
  "unreclaimed_space_threshold": 20,
  "used": 0
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

Aggregate

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

target

Cloud target

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

unavailable\_reason

| Name    | Type   | Description                                    |
|---------|--------|--|
| message | string | Indicates why the object store is unavailable. |

cloud\_store

| Name         | Type                      | Description                       |
|--------------|---------------------------|-----------------------------------|
| _links       | <a href="#">_links</a>    |                                   |
| aggregate    | <a href="#">aggregate</a> | Aggregate                         |
| availability | string                    | Availability of the object store. |

| Name                        | Type                               | Description  |
|-----------------------------|------------------------------------|--|
| mirror_degraded             | boolean                            | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool.   |
| primary                     | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.  |
| target                      | <a href="#">target</a>             | Cloud target   |
| unavailable_reason          | <a href="#">unavailable_reason</a> |  |
| unreclaimed_space_threshold | integer                            | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer                            | The amount of object space used. Calculated every 5 minutes and cached.  |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |

| Name    | Type   | Description                                 |
|---------|--------|---|
| code    | string | Error code                                  |
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Remove a cloud target from an aggregate

```
DELETE /storage/aggregates/{aggregate.uuid}/cloud-stores/{target.uuid}
```

**Introduced In:** 9.6

Removes the specified cloud target from the aggregate. Only removal of a mirror is allowed. The primary cannot be removed. This request starts a job and returns a link to that job.

### Related ONTAP commands

- `storage aggregate object-store unmirror`

### Parameters

| Name           | Type   | In   | Required | Description       |
|----------------|--------|------|----------|-------------------|
| aggregate.uuid | string | path | True     | Aggregate UUID    |
| target.uuid    | string | path | True     | Cloud target UUID |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve the cloud store for an aggregate

GET /storage/aggregates/{aggregate.uuid}/cloud-stores/{target.uuid}

## Introduced In: 9.6

Retrieves the cloud store for the aggregate using the specified cloud target UUID.

## Related ONTAP commands

- `storage aggregate object-store show`

## Parameters

| Name           | Type          | In    | Required | Description                   |
|----------------|---------------|-------|----------|-------------------------------|
| aggregate.uuid | string        | path  | True     | Aggregate UUID                |
| target.uuid    | string        | path  | True     | Cloud target UUID             |
| fields         | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name               | Type                               | Description  |
|--------------------|------------------------------------|--|
| _links             | <a href="#">_links</a>             |  |
| aggregate          | <a href="#">aggregate</a>          | Aggregate  |
| availability       | string                             | Availability of the object store.  |
| mirror_degraded    | boolean                            | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool. |
| primary            | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.        |
| target             | <a href="#">target</a>             | Cloud target   |
| unavailable_reason | <a href="#">unavailable_reason</a> |  |

| Name                        | Type    | Description  |
|-----------------------------|---------|--|
| unreclaimed_space_threshold | integer | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer | The amount of object space used. Calculated every 5 minutes and cached.  |

### Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregate": {
    "name": "aggr1"
  },
  "availability": "available",
  "target": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "target1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "unavailable_reason": {
    "message": "string"
  },
  "unreclaimed_space_threshold": 20,
  "used": 0
}
```

### Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

Aggregate

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

target

Cloud target

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

unavailable\_reason

| Name    | Type   | Description                                    |
|---------|--------|--|
| message | string | Indicates why the object store is unavailable. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a cloud store

PATCH /storage/aggregates/{aggregate.uuid}/cloud-stores/{target.uuid}

**Introduced In:** 9.6

Updates the cloud store specified by the UUID with the fields in the body. This request starts a job and returns a link to that job.

### Related ONTAP commands

- `storage aggregate object-store modify`

### Parameters

| Name           | Type   | In   | Required | Description       |
|----------------|--------|------|----------|-------------------|
| aggregate.uuid | string | path | True     | Aggregate UUID    |
| target.uuid    | string | path | True     | Cloud target UUID |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Request Body

| Name            | Type                      | Description  |
|-----------------|---------------------------|--|
| _links          | <a href="#">_links</a>    |  |
| aggregate       | <a href="#">aggregate</a> | Aggregate  |
| availability    | string                    | Availability of the object store.  |
| mirror_degraded | boolean                   | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool. |

| Name                        | Type                               | Description  |
|-----------------------------|------------------------------------|--|
| primary                     | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.  |
| target                      | <a href="#">target</a>             | Cloud target   |
| unavailable_reason          | <a href="#">unavailable_reason</a> |  |
| unreclaimed_space_threshold | integer                            | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer                            | The amount of object space used. Calculated every 5 minutes and cached.  |



## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregate": {
    "name": "aggr1"
  },
  "availability": "available",
  "target": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "target1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "unavailable_reason": {
    "message": "string"
  },
  "unreclaimed_space_threshold": 20,
  "used": 0
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

Aggregate

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

target

Cloud target

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

unavailable\_reason

| Name    | Type   | Description                                    |
|---------|--------|--|
| message | string | Indicates why the object store is unavailable. |

cloud\_store

| Name         | Type                      | Description                       |
|--------------|---------------------------|-----------------------------------|
| _links       | <a href="#">_links</a>    |                                   |
| aggregate    | <a href="#">aggregate</a> | Aggregate                         |
| availability | string                    | Availability of the object store. |

| Name                        | Type                               | Description  |
|-----------------------------|------------------------------------|--|
| mirror_degraded             | boolean                            | This field identifies if the mirror cloud store is in sync with the primary cloud store of a FabricPool.   |
| primary                     | boolean                            | This field indicates whether the cloud store is the primary cloud store of a mirrored FabricPool.  |
| target                      | <a href="#">target</a>             | Cloud target   |
| unavailable_reason          | <a href="#">unavailable_reason</a> |  |
| unreclaimed_space_threshold | integer                            | Usage threshold for reclaiming unused space in the cloud store. Valid values are 0 to 99. The default value depends on the provider type. This can be specified in PATCH but not POST. |
| used                        | integer                            | The amount of object space used. Calculated every 5 minutes and cached.  |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |

| Name    | Type   | Description                                 |
|---------|--------|---|
| code    | string | Error code                                  |
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Manage storage aggregate plexes

### Storage aggregates aggregate.uuid plexes endpoint overview

#### Overview

The Storage Aggregate Plex API provides relevant state information for each plex in the aggregate. For each plex, details are provided for the RAID groups in the plex and the disks that make up each RAID group.

#### Examples

##### Retrieving all aggregates and plexes

The following example shows the response with a list of aggregates and plexes:

#### The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/*/plexes" -H "accept: application/json"</mgmt-ip>
```

#### The response:

```
{ "records": [ { "aggregate": { "uuid": "04b7296e-a302-42a6-a2a9-dda6be054b29", "name": "test2" }, "name": "plex0" }, { "aggregate": { "uuid": "04b7296e-a302-42a6-a2a9-dda6be054b29", "name": "test2" }, "name": "plex1" }, { "aggregate": { "uuid": "66c4b221-65ff-4211-9b58-ada3c6fc41af", "name": "test" }, "name": "plex0" }, { "aggregate": { "uuid": "66c4b221-65ff-4211-9b58-ada3c6fc41af", "name": "test" }, "name": "plex1" }, { "aggregate": { "uuid": "7ee89e48-5d81-4609-9e1b-5d8d0995a886", "name": "aggr1" }, "name": "plex0" }, { "aggregate": { "uuid": "8bb2e3bf-c4f1-4748-9033-ca9231cf1c40", "name": "test3" }, "name": "plex0" }, { "aggregate": { "uuid": "8bb2e3bf-c4f1-4748-9033-ca9231cf1c40", "name": "test3" }, "name": "plex1" }, { "aggregate": { "uuid": "8f13de5c-99cf-4ada-884c-3cc32deb304a", "name": "aggr2" }, "name": "plex0" } ], "num_records": 8 }
```

```
### Retrieving a specific plex in all aggregates
```

The following example shows the response with a list of specific plexes in all aggregates:

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/*/plexes/plex0" -H "accept: application/json"
```

```

# The response:
{
  "records": [
    {
      "aggregate": {
        "uuid": "04b7296e-a302-42a6-a2a9-dda6be054b29",
        "name": "test2"
      },
      "name": "plex0"
    },
    {
      "aggregate": {
        "uuid": "66c4b221-65ff-4211-9b58-ada3c6fc41af",
        "name": "test"
      },
      "name": "plex0"
    },
    {
      "aggregate": {
        "uuid": "7ee89e48-5d81-4609-9e1b-5d8d0995a886",
        "name": "aggr1",
      },
      "name": "plex0",
    },
    {
      "aggregate": {
        "uuid": "8bb2e3bf-c4f1-4748-9033-ca9231cf1c40",
        "name": "test3",
      },
      "name": "plex0",
    },
    {
      "aggregate": {
        "uuid": "8f13de5c-99cf-4ada-884c-3cc32deb304a",
        "name": "aggr2",
      },
      "name": "plex0"
    }
  ],
  "num_records": 8
}

```

### Retrieving the list of plexes in an aggregate

The following example shows the response with the list of plexes in an aggregate:

```

# The API:
/api/storage/aggregates/{uuid}/plexes

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c/plexes" -H "accept: application/json"

# The response:
{
  "records": [
    {
      "name": "plex0",
    },
    {
      "name": "plex4",
    }
  ],
  "num_records": 2,
}

```

### Retrieving a specific plex in an aggregate

The following example shows the response when requesting a specific plex of an aggregate:

```

# The API:
/api/storage/aggregates/{uuid}/plexes/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c/plexes/plex0" -H "accept: application/json"

# The response:
{
  "aggregate": {
    "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
    "name": "test1",
  },
  "name": "plex0",
  "online": true,
  "state": "normal",
  "pool": "pool0",
  "resync": {
    "active": false
  },
  "raid_groups": [

```

```

{
  "name": "rg0",
  "raid_type": "raid_dp",
  "cache_tier": false,
  "degraded": false,
  "recomputing_parity": {
    "active": false
  },
  "reconstruct": {
    "active": false
  },
  "disks": [
    {
      "position": "dparity",
      "state": "normal",
      "type": "ssd",
      "usable_size": 86769664,
      "disk": {
        "name": "1.1.29",
      }
    },
    {
      "position": "parity",
      "state": "normal",
      "type": "ssd",
      "usable_size": 86769664,
      "disk": {
        "name": "1.1.4",
      }
    },
    {
      "position": "data",
      "state": "normal",
      "type": "ssd",
      "usable_size": 86769664,
      "disk": {
        "name": "1.1.30",
      }
    },
    {
      "position": "data",
      "state": "normal",
      "type": "ssd",
      "usable_size": 86769664,
      "disk": {
        "name": "1.1.5",
      }
    }
  ]
}

```



```

    }
  },
  {
    "position": "data",
    "state": "normal",
    "type": "ssd",
    "usable_size": 86769664,
    "disk": {
      "name": "1.1.31",
    }
  },
  {
    "position": "data",
    "state": "normal",
    "type": "ssd",
    "usable_size": 86769664,
    "disk": {
      "name": "1.1.6",
    }
  }
]
}
],
}

```

## Retrieve a collection of plexes for an aggregate

GET /storage/aggregates/{aggregate.uuid}/plexes

**Introduced In:** 9.6

Retrieves the collection of plexes for the specified aggregate.

### Related ONTAP commands

- storage aggregate plex show

### Parameters

| Name           | Type   | In    | Required | Description              |
|----------------|--------|-------|----------|--------------------------|
| aggregate.uuid | string | path  | True     | Aggregate UUID           |
| aggregate.name | string | query | False    | Filter by aggregate.name |
| state          | string | query | False    | Filter by state          |

| Name                                   | Type    | In    | Required | Description  |
|--|---------|-------|----------|--|
| raid_groups.reconstruct.active         | boolean | query | False    | Filter by raid_groups.reconstruct.active<br><br>• Introduced in: 9.7         |
| raid_groups.reconstruct.percent        | integer | query | False    | Filter by raid_groups.reconstruct.percent<br><br>• Introduced in: 9.7        |
| raid_groups.raid_type                  | string  | query | False    | Filter by raid_groups.raid_type<br><br>• Introduced in: 9.9                  |
| raid_groups.recomputing_parity.active  | boolean | query | False    | Filter by raid_groups.recomputing_parity.active<br><br>• Introduced in: 9.7  |
| raid_groups.recomputing_parity.percent | integer | query | False    | Filter by raid_groups.recomputing_parity.percent<br><br>• Introduced in: 9.7 |
| raid_groups.cache_tier                 | boolean | query | False    | Filter by raid_groups.cache_tier<br><br>• Introduced in: 9.7                 |
| raid_groups.degraded                   | boolean | query | False    | Filter by raid_groups.degraded<br><br>• Introduced in: 9.7                   |

| Name                          | Type    | In    | Required | Description   |
|-------------------------------|---------|-------|----------|---|
| raid_groups.disks.disk.name   | string  | query | False    | Filter by raid_groups.disks.disk.name<br><br>• Introduced in: 9.7   |
| raid_groups.disks.position    | string  | query | False    | Filter by raid_groups.disks.position<br><br>• Introduced in: 9.7    |
| raid_groups.disks.usable_size | integer | query | False    | Filter by raid_groups.disks.usable_size<br><br>• Introduced in: 9.7 |
| raid_groups.disks.state       | string  | query | False    | Filter by raid_groups.disks.state<br><br>• Introduced in: 9.7       |
| raid_groups.disks.type        | string  | query | False    | Filter by raid_groups.disks.type<br><br>• Introduced in: 9.7        |
| raid_groups.name              | string  | query | False    | Filter by raid_groups.name<br><br>• Introduced in: 9.7              |
| pool                          | string  | query | False    | Filter by pool  |
| name                          | string  | query | False    | Filter by name  |
| online                        | boolean | query | False    | Filter by online  |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| resync.active  | boolean       | query | False    | Filter by resync.active   |
| resync.percent | integer       | query | False    | Filter by resync.percent  |
| resync.level   | string        | query | False    | Filter by resync.level  |
| fields         | array[string] | query | False    | Specify the fields to return.   |
| max_records    | integer       | query | False    | Limit the number of records returned.   |
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                          | Description       |
|-------------|-------------------------------|-------------------|
| _links      | <a href="#">_links</a>        |                   |
| error       | <a href="#">error</a>         |                   |
| num_records | integer                       | Number of records |
| records     | array[ <a href="#">plex</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "records": {
    "aggregate": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "name": "plex0",
    "pool": "pool0",
    "raid_groups": {
      "disks": {
        "disk": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "1.0.1"
        },
        "position": "data",
        "state": "normal",
        "type": "ssd",
        "usable_size": 947912704
      }
    }
  }
}
```

```

    },
    "name": "rg0",
    "raid_type": "raid_dp",
    "recomputing_parity": {
      "percent": 10
    },
    "reconstruct": {
      "percent": 10
    }
  },
  "resync": {
    "level": "full",
    "percent": 10
  },
  "state": "normal"
}
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

## Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

## disk

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

## raid\_group\_disk

| Name        | Type                 | Description                                     |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> |   |
| position    | string               | The position of the disk within the RAID group. |
| state       | string               | The state of the disk within the RAID group.    |
| type        | string               | Disk interface type                             |
| usable_size | integer              | Size in bytes that is usable by the aggregate.  |

## recomputing\_parity

| Name    | Type    | Description                      |
|---------|---------|----------------------------------|
| active  | boolean | RAID group is recomputing parity |
| percent | integer | Recomputing parity percentage    |

## reconstruct

| Name    | Type    | Description   |
|---------|---------|---|
| active  | boolean | One or more disks in this RAID group are being reconstructed. |
| percent | integer | Reconstruct percentage  |

## raid\_group

| Name       | Type    | Description                |
|------------|---------|----------------------------|
| cache_tier | boolean | RAID group is a cache tier |

| Name               | Type                   | Description   |
|--------------------|------------------------|---|
| degraded           | boolean                | RAID group is degraded. A RAID group is degraded when at least one disk from that group has failed or is offline. |
| disks              | array[raid_group_disk] |   |
| name               | string                 | RAID group name   |
| raid_type          | string                 | RAID type of the raid group.  |
| recomputing_parity | recomputing_parity     |   |
| reconstruct        | reconstruct            |   |

#### resync

| Name    | Type    | Description                                       |
|---------|---------|---|
| active  | boolean | Plex is being resynchronized to its mirrored plex |
| level   | string  | Plex resyncing level                              |
| percent | integer | Plex resyncing percentage                         |

#### plex

| Name        | Type              | Description                |
|-------------|-------------------|----------------------------|
| aggregate   | aggregate         |                            |
| name        | string            | Plex name                  |
| online      | boolean           | Plex is online             |
| pool        | string            | SyncMirror pool assignment |
| raid_groups | array[raid_group] |                            |
| resync      | resync            |                            |
| state       | string            | Plex state                 |

## Retrieve a plex specified by the aggregate UUID and plex name

GET /storage/aggregates/{aggregate.uuid}/plexes/{name}

## Introduced In: 9.6

Retrieves the plex specified by the aggregate UUID and plex name.

### Related ONTAP commands

- `storage aggregate plex show`

### Parameters

| Name           | Type          | In    | Required | Description                   |
|----------------|---------------|-------|----------|-------------------------------|
| aggregate.uuid | string        | path  | True     | Aggregate UUID                |
| name           | string        | path  | True     | Plex name                     |
| fields         | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name        | Type                                | Description                |
|-------------|-------------------------------------|----------------------------|
| aggregate   | <a href="#">aggregate</a>           |                            |
| name        | string                              | Plex name                  |
| online      | boolean                             | Plex is online             |
| pool        | string                              | SyncMirror pool assignment |
| raid_groups | array[ <a href="#">raid_group</a> ] |                            |
| resync      | <a href="#">resync</a>              |                            |
| state       | string                              | Plex state                 |

## Example response

```
{
  "aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "plex0",
  "pool": "pool0",
  "raid_groups": {
    "disks": {
      "disk": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "1.0.1"
      },
      "position": "data",
      "state": "normal",
      "type": "ssd",
      "usable_size": 947912704
    },
    "name": "rg0",
    "raid_type": "raid_dp",
    "recomputing_parity": {
      "percent": 10
    },
    "reconstruct": {
      "percent": 10
    }
  },
  "resync": {
    "level": "full",
    "percent": 10
  },
  "state": "normal"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregate

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

disk

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

raid\_group\_disk

| Name        | Type                 | Description                                     |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> |   |
| position    | string               | The position of the disk within the RAID group. |
| state       | string               | The state of the disk within the RAID group.    |
| type        | string               | Disk interface type                             |
| usable_size | integer              | Size in bytes that is usable by the aggregate.  |

recomputing\_parity

| Name    | Type    | Description                      |
|---------|---------|----------------------------------|
| active  | boolean | RAID group is recomputing parity |
| percent | integer | Recomputing parity percentage    |

#### reconstruct

| Name    | Type    | Description   |
|---------|---------|---|
| active  | boolean | One or more disks in this RAID group are being reconstructed. |
| percent | integer | Reconstruct percentage  |

#### raid\_group

| Name               | Type                               | Description   |
|--------------------|------------------------------------|---|
| cache_tier         | boolean                            | RAID group is a cache tier  |
| degraded           | boolean                            | RAID group is degraded. A RAID group is degraded when at least one disk from that group has failed or is offline. |
| disks              | array[raid_group_disk]             |   |
| name               | string                             | RAID group name   |
| raid_type          | string                             | RAID type of the raid group.  |
| recomputing_parity | <a href="#">recomputing_parity</a> |   |
| reconstruct        | <a href="#">reconstruct</a>        |   |

#### resync

| Name    | Type    | Description                                       |
|---------|---------|---|
| active  | boolean | Plex is being resynchronized to its mirrored plex |
| level   | string  | Plex resyncing level                              |
| percent | integer | Plex resyncing percentage                         |

#### error\_arguments



| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage aggregates

### Storage aggregates UUID endpoint overview

#### Updating storage aggregates

The PATCH operation is used to modify properties of the aggregate. There are several properties that can be modified on an aggregate. Only one property can be modified for each PATCH request. PATCH operations on the aggregate's disk count will be blocked while one or more nodes in the cluster are simulating or implementing automatic aggregate creation.

The following is a list of properties that can be modified using the PATCH operation including a brief description for each:

- name - This property can be changed to rename the aggregate.
- node.name and node.uuid - Either property can be updated in order to relocate the aggregate to a different node in the cluster.
- state - This property can be changed to 'online' or 'offline'. Setting an aggregate 'offline' would automatically offline all the volumes currently hosted on the aggregate.
- block\_storage.mirror.enabled - This property can be changed from 'false' to 'true' in order to mirror the aggregate, if the system is capable of doing so.
- block\_storage.primary.disk\_count - This property can be updated to increase the number of disks in an aggregate.
- block\_storage.primary.raid\_size - This property can be updated to set the desired RAID size.
- block\_storage.primary.raid\_type - This property can be updated to set the desired RAID type.
- cloud\_storage.tiering\_fullness\_threshold - This property can be updated to set the desired tiering fullness threshold if using FabricPool.

- `data_encryption.software_encryption_enabled` - This property enables or disables NAE on the aggregate.
- `block_storage.hybrid_cache.storage_pools.allocation_units_count` - This property can be updated to add a storage pool to the aggregate specifying the number of allocation units.
- `block_storage.hybrid_cache.storage_pools.name` - This property can be updated to add a storage pool to the aggregate specifying the storage pool name. `block_storage.hybrid_cache.storage_pools.uuid` or this field must be specified with `block_storage.hybrid_cache.storage_pools.allocation_units_count`.
- `block_storage.hybrid_cache.storage_pools.uuid` - This property can be updated to add a storage pool to the aggregate specifying the storage pool uuid. `block_storage.hybrid_cache.storage_pools.name` or this field must be specified with `block_storage.hybrid_cache.storage_pools.allocation_units_count`.
- `block_storage.hybrid_cache.raid_type` - This property can be specified on the first time addition of a storage pool to the aggregate. When specifying a raidtype of `raid4`, the node is required to have spare SSDs for the storage pool as well.

### Aggregate expansion

The PATCH operation also supports automatically expanding an aggregate based on the spare disks which are present within the system. Running PATCH with the query `"auto_provision_policy"` set to `"expand"` starts the recommended expansion job. In order to see the expected change in capacity before starting the job, call GET on an aggregate instance with the query `"auto_provision_policy"` set to `"expand"`.

### Manual simulated aggregate expansion

The PATCH operation also supports simulated manual expansion of an aggregate. Running PATCH with the query `"simulate"` set to `"true"` and `"block_storage.primary.disk_count"` set to the final disk count will start running the prechecks associated with expanding the aggregate to the proposed size. The response body will include information on how many disks the aggregate can be expanded to, any associated warnings, along with the proposed final size of the aggregate.

### Deleting storage aggregates

If volumes exist on an aggregate, they must be deleted or moved before the aggregate can be deleted. See the `/storage/volumes` API for details on moving or deleting volumes.

### Adding a storage pool to an aggregate

A storage pool can be added to an aggregate by patching the field `"block_storage.hybrid_cache.storage_pools.allocation_units_count"` while also specifying the specific storage pool using the `"block_storage.hybrid_cache.storage_pools.name"` or `"block_storage.hybrid_cache.storage_pools.uuid"`. Subsequent patches to the aggregate can be completed to increase allocation unit counts or adding additional storage pools. On the first time addition of a storage pool to the aggregate, the raidtype can be optionally specified using the `"block_storage.hybrid_cache.raid_type"` field.

## Examples

### Retrieving a specific aggregate from the cluster

The following example shows the response of the requested aggregate. If there is no aggregate with the requested UUID, an error is returned.

```
# The API:
```

```
/api/storage/aggregates/{uuid}
```

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/870dd9f2-bdfa-4167-  
b692-57d1cec874d4" -H "accept: application/json"
```

```
# The response:
```

```
{  
  "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",  
  "name": "test1",  
  "node": {  
    "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",  
    "name": "node-1",  
  },  
  "home_node": {  
    "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",  
    "name": "node-1",  
  },  
  "space": {  
    "block_storage": {  
      "size": 235003904,  
      "available": 191942656,  
      "used": 43061248,  
      "full_threshold_percent": 98,  
      "physical_used": 5271552,  
      "physical_used_percent": 1,  
      "volume_footprints_percent": 14,  
      "aggregate_metadata": 2655,  
      "aggregate_metadata_percent": 8,  
      "used_including_snapshot_reserve": 674685,  
      "used_including_snapshot_reserve_percent": 35,  
      "data_compacted_count": 666666,  
      "data_compaction_space_saved": 654566,  
      "data_compaction_space_saved_percent": 47,  
      "volume_deduplication_shared_count": 567543,  
      "volume_deduplication_space_saved": 23765,  
      "volume_deduplication_space_saved_percent": 32  
    },  
    "snapshot": {  
      "used_percent": 45,  
      "available": 2000,  
      "total": 5000,  
      "used": 3000,  
      "reserve_percent": 20  
    },  
    "cloud_storage": {
```

```

    "used": 0
  },
  "efficiency": {
    "savings": 1408029,
    "ratio": 6.908119720880661,
    "logical_used": 1646350
  },
  "efficiency_without_snapshots": {
    "savings": 0,
    "ratio": 1,
    "logical_used": 737280
  },
  "efficiency_without_snapshots_flexclones": {
    "savings": 5000,
    "ratio": 2,
    "logical_used": 10000
  }
},
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"state": "online",
"snaplock_type": "non_snaplock",
"create_time": "2018-12-04T15:40:38-05:00",
"data_encryption": {
  "software_encryption_enabled": false,
  "drive_protection_enabled": false
},
"block_storage": {
  "uses_partitions": false,
  "storage_type": "vmdisk",
  "primary": {
    "disk_count": 6,
    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "raid_size": 24,
    "checksum_style": "block",
    "disk_type": "ssd"
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {

```

```

    "enabled": false,
    "state": "unmirrored"
  },
  "plexes": [
    {
      "name": "plex0",
    }
  ]
},
"cloud_storage": {
  "attach_eligible": false
},
"inode_attributes": {
  "files_total": 31136,
  "files_used": 97,
  "max_files_available": 31136,
  "max_files_possible": 2844525,
  "max_files_used": 97,
  "used_percent": 5
},
"volume_count": 0,
}

```

### Retrieving statistics and metric for an aggregate

In this example, the API returns the "statistics" and "metric" properties for the aggregate requested.

```

#The API:
/api/storage/aggregates/{uuid}?fields=statistics,metric

#The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/538bf337-1b2c-11e8-bad0-005056b48388?fields=statistics,metric" -H "accept: application/json"

#The response:
{
  "uuid": "538bf337-1b2c-11e8-bad0-005056b48388",
  "name": "aggr4",
  "metric": {
    "timestamp": "2019-07-08T22:16:45Z",
    "duration": "PT15S",
    "status": "ok",
    "throughput": {
      "read": 7099,
      "write": 840226,
      "other": 193293789,
    }
  }
}

```

```

    "total": 194141115
  },
  "latency": {
    "read": 149,
    "write": 230,
    "other": 123,
    "total": 124
  },
  "iops": {
    "read": 1,
    "write": 17,
    "other": 11663,
    "total": 11682
  },
},
"statistics": {
  "timestamp": "2019-07-08T22:17:09Z",
  "status": "ok",
  "throughput_raw": {
    "read": 3106045952,
    "write": 63771742208,
    "other": 146185560064,
    "total": 213063348224
  },
  "latency_raw": {
    "read": 54072313,
    "write": 313354426,
    "other": 477201985,
    "total": 844628724
  },
  "iops_raw": {
    "read": 328267,
    "write": 1137230,
    "other": 1586535,
    "total": 3052032
  }
},
}

```

For more information and examples on viewing historical performance metrics for any given aggregate, see [DOC /storage/aggregates/{uuid}/metrics](#)

### Simulating aggregate expansion

The following example shows the response for a simulated data aggregate expansion based on the values of the 'block\_storage.primary.disk\_count' attribute passed in. The query does not modify the existing aggregate but returns how the aggregate will look after the expansion along with any associated warnings. Simulated

data aggregate expansion will be blocked while one or more nodes in the cluster are simulating or implementing automatic aggregate creation. This will be reflected in the following attributes:

- `space.block_storage.size` - Total usable space in bytes, not including WAFL reserve and aggregate Snapshot copy reserve.
- `block_storage.primary.disk_count` - Number of disks that could be used to create the aggregate.

```
# The API:
/api/storage/aggregates/{uuid}?simulate=true

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/aggregates/cae60cfe-deae-42bd-babb-ef437d118314?simulate=true" -H "accept: application/json" -d '{"block_storage": {"primary": {"disk_count": 13}}}'

# The response:
{
  "warnings": [
    {
      "name": "node_2_SSD_1",
      "warning": {
        "message": "One or more disks will not be added. 10 disks specified, 9 disks will be added.",
        "code": 787170,
        "arguments": [
          "10",
          "9"
        ]
      }
    }
  ],
  "num_records": 1,
  "records": [
    {
      "uuid": "cae60cfe-deae-42bd-babb-ef437d118314",
      "name": "node_2_SSD_1",
      "node": {
        "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
        "name": "node-2",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/4046dda8-f802-11e8-8f6d-005056bb2030"
          }
        }
      }
    }
  ],
}
```

```

"space": {
  "block_storage": {
    "size": 1116180480
  }
},
"block_storage": {
  "primary": {
    "disk_count": 12,
    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "disk_type": "ssd",
    "raid_size": 12,
    "simulated_raid_groups": [
      {
        "name": "test/plex0/rg0",
        "existing_parity_disk_count": 2,
        "added_parity_disk_count": 0,
        "existing_data_disk_count": 1,
        "added_data_disk_count": 9,
        "usable_size": 12309487,
        "is_partition": false
      }
    ]
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {
    "enabled": false
  }
},
}
]
}

```

### Simulating a manual aggregate expansion with raid group query

The following example shows the response for a manual aggregate expansion based on the values of the 'block\_storage.primary.disk\_count' attribute passed in. The query internally maps out the appropriate expansion as well as warnings that may be associated and lays out the new raidgroups in a more detailed view. An additional query can be passed in to specify raidgroup addition by new raidgroup, all raidgroups or a specific raidgroup.

```

# The API:
/api/storage/aggregate/{uuid}?simulate=true&raid_group=[new#124;all#124;
rgX]

```



```

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/aggregates/cae60cfe-deae-42bd-babb-ef437d118314?simulate=true&raid_group=new" -H "accept: application/json" -d "{\"block_storage\": {\"primary\": {\"disk_count\": 24}}}"

# The response:
{
  "warnings": [
    {
      "name": "test",
      "warning": {
        "code": 11,
        "message": "Number of unassigned disks attached to node \"node-2\": 6.",
        "arguments": [
          "6",
          "node-2"
        ]
      }
    }
  ],
  "num_records": 1,
  "records": [
    {
      "uuid": "cae60cfe-deae-42bd-babb-ef437d118314",
      "name": "test",
      "node": {
        "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
        "name": "node-2",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/4046dda8-f802-11e8-8f6d-005056bb2030"
          }
        }
      },
      "space": {
        "block_storage": {
          "size": 33292025856
        }
      },
      "block_storage": {
        "primary": {
          "disk_count": 24,

```

```

    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "disk_type": "ssd",
    "raid_size": 24,
    "simulated_raid_groups": [
      {
        "name": "test/plex0/rg0",
        "existing_parity_disk_count": 0,
        "added_parity_disk_count": 2,
        "existing_data_disk_count": 0,
        "added_data_disk_count": 10,
        "usable_size": 12309487,
        "is_partition": false
      },
      {
        "name": "test/plex1/rg1",
        "existing_parity_disk_count": 0,
        "added_parity_disk_count": 2,
        "existing_data_disk_count": 0,
        "added_data_disk_count": 10,
        "usable_size": 12309487,
        "is_partition": false
      }
    ]
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {
    "enabled": false
  }
},
"_links": {
  "self": {
    "href": "/api/storage/aggregates/cae60cfe-deae-42bd-babb-ef437d118314"
  }
}
]
}

```

### Retrieving the usable spare information for the cluster

The following example shows the response from retrieving usable spare information for the expansion of this particular aggregate. The output is restricted to only spares that are compatible with this aggregate.

```

# The API:
/api/storage/aggregates/{uuid}?show_spares=true

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates?uuid=cae60cfe-deae-42bd-babb-ef437d118314&show_spares=true" -H "accept: application/json"

# The response:
{
  "records": [],
  "num_records": 0,
  "spares": [
    {
      "node": {
        "uuid": "0cdd84fa-b99c-11eb-b0ed-005056bb4fc2",
        "name": "node-2",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0cdd84fa-b99c-11eb-b0ed-005056bb4fc2"
          }
        }
      },
      "disk_class": "solid_state",
      "disk_type": "ssd",
      "size": 3720609792,
      "checksum_style": "block",
      "syncmirror_pool": "pool0",
      "usable": 12,
      "layout_requirements": [
        {
          "raid_type": "raid_dp",
          "default": true,
          "aggregate_min_disks": 3,
          "raid_group": {
            "min": 3,
            "max": 28,
            "default": 24
          }
        },
        {
          "raid_type": "raid4",
          "default": false,
          "aggregate_min_disks": 2,
          "raid_group": {

```

```

        "min": 2,
        "max": 14,
        "default": 8
    }
},
{
    "raid_type": "raid_tec",
    "default": false,
    "aggregate_min_disks": 7,
    "raid_group": {
        "min": 4,
        "max": 29,
        "default": 25
    }
}
]
}
],
"_link": {
    "self": {
        "href": "/api/storage/aggregates?uuid=cae60cfe-deae-42bd-babb-ef437d118314&show_spares=true"
    }
}
}
}

```

### Retrieving a recommendation for an aggregate expansion

The following example shows the response with the recommended data aggregate expansion based on what disks are present within the system. The query does not modify the existing aggregate but returns how the aggregate will look after the expansion. The recommendation will be reflected in the attributes - 'space.block\_storage.size' and 'block\_storage.primary.disk\_count'. Recommended data aggregate expansion will be blocked while one or more nodes in the cluster are simulating or implementing automatic aggregate creation.

```

# The API:
/api/storage/aggregates/{uuid}?auto_provision_policy=expand

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/cae60cfe-deae-42bd-babb-ef437d118314?auto_provision_policy=expand" -H "accept: application/json"

# The response:
{
  "uuid": "cae60cfe-deae-42bd-babb-ef437d118314",

```

```
"name": "node_2_SSD_1",
"node": {
  "uuid": "4046dda8-f802-11e8-8f6d-005056bb2030",
  "name": "node-2",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/4046dda8-f802-11e8-8f6d-005056bb2030"
    }
  }
},
"space": {
  "block_storage": {
    "size": 1116180480
  }
},
"block_storage": {
  "primary": {
    "disk_count": 12,
    "disk_class": "solid_state",
    "raid_type": "raid_dp",
    "disk_type": "ssd",
    "raid_size": 24,
    "simulated_raid_groups": [
      {
        "name": "test/plex0/rg0",
        "parity_disk_count": 2,
        "data_disk_count": 10,
        "usable_size": 12309487,
        "is_partition": false
      }
    ]
  },
  "hybrid_cache": {
    "enabled": false
  },
  "mirror": {
    "enabled": false
  }
},
_links": {
  "self": {
    "href": "/api/storage/aggregates/cae60cfe-deae-42bd-babb-ef437d118314"
  }
}
}
```

## Updating an aggregate in the cluster

The following example shows the workflow of adding disks to the aggregate.

Step 1: Check the current disk count on the aggregate.

```
# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c?fields=block_storage.primary.disk_count" -H "accept: application/json"

# The response:
{
  "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
  "name": "test1",
  "block_storage": {
    "primary": {
      "disk_count": 6
    }
  }
},
}
```

Step 2: Update the aggregate with the new disk count in 'block\_storage.primary.disk\_count'. The response to PATCH is a job unless the request is invalid.

```

# The API:
/api/storage/aggregates

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c" -H "accept: application/hal+json" -d
"{\"block_storage\": {\"primary\": {\"disk_count\": 8}}}"

# The response:
{
  "job": {
    "uuid": "c103d15e-730b-11e8-a57f-005056b465d6",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/c103d15e-730b-11e8-a57f-005056b465d6"
      }
    }
  }
}

```

Step 3: Wait for the job to finish, then call GET to see the reflected change.

```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c?fields=block_storage.primary.disk_count" -H "accept: application/json"

# The response:
{
  "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
  "name": "test1",
  "block_storage": {
    "primary": {
      "disk_count": 8
    }
  },
}

```

### Adding a storage pool to an aggregate

The following example shows how to add cache capacity from an existing storage pool to an aggregate. Step 1: Update the aggregate with the new storage pool allocation unit in

'block\_storage.hybrid\_cache.storage\_pools.allocation\_units\_count'. Additionally, specify 'block\_storage.hybrid\_cache.storage\_pools.name' or 'block\_storage.hybrid\_cache.storage\_pools.uuid' to the storage pool. On the first storage pool, 'block\_storage.hybrid\_cache.raid\_type' can be specified for the raidtype of the hybrid cache. The response to PATCH is a job unless the request is invalid.

```
# The API:
/api/storage/aggregates

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c" -H "accept: application/json" -d
"{\"block_storage\": {\"hybrid_cache\": {\"raid_type\": \"raid_dp\",
\"storage_pools\": [{ \"allocation_units_count\": 2, \"storage_pool\": {
\"name\": \"sp1\"}]}}}"

# The response:
{
  "job": {
    "uuid": "c103d15e-730b-11e8-a57f-005056b465d6",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/c103d15e-730b-11e8-a57f-005056b465d6"
      }
    }
  }
}
```

Step 2: Wait for the job to finish, then call GET to see the reflected change.



```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/19425837-f2fa-4a9f-8f01-712f626c983c?fields=block_storage.hybrid_cache" -H "accept: application/json"

# The response:
{
  "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
  "name": "test1",
  "hybrid_cache": {
    "enabled": true,
    "disk_count": 3,
    "raid_type": "raid_dp",
    "size": 880279552,
    "used": 73728,
    "storage_pools": [
      {
        "allocation_units_count": 2,
        "storage_pool": {
          "name": "sp1",
          "uuid": "eeef0b24-846b-11ec-8fcb-005056bb12c7",
          "_links": {
            "self": {
              "href": "/api/storage/pools/eeef0b24-846b-11ec-8fcb-005056bb12c7"
            }
          }
        }
      }
    ]
  }
}

```

The following example shows the workflow to enable software encryption on an aggregate.

Step 1: Check the current software encryption status of the aggregate.

```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/f3aafdc6-be35-4d93-9590-5a402bffb4b?fields=data_encryption.software_encryption_enabled" -H "accept: application/json"

# The response:
{
  "uuid": "f3aafdc6-be35-4d93-9590-5a402bffb4b",
  "name": "aggr5",
  "data_encryption": {
    "software_encryption_enabled": false
  },
}

```

Step 2: Update the aggregate with the encryption status in 'data\_encryption.software\_encryption\_enabled'. The response to PATCH is a job unless the request is invalid.

```

# The API:
/api/storage/aggregates

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/aggregates/f3aafdc6-be35-4d93-9590-5a402bffb4b" -H "accept: application/hal+json" -d '{"data_encryption": {"software_encryption_enabled": "true"}}'

# The response:
{
  "job": {
    "uuid": "6b7ab28e-168d-11ea-8a50-0050568eca76",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/6b7ab28e-168d-11ea-8a50-0050568eca76"
      }
    }
  }
}

```

Step 3: Wait for the job to finish, then call GET to see the reflected change.

```

# The API:
/api/storage/aggregates

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/f3aafdc6-be35-4d93-9590-5a402bfffbe4b?fields=data_encryption.software_encryption_enabled" -H "accept: application/json"

# The response:
{
  "uuid": "f3aafdc6-be35-4d93-9590-5a402bfffbe4b",
  "name": "aggr5",
  "data_encryption": {
    "software_encryption_enabled": true
  },
}

```

## Delete an aggregate specified by the UUID

DELETE /storage/aggregates/{uuid}

**Introduced In:** 9.6

Deletes the aggregate specified by the UUID. This request starts a job and returns a link to that job.

### Related ONTAP commands

- storage aggregate delete

### Parameters

| Name | Type   | In   | Required | Description    |
|------|--------|------|----------|----------------|
| uuid | string | path | True     | Aggregate UUID |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 460770     | The aggregate delete job failed to delete the aggregate.                       |
| 460777     | Failed to get information on the delete job.                                   |
| 786435     | Internal Error. Failed to create a communication handle.                       |
| 786451     | Failed to delete specified aggregate.  |
| 786468     | VLDB is offline.   |
| 786472     | Node that hosts the aggregate is offline.                                      |
| 786497     | Cannot delete an aggregate that has volumes.                                   |
| 786771     | Aggregate does not exist.  |
| 786867     | Specified aggregate resides on the remote cluster.                             |
| 786897     | Specified aggregate cannot be deleted as it is a switched-over root aggregate. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve an aggregate specified by the UUID

GET /storage/aggregates/{uuid}

## Introduced In: 9.6

Retrieves the aggregate specified by the UUID. The recommend query cannot be used for this operation.

### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `metric.*`
- `space.block_storage.inactive_user_data`
- `space.block_storage.inactive_user_data_percent`
- `space.footprint`
- `is_spare_low`
- `statistics.*`

### Related ONTAP commands

- `storage aggregate show`

### Parameters

| Name                               | Type          | In    | Required | Description   |
|------------------------------------|---------------|-------|----------|---|
| <code>uuid</code>                  | string        | path  | True     | Aggregate UUID  |
| <code>auto_provision_policy</code> | string        | query | False    | If set to expand, a query is run on the system for the recommended optimal expansion layout of the aggregate.<br><br>• Introduced in: 9.8 |
| <code>fields</code>                | array[string] | query | False    | Specify the fields to return.   |

### Response

```
Status: 200, Ok
```



| Name                    | Type                                    | Description  |
|-------------------------|---|--|
| _links                  | <a href="#">_links</a>                  |  |
| block_storage           | <a href="#">block_storage</a>           | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.   |
| cloud_storage           | <a href="#">cloud_storage</a>           | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |
| create_time             | string                                  | Timestamp of aggregate creation.   |
| data_encryption         | <a href="#">data_encryption</a>         |  |
| dr_home_node            | <a href="#">dr_home_node</a>            | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | <a href="#">home_node</a>               | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | <a href="#">inactive_data_reporting</a> |  |
| inode_attributes        | <a href="#">inode_attributes</a>        |  |
| is_spare_low            | boolean                                 | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| metric                  | <a href="#">metric</a>                  | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                                  | Aggregate name.  |
| node                    | <a href="#">node</a>                    | Node where the aggregate currently resides.  |

| Name                  | Type                                     | Description  |
|-----------------------|--|--|
| recommendation_spares | array[ <a href="#">aggregate_spare</a> ] | Information on the aggregate's remaining hot spare disks.  |
| sidl_enabled          | boolean                                  | Specifies whether or not SIDL is enabled on the aggregate. |
| snaplock_type         | string                                   | SnapLock type.   |
| snapshot              | <a href="#">snapshot</a>                 |  |
| space                 | <a href="#">space</a>                    |  |
| state                 | string                                   | Operational state of the aggregate.                        |
| statistics            | <a href="#">statistics</a>               | The real time I/O statistics for the aggregate.            |
| uuid                  | string                                   | Aggregate UUID.  |
| volume-count          | integer                                  | Number of volumes in the aggregate.                        |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "block_storage": {
    "hybrid_cache": {
      "disk_count": 6,
      "raid_type": "raid_dp",
      "size": 1612709888,
      "storage_pools": {
        "storage_pool": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "storage_pool_1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      },
      "used": 26501122
    },
    "mirror": {
      "enabled": "",
      "state": "unmirrored"
    },
    "plexes": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "plex0"
    },
    "primary": {
      "checksum_style": "block",
      "disk_class": "performance",
      "disk_count": 8,
      "disk_type": "fc",
      "raid_size": 16,
      "raid_type": "raid_dp",
      "simulated_raid_groups": {
```

```

    "raid_type": "raid_dp"
  }
},
"storage_type": "hdd"
},
"cloud_storage": {
  "stores": {
    "cloud_store": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "store1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "used": 0
  }
},
"create_time": "2018-01-01T12:00:00-04:00",
"dr_home_node": {
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"home_node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"inactive_data_reporting": {
  "start_time": "2019-12-12T12:00:00-04:00"
},
"inode_attributes": {
  "file_private_capacity": 31136,
  "file_public_capacity": 31136,
  "files_private_used": 502,
  "files_total": 31136,
  "files_used": 97,
  "max_files_available": 31136,
  "max_files_possible": 2844525,
  "max_files_used": 97,
  "used_percent": 5,

```

```
    "version": 4
  },
  "is_spare_low": "",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "name": "node1_aggr_1",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "recommendation_spares": {
    "checksum_style": "block",
    "disk_class": "solid_state",
    "disk_type": "fc",
    "is_partition": 1,
    "layout_requirements": {
      "aggregate_min_disks": 6,
      "raid_group": {
```

```

    "default": 16,
    "max": 28,
    "min": 5
  },
  "raid_type": "raid_dp"
},
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 10156769280,
"syncmirror_pool": "pool0",
"total": 10,
"usable": 9
},
"snaplock_type": "non_snaplock",
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"space": {
  "block_storage": {
    "aggregate_metadata": 2655,
    "aggregate_metadata_percent": 8,
    "available": 10156560384,
    "data_compacted_count": 1990000,
    "data_compaction_space_saved": 1996000,
    "data_compaction_space_saved_percent": 27,
    "full_threshold_percent": 0,
    "inactive_user_data": 304448,
    "inactive_user_data_percent": 0,
    "physical_used": 2461696,
    "physical_used_percent": 50,
    "size": 10156769280,
    "used": 2088960,
    "used_including_snapshot_reserve": 674685,
    "used_including_snapshot_reserve_percent": 35,
    "volume_deduplication_shared_count": 1990000,
    "volume_deduplication_space_saved": 1996000,

```

```
    "volume_deduplication_space_saved_percent": 27,  
    "volume_footprints_percent": 14  
  },  
  "cloud_storage": {  
    "used": 402743264  
  },  
  "efficiency": {  
    "logical_used": 0,  
    "ratio": 0,  
    "savings": 0  
  },  
  "efficiency_without_snapshots": {  
    "logical_used": 0,  
    "ratio": 0,  
    "savings": 0  
  },  
  "efficiency_without_snapshots_flexclones": {  
    "logical_used": 0,  
    "ratio": 0,  
    "savings": 0  
  },  
  "footprint": 608896,  
  "snapshot": {  
    "available": 2000,  
    "reserve_percent": 20,  
    "total": 5000,  
    "used": 3000,  
    "used_percent": 45  
  }  
},  
"state": "online",  
"statistics": {  
  "iops_raw": {  
    "read": 200,  
    "total": 1000,  
    "write": 100  
  },  
  "latency_raw": {  
    "read": 200,  
    "total": 1000,  
    "write": 100  
  },  
  "status": "ok",  
  "throughput_raw": {  
    "read": 200,  
    "total": 1000,
```

```

    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"uuid": "string",
"volume-count": 0
}

```

## Error

Status: Default

### ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 787092     | The target field cannot be specified for this operation.  |
| 7209049    | Cannot perform the operation because the aggregate is currently expanding.                                      |
| 8586225    | Unexpected error encountered when retrieving metrics and statistics for this aggregate.                         |
| 19726382   | Another provisioning operation is in progress on this cluster. Wait a few minutes, and try the operation again. |
| 19726390   | Unable to provide a recommendation to expand the aggregate.   |
| 19726391   | Too many unassigned disks visible to the node that owns this aggregate.   |
| 19726392   | Layout of this aggregate is not a supported configuration.  |
| 19726393   | Failed to expand the aggregate. Aggregate expansion is not supported on this system.                            |
| 19726394   | Automatic aggregate expansion is not supported on systems with multiple data aggregates.                        |
| 19726395   | Automatic aggregate expansion is not supported when MetroCluster is not configured                              |
| 19726396   | Automatic aggregate expansion is not supported when the DR group is not in a normal state                       |
| 19726397   | Aggregates must contain disks with identical disk-types and disk-sizes.   |
| 19726402   | Internal error. Unable to determine the MetroCluster configuration state.                                       |



| Error Code | Description   |
|------------|---|
| 19726538   | Cannot perform the operation because the aggregate is not in a healthy state. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

storage\_pool\_reference

Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pools

| Name                   | Type                                   | Description                       |
|------------------------|--|-----------------------------------|
| allocation_units_count | integer                                | Allocation count of storage pool. |
| storage_pool           | <a href="#">storage_pool_reference</a> | Shared Storage Pool               |

hybrid\_cache

Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs.

| Name       | Type    | Description  |
|------------|---------|--|
| disk_count | integer | Number of disks used in the cache tier of the aggregate. Only provided when <code>hybrid_cache.enabled</code> is 'true'. |
| enabled    | boolean | Specifies whether the aggregate uses HDDs with SSDs as a cache.  |

| Name          | Type                                   | Description  |
|---------------|--|--|
| raid_type     | string                                 | RAID type for SSD cache of the aggregate. Only provided when hybrid_cache.enabled is 'true'. |
| size          | integer                                | Total usable space in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'. |
| storage_pools | array[ <a href="#">storage_pools</a> ] | List of storage pool properties and allocation_units_count for aggregate.                    |
| used          | integer                                | Space used in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'.         |

#### mirror

| Name    | Type    | Description                       |
|---------|---------|-----------------------------------|
| enabled | boolean | Aggregate is SyncMirror protected |
| state   | string  |                                   |

#### plex\_reference

##### Plex

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

#### simulated\_raid\_groups

| Name                    | Type    | Description                                 |
|-------------------------|---------|---|
| added_data_disk_count   | integer | Number of added data disks in RAID group.   |
| added_parity_disk_count | integer | Number of added parity disks in RAID group. |
| data_disk_count         | integer | Number of data disks in RAID group.         |

| Name                       | Type    | Description  |
|----------------------------|---------|--|
| existing_data_disk_count   | integer | Number of existing data disks in the RAID group.                   |
| existing_parity_disk_count | integer | Number of existing parity disks in the RAID group.                 |
| is_partition               | boolean | Indicates whether the disk is partitioned (true) or whole (false). |
| name                       | string  | Name of the raid group.  |
| parity_disk_count          | integer | Number of parity disks in RAID group.                              |
| raid_type                  | string  | RAID type of the aggregate.  |
| usable_size                | integer | Usable size of each disk, in bytes.                                |

#### primary

Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.

| Name                  | Type   | Description  |
|-----------------------|--|--|
| checksum_style        | string   | The checksum style used by the aggregate.  |
| disk_class            | string   | The class of disks being used by the aggregate.  |
| disk_count            | integer  | Number of disks used in the aggregate. This includes parity disks, but excludes disks in the hybrid cache. |
| disk_type             | string   | The type of disk being used by the aggregate.  |
| raid_size             | integer  | Option to specify the maximum number of disks that can be included in a RAID group.                        |
| raid_type             | string   | RAID type of the aggregate.  |
| simulated_raid_groups | array[ <a href="#">simulated_raid_groups</a> ] |  |

## block\_storage

Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.

| Name            | Type                                    | Description   |
|-----------------|---|---|
| hybrid_cache    | <a href="#">hybrid_cache</a>            | Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs. |
| mirror          | <a href="#">mirror</a>                  |   |
| plexes          | array[ <a href="#">plex_reference</a> ] | Plex reference for each plex in the aggregate.  |
| primary         | <a href="#">primary</a>                 | Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.     |
| storage_type    | string                                  | Type of aggregate.  |
| uses_partitions | boolean                                 | If true, aggregate is using shared disks.   |

## cloud\_store

Cloud store

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

## cloud\_storage\_tier

| Name        | Type                        | Description   |
|-------------|-----------------------------|---|
| cloud_store | <a href="#">cloud_store</a> | Cloud store   |
| used        | integer                     | Capacity used in bytes in the cloud store by this aggregate. This is a cached value calculated every 5 minutes. |

## cloud\_storage

Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.

| Name                       | Type  | Description  |
|----------------------------|---|--|
| attach_eligible            | boolean                                     | Specifies whether the aggregate is eligible for a cloud store to be attached.  |
| stores                     | array[ <a href="#">cloud_storage_tier</a> ] | Configuration information for each cloud storage portion of the aggregate.   |
| tiering_fullness_threshold | integer                                     | The percentage of space in the performance tier that must be used before data is tiered out to the cloud store. Only valid for PATCH operations. |

#### data\_encryption

| Name                        | Type    | Description   |
|-----------------------------|---------|---|
| drive_protection_enabled    | boolean | Specifies whether the aggregate uses self-encrypting drives with data protection enabled.         |
| software_encryption_enabled | boolean | Specifies whether NetApp aggregate encryption is enabled. All data in the aggregate is encrypted. |

#### dr\_home\_node

Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### home\_node

Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### inactive\_data\_reporting

| Name       | Type    | Description   |
|------------|---------|---|
| enabled    | boolean | Specifies whether or not inactive data reporting is enabled on the aggregate. |
| start_time | string  | Timestamp at which inactive data reporting was enabled on the aggregate.      |

#### inode\_attributes

| Name                  | Type    | Description   |
|-----------------------|---------|---|
| file_private_capacity | integer | Number of files that can currently be stored on disk for system metadata files. This number will dynamically increase as more system files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> .    |
| file_public_capacity  | integer | Number of files that can currently be stored on disk for user-visible files. This number will dynamically increase as more user-visible files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

| Name                | Type    | Description  |
|---------------------|---------|--|
| files_private_used  | integer | Number of system metadata files used. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| files_total         | integer | Maximum number of user-visible files that this referenced file system can currently hold. If the referenced file system is restricted or offline, a value of 0 is returned.  |
| files_used          | integer | Number of user-visible files used in the referenced file system. If the referenced file system is restricted or offline, a value of 0 is returned.   |
| max_files_available | integer | The count of the maximum number of user-visible files currently allowable on the referenced file system.   |
| max_files_possible  | integer | The largest value to which the maxfiles-available parameter can be increased by reconfiguration, on the referenced file system.  |
| max_files_used      | integer | The number of user-visible files currently in use on the referenced file system.   |
| used_percent        | integer | The percentage of disk space currently in use based on user-visible file count on the referenced file system.  |



| Name    | Type    | Description  |
|---------|---------|--|
| version | integer | The inofile-version of the aggregate. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

### iops

The rate of I/O operations observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### latency

The round trip latency in microseconds observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |

| Name  | Type    | Description   |
|-------|---------|---|
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations.                    |

### throughput

The rate of throughput bytes per second observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### metric

The most recent sample of I/O metrics for the aggregate.

| Name                   | Type                    | Description  |
|------------------------|-------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a>  |  |
| duration               | string                  | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops                   | <a href="#">iops</a>    | The rate of I/O operations observed at the storage object.   |
| latency                | <a href="#">latency</a> | The round trip latency in microseconds observed at the storage object.   |

| Name       | Type                       | Description   |
|------------|----------------------------|---|
| status     | string                     | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | <a href="#">throughput</a> | The rate of throughput bytes per second observed at the storage object.   |
| timestamp  | string                     | The timestamp of the performance data.  |

node

Node where the aggregate currently resides.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

raid\_group

| Name    | Type    | Description                              |
|---------|---------|--|
| default | integer | Default number of disks in a RAID group. |

| Name | Type    | Description                                      |
|------|---------|--|
| max  | integer | Maximum number of disks allowed in a RAID group. |
| min  | integer | Minimum number of disks allowed in a RAID group. |

#### layout\_requirement

| Name                | Type                       | Description                                     |
|---------------------|----------------------------|---|
| aggregate_min_disks | integer                    | Minimum number of disks to create an aggregate. |
| default             | boolean                    | Indicates if this RAID type is the default.     |
| raid_group          | <a href="#">raid_group</a> |   |
| raid_type           | string                     | RAID type.                                      |

#### node

Node where the spares are assigned.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### aggregate\_spare

| Name                | Type  | Description   |
|---------------------|---|---|
| checksum_style      | string                                      | The checksum type that has been assigned to the spares.         |
| disk_class          | string                                      | Disk class of spares.   |
| disk_type           | string                                      | Type of disk.   |
| is_partition        | boolean                                     | Indicates whether a disk is partitioned (true) or whole (false) |
| layout_requirements | array[ <a href="#">layout_requirement</a> ] | Available RAID protections and their restrictions.              |

| Name            | Type    | Description  |
|-----------------|---------|--|
| node            | node    | Node where the spares are assigned.  |
| size            | integer | Usable size of each spare, in bytes.   |
| syncmirror_pool | string  | SyncMirror spare pool.   |
| total           | integer | Total number of spares in the bucket. The total spare count for each class of spares also includes reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 10</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.11</li> </ul>    |
| usable          | integer | Total number of usable spares in the bucket. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 9</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul> |

#### snapshot

| Name                | Type    | Description                                 |
|---------------------|---------|---|
| files_total         | integer | Total files allowed in Snapshot copies      |
| files_used          | integer | Total files created in Snapshot copies      |
| max_files_available | integer | Maximum files available for Snapshot copies |
| max_files_used      | integer | Files in use by Snapshot copies             |

#### block\_storage

| Name                                | Type    | Description  |
|-------------------------------------|---------|--|
| aggregate_metadata                  | integer | Space used by different metafiles and internal operations inside the aggregate, in bytes.  |
| aggregate_metadata_percent          | integer | Aggregate metadata as a percentage.  |
| available                           | integer | Space available in bytes.  |
| data_compacted_count                | integer | Amount of compacted data in bytes.   |
| data_compaction_space_saved         | integer | Space saved in bytes by compacting the data.   |
| data_compaction_space_saved_percent | integer | Percentage saved by compacting the data.   |
| full_threshold_percent              | integer | The aggregate used percentage at which 'monitor.volume.full' EMS is generated.   |
| inactive_user_data                  | integer | The size that is physically used in the block storage and has a cold temperature, in bytes. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data</code> or <code>**</code> . |

| Name                                     | Type    | Description   |
|--|---------|---|
| inactive_user_data_percent               | integer | The percentage of inactive user data in the block storage. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data_percent</code> or <code>**</code> . |
| physical_used                            | integer | Total physical used size of an aggregate in bytes.  |
| physical_used_percent                    | integer | Physical used percentage.   |
| size                                     | integer | Total usable space in bytes, not including WAFL reserve and aggregate Snapshot copy reserve.  |
| used                                     | integer | Space used or reserved in bytes. Includes volume guarantees and aggregate metadata.   |
| used_including_snapshot_reserve          | integer | Total used including the Snapshot copy reserve, in bytes.   |
| used_including_snapshot_reserve_percent  | integer | Total used including the Snapshot reserve as a percentage.  |
| volume_deduplication_shared_count        | integer | Amount of shared bytes counted by storage efficiency.   |
| volume_deduplication_space_saved         | integer | Amount of space saved in bytes by storage efficiency.   |
| volume_deduplication_space_saved_percent | integer | Percentage of space saved by storage efficiency.  |

| Name                      | Type    | Description   |
|---------------------------|---------|---|
| volume_footprints_percent | integer | A summation of volume footprints inside the aggregate, as a percentage. A volume's footprint is the amount of space being used for the volume in the aggregate. |

#### cloud\_storage

| Name | Type    | Description   |
|------|---------|---|
| used | integer | Used space in bytes in the cloud store. Only applicable for aggregates with a cloud store tier. |

#### efficiency

Storage efficiency.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots

Storage efficiency that does not include the savings provided by Snapshot copies.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots\_flexclones

Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes.



| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### snapshot

| Name            | Type    | Description                                      |
|-----------------|---------|--|
| available       | integer | Available space for Snapshot copies in bytes     |
| reserve_percent | integer | Percentage of space reserved for Snapshot copies |
| total           | integer | Total space for Snapshot copies in bytes         |
| used            | integer | Space used by Snapshot copies in bytes           |
| used_percent    | integer | Percentage of disk space used by Snapshot copies |

#### space

| Name                                     | Type   | Description   |
|--|--|---|
| block_storage                            | <a href="#">block_storage</a>                            |   |
| cloud_storage                            | <a href="#">cloud_storage</a>                            |   |
| efficiency                               | <a href="#">efficiency</a>                               | Storage efficiency.   |
| efficiency_without_snapshots             | <a href="#">efficiency_without_snapshots</a>             | Storage efficiency that does not include the savings provided by Snapshot copies.                       |
| efficiency_without_snapshots_flex_clones | <a href="#">efficiency_without_snapshots_flex_clones</a> | Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes. |

| Name      | Type                     | Description   |
|-----------|--------------------------|---|
| footprint | integer                  | A summation of volume footprints (including volume guarantees), in bytes. This includes all of the volume footprints in the block_storage tier and the cloud_storage tier. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or **. |
| snapshot  | <a href="#">snapshot</a> |   |

#### iops\_raw

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### latency\_raw

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

The real time I/O statistics for the aggregate.

| Name           | Type                           | Description   |
|----------------|--------------------------------|---|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| latency_raw    | <a href="#">latency_raw</a>    | The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.   |
| status         | string                         | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.  |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update an aggregate specified by the UUID

PATCH /storage/aggregates/{uuid}

**Introduced In:** 9.6

Updates the aggregate specified by the UUID with the properties in the body. This request starts a job and returns a link to that job.

### Related ONTAP commands

- `storage aggregate add-disks`
- `storage aggregate mirror`
- `storage aggregate modify`
- `storage aggregate relocation start`
- `storage aggregate rename`

### Parameters

| Name | Type   | In   | Required | Description    |
|------|--------|------|----------|----------------|
| uuid | string | path | True     | Aggregate UUID |

| Name                  | Type    | In    | Required | Description  |
|-----------------------|---------|-------|----------|--|
| auto_provision_policy | string  | query | False    | <p>If set to expand, the PATCH operation runs the recommended expansion of the aggregate.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul>   |
| simulate              | boolean | query | False    | <p>If set to true, the PATCH operation runs a simulated aggregate expansion with the provided input disk count and returns the proposed size of the new aggregate along with any associated warnings.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul> |
| disk_size             | integer | query | False    | <p>If set, PATCH only selects disks of the specified size.</p>   |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name          | Type                          | Description  |
|---------------|-------------------------------|--|
| _links        | <a href="#">_links</a>        |  |
| block_storage | <a href="#">block_storage</a> | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier. |
| cloud_storage | <a href="#">cloud_storage</a> | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |

| Name                    | Type                                     | Description  |
|-------------------------|--|--|
| create_time             | string                                   | Timestamp of aggregate creation.   |
| data_encryption         | <a href="#">data_encryption</a>          |  |
| dr_home_node            | <a href="#">dr_home_node</a>             | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | <a href="#">home_node</a>                | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | <a href="#">inactive_data_reporting</a>  |  |
| inode_attributes        | <a href="#">inode_attributes</a>         |  |
| is_spare_low            | boolean                                  | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| metric                  | <a href="#">metric</a>                   | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                                   | Aggregate name.  |
| node                    | <a href="#">node</a>                     | Node where the aggregate currently resides.  |
| recommendation_spares   | array[ <a href="#">aggregate_spare</a> ] | Information on the aggregate's remaining hot spare disks.  |
| sidl_enabled            | boolean                                  | Specifies whether or not SIDL is enabled on the aggregate.   |
| snaplock_type           | string                                   | SnapLock type.   |
| snapshot                | <a href="#">snapshot</a>                 |  |
| space                   | <a href="#">space</a>                    |  |



| <b>Name</b>  | <b>Type</b>                | <b>Description</b>                              |
|--------------|----------------------------|---|
| state        | string                     | Operational state of the aggregate.             |
| statistics   | <a href="#">statistics</a> | The real time I/O statistics for the aggregate. |
| uuid         | string                     | Aggregate UUID.                                 |
| volume-count | integer                    | Number of volumes in the aggregate.             |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "block_storage": {
    "hybrid_cache": {
      "disk_count": 6,
      "raid_type": "raid_dp",
      "size": 1612709888,
      "storage_pools": {
        "storage_pool": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "storage_pool_1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      },
      "used": 26501122
    },
    "mirror": {
      "enabled": "",
      "state": "unmirrored"
    },
    "plexes": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "plex0"
    },
    "primary": {
      "checksum_style": "block",
      "disk_class": "performance",
      "disk_count": 8,
      "disk_type": "fc",
      "raid_size": 16,
      "raid_type": "raid_dp",
      "simulated_raid_groups": {
```

```

    "raid_type": "raid_dp"
  }
},
"storage_type": "hdd"
},
"cloud_storage": {
  "stores": {
    "cloud_store": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "store1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "used": 0
  }
},
"create_time": "2018-01-01T12:00:00-04:00",
"dr_home_node": {
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"home_node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"inactive_data_reporting": {
  "start_time": "2019-12-12T12:00:00-04:00"
},
"inode_attributes": {
  "file_private_capacity": 31136,
  "file_public_capacity": 31136,
  "files_private_used": 502,
  "files_total": 31136,
  "files_used": 97,
  "max_files_available": 31136,
  "max_files_possible": 2844525,
  "max_files_used": 97,
  "used_percent": 5,

```

```

    "version": 4
  },
  "is_spare_low": "",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"name": "node1_aggr_1",
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"name": "node1",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"recommendation_spares": {
  "checksum_style": "block",
  "disk_class": "solid_state",
  "disk_type": "fc",
  "is_partition": 1,
  "layout_requirements": {
    "aggregate_min_disks": 6,
    "raid_group": {

```

```

    "default": 16,
    "max": 28,
    "min": 5
  },
  "raid_type": "raid_dp"
},
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 10156769280,
"syncmirror_pool": "pool0",
"total": 10,
"usable": 9
},
"snaplock_type": "non_snaplock",
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"space": {
  "block_storage": {
    "aggregate_metadata": 2655,
    "aggregate_metadata_percent": 8,
    "available": 10156560384,
    "data_compacted_count": 1990000,
    "data_compaction_space_saved": 1996000,
    "data_compaction_space_saved_percent": 27,
    "full_threshold_percent": 0,
    "inactive_user_data": 304448,
    "inactive_user_data_percent": 0,
    "physical_used": 2461696,
    "physical_used_percent": 50,
    "size": 10156769280,
    "used": 2088960,
    "used_including_snapshot_reserve": 674685,
    "used_including_snapshot_reserve_percent": 35,
    "volume_deduplication_shared_count": 1990000,
    "volume_deduplication_space_saved": 1996000,

```

```

    "volume_deduplication_space_saved_percent": 27,
    "volume_footprints_percent": 14
  },
  "cloud_storage": {
    "used": 402743264
  },
  "efficiency": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots_flexclones": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "footprint": 608896,
  "snapshot": {
    "available": 2000,
    "reserve_percent": 20,
    "total": 5000,
    "used": 3000,
    "used_percent": 45
  }
},
"state": "online",
"statistics": {
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput_raw": {
    "read": 200,
    "total": 1000,

```

```
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"uuid": "string",
"volume-count": 0
}
```

## Response

Status: 200, Ok

| Name        | Type                                       | Description   |
|-------------|--|---|
| job         | <a href="#">job_link</a>                   |   |
| num_records | integer                                    | Number of records   |
| records     | array[ <a href="#">aggregate</a> ]         |   |
| warnings    | array[ <a href="#">aggregate_warning</a> ] | List of validation warnings and remediation advice for the aggregate simulate behavior. |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "block_storage": {
      "hybrid_cache": {
        "disk_count": 6,
        "raid_type": "raid_dp",
        "size": 1612709888,
        "storage_pools": {
          "storage_pool": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "storage_pool_1",
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          }
        },
        "used": 26501122
      },
      "mirror": {
        "enabled": "",
        "state": "unmirrored"
      },
      "plexes": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "plex0"
      }
    }
  }
}
```



```

    },
    "primary": {
      "checksum_style": "block",
      "disk_class": "performance",
      "disk_count": 8,
      "disk_type": "fc",
      "raid_size": 16,
      "raid_type": "raid_dp",
      "simulated_raid_groups": {
        "raid_type": "raid_dp"
      }
    },
    "storage_type": "hdd"
  },
  "cloud_storage": {
    "stores": {
      "cloud_store": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "store1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "used": 0
    }
  },
  "create_time": "2018-01-01T12:00:00-04:00",
  "dr_home_node": {
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "home_node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "inactive_data_reporting": {
    "start_time": "2019-12-12T12:00:00-04:00"
  },
  "inode_attributes": {

```

```

    "file_private_capacity": 31136,
    "file_public_capacity": 31136,
    "files_private_used": 502,
    "files_total": 31136,
    "files_used": 97,
    "max_files_available": 31136,
    "max_files_possible": 2844525,
    "max_files_used": 97,
    "used_percent": 5,
    "version": 4
  },
  "is_spare_low": "",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "name": "node1_aggr_1",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}

```

```

},
"recommendation_spare": {
  "checksum_style": "block",
  "disk_class": "solid_state",
  "disk_type": "fc",
  "is_partition": 1,
  "layout_requirements": {
    "aggregate_min_disks": 6,
    "raid_group": {
      "default": 16,
      "max": 28,
      "min": 5
    },
    "raid_type": "raid_dp"
  },
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "size": 10156769280,
  "syncmirror_pool": "pool0",
  "total": 10,
  "usable": 9
},
"snaplock_type": "non_snaplock",
"snapshot": {
  "files_total": 10,
  "files_used": 3,
  "max_files_available": 5,
  "max_files_used": 50
},
"space": {
  "block_storage": {
    "aggregate_metadata": 2655,
    "aggregate_metadata_percent": 8,
    "available": 10156560384,
    "data_compacted_count": 1990000,
    "data_compaction_space_saved": 1996000,
    "data_compaction_space_saved_percent": 27,
    "full_threshold_percent": 0,
    "inactive_user_data": 304448,

```

```

    "inactive_user_data_percent": 0,
    "physical_used": 2461696,
    "physical_used_percent": 50,
    "size": 10156769280,
    "used": 2088960,
    "used_including_snapshot_reserve": 674685,
    "used_including_snapshot_reserve_percent": 35,
    "volume_deduplication_shared_count": 1990000,
    "volume_deduplication_space_saved": 1996000,
    "volume_deduplication_space_saved_percent": 27,
    "volume_footprints_percent": 14
  },
  "cloud_storage": {
    "used": 402743264
  },
  "efficiency": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots_flexclones": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "footprint": 608896,
  "snapshot": {
    "available": 2000,
    "reserve_percent": 20,
    "total": 5000,
    "used": 3000,
    "used_percent": 45
  }
},
"state": "online",
"statistics": {
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  }
},

```

```

"latency_raw": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"status": "ok",
"throughput_raw": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},
"uuid": "string",
"volume-count": 0
},
"warnings": {
  "action": {
    "arguments": {
    }
  },
  "warning": {
    "arguments": {
    }
  }
}
}

```

## Response

Status: 202, Accepted

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 262247     | The value is invalid for the field.                 |
| 460777     | Failed to get information on the job.               |
| 786434     | Cannot connect to node where the aggregate resides. |

| Error Code | Description   |
|------------|---|
| 786435     | Internal Error. Failed to create a communication handle.  |
| 786439     | An aggregate already uses the specified name.   |
| 786447     | Failed to modify the aggregate.   |
| 786456     | Failed to add disks to the aggregate.   |
| 786458     | Failed to rename aggregate.   |
| 786465     | Failed to take aggregate offline because of the reason outlined in the message.                                 |
| 786467     | Failed to take aggregate online because of the reason outlined in the message.                                  |
| 786468     | VLDB is offline.  |
| 786472     | Node that hosts the aggregate is offline.   |
| 786479     | Cannot find node ID for the node.   |
| 786491     | Not enough spares on the node.  |
| 786730     | Internal Error  |
| 786771     | Aggregate does not exist.   |
| 786787     | Aggregate is not online.  |
| 786808     | Aggregate mirror failed.  |
| 786867     | Specified aggregate resides on the remote cluster.  |
| 786911     | Not every node in the cluster has the Data ONTAP version required for the feature.                              |
| 786923     | This operation is not allowed during the pre-commit phase of a 7-mode to clustered Data ONTAP transition.       |
| 786924     | Internal error for an aggregate that is in the pre-commit phase of a 7-mode to clustered Data ONTAP transition. |
| 786955     | Modifying raidtype to raid_tec requires a minimum of six disks in the RAID Group.                               |
| 786956     | Modifying raidtype to raid_dp requires a minimum of four disks in the RAID Group.                               |
| 786965     | Spare Selection in userspace failed.  |
| 787046     | Mirroring of a FabricPool is not allowed.   |
| 787092     | The target field cannot be specified for this operation.  |
| 787144     | Aggregate is not a FabricPool.  |
| 787156     | Modifying the attributes of mirror object store is not allowed.   |

| Error Code | Description  |
|------------|--|
| 787169     | Only one field can be modified per operation.  |
| 787170     | Failed to patch the "block_storage.primary.disk_count" because the disk count specified is smaller than existing disk count. |
| 787172     | This query is only allowed during the modification of the specified field.   |
| 787178     | Unmirroring an aggregate with a PATCH operation is not supported.  |
| 787187     | Internal error. Failed to check if the aggregate is a FabricPool.  |
| 787266     | Invalid aggregate state. This state is not supported for a PATCH operation.  |
| 787273     | Allocation unit count is not valid.  |
| 787274     | Raidtype is not valid.   |
| 787275     | Patch request with multiple records is not valid.  |
| 787276     | Storage pool name and uuid do not match.   |
| 787277     | Storage pool name and uuid are empty.  |
| 787278     | Incorrect storage pool name specified.   |
| 787279     | Incorrect storage pool uuid specified.   |
| 787280     | Allocation unit count specified is smaller than the existing allocation unit count.  |
| 787281     | Cannot modify RAID type of aggregate hybrid cache tier.  |
| 787282     | RAID group must be specified on a disk addition to an aggregate with mixed RAID types.                                       |
| 787283     | RAID group must be specified on a disk addition to a Flash Pool aggregate.   |
| 787284     | The specified RAID group uses capacity from one or more storage pools.   |
| 1258699    | Cannot use all the disks specified for the requested operation.  |
| 1263500    | Operation will lead to creation of new raid group.   |
| 1263501    | Operation will exceed half of the maximum volume sizes allowed on the node.  |
| 1263502    | One spare data partition from at least one of the chosen root-data1-data2 disks will not be used.                            |
| 1263503    | Operation will lead to downsizing of one or more disks.  |
| 1263504    | Operation will lead to a spares low condition.   |

| <b>Error Code</b> | <b>Description</b>  |
|-------------------|---|
| 1263598           | One or more selected disks will be partitioned.   |
| 1263624           | Operation will lead to a no sparecore condition.  |
| 2425736           | No matching node found for the UUID provided.   |
| 7208962           | Aggregate in an inconsistent state.   |
| 7208993           | Failed to offline as the volume is being used.  |
| 7209033           | CIFS open files prevent operation.  |
| 7209049           | Cannot perform the operation because the aggregate is currently expanding.  |
| 7209075           | Cannot perform the operation because the volume size limit for this system type would be exceeded.  |
| 7209090           | Inconsistent state.   |
| 7209183           | Volume is a partial volume.   |
| 7209229           | This version of ONTAP does not recognize the filesystem. It is probably from a later version of the software and is being left offline.                                 |
| 7209246           | The specified operation could not be completed as the volume is currently busy.   |
| 7209247           | The volume was not found.   |
| 7209263           | Container has failed.   |
| 7209271           | wafiron is currently active.  |
| 7209275           | Container was created in an unclustered ONTAP deployment.   |
| 7209463           | Nvfile replay pending.  |
| 7209966           | Another online request is already in progress for aggregate. The previous online request is waiting on a response from the licensing manager.                           |
| 11206666          | Storage pool is not healthy.  |
| 11210659          | Aggregate is not online.  |
| 11210662          | Adding capacity from storage pool to a mirrored aggregate is not supported.   |
| 11210667          | Storage pool does not have enough spare allocation units.   |
| 11210670          | Cannot add capacity from storage pool to aggregate, because currently allocated capacity to the aggregate does not span across all disks belonging to the storage pool. |
| 11210672          | Cannot grow aggregate as no capacity is allocated to it from storage pool.  |



| <b>Error Code</b> | <b>Description</b>   |
|-------------------|--|
| 11210673          | Mixing of physical SSDs and capacity from a storage pool is not allowed in same aggregate.                               |
| 11210675          | Capacity in storage pool belongs to different fault isolation domain than aggregate.                                     |
| 11210678          | Storage pool does not have enough disks to create RAID groups of same raid type as that of already allocated cache tier. |
| 11210679          | Storage pool does not have enough disks to create RAID groups of type RAID-DP.   |
| 11210680          | Storage pool does not have enough disks to create RAID groups of same raid type as that of the aggregate.                |
| 11210685          | Storage pool does not have enough disks to create RAID groups of type RAID-TEC.  |
| 11210688          | Capacity from storage pool cannot be added to an SSD aggregate and a Flash Pool.   |
| 13108106          | Cannot run aggregate relocation because volume expand is in progress.  |
| 19726347          | There are a number of unassigned disks visible to the node that owns this aggregate.                                     |
| 19726382          | Another provisioning operation is in progress on this cluster. Wait a few minutes, and try the operation again.          |
| 19726390          | Unable to automatically expand this aggregate.   |
| 19726391          | Too many unassigned disks visible to the node that owns this aggregate.  |
| 19726392          | Layout of this aggregate is not a supported configuration.   |
| 19726393          | Failed to expand the aggregate. Aggregate expansion is not supported on this system.                                     |
| 19726394          | Automatic aggregate expansion is not supported on systems with multiple data aggregates.                                 |
| 19726395          | Automatic aggregate expansion is not supported when MetroCluster is not configured.                                      |
| 19726396          | Automatic aggregate expansion is not supported when the DR group is not in a normal state.                               |
| 19726397          | Aggregates must contain disks with identical disk-types and disk-sizes.  |
| 19726402          | Internal error. Unable to determine the MetroCluster configuration state.  |

| Error Code | Description  |
|------------|--|
| 19726538   | Cannot perform the operation because the aggregate is not in a healthy state.  |
| 26542083   | Destination node is at higher Data ONTAP version than source node.   |
| 26542084   | Source node is at higher Data ONTAP version than destination node.   |
| 26542097   | Unable to get D-blade ID of destination.   |
| 26542101   | Unable to contact the source node.   |
| 26542102   | Unable to contact the destination node.  |
| 26542120   | An SVM migrate operation is in progress. When the migrate operation completes, try the operation again.                    |
| 26542121   | A MetroCluster disaster recovery operation is in progress. When the recovery operation completes, try the operation again. |
| 196608334  | Failed to modify the aggregate because it contains NAE volumes.  |
| 196608335  | Failed to modify the aggregate because it contains non-encrypted volumes.  |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

storage\_pool\_reference

Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pools

| Name                   | Type                                   | Description                       |
|------------------------|--|-----------------------------------|
| allocation_units_count | integer                                | Allocation count of storage pool. |
| storage_pool           | <a href="#">storage_pool_reference</a> | Shared Storage Pool               |

hybrid\_cache

Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs.

| Name       | Type    | Description  |
|------------|---------|--|
| disk_count | integer | Number of disks used in the cache tier of the aggregate. Only provided when <code>hybrid_cache.enabled</code> is 'true'. |
| enabled    | boolean | Specifies whether the aggregate uses HDDs with SSDs as a cache.  |

| Name          | Type                                   | Description  |
|---------------|--|--|
| raid_type     | string                                 | RAID type for SSD cache of the aggregate. Only provided when hybrid_cache.enabled is 'true'. |
| size          | integer                                | Total usable space in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'. |
| storage_pools | array[ <a href="#">storage_pools</a> ] | List of storage pool properties and allocation_units_count for aggregate.                    |
| used          | integer                                | Space used in bytes of SSD cache. Only provided when hybrid_cache.enabled is 'true'.         |

#### mirror

| Name    | Type    | Description                       |
|---------|---------|-----------------------------------|
| enabled | boolean | Aggregate is SyncMirror protected |
| state   | string  |                                   |

#### plex\_reference

##### Plex

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

#### simulated\_raid\_groups

| Name                    | Type    | Description                                 |
|-------------------------|---------|---|
| added_data_disk_count   | integer | Number of added data disks in RAID group.   |
| added_parity_disk_count | integer | Number of added parity disks in RAID group. |
| data_disk_count         | integer | Number of data disks in RAID group.         |

| Name                       | Type    | Description  |
|----------------------------|---------|--|
| existing_data_disk_count   | integer | Number of existing data disks in the RAID group.                   |
| existing_parity_disk_count | integer | Number of existing parity disks in the RAID group.                 |
| is_partition               | boolean | Indicates whether the disk is partitioned (true) or whole (false). |
| name                       | string  | Name of the raid group.  |
| parity_disk_count          | integer | Number of parity disks in RAID group.                              |
| raid_type                  | string  | RAID type of the aggregate.  |
| usable_size                | integer | Usable size of each disk, in bytes.                                |

#### primary

Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.

| Name                  | Type   | Description  |
|-----------------------|--|--|
| checksum_style        | string   | The checksum style used by the aggregate.  |
| disk_class            | string   | The class of disks being used by the aggregate.  |
| disk_count            | integer  | Number of disks used in the aggregate. This includes parity disks, but excludes disks in the hybrid cache. |
| disk_type             | string   | The type of disk being used by the aggregate.  |
| raid_size             | integer  | Option to specify the maximum number of disks that can be included in a RAID group.                        |
| raid_type             | string   | RAID type of the aggregate.  |
| simulated_raid_groups | array[ <a href="#">simulated_raid_groups</a> ] |  |

## block\_storage

Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.

| Name            | Type                                    | Description   |
|-----------------|---|---|
| hybrid_cache    | <a href="#">hybrid_cache</a>            | Contains the configuration for the hybrid cache. The hybrid cache is made up of either whole SSDs or storage pool SSDs. |
| mirror          | <a href="#">mirror</a>                  |   |
| plexes          | array[ <a href="#">plex_reference</a> ] | Plex reference for each plex in the aggregate.  |
| primary         | <a href="#">primary</a>                 | Configuration information for the primary storage portion of the aggregate. This excludes the hybrid cache details.     |
| storage_type    | string                                  | Type of aggregate.  |
| uses_partitions | boolean                                 | If true, aggregate is using shared disks.   |

## cloud\_store

Cloud store

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

## cloud\_storage\_tier

| Name        | Type                        | Description   |
|-------------|-----------------------------|---|
| cloud_store | <a href="#">cloud_store</a> | Cloud store   |
| used        | integer                     | Capacity used in bytes in the cloud store by this aggregate. This is a cached value calculated every 5 minutes. |

## cloud\_storage

Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.

| Name                       | Type  | Description  |
|----------------------------|---|--|
| attach_eligible            | boolean                                     | Specifies whether the aggregate is eligible for a cloud store to be attached.  |
| stores                     | array[ <a href="#">cloud_storage_tier</a> ] | Configuration information for each cloud storage portion of the aggregate.   |
| tiering_fullness_threshold | integer                                     | The percentage of space in the performance tier that must be used before data is tiered out to the cloud store. Only valid for PATCH operations. |

#### data\_encryption

| Name                        | Type    | Description   |
|-----------------------------|---------|---|
| drive_protection_enabled    | boolean | Specifies whether the aggregate uses self-encrypting drives with data protection enabled.         |
| software_encryption_enabled | boolean | Specifies whether NetApp aggregate encryption is enabled. All data in the aggregate is encrypted. |

#### dr\_home\_node

Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### home\_node

Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### inactive\_data\_reporting

| Name       | Type    | Description   |
|------------|---------|---|
| enabled    | boolean | Specifies whether or not inactive data reporting is enabled on the aggregate. |
| start_time | string  | Timestamp at which inactive data reporting was enabled on the aggregate.      |

#### inode\_attributes

| Name                  | Type    | Description   |
|-----------------------|---------|---|
| file_private_capacity | integer | Number of files that can currently be stored on disk for system metadata files. This number will dynamically increase as more system files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> .    |
| file_public_capacity  | integer | Number of files that can currently be stored on disk for user-visible files. This number will dynamically increase as more user-visible files are created. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |



| Name                | Type    | Description  |
|---------------------|---------|--|
| files_private_used  | integer | Number of system metadata files used. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |
| files_total         | integer | Maximum number of user-visible files that this referenced file system can currently hold. If the referenced file system is restricted or offline, a value of 0 is returned.  |
| files_used          | integer | Number of user-visible files used in the referenced file system. If the referenced file system is restricted or offline, a value of 0 is returned.   |
| max_files_available | integer | The count of the maximum number of user-visible files currently allowable on the referenced file system.   |
| max_files_possible  | integer | The largest value to which the maxfiles-available parameter can be increased by reconfiguration, on the referenced file system.  |
| max_files_used      | integer | The number of user-visible files currently in use on the referenced file system.   |
| used_percent        | integer | The percentage of disk space currently in use based on user-visible file count on the referenced file system.  |

| Name    | Type    | Description  |
|---------|---------|--|
| version | integer | The inofile-version of the aggregate. If the referenced file system is restricted or offline, a value of 0 is returned. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or <b>**</b> . |

### iops

The rate of I/O operations observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### latency

The round trip latency in microseconds observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |

| Name  | Type    | Description   |
|-------|---------|---|
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations.                    |

### throughput

The rate of throughput bytes per second observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### metric

The most recent sample of I/O metrics for the aggregate.

| Name                   | Type                    | Description  |
|------------------------|-------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a>  |  |
| duration               | string                  | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops                   | <a href="#">iops</a>    | The rate of I/O operations observed at the storage object.   |
| latency                | <a href="#">latency</a> | The round trip latency in microseconds observed at the storage object.   |

| Name       | Type                       | Description   |
|------------|----------------------------|---|
| status     | string                     | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | <a href="#">throughput</a> | The rate of throughput bytes per second observed at the storage object.   |
| timestamp  | string                     | The timestamp of the performance data.  |

node

Node where the aggregate currently resides.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

raid\_group

| Name    | Type    | Description                              |
|---------|---------|--|
| default | integer | Default number of disks in a RAID group. |

| Name | Type    | Description                                      |
|------|---------|--|
| max  | integer | Maximum number of disks allowed in a RAID group. |
| min  | integer | Minimum number of disks allowed in a RAID group. |

#### layout\_requirement

| Name                | Type                       | Description                                     |
|---------------------|----------------------------|---|
| aggregate_min_disks | integer                    | Minimum number of disks to create an aggregate. |
| default             | boolean                    | Indicates if this RAID type is the default.     |
| raid_group          | <a href="#">raid_group</a> |   |
| raid_type           | string                     | RAID type.                                      |

#### node

Node where the spares are assigned.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### aggregate\_spare

| Name                | Type  | Description   |
|---------------------|---|---|
| checksum_style      | string                                      | The checksum type that has been assigned to the spares.         |
| disk_class          | string                                      | Disk class of spares.   |
| disk_type           | string                                      | Type of disk.   |
| is_partition        | boolean                                     | Indicates whether a disk is partitioned (true) or whole (false) |
| layout_requirements | array[ <a href="#">layout_requirement</a> ] | Available RAID protections and their restrictions.              |

| Name            | Type                 | Description  |
|-----------------|----------------------|--|
| node            | <a href="#">node</a> | Node where the spares are assigned.  |
| size            | integer              | Usable size of each spare, in bytes.   |
| syncmirror_pool | string               | SyncMirror spare pool.   |
| total           | integer              | Total number of spares in the bucket. The total spare count for each class of spares also includes reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 10</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.11</li> </ul>    |
| usable          | integer              | Total number of usable spares in the bucket. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices. <ul style="list-style-type: none"> <li>• example: 9</li> <li>• readOnly: 1</li> <li>• Introduced in: 9.6</li> </ul> |

#### snapshot

| Name                | Type    | Description                                 |
|---------------------|---------|---|
| files_total         | integer | Total files allowed in Snapshot copies      |
| files_used          | integer | Total files created in Snapshot copies      |
| max_files_available | integer | Maximum files available for Snapshot copies |
| max_files_used      | integer | Files in use by Snapshot copies             |

#### block\_storage

| Name                                | Type    | Description  |
|-------------------------------------|---------|--|
| aggregate_metadata                  | integer | Space used by different metafiles and internal operations inside the aggregate, in bytes.  |
| aggregate_metadata_percent          | integer | Aggregate metadata as a percentage.  |
| available                           | integer | Space available in bytes.  |
| data_compacted_count                | integer | Amount of compacted data in bytes.   |
| data_compaction_space_saved         | integer | Space saved in bytes by compacting the data.   |
| data_compaction_space_saved_percent | integer | Percentage saved by compacting the data.   |
| full_threshold_percent              | integer | The aggregate used percentage at which 'monitor.volume.full' EMS is generated.   |
| inactive_user_data                  | integer | The size that is physically used in the block storage and has a cold temperature, in bytes. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data</code> or <code>**</code> . |

| Name                                     | Type    | Description   |
|--|---------|---|
| inactive_user_data_percent               | integer | The percentage of inactive user data in the block storage. This property is only supported if the aggregate is either attached to a cloud store or can be attached to a cloud store. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either <code>block_storage.inactive_user_data_percent</code> or <code>**</code> . |
| physical_used                            | integer | Total physical used size of an aggregate in bytes.  |
| physical_used_percent                    | integer | Physical used percentage.   |
| size                                     | integer | Total usable space in bytes, not including WAFL reserve and aggregate Snapshot copy reserve.  |
| used                                     | integer | Space used or reserved in bytes. Includes volume guarantees and aggregate metadata.   |
| used_including_snapshot_reserve          | integer | Total used including the Snapshot copy reserve, in bytes.   |
| used_including_snapshot_reserve_percent  | integer | Total used including the Snapshot reserve as a percentage.  |
| volume_deduplication_shared_count        | integer | Amount of shared bytes counted by storage efficiency.   |
| volume_deduplication_space_saved         | integer | Amount of space saved in bytes by storage efficiency.   |
| volume_deduplication_space_saved_percent | integer | Percentage of space saved by storage efficiency.  |



| Name                      | Type    | Description   |
|---------------------------|---------|---|
| volume_footprints_percent | integer | A summation of volume footprints inside the aggregate, as a percentage. A volume's footprint is the amount of space being used for the volume in the aggregate. |

#### cloud\_storage

| Name | Type    | Description   |
|------|---------|---|
| used | integer | Used space in bytes in the cloud store. Only applicable for aggregates with a cloud store tier. |

#### efficiency

##### Storage efficiency.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots

##### Storage efficiency that does not include the savings provided by Snapshot copies.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### efficiency\_without\_snapshots\_flexclones

##### Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

#### snapshot

| Name            | Type    | Description                                      |
|-----------------|---------|--|
| available       | integer | Available space for Snapshot copies in bytes     |
| reserve_percent | integer | Percentage of space reserved for Snapshot copies |
| total           | integer | Total space for Snapshot copies in bytes         |
| used            | integer | Space used by Snapshot copies in bytes           |
| used_percent    | integer | Percentage of disk space used by Snapshot copies |

#### space

| Name                                     | Type   | Description   |
|--|--|---|
| block_storage                            | <a href="#">block_storage</a>                            |   |
| cloud_storage                            | <a href="#">cloud_storage</a>                            |   |
| efficiency                               | <a href="#">efficiency</a>                               | Storage efficiency.   |
| efficiency_without_snapshots             | <a href="#">efficiency_without_snapshots</a>             | Storage efficiency that does not include the savings provided by Snapshot copies.                       |
| efficiency_without_snapshots_flex_clones | <a href="#">efficiency_without_snapshots_flex_clones</a> | Storage efficiency that does not include the savings provided by Snapshot copies and Flexclone volumes. |

| Name      | Type                     | Description   |
|-----------|--------------------------|---|
| footprint | integer                  | A summation of volume footprints (including volume guarantees), in bytes. This includes all of the volume footprints in the block_storage tier and the cloud_storage tier. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or **. |
| snapshot  | <a href="#">snapshot</a> |   |

#### iops\_raw

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### latency\_raw

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

The real time I/O statistics for the aggregate.

| Name           | Type           | Description   |
|----------------|----------------|---|
| iops_raw       | iops_raw       | The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| latency_raw    | latency_raw    | The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.   |
| status         | string         | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | throughput_raw | Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string         | The timestamp of the performance data.  |

aggregate

| Name                    | Type                                    | Description  |
|-------------------------|---|--|
| _links                  | <a href="#">_links</a>                  |  |
| block_storage           | <a href="#">block_storage</a>           | Configuration information for the locally attached portion of the aggregate. When a cloud store is also used by this aggregate, this is referred to as the performance tier.   |
| cloud_storage           | <a href="#">cloud_storage</a>           | Configuration information for the cloud storage portion of the aggregate. This is referred to as the capacity tier.  |
| create_time             | string                                  | Timestamp of aggregate creation.   |
| data_encryption         | <a href="#">data_encryption</a>         |  |
| dr_home_node            | <a href="#">dr_home_node</a>            | Node where the aggregate resides after disaster recovery. The value for this field might differ from the 'node' field during switchover.   |
| home_node               | <a href="#">home_node</a>               | Node where the aggregate resides after giveback. The value for this field might differ from the value of the 'node' field during takeover.   |
| inactive_data_reporting | <a href="#">inactive_data_reporting</a> |  |
| inode_attributes        | <a href="#">inode_attributes</a>        |  |
| is_spare_low            | boolean                                 | Specifies whether the aggregate is in a spares low condition on any of the RAID groups. This is an advanced property; there is an added cost to retrieving its value. The field is not populated for either a collection GET or an instance GET unless it is explicitly requested using the <i>fields</i> query parameter containing either footprint or **. |
| metric                  | <a href="#">metric</a>                  | The most recent sample of I/O metrics for the aggregate.   |
| name                    | string                                  | Aggregate name.  |

| Name                  | Type                                     | Description  |
|-----------------------|--|--|
| node                  | <a href="#">node</a>                     | Node where the aggregate currently resides.                |
| recommendation_spares | array[ <a href="#">aggregate_spare</a> ] | Information on the aggregate's remaining hot spare disks.  |
| sidl_enabled          | boolean                                  | Specifies whether or not SIDL is enabled on the aggregate. |
| snaplock_type         | string                                   | SnapLock type.   |
| snapshot              | <a href="#">snapshot</a>                 |  |
| space                 | <a href="#">space</a>                    |  |
| state                 | string                                   | Operational state of the aggregate.                        |
| statistics            | <a href="#">statistics</a>               | The real time I/O statistics for the aggregate.            |
| uuid                  | string                                   | Aggregate UUID.  |
| volume-count          | integer                                  | Number of volumes in the aggregate.                        |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### action

| Name      | Type          | Description  |
|-----------|---------------|--|
| arguments | array[string] | Arguments present in the specified action message. |
| code      | integer       | Corrective action code of the specified action.    |

| Name    | Type   | Description   |
|---------|--------|---|
| message | string | Specifies the corrective action to be taken to resolve the issue. |

warning

| Name      | Type          | Description   |
|-----------|---------------|---|
| arguments | array[string] | Arguments present in the warning message encountered.               |
| code      | integer       | Warning code of the warning encountered.                            |
| message   | string        | Details of the warning encountered by the aggregate simulate query. |

aggregate\_warning

| Name    | Type                    | Description                                  |
|---------|-------------------------|--|
| action  | <a href="#">action</a>  |  |
| name    | string                  | Name of the entity that returns the warning. |
| warning | <a href="#">warning</a> |  |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |
| message   | string                                   | Error message     |



| Name   | Type   | Description                                 |
|--------|--------|---|
| target | string | The target parameter that caused the error. |

## Storage aggregate metrics

### Storage aggregates UUID metrics endpoint overview

#### Overview

The Storage Aggregate Metrics API provides historical performance metrics for the specified aggregate. The collection GET operation retrieves read, write, other and total metrics for a given aggregate, in terms of IOPS, latency and throughput. The read and write categories display the I/O operations that service user reads and writes across all the hosted volumes on a given aggregate. The other category encompasses background I/O operations that implement data protection services currently running on the aggregate. IOPs are the number of I/O operations reported per second, throughput is the amount of I/O operations measured in bytes per second and latency is the average response time for an IOP, reported in microseconds. Without a specified time interval, the output is limited to statistics collected at 15 second intervals over the last hour.

#### Examples

##### Retrieving metrics for an aggregate

In this example, the API returns a set of records that exist for the aggregate with the given UUID for the last hour.

```
# The API:
/api/storage/aggregates/{uuid}/metrics

#The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/538bf337-1b2c-11e8-
bad0-005056b48388/metrics?max_records=4" -H "accept: application/json"

#The response:
{
  "records": [
    {
      "timestamp": "2019-01-14T23:33:45Z"
    },
    {
      "timestamp": "2019-01-14T23:33:30Z"
    },
    {
      "timestamp": "2019-01-14T23:33:15Z"
    },
    {
      "timestamp": "2019-01-14T23:33:00Z"
    }
  ],
  "num_records": 4
}
```

### Retrieving metrics for an aggregate with a set timestamp

In this example, the API returns metric values for latency, IOPS, and throughput properties such as read, write and total. The status and duration for which the metrics are requested are also returned.

```

#The API:
/api/storage/aggregates/{uuid}/metrics?timestamp={timestamp}

#The call:
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/538bf337-1b2c-11e8-
bad0-005056b48388/metrics?timestamp=2019-01-1T23:33:00Z" -H "accept:
application/json"

#The response:
{
  "records": [
    {
      "uuid": "538bf337-1b2c-11e8-bad0-005056b48388",
      "timestamp": "2019-01-01T23:33:00Z",
      "status": "ok",
      "duration": "PT15S",
      "throughput": {
        "read": 6826,
        "write": 205892,
        "other": 0,
        "total": 212718
      },
      "latency": {
        "read": 148,
        "write": 216,
        "other": 0,
        "total": 199
      },
      "iops": {
        "read": 1,
        "write": 5,
        "other": 0,
        "total": 6
      }
    }
  ]
}

```

### Retrieving metrics for an aggregate for a set time interval

In this example, the API returns the requested metrics for the given time interval of 1 week. The interval value can be 1 hour, 1 day, 1 week, 1 month or 1 year. If the interval value is not set, a default value of 1 hour is used.

```
#The API:
```

```
/api/storage/aggregates/{uuid}/metrics
```

```
#The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/aggregates/538bf337-1b2c-11e8-bad0-005056b48388/metrics?return_timeout=15&fields=*&interval=1w&max_records=4" -H "accept: application/json"
```

```
#The response:
```

```
{
  "records": [
    {
      "timestamp": "2019-01-01T23:30:00Z",
      "status": "ok",
      "duration": "PT30M",
      "throughput": {
        "read": 268328,
        "write": 5556255,
        "other": 0,
        "total": 5824584
      },
      "latency": {
        "read": 156,
        "write": 430,
        "other": 0,
        "total": 318
      },
      "iops": {
        "read": 18,
        "write": 26,
        "other": 0,
        "total": 45
      }
    },
    {
      "timestamp": "2019-01-01T23:00:00Z",
      "status": "ok",
      "duration": "PT30M",
      "throughput": {
        "read": 474266,
        "write": 6121908,
        "other": 0,
        "total": 6596175
      },
      "latency": {
        "read": 154,
```

```
    "write": 448,  
    "other": 0,  
    "total": 262  
  },  
  "iops": {  
    "read": 48,  
    "write": 28,  
    "other": 0,  
    "total": 76  
  }  
},  
{  
  "timestamp": "2019-01-01T22:30:00Z",  
  "status": "ok",  
  "duration": "PT30M",  
  "throughput": {  
    "read": 540164,  
    "write": 2411356,  
    "other": 26244685,  
    "total": 29196206  
  },  
  "latency": {  
    "read": 159,  
    "write": 394,  
    "other": 192,  
    "total": 193  
  },  
  "iops": {  
    "read": 94,  
    "write": 16,  
    "other": 437,  
    "total": 548  
  }  
},  
{  
  "timestamp": "2019-01-01T22:00:00Z",  
  "status": "ok",  
  "duration": "PT30M",  
  "throughput": {  
    "read": 2842,  
    "write": 2765407,  
    "other": 0,  
    "total": 2768249  
  },  
  "latency": {  
    "read": 189,
```

```

    "write": 540,
    "other": 0,
    "total": 523
  },
  "iops": {
    "read": 0,
    "write": 13,
    "other": 0,
    "total": 13
  }
},
"num_records": 4
}

```

### Related ONTAP commands

- `statistics aggregate show`

## Retrieve historical performance metrics for an aggregate

GET `/storage/aggregates/{uuid}/metrics`

**Introduced In:** 9.7

Retrieves historical performance metrics for an aggregate.

### Parameters

| Name          | Type    | In    | Required | Description             |
|---------------|---------|-------|----------|-------------------------|
| iops.other    | integer | query | False    | Filter by iops.other    |
| iops.read     | integer | query | False    | Filter by iops.read     |
| iops.write    | integer | query | False    | Filter by iops.write    |
| iops.total    | integer | query | False    | Filter by iops.total    |
| timestamp     | string  | query | False    | Filter by timestamp     |
| latency.other | integer | query | False    | Filter by latency.other |
| latency.read  | integer | query | False    | Filter by latency.read  |

| <b>Name</b>      | <b>Type</b> | <b>In</b> | <b>Required</b> | <b>Description</b>                  |
|------------------|-------------|-----------|-----------------|-------------------------------------|
| latency.write    | integer     | query     | False           | Filter by latency.write             |
| latency.total    | integer     | query     | False           | Filter by latency.total             |
| duration         | string      | query     | False           | Filter by duration                  |
| status           | string      | query     | False           | Filter by status                    |
| throughput.other | integer     | query     | False           | Filter by throughput.other          |
| throughput.read  | integer     | query     | False           | Filter by throughput.read           |
| throughput.write | integer     | query     | False           | Filter by throughput.write          |
| throughput.total | integer     | query     | False           | Filter by throughput.total          |
| uuid             | string      | path      | True            | Unique identifier of the aggregate. |

| Name     | Type   | In    | Required | Description  |
|----------|--------|-------|----------|--|
| interval | string | query | False    | <p>The time range for the data. Values can be 1h, 1d, 1w, 1m, or 1y. The period for each time range is as follows:</p> <ul style="list-style-type: none"> <li>• 1h: Metrics over the most recent hour sampled over 15 seconds.</li> <li>• 1d: Metrics over the most recent day sampled over 5 minutes.</li> <li>• 1w: Metrics over the most recent week sampled over 30 minutes.</li> <li>• 1m: Metrics over the most recent month sampled over 2 hours.</li> <li>• 1y: Metrics over the most recent year sampled over a day.</li> <li>• Default value: 1</li> <li>• enum: ["1h", "1d", "1w", "1m", "1y"]</li> </ul> |



| Name   | Type           | In      | Required | Description   |
|--|----------------|---------|----------|---|
| return_timeout   | integer        | query   | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| fields   | array[string]  | query   | False    | Specify the fields to return.   |
| max_records  | integer        | query   | False    | Limit the number of records returned.   |
| order_by   | array[string]  | query   | False    | Order results by specified fields and optional [asc   |
| desc] direction. Default direction is 'asc' for ascending. | return_records | boolean | query    | False   |

## Response

Status: 200, Ok

| Name        | Type                             | Description       |
|-------------|----------------------------------|-------------------|
| _links      | <a href="#">_links</a>           |                   |
| num_records | integer                          | Number of records |
| records     | array[ <a href="#">records</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 8586225    | Encountered unexpected error in retrieving metrics for the requested aggregate. |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

iops

The rate of I/O operations observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

latency

The round trip latency in microseconds observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### throughput

The rate of throughput bytes per second observed at the storage object.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

### records

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| duration               | string                 | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |

| Name       | Type                       | Description   |
|------------|----------------------------|---|
| iops       | <a href="#">iops</a>       | The rate of I/O operations observed at the storage object.  |
| latency    | <a href="#">latency</a>    | The round trip latency in microseconds observed at the storage object.  |
| status     | string                     | Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | <a href="#">throughput</a> | The rate of throughput bytes per second observed at the storage object.   |
| timestamp  | string                     | The timestamp of the performance data.  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage bridges

### Storage bridges endpoint overview

#### Retrieving storage bridge information

The storage bridge GET API retrieves all of the bridges in the cluster.

---

#### Examples

1) Retrieves a list of bridges from the cluster

The following example shows the response with a list of bridges from the cluster:

---

```
# The API:
/api/storage/bridges

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/bridges" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "wwn": "2000001086a18100",
      "name": "ATTO_2000001086a18100",
      "_links": {
        "self": {
          "href": "/api/storage/bridges/2000001086a18100"
        }
      }
    },
    {
      "wwn": "2000001086a18380",
      "name": "ATTO_2000001086a18380",
      "_links": {
        "self": {
          "href": "/api/storage/bridges/2000001086a18380"
        }
      }
    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/storage/bridges/"
    }
  }
}
```

---

## 2) Retrieves a specific bridge from the cluster

The following example shows the response of the requested bridge. If there is no bridge with the requested wwn, an error is returned.

---



```

# The API:
/api/storage/bridges/{wnn}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/bridges/2000001086a18100" -H
"accept: application/hal+json"

# The response:
{
  "wnn": "2000001086a18100",
  "chassis_throughput_state": "ok",
  "dram_single_bit_error_count": 0,
  "firmware_version": "3.10 007A",
  "ip_address": "10.226.57.178",
  "security_enabled": false,
  "monitoring_enabled": true,
  "model": "FibreBridge 7500N",
  "state": "ok",
  "managed_by": "in_band",
  "serial_number": "FB7500N102450",
  "symbolic_name": "RTP-FCSAS02-41KK10",
  "vendor": "atto",
  "name": "ATTO_2000001086a18100",
  "last_reboot": {
    "reason": {
      "message": "Reason: \"FirmwareRestart Command\".",
      "code": "39321683"
    }
  },
  "time": "2020-12-09T00:47:58-05:00"
},
"paths": [
{
  "name": "0e",
  "node": {
    "name": "sti8080mcc-htp-005",
    "uuid": "ecc3d992-3a86-11eb-9fab-00a0985a6024",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/ecc3d992-3a86-11eb-9fab-00a0985a6024"
      }
    }
  }
},
  "_links": {
    "self": {
      "href": "/api/storage/ports/ecc3d992-3a86-11eb-9fab-00a0985a6024/0e"
    }
  }
}

```

```

    }
  },
  "target_port": {
    "wwn": "2100001086a18380"
  }
}
],
"temperature_sensor": {
  "name": "Chassis Temperature Sensor",
  "minimum": 0,
  "maximum": 90,
  "reading": 54,
  "state": "ok"
},
"fc_ports": [
{
  "id": 1,
  "state": "online",
  "enabled": true,
  "negotiated_data_rate": 8,
  "configured_data_rate": 8,
  "conn_mode": "ptp",
  "data_rate_capability": 16,
  "wwn": "2100001086a18100",
  "peer_wwn": "0000000000000000",
  "sfp": {
    "vendor": "FINISAR CORP.",
    "serial_number": "UW106SA",
    "part_number": "FTLF8529P3BCV",
    "data_rate_capability": 16
  }
},
{
  "id": 2,
  "state": "online",
  "enabled": true,
  "negotiated_data_rate": 16,
  "configured_data_rate": 16,
  "conn_mode": "ptp",
  "data_rate_capability": 16,
  "wwn": "2200001086a18100",
  "peer_wwn": "0000000000000000",
  "sfp": {
    "vendor": "FINISAR CORP.",
    "serial_number": "UW1072B",
    "part_number": "FTLF8529P3BCV",

```

```

    "data_rate_capability": 16
  }
}
],
"power_supply_units": [
{
  "name": "A",
  "state": "ok"
},
{
  "name": "B",
  "state": "ok"
}
],
"sas_ports": [
{
  "id": 1,
  "state": "online",
  "enabled": true,
  "data_rate_capability": 12,
  "negotiated_data_rate": 6,
  "wwn": "5001086000a18100",
  "phy_1": {
    "state": "online"
  },
  "phy_2": {
    "state": "online"
  },
  "phy_3": {
    "state": "online"
  },
  "phy_4": {
    "state": "online"
  },
  "cable": {
    "vendor": "Molex Inc.",
    "serial_number": "618130935",
    "technology": "Passive Copper 5m ID:00",
    "part_number": "112-00431"
  }
},
{
  "state": "offline",
  "enabled": false,
  "data_rate_capability": 12,
  "negotiated_data_rate": 0,

```

```
"wwn": "5001086000a18104",
"phy_1": {
  "state": "offline"
},
"phy_2": {
  "state": "offline"
},
"phy_3": {
  "state": "offline"
},
"phy_4": {
  "state": "offline"
},
},
{
  "state": "offline",
  "enabled": false,
  "data_rate_capability": 12,
  "negotiated_data_rate": 0,
  "wwn": "5001086000a18108",
  "phy_1": {
    "state": "offline"
  },
  "phy_2": {
    "state": "offline"
  },
  "phy_3": {
    "state": "offline"
  },
  "phy_4": {
    "state": "offline"
  },
},
{
  "state": "offline",
  "enabled": false,
  "data_rate_capability": 12,
  "negotiated_data_rate": 0,
  "wwn": "5001086000a1810c",
  "phy_1": {
    "state": "offline"
  },
  "phy_2": {
    "state": "offline"
  },
  "phy_3": {
```

```

    "state": "offline"
  },
  "phy_4": {
    "state": "offline"
  },
}
],
"_links": {
"self": {
  "href": "/api/storage/bridges/2000001086a18100"
}
}
}

```

## Retrieve a collection of bridges

GET /storage/bridges

**Introduced In:** 9.9

Retrieves a collection of bridges.

### Related ONTAP commands

- `storage bridge show`

### Learn more

- [DOC /storage/bridges](#)

### Parameters

| Name                     | Type   | In    | Required | Description                        |
|--------------------------|--------|-------|----------|------------------------------------|
| chassis_throughput_state | string | query | False    | Filter by chassis_throughput_state |
| ip_address               | string | query | False    | Filter by ip_address               |
| name                     | string | query | False    | Filter by name                     |
| last_reboot.time         | string | query | False    | Filter by last_reboot.time         |

| Name                                 | Type    | In    | Required | Description   |
|--------------------------------------|---------|-------|----------|---|
| last_reboot.reason.arguments.message | string  | query | False    | Filter by last_reboot.reason.arguments.message<br><br>• Introduced in: 9.10 |
| last_reboot.reason.arguments.code    | string  | query | False    | Filter by last_reboot.reason.arguments.code<br><br>• Introduced in: 9.10    |
| last_reboot.reason.target            | string  | query | False    | Filter by last_reboot.reason.target<br><br>• Introduced in: 9.10            |
| last_reboot.reason.code              | string  | query | False    | Filter by last_reboot.reason.code   |
| last_reboot.reason.message           | string  | query | False    | Filter by last_reboot.reason.message  |
| security_enabled                     | boolean | query | False    | Filter by security_enabled  |
| serial_number                        | string  | query | False    | Filter by serial_number   |
| sas_ports.id                         | integer | query | False    | Filter by sas_ports.id  |
| sas_ports.phy_1.state                | string  | query | False    | Filter by sas_ports.phy_1.state   |
| sas_ports.wwn                        | string  | query | False    | Filter by sas_ports.wwn   |
| sas_ports.state                      | string  | query | False    | Filter by sas_ports.state   |

| Name                           | Type    | In    | Required | Description                              |
|--------------------------------|---------|-------|----------|--|
| sas_ports.phy_4.state          | string  | query | False    | Filter by sas_ports.phy_4.state          |
| sas_ports.phy_2.state          | string  | query | False    | Filter by sas_ports.phy_2.state          |
| sas_ports.data_rate_capability | number  | query | False    | Filter by sas_ports.data_rate_capability |
| sas_ports.enabled              | boolean | query | False    | Filter by sas_ports.enabled              |
| sas_ports.negotiated_data_rate | number  | query | False    | Filter by sas_ports.negotiated_data_rate |
| sas_ports.cable.part_number    | string  | query | False    | Filter by sas_ports.cable.part_number    |
| sas_ports.cable.vendor         | string  | query | False    | Filter by sas_ports.cable.vendor         |
| sas_ports.cable.serial_number  | string  | query | False    | Filter by sas_ports.cable.serial_number  |
| sas_ports.cable.technology     | string  | query | False    | Filter by sas_ports.cable.technology     |
| sas_ports.phy_3.state          | string  | query | False    | Filter by sas_ports.phy_3.state          |
| model                          | string  | query | False    | Filter by model                          |
| power_supply_units.state       | string  | query | False    | Filter by power_supply_units.state       |

| Name                            | Type    | In    | Required | Description  |
|---------------------------------|---------|-------|----------|--|
| power_supply_units.name         | string  | query | False    | Filter by power_supply_units.name                                      |
| monitoring_enabled              | boolean | query | False    | Filter by monitoring_enabled   |
| errors.type                     | string  | query | False    | Filter by errors.type  |
| errors.component.name           | string  | query | False    | Filter by errors.component.name  |
| errors.component.unique_id      | string  | query | False    | Filter by errors.component.unique_id                                   |
| errors.component.id             | integer | query | False    | Filter by errors.component.id  |
| errors.reason.arguments.message | string  | query | False    | Filter by errors.reason.arguments.message<br><br>• Introduced in: 9.10 |
| errors.reason.arguments.code    | string  | query | False    | Filter by errors.reason.arguments.code<br><br>• Introduced in: 9.10    |
| errors.reason.target            | string  | query | False    | Filter by errors.reason.target<br><br>• Introduced in: 9.10            |
| errors.reason.code              | string  | query | False    | Filter by errors.reason.code   |
| errors.reason.message           | string  | query | False    | Filter by errors.reason.message  |



| Name                        | Type    | In    | Required | Description                           |
|-----------------------------|---------|-------|----------|---------------------------------------|
| errors.severity             | string  | query | False    | Filter by errors.severity             |
| state                       | string  | query | False    | Filter by state                       |
| managed_by                  | string  | query | False    | Filter by managed_by                  |
| dram_single_bit_error_count | integer | query | False    | Filter by dram_single_bit_error_count |
| paths.target_port.id        | string  | query | False    | Filter by paths.target_port.id        |
| paths.target_port.name      | string  | query | False    | Filter by paths.target_port.name      |
| paths.target_port.wwn       | string  | query | False    | Filter by paths.target_port.wwn       |
| paths.source_port.id        | string  | query | False    | Filter by paths.source_port.id        |
| paths.source_port.name      | string  | query | False    | Filter by paths.source_port.name      |
| paths.node.uuid             | string  | query | False    | Filter by paths.node.uuid             |
| paths.node.name             | string  | query | False    | Filter by paths.node.name             |
| paths.name                  | string  | query | False    | Filter by paths.name                  |
| symbolic_name               | string  | query | False    | Filter by symbolic_name               |
| vendor                      | string  | query | False    | Filter by vendor                      |
| fc_ports.peer_wwn           | string  | query | False    | Filter by fc_ports.peer_wwn           |

| Name                              | Type    | In    | Required | Description                                 |
|-----------------------------------|---------|-------|----------|---|
| fc_ports.sfp.part_number          | string  | query | False    | Filter by fc_ports.sfp.part_number          |
| fc_ports.sfp.vendor               | string  | query | False    | Filter by fc_ports.sfp.vendor               |
| fc_ports.sfp.data_rate_capability | number  | query | False    | Filter by fc_ports.sfp.data_rate_capability |
| fc_ports.sfp.serial_number        | string  | query | False    | Filter by fc_ports.sfp.serial_number        |
| fc_ports.enabled                  | boolean | query | False    | Filter by fc_ports.enabled                  |
| fc_ports.data_rate_capability     | number  | query | False    | Filter by fc_ports.data_rate_capability     |
| fc_ports.connection_mode          | string  | query | False    | Filter by fc_ports.connection_mode          |
| fc_ports.negotiated_data_rate     | number  | query | False    | Filter by fc_ports.negotiated_data_rate     |
| fc_ports.id                       | integer | query | False    | Filter by fc_ports.id                       |
| fc_ports.configured_data_rate     | number  | query | False    | Filter by fc_ports.configured_data_rate     |
| fc_ports.state                    | string  | query | False    | Filter by fc_ports.state                    |
| fc_ports.wwn                      | string  | query | False    | Filter by fc_ports.wwn                      |
| temperature_sensor.state          | string  | query | False    | Filter by temperature_sensor.state          |

| Name                       | Type          | In    | Required | Description   |
|----------------------------|---------------|-------|----------|---|
| temperature_sensor.name    | string        | query | False    | Filter by temperature_sensor.name   |
| temperature_sensor.reading | integer       | query | False    | Filter by temperature_sensor.reading  |
| temperature_sensor.minimum | integer       | query | False    | Filter by temperature_sensor.minimum  |
| temperature_sensor.maximum | integer       | query | False    | Filter by temperature_sensor.maximum  |
| wwn                        | string        | query | False    | Filter by wwn   |
| firmware_version           | string        | query | False    | Filter by firmware_version  |
| fields                     | array[string] | query | False    | Specify the fields to return.   |
| max_records                | integer       | query | False    | Limit the number of records returned.   |
| return_records             | boolean       | query | False    | <p>The default is true for GET calls. When set to false, only the number of records is returned.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul> |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                                    | Description       |
|-------------|---|-------------------|
| _links      | <a href="#">_links</a>                  |                   |
| num_records | integer                                 | Number of records |
| records     | array[ <a href="#">storage_bridge</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "chassis_throughput_state": "ok",
    "errors": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      },
      "severity": "unknown",
      "type": "unknown"
    },
    "fc_ports": {
      "configured_data_rate": "0",
      "connection_mode": "loop",
      "data_rate_capability": "2",
      "negotiated_data_rate": "0",
      "peer_wwn": "200650eb1a238892",
      "sfp": {
        "data_rate_capability": "2"
      },
      "state": "error",
      "wwn": "2100001086a54100"
    },
    "firmware_version": "4.10 007A",
    "ip_address": "string",
    "last_reboot": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        }
      }
    }
  }
}
```

```

    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "time": "2020-12-09T00:47:58-05:00"
},
"managed_by": "snmp",
"model": "FibreBridge6500N",
"name": "ATTO_FibreBridge6500N_1",
"paths": {
  "name": "2c",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "source_port": {
    "id": "100050eb1a238892",
    "name": "rtp-fc03-41kk11:1"
  },
  "target_port": {
    "id": "100050eb1a238892",
    "name": "rtp-fc03-41kk11:6",
    "wwn": "2100001086a54100"
  }
},
"power_supply_units": {
  "state": "ok"
},
"sas_ports": {
  "data_rate_capability": "0",
  "negotiated_data_rate": "0",
  "state": "error",
  "wwn": "2100001086a54100"
},
"serial_number": "FB7600N100004",
"state": "unknown",
"symbolic_name": "rtp-fcsas03-41kk11",
"temperature_sensor": {
  "name": "Chassis temperature sensor",
  "state": "ok"
},

```

```
"vendor": "atto",
"wwn": "2000001086600476"
}
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

component

| Name      | Type    | Description                      |
|-----------|---------|----------------------------------|
| id        | integer | Bridge error component ID        |
| name      | string  | Bridge error component name      |
| unique_id | string  | Bridge error component unique ID |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

errors



| Name      | Type                      | Description           |
|-----------|---------------------------|-----------------------|
| component | <a href="#">component</a> |                       |
| reason    | <a href="#">error</a>     |                       |
| severity  | string                    | Bridge error severity |
| type      | string                    | Bridge error type     |

#### sfp

| Name                 | Type   | Description                                      |
|----------------------|--------|--|
| data_rate_capability | number | Bridge FC port SFP data rate capability, in Gbps |
| part_number          | string |  |
| serial_number        | string | Bridge FC port SFP serial number                 |
| vendor               | string | Bridge FC port SFP vendor                        |

#### fc\_ports

| Name                 | Type                | Description                                      |
|----------------------|---------------------|--|
| configured_data_rate | number              | Bridge FC port configured data rate, in Gbps     |
| connection_mode      | string              | Bridge FC port configured connection mode        |
| data_rate_capability | number              | Bridge FC port data rate capability, in Gbps     |
| enabled              | boolean             | Indicates whether the bridge FC port is enabled. |
| id                   | integer             | Bridge FC port index                             |
| negotiated_data_rate | number              | Bridge FC port negotiated data rate, in Gbps     |
| peer_wwn             | string              | Bridge FC port peer port world wide name         |
| sfp                  | <a href="#">sfp</a> |  |

| Name  | Type   | Description                    |
|-------|--------|--------------------------------|
| state | string | Bridge FC port state           |
| wwn   | string | Bridge FC port world wide name |

error

The error message and code explaining why the bridge rebooted.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

last\_reboot

| Name   | Type                  | Description  |
|--------|-----------------------|--|
| reason | <a href="#">error</a> | The error message and code explaining why the bridge rebooted. |
| time   | string                |  |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

source\_port

| Name | Type   | Description                     |
|------|--------|---------------------------------|
| id   | string | Initiator side switch port id   |
| name | string | Initiator side switch port name |

#### target\_port

| Name | Type   | Description                             |
|------|--------|---|
| id   | string | Target side switch port id              |
| name | string | Target side switch port name            |
| wwn  | string | Target side switch port world wide name |

#### paths

| Name        | Type                        | Description |
|-------------|-----------------------------|-------------|
| name        | string                      |             |
| node        | <a href="#">node</a>        |             |
| source_port | <a href="#">source_port</a> |             |
| target_port | <a href="#">target_port</a> |             |

#### power\_supply\_units

| Name  | Type   | Description             |
|-------|--------|-------------------------|
| name  | string | Power supply unit name  |
| state | string | Power supply unit state |

#### cable

| Name          | Type   | Description                |
|---------------|--------|----------------------------|
| part_number   | string | Bridge cable part number   |
| serial_number | string | Bridge cable serial number |
| technology    | string | Bridge cable type          |
| vendor        | string | Bridge cable vendor        |

phy\_1

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY1 state |

phy\_2

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY2 state |

phy\_3

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY3 state |

phy\_4

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY4 state |

sas\_ports

| Name                 | Type                  | Description                                     |
|----------------------|-----------------------|---|
| cable                | <a href="#">cable</a> |   |
| data_rate_capability | number                | Bridge SAS port data rate capability, in Gbps   |
| enabled              | boolean               | Indicates whether a bridge SAS port is enabled. |
| id                   | integer               | Bridge SAS port index                           |
| negotiated_data_rate | number                | Bridge SAS port negotiated data rate, in Gbps   |
| phy_1                | <a href="#">phy_1</a> |   |
| phy_2                | <a href="#">phy_2</a> |   |
| phy_3                | <a href="#">phy_3</a> |   |
| phy_4                | <a href="#">phy_4</a> |   |
| state                | string                | Bridge SAS port state                           |

| Name | Type   | Description                     |
|------|--------|---------------------------------|
| wwn  | string | Bridge SAS port world wide name |

#### temperature\_sensor

| Name    | Type    | Description   |
|---------|---------|---|
| maximum | integer | Maximum safe operating temperature, in degrees Celsius. |
| minimum | integer | Minimum safe operating temperature, in degrees Celsius. |
| name    | string  | Temperature sensor name                                 |
| reading | integer | Chassis temperature sensor reading, in degrees Celsius. |
| state   | string  |   |

#### storage\_bridge

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| chassis_throughput_state    | string                                      | Chassis throughput status                               |
| dram_single_bit_error_count | integer                                     |   |
| errors                      | array[ <a href="#">errors</a> ]             |   |
| fc_ports                    | array[ <a href="#">fc_ports</a> ]           |   |
| firmware_version            | string                                      | Bridge firmware version                                 |
| ip_address                  | string                                      | IP Address  |
| last_reboot                 | <a href="#">last_reboot</a>                 |   |
| managed_by                  | string                                      |   |
| model                       | string                                      | Bridge model  |
| monitoring_enabled          | boolean                                     | Indicates whether monitoring is enabled for the bridge. |
| name                        | string                                      | Bridge name   |
| paths                       | array[ <a href="#">paths</a> ]              |   |
| power_supply_units          | array[ <a href="#">power_supply_units</a> ] |   |

| Name               | Type                               | Description   |
|--------------------|------------------------------------|---|
| sas_ports          | array[sas_ports]                   |   |
| security_enabled   | boolean                            | Indicates whether security is enabled for the bridge. |
| serial_number      | string                             | Bridge serial number                                  |
| state              | string                             | Bridge state  |
| symbolic_name      | string                             | Bridge symbolic name                                  |
| temperature_sensor | <a href="#">temperature_sensor</a> |   |
| vendor             | string                             | Bridge vendor   |
| wwn                | string                             | Bridge world wide name                                |

## Retrieve a specific bridge

GET /storage/bridges/{wwn}

**Introduced In:** 9.9

Retrieves a specific bridge

### Related ONTAP commands

- `storage bridge show`

### Learn more

- [DOC /storage/bridges](#)

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| wwn    | string        | path  | True     |                               |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name                        | Type                      | Description   |
|-----------------------------|---------------------------|---|
| chassis_throughput_state    | string                    | Chassis throughput status                               |
| dram_single_bit_error_count | integer                   |   |
| errors                      | array[errors]             |   |
| fc_ports                    | array[fc_ports]           |   |
| firmware_version            | string                    | Bridge firmware version                                 |
| ip_address                  | string                    | IP Address  |
| last_reboot                 | last_reboot               |   |
| managed_by                  | string                    |   |
| model                       | string                    | Bridge model  |
| monitoring_enabled          | boolean                   | Indicates whether monitoring is enabled for the bridge. |
| name                        | string                    | Bridge name   |
| paths                       | array[paths]              |   |
| power_supply_units          | array[power_supply_units] |   |
| sas_ports                   | array[sas_ports]          |   |
| security_enabled            | boolean                   | Indicates whether security is enabled for the bridge.   |
| serial_number               | string                    | Bridge serial number                                    |
| state                       | string                    | Bridge state  |
| symbolic_name               | string                    | Bridge symbolic name                                    |
| temperature_sensor          | temperature_sensor        |   |
| vendor                      | string                    | Bridge vendor   |
| wwn                         | string                    | Bridge world wide name                                  |

## Example response

```
{
  "chassis_throughput_state": "ok",
  "errors": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "severity": "unknown",
    "type": "unknown"
  },
  "fc_ports": {
    "configured_data_rate": "0",
    "connection_mode": "loop",
    "data_rate_capability": "2",
    "negotiated_data_rate": "0",
    "peer_wwn": "200650eb1a238892",
    "sfp": {
      "data_rate_capability": "2"
    },
    "state": "error",
    "wwn": "2100001086a54100"
  },
  "firmware_version": "4.10 007A",
  "ip_address": "string",
  "last_reboot": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "time": "2020-12-09T00:47:58-05:00"
  },
  "managed_by": "snmp",
  "model": "FibreBridge6500N",
  "name": "ATTO_FibreBridge6500N_1",
```



```

"paths": {
  "name": "2c",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "source_port": {
    "id": "100050eb1a238892",
    "name": "rtp-fc03-41kk11:1"
  },
  "target_port": {
    "id": "100050eb1a238892",
    "name": "rtp-fc03-41kk11:6",
    "wn": "2100001086a54100"
  }
},
"power_supply_units": {
  "state": "ok"
},
"sas_ports": {
  "data_rate_capability": "0",
  "negotiated_data_rate": "0",
  "state": "error",
  "wn": "2100001086a54100"
},
"serial_number": "FB7600N100004",
"state": "unknown",
"symbolic_name": "rtp-fcsas03-41kk11",
"temperature_sensor": {
  "name": "Chassis temperature sensor",
  "state": "ok"
},
"vendor": "atto",
"wn": "2000001086600476"
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

### component

| Name      | Type    | Description                      |
|-----------|---------|----------------------------------|
| id        | integer | Bridge error component ID        |
| name      | string  | Bridge error component name      |
| unique_id | string  | Bridge error component unique ID |

### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

### errors

| Name      | Type                      | Description           |
|-----------|---------------------------|-----------------------|
| component | <a href="#">component</a> |                       |
| reason    | <a href="#">error</a>     |                       |
| severity  | string                    | Bridge error severity |
| type      | string                    | Bridge error type     |

### sfp

| Name                 | Type   | Description                                      |
|----------------------|--------|--|
| data_rate_capability | number | Bridge FC port SFP data rate capability, in Gbps |
| part_number          | string |  |
| serial_number        | string | Bridge FC port SFP serial number                 |
| vendor               | string | Bridge FC port SFP vendor                        |

#### fc\_ports

| Name                 | Type                | Description                                      |
|----------------------|---------------------|--|
| configured_data_rate | number              | Bridge FC port configured data rate, in Gbps     |
| connection_mode      | string              | Bridge FC port configured connection mode        |
| data_rate_capability | number              | Bridge FC port data rate capability, in Gbps     |
| enabled              | boolean             | Indicates whether the bridge FC port is enabled. |
| id                   | integer             | Bridge FC port index                             |
| negotiated_data_rate | number              | Bridge FC port negotiated data rate, in Gbps     |
| peer_wwn             | string              | Bridge FC port peer port world wide name         |
| sfp                  | <a href="#">sfp</a> |  |
| state                | string              | Bridge FC port state                             |
| wwn                  | string              | Bridge FC port world wide name                   |

#### error

The error message and code explaining why the bridge rebooted.

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |

| Name    | Type   | Description                                 |
|---------|--------|---|
| code    | string | Error code                                  |
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

last\_reboot

| Name   | Type                  | Description  |
|--------|-----------------------|--|
| reason | <a href="#">error</a> | The error message and code explaining why the bridge rebooted. |
| time   | string                |  |

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

source\_port

| Name | Type   | Description                     |
|------|--------|---------------------------------|
| id   | string | Initiator side switch port id   |
| name | string | Initiator side switch port name |

target\_port

| Name | Type   | Description                             |
|------|--------|---|
| id   | string | Target side switch port id              |
| name | string | Target side switch port name            |
| wwn  | string | Target side switch port world wide name |

#### paths

| Name        | Type                        | Description |
|-------------|-----------------------------|-------------|
| name        | string                      |             |
| node        | <a href="#">node</a>        |             |
| source_port | <a href="#">source_port</a> |             |
| target_port | <a href="#">target_port</a> |             |

#### power\_supply\_units

| Name  | Type   | Description             |
|-------|--------|-------------------------|
| name  | string | Power supply unit name  |
| state | string | Power supply unit state |

#### cable

| Name          | Type   | Description                |
|---------------|--------|----------------------------|
| part_number   | string | Bridge cable part number   |
| serial_number | string | Bridge cable serial number |
| technology    | string | Bridge cable type          |
| vendor        | string | Bridge cable vendor        |

#### phy\_1

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY1 state |

#### phy\_2

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY2 state |

phy\_3

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY3 state |

phy\_4

| Name  | Type   | Description                |
|-------|--------|----------------------------|
| state | string | Bridge SAS port PHY4 state |

sas\_ports

| Name                 | Type                  | Description                                     |
|----------------------|-----------------------|---|
| cable                | <a href="#">cable</a> |   |
| data_rate_capability | number                | Bridge SAS port data rate capability, in Gbps   |
| enabled              | boolean               | Indicates whether a bridge SAS port is enabled. |
| id                   | integer               | Bridge SAS port index                           |
| negotiated_data_rate | number                | Bridge SAS port negotiated data rate, in Gbps   |
| phy_1                | <a href="#">phy_1</a> |   |
| phy_2                | <a href="#">phy_2</a> |   |
| phy_3                | <a href="#">phy_3</a> |   |
| phy_4                | <a href="#">phy_4</a> |   |
| state                | string                | Bridge SAS port state                           |
| wwn                  | string                | Bridge SAS port world wide name                 |

temperature\_sensor

| Name    | Type    | Description   |
|---------|---------|---|
| maximum | integer | Maximum safe operating temperature, in degrees Celsius. |
| minimum | integer | Minimum safe operating temperature, in degrees Celsius. |
| name    | string  | Temperature sensor name                                 |
| reading | integer | Chassis temperature sensor reading, in degrees Celsius. |
| state   | string  |   |

## Report cluster-wide storage details across different tiers

GET /storage/cluster

**Introduced In:** 9.6

Reports cluster wide storage details across different tiers. By default, this endpoint returns all fields. Supports the following roles: admin, and readonly.

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name                         | Type                             | Description   |
|------------------------------|----------------------------------|---|
| block_storage                | <a href="#">block_storage</a>    |   |
| cloud_storage                | <a href="#">cloud_storage</a>    |   |
| efficiency                   | <a href="#">space_efficiency</a> | Storage efficiency  |
| efficiency_without_snapshots | <a href="#">space_efficiency</a> | Storage efficiency that does not include the savings provided by Snapshot copies. |



| Name                                    | Type                             | Description  |
|---|----------------------------------|--|
| efficiency_without_snapshots_flexclones | <a href="#">space_efficiency</a> | Storage efficiency that does not include the savings provided by Snapshot copies and FlexClones. |

## Example response

```
{
  "block_storage": {
    "medias": {
      "efficiency": {
        "logical_used": 0,
        "ratio": 0,
        "savings": 0
      },
      "efficiency_without_snapshots": {
        "logical_used": 0,
        "ratio": 0,
        "savings": 0
      },
      "efficiency_without_snapshots_flexclones": {
        "logical_used": 0,
        "ratio": 0,
        "savings": 0
      },
      "type": "hdd"
    }
  },
  "cloud_storage": {
    "used": 0
  },
  "efficiency": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  },
  "efficiency_without_snapshots_flexclones": {
    "logical_used": 0,
    "ratio": 0,
    "savings": 0
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

space\_efficiency

Storage Efficiency

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

space\_efficiency

Storage efficiency that does not include the savings provided by Snapshot copies.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

space\_efficiency

Storage efficiency that does not include the savings provided by Snapshot copies and FlexClones.

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

medias

| Name      | Type    | Description     |
|-----------|---------|-----------------|
| available | integer | Available space |

| Name                                     | Type                             | Description  |
|--|----------------------------------|--|
| efficiency                               | <a href="#">space_efficiency</a> | Storage Efficiency   |
| efficiency_without_snapshots             | <a href="#">space_efficiency</a> | Storage efficiency that does not include the savings provided by Snapshot copies.                |
| efficiency_without_snapshots_flex_clones | <a href="#">space_efficiency</a> | Storage efficiency that does not include the savings provided by Snapshot copies and FlexClones. |
| physical_used                            | integer                          | Total physical used space  |
| size                                     | integer                          | Total space  |
| type                                     | string                           | The type of media being used   |
| used                                     | integer                          | Used space   |

#### block\_storage

| Name          | Type                            | Description                                  |
|---------------|---------------------------------|--|
| available     | integer                         | Available space across the cluster           |
| inactive_data | integer                         | Inactive data across all aggregates          |
| medias        | array[ <a href="#">medias</a> ] |  |
| physical_used | integer                         | Total physical used space across the cluster |
| size          | integer                         | Total space across the cluster               |
| used          | integer                         | Space used (includes volume reserves)        |

#### cloud\_storage

| Name | Type    | Description                |
|------|---------|----------------------------|
| used | integer | Total space used in cloud. |

#### space\_efficiency

## Storage efficiency

| Name         | Type    | Description   |
|--------------|---------|---|
| logical_used | integer | Logical used  |
| ratio        | number  | Data reduction ratio (logical_used / used)                |
| savings      | integer | Space saved by storage efficiencies (logical_used - used) |

## error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

## error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

# Manage disks

## Storage disks endpoint overview

### Retrieving storage disk information

The storage disk GET API retrieves all of the disks in the cluster.

### Examples

## 1) Retrieve a list of disks from the cluster.

The following example shows the response with a list of disks in the cluster:

```
# The API:
/api/storage/disks

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "name": "1.24.4",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.4"
        }
      }
    },
    {
      "name": "1.24.3",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.3"
        }
      }
    },
    {
      "name": "1.24.5",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.5"
        }
      }
    },
    {
      "name": "1.24.0",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.0"
        }
      }
    }
  ]
}
```

```

    },
    {
      "name": "1.24.2",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.2"
        }
      }
    },
    {
      "name": "1.24.1",
      "_links": {
        "self": {
          "href": "/api/storage/disks/1.24.1"
        }
      }
    }
  ],
  "num_records": 6,
  "_links": {
    "self": {
      "href": "/api/storage/disks"
    }
  }
}

```

## 2) Retrieve a specific disk from the cluster.

The following example shows the response of the requested disk. If there is no disk with the requested name, an error is returned:

```

# The API:
/api/storage/disks/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks/1.24.3" -H "accept:
application/hal+json"

# The response:
{
  "name": "1.24.3",
  "uid":
  "50000394:0808AA88:00000000:00000000:00000000:00000000:00000000:00000000:0

```



```
0000000:00000000",
"serial_number": "EC47PC5021SW",
"model": "X421_FAL12450A10",
"vendor": "NETAPP",
"firmware_version": "NA02",
"usable_size": 438304768000,
"rpm": 10000,
"type": "sas",
"effective_type": "sas",
"class": "performance",
"container_type": "aggregate",
"pool": "pool0",
"state": "present",
"node": {
  "uuid": "3a89ed49-8c6d-11e8-93bc-00a0985a64b6",
  "name": "node-2",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/3a89ed49-8c6d-11e8-93bc-00a0985a64b6"
    }
  }
},
"home_node": {
  "uuid": "3a89ed49-8c6d-11e8-93bc-00a0985a64b6",
  "name": "node-2",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/3a89ed49-8c6d-11e8-93bc-00a0985a64b6"
    }
  }
},
"aggregates": [
  {
    "uuid": "3fd9c345-ba91-4949-a7b1-6e2b898d74e3",
    "name": "node_2_SAS_1",
    "_links": {
      "self": {
        "href": "/api/storage/aggregates/3fd9c345-ba91-4949-a7b1-6e2b898d74e3"
      }
    }
  }
],
"shelf": {
  "uid": "10318311901725526608",
  "_links": {
```

```

    "self": {
      "href": "/api/storage/shelves/10318311901725526608"
    }
  },
  "local": true,
  "paths": [
    {
      "initiator": "3a",
      "port_name": "B",
      "port_type": "sas",
      "wwnn": "5000cca02f0e6768",
      "wwpn": "5000cca02f0e676a",
      "node": {
        "name": "vsim3",
        "uuid": "3f7fa09a-5c56-11ec-b366-005056bbbb3f",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/3f7fa09a-5c56-11ec-b366-005056bbbb3f"
          }
        }
      }
    },
    {
      "initiator": "3d",
      "port_name": "A",
      "port_type": "sas",
      "wwnn": "5000cca02f0e6768",
      "wwpn": "5000cca02f0e6769",
      "node": {
        "name": "vsim4",
        "uuid": "4f7fa09a-5c56-11ec-b366-005056bbbb3f",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/4f7fa09a-5c56-11ec-b366-005056bbbb3f"
          }
        }
      }
    },
    {
      "initiator": "3d",
      "port_name": "A",
      "port_type": "sas",
      "wwnn": "5000cca02f0e6768",

```

```

"wwpn": "5000cca02f0e6769",
"node": {
  "name": "vsim3",
  "uuid": "3f7fa09a-5c56-11ec-b366-005056bbbb3f",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/3f7fa09a-5c56-11ec-b366-
005056bbbb3f"
    }
  }
},
{
  "initiator": "3a",
  "port_name": "B",
  "port_type": "sas",
  "wwnn": "5000cca02f0e6768",
  "wwpn": "5000cca02f0e676a",
  "node": {
    "name": "vsim4",
    "uuid": "4f7fa09a-5c56-11ec-b366-005056bbbb3f",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/4f7fa09a-5c56-11ec-b366-
005056bbbb3f"
      }
    }
  }
},
"outage": {
  "persistently_failed": true,
  "reason": {
    "message": "Failed disk. Reason: \"admin failed\".",
    "code": "721081"
  }
},
"bay": 3,
"_links": {
  "self": {
    "href": "/api/storage/disks/1.24.3"
  }
},
"error": [
{
  "reason": {

```

```
    "message": "\"The node is configured with All-Flash Optimized
personality and this disk is not an SSD. The disk needs to be removed from
the system.\"",
    "code": "721082"
  },
  "type": "notallflashdisk"
}
],
"bytes_per_sector": 512,
"sector_count": 1172123568,
"right_size_sector_count": 5579776,
"physical_size": 438804988000,
"stats": {
  "average_latency": 6,
  "throughput": 1957888,
  "iops_total": 12854,
  "path_error_count": 0,
  "power_on_hours": 11797
}
}
```

### 3) Retrieving a specific disk from the hypervisor

The following example shows the response of the requested disk. If there is no disk with the requested name, an error is returned:

```
# The API:
/api/storage/disks/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks/NET-3.2" -H "accept:
application/hal+json"

# The response:
{
  "name": "NET-3.2",
  "uid":
"32343637:65386464:00000000:00000000:00000000:00000000:00000000:00000000:0
0000000:00000000",
  "serial_number": "3234363765386464",
  "model": "PHA-DISK",
  "vendor": "NETAPP",
  "firmware_version": "0001",
```

```

"type": "vmdisk",
"class": "virtual",
"container_type": "mediator",
"pool": "pool0",
"node": {
  "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
  "name": "aws-43905099-44129379-awsha-vm1",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
    }
  }
},
"home_node": {
"uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
"name": "aws-43905099-44129379-awsha-vm1",
"_links": {
  "self": {
    "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
  }
}
},
"local": true,
"paths": [
{
  "initiator": "0f",
  "port_name": "A",
  "port_type": "sas",
  "wwnn": "53059d50444f5476",
  "wwpn": "53059d50444f5476",
  "vmdisk_hypervisor_file_name": "LUN 4.0",
  "node": {
    "name": "aws-43905099-44129379-awsha-vm1",
    "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
      }
    }
  }
}
],
{
  "initiator": "0f",

```

```

    "port_name": "A",
    "port_type": "sas",
    "wwnn": "53059d50444f5476",
    "wwpn": "53059d50444f5476",
    "vmdisk_hypervisor_file_name": "LUN 2.0",
    "node": {
      "name": "aws-43905099-44129379-awsha-vm1",
      "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
        }
      }
    }
  ],
  "outage": {
    "persistently_failed": false,
    "reason": {
      "message": "Failed disk. Reason: \"\".",
      "code": "721081"
    }
  },
  "self_encrypting": false,
  "fips_certified": false,
  "bytes_per_sector": 512,
  "sector_count": 204808,
  "right_size_sector_count": 5579776,
  "physical_size": 204808,
  "stats": {
    "average_latency": 2157188883,
    "throughput": 4096,
    "iops_total": 1,
    "path_error_count": 0,
    "power_on_hours": 0
  },
  "_links": {
    "self": {
      "href": "/api/storage/disks/NET-3.2"
    }
  }
}

```

## Modifying storage disk

The storage disk PATCH API modifies disk ownership, unfails a disk, or updates encrypting drive authentication keys (AKs) in the cluster. The storage disk API currently supports patching one attribute at a time.

### Updating the disk ownership for a specified disk

#### 1. When the disk is not assigned

When the disk is a spare (or unowned) disk and node name is specified, the PATCH operation assigns the disk to the specified node.

#### 2. When the disk is already assigned

When the disk is already assigned (already has a owner), and a new node is specified, the PATCH operation changes the ownership to the new node.

### Removing the disk ownership for a specified disk

When the disk is already assigned, and node name is specified as null (no-quotes), the PATCH operation removes the owner.

---

## Examples

### 1. Update the disk ownership for an unowned disk

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks/<disk-name>" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json" -d
'{"node": {"name": "node-name"}}'

# The response:
{
}
```

---

### 2. Update the disk ownership for an already owned disk

---

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks/<disk-name>" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json" -d
'{"node": {"name": "node-name"}}'

# The response:
{
}
```

---

### 3. Rekey the data AK of all encrypting drives to an AK selected automatically by the system

---

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-
ip>/api/storage/disks?name=*&encryption_operation=rekey_data_auto_id" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json"

# The response contains the number of disks attempted.
{
  "num_records": 32
}
```

---

### 4. Cryptographically sanitize a spare or broken disk

---



```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-
name>&encryption_operation=sanitize_disk" -H "accept:
application/hal+json" -H "Content-Type: application/hal+json"

# The response contains the number of disks attempted.
{
  "num_records": 1
}
```

---

## 5. Unfailing a disk to a spare.

---

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-name>" -d
'{"state": "spare"}' -H "accept: application/hal+json" -H "Content-Type:
application/hal+json"

# The response:
{
}
```

---

## 6. Unfailing a disk and attempting to reassimilate filesystem labels.

If unable or unnecessary to reassimilate filesystem labels, the disk will be set as spare.

---

```

# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-name>" -d
'{"state": "present"}' -H "accept: application/hal+json" -H "Content-Type:
application/hal+json"

# The response:
{
}

```

## Retrieve a collection of disks

GET /storage/disks

**Introduced In:** 9.6

Retrieves a collection of disks.

### Related ONTAP commands

- `storage disk show`

### Learn more

- [DOC /storage/disks](#)

### Parameters

| Name        | Type    | In    | Required | Description   |
|-------------|---------|-------|----------|---|
| key_id.fips | string  | query | False    | Filter by key_id.fips<br><ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul> |
| key_id.data | string  | query | False    | Filter by key_id.data<br><ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> </ul> |
| local       | boolean | query | False    | Filter by local<br><ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>       |

| Name                           | Type    | In    | Required | Description   |
|--------------------------------|---------|-------|----------|---|
| serial_number                  | string  | query | False    | Filter by serial_number   |
| home_node.uuid                 | string  | query | False    | Filter by home_node.uuid  |
| home_node.name                 | string  | query | False    | Filter by home_node.name  |
| right_size_sector_count        | integer | query | False    | Filter by right_size_sector_count<br><br>• Introduced in: 9.11        |
| error.type                     | string  | query | False    | Filter by error.type<br><br>• Introduced in: 9.9                      |
| error.reason.arguments.message | string  | query | False    | Filter by error.reason.arguments.message<br><br>• Introduced in: 9.10 |
| error.reason.arguments.code    | string  | query | False    | Filter by error.reason.arguments.code<br><br>• Introduced in: 9.10    |
| error.reason.target            | string  | query | False    | Filter by error.reason.target<br><br>• Introduced in: 9.10            |
| error.reason.code              | string  | query | False    | Filter by error.reason.code<br><br>• Introduced in: 9.9               |

| Name                   | Type    | In    | Required | Description  |
|------------------------|---------|-------|----------|--|
| error.reason.message   | string  | query | False    | Filter by error.reason.message<br><br>• Introduced in: 9.9   |
| physical_size          | integer | query | False    | Filter by physical_size<br><br>• Introduced in: 9.11         |
| class                  | string  | query | False    | Filter by class  |
| compliance_standard    | string  | query | False    | Filter by compliance_standard<br><br>• Introduced in: 9.11   |
| stats.power_on_hours   | integer | query | False    | Filter by stats.power_on_hours<br><br>• Introduced in: 9.9   |
| stats.iops_total       | integer | query | False    | Filter by stats.iops_total<br><br>• Introduced in: 9.9       |
| stats.path_error_count | integer | query | False    | Filter by stats.path_error_count<br><br>• Introduced in: 9.9 |
| stats.average_latency  | integer | query | False    | Filter by stats.average_latency<br><br>• Introduced in: 9.9  |

| Name                    | Type    | In    | Required | Description  |
|-------------------------|---------|-------|----------|--|
| stats.throughput        | integer | query | False    | Filter by stats.throughput<br><br>• Introduced in: 9.9         |
| firmware_version        | string  | query | False    | Filter by firmware_version                                     |
| storage_pool.name       | string  | query | False    | Filter by storage_pool.name<br><br>• Introduced in: 9.11       |
| storage_pool.uuid       | string  | query | False    | Filter by storage_pool.uuid<br><br>• Introduced in: 9.11       |
| vendor                  | string  | query | False    | Filter by vendor   |
| type                    | string  | query | False    | Filter by type   |
| virtual.container       | string  | query | False    | Filter by virtual.container<br><br>• Introduced in: 9.11       |
| virtual.object          | string  | query | False    | Filter by virtual.object<br><br>• Introduced in: 9.11          |
| virtual.storage_account | string  | query | False    | Filter by virtual.storage_account<br><br>• Introduced in: 9.11 |
| dr_node.name            | string  | query | False    | Filter by dr_node.name   |

| Name             | Type    | In    | Required | Description   |
|------------------|---------|-------|----------|---|
| dr_node.uuid     | string  | query | False    | Filter by dr_node.uuid                                  |
| sector_count     | integer | query | False    | Filter by sector_count<br><br>• Introduced in: 9.9      |
| bytes_per_sector | integer | query | False    | Filter by bytes_per_sector<br><br>• Introduced in: 9.9  |
| state            | string  | query | False    | Filter by state   |
| control_standard | string  | query | False    | Filter by control_standard<br><br>• Introduced in: 9.11 |
| model            | string  | query | False    | Filter by model   |
| rpm              | integer | query | False    | Filter by rpm   |
| shelf.uuid       | string  | query | False    | Filter by shelf.uuid                                    |
| effective_type   | string  | query | False    | Filter by effective_type<br><br>• Introduced in: 9.9    |
| overall_security | string  | query | False    | Filter by overall_security<br><br>• Introduced in: 9.11 |
| name             | string  | query | False    | Filter by name  |
| pool             | string  | query | False    | Filter by pool  |
| aggregates.uuid  | string  | query | False    | Filter by aggregates.uuid                               |

| Name                            | Type    | In    | Required | Description  |
|---------------------------------|---------|-------|----------|--|
| aggregates.name                 | string  | query | False    | Filter by aggregates.name  |
| usable_size                     | integer | query | False    | Filter by usable_size  |
| protection_mode                 | string  | query | False    | Filter by protection_mode<br><br>• Introduced in: 9.7                  |
| outage.persistently_failed      | boolean | query | False    | Filter by outage.persistently_failed<br><br>• Introduced in: 9.9       |
| outage.reason.arguments.message | string  | query | False    | Filter by outage.reason.arguments.message<br><br>• Introduced in: 9.10 |
| outage.reason.arguments.code    | string  | query | False    | Filter by outage.reason.arguments.code<br><br>• Introduced in: 9.10    |
| outage.reason.target            | string  | query | False    | Filter by outage.reason.target<br><br>• Introduced in: 9.10            |
| outage.reason.code              | string  | query | False    | Filter by outage.reason.code<br><br>• Introduced in: 9.9               |

| Name                              | Type    | In    | Required | Description  |
|-----------------------------------|---------|-------|----------|--|
| outage.reason.message             | string  | query | False    | Filter by outage.reason.message<br><br>• Introduced in: 9.9              |
| fips_certified                    | boolean | query | False    | Filter by fips_certified<br><br>• Introduced in: 9.7                     |
| node.uuid                         | string  | query | False    | Filter by node.uuid  |
| node.name                         | string  | query | False    | Filter by node.name  |
| container_type                    | string  | query | False    | Filter by container_type   |
| uid                               | string  | query | False    | Filter by uid  |
| bay                               | integer | query | False    | Filter by bay  |
| paths.wwpn                        | string  | query | False    | Filter by paths.wwpn<br><br>• Introduced in: 9.9                         |
| paths.port_name                   | string  | query | False    | Filter by paths.port_name<br><br>• Introduced in: 9.9                    |
| paths.port_type                   | string  | query | False    | Filter by paths.port_type<br><br>• Introduced in: 9.9                    |
| paths.vmdisk_hypervisor_file_name | string  | query | False    | Filter by paths.vmdisk_hypervisor_file_name<br><br>• Introduced in: 9.11 |



| Name                    | Type          | In    | Required | Description  |
|-------------------------|---------------|-------|----------|--|
| paths.initiator         | string        | query | False    | Filter by paths.initiator<br><br>• Introduced in: 9.9  |
| paths.wwnn              | string        | query | False    | Filter by paths.wwnn<br><br>• Introduced in: 9.9       |
| paths.node.uuid         | string        | query | False    | Filter by paths.node.uuid<br><br>• Introduced in: 9.11 |
| paths.node.name         | string        | query | False    | Filter by paths.node.name<br><br>• Introduced in: 9.11 |
| rated_life_used_percent | integer       | query | False    | Filter by rated_life_used_percent                      |
| self_encrypting         | boolean       | query | False    | Filter by self_encrypting<br><br>• Introduced in: 9.7  |
| drawer.slot             | integer       | query | False    | Filter by drawer.slot                                  |
| drawer.id               | integer       | query | False    | Filter by drawer.id                                    |
| fields                  | array[string] | query | False    | Specify the fields to return.                          |
| max_records             | integer       | query | False    | Limit the number of records returned.                  |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                          | Description       |
|-------------|-------------------------------|-------------------|
| _links      | <a href="#">_links</a>        |                   |
| num_records | integer                       | Number of records |
| records     | array[ <a href="#">disk</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "aggregates": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "bay": 1,
    "bytes_per_sector": 520,
    "class": "solid_state",
    "compliance_standard": "FIPS 140-2",
    "container_type": "spare",
    "control_standard": "TCG Enterprise",
    "dr_node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "effective_type": "vmdisk",
    "error": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      },
      "type": "notallflashdisk"
    },
    "firmware_version": "NA51",
    "home_node": {
```

```

    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "model": "X421_HCOBE450A10",
  "name": "1.0.1",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "outage": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "overall_security": "Level 2",
  "paths": {
    "initiator": "3a",
    "node.name": "vsim4",
    "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
    "port_name": "A",
    "port_type": "sas",
    "vmdisk_hypervisor_file_name": "xvds vol0a0567ae156ca59f6",
    "wwnn": "5000c2971c1b2b8c",
    "wwpn": "5000c2971c1b2b8d"
  },
  "physical_size": 228930,
  "pool": "pool0",
  "protection_mode": "data",
  "rated_life_used_percent": 10,
  "right_size_sector_count": 1172123568,

```

```

"rpm": 15000,
"sector_count": 1172123568,
"serial_number": "KHG2VX8R",
"shelf": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "uid": "7777841915827391056"
},
"state": "present",
"stats": {
  "average_latency": 3,
  "iops_total": 12854,
  "path_error_count": 0,
  "power_on_hours": 21016,
  "throughput": 1957888
},
"storage_pool": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "storage_pool_1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"type": "ssd",
"uid":
"002538E5:71B00B2F:00000000:00000000:00000000:00000000:00000000:00000000:00000000:00000000",
"usable_size": 959934889984,
"vendor": "NETAPP",
"virtual": {
  "container": "nviet12122018113936-rg",
  "object": "f1fu63se",
  "storage_account": "nviet12122018113936ps"
}
}
}

```

**Error**

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

dr\_node

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

drawer

| Name | Type    | Description |
|------|---------|-------------|
| id   | integer |             |
| slot | integer |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

## error

The message and code detailing the error state of this disk.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## disk\_error\_info

| Name   | Type                  | Description  |
|--------|-----------------------|--|
| reason | <a href="#">error</a> | The message and code detailing the error state of this disk. |
| type   | string                | Disk error type.   |

## home\_node

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

## key\_id

| Name | Type   | Description                           |
|------|--------|---------------------------------------|
| data | string | Key ID of the data authentication key |
| fips | string | Key ID of the FIPS authentication key |

## node

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |



| Name | Type   | Description |
|------|--------|-------------|
| uuid | string |             |

error

This error message and code explaining the disk failure.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

| Name                | Type                  | Description  |
|---------------------|-----------------------|--|
| persistently_failed | boolean               | Indicates whether RAID maintains the state of this disk as failed accross reboots. |
| reason              | <a href="#">error</a> | This error message and code explaining the disk failure.                           |

disk\_path\_info

| Name      | Type   | Description                                       |
|-----------|--------|---|
| initiator | string | Initiator port.                                   |
| node.name | string | Controller with the initiator port for this path. |
| node.uuid | string | Controller UUID, to identify node for this path.  |
| port_name | string | Name of the disk port.                            |
| port_type | string | Disk port type.                                   |

| Name                        | Type   | Description                           |
|-----------------------------|--------|---------------------------------------|
| vmdisk_hypervisor_file_name | string | Virtual disk hypervisor file name.    |
| wwnn                        | string | Target device's World Wide Node Name. |
| wwpn                        | string | Target device's World Wide Port Name. |

#### shelf

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| uid    | string                 |             |

#### stats

| Name             | Type    | Description  |
|------------------|---------|--|
| average_latency  | integer | Average I/O latency across all active paths, in milliseconds.                          |
| iops_total       | integer | Total I/O operations per second read and written to this disk across all active paths. |
| path_error_count | integer | Disk path error count; failed I/O operations.  |
| power_on_hours   | integer | Hours powered on.  |
| throughput       | integer | Total disk throughput per second across all active paths, in bytes.                    |

#### storage\_pool

##### Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### virtual

Information about backing storage for disks on cloud platforms.

| Name            | Type   | Description                               |
|-----------------|--------|---|
| container       | string | Container name of the virtual disk.       |
| object          | string | Object name of the virtual disk.          |
| storage_account | string | Storage account name of the virtual disk. |

#### disk

| Name                 | Type                                     | Description  |
|----------------------|--|--|
| aggregates           | array[ <a href="#">aggregates</a> ]      | List of aggregates sharing this disk   |
| bay                  | integer                                  | Disk shelf bay   |
| bytes_per_sector     | integer                                  | Bytes per sector.  |
| class                | string                                   | Disk class   |
| compliance_standard  | string                                   | Security standard that the device is certified to.   |
| container_type       | string                                   | Type of overlying disk container   |
| control_standard     | string                                   | Standard that the device supports for encryption control.  |
| dr_node              | <a href="#">dr_node</a>                  |  |
| drawer               | <a href="#">drawer</a>                   |  |
| effective_type       | string                                   | Effective Disk type  |
| encryption_operation | string                                   | This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET. |
| error                | array[ <a href="#">disk_error_info</a> ] | List of disk errors information.   |
| fips_certified       | boolean                                  |  |
| firmware_version     | string                                   |  |
| home_node            | <a href="#">home_node</a>                |  |

| Name                    | Type                                    | Description   |
|-------------------------|---|---|
| key_id                  | <a href="#">key_id</a>                  |   |
| local                   | boolean                                 | Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.   |
| model                   | string                                  |   |
| name                    | string                                  | Cluster-wide disk name  |
| node                    | <a href="#">node</a>                    |   |
| outage                  | <a href="#">outage</a>                  | Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.  |
| overall_security        | string                                  | Overall Security rating, for FIPS-certified devices.  |
| paths                   | array[ <a href="#">disk_path_info</a> ] | List of paths to a disk   |
| physical_size           | integer                                 | Physical size, in units of bytes  |
| pool                    | string                                  | Pool to which disk is assigned  |
| protection_mode         | string                                  | Mode of drive data protection and FIPS compliance. Possible values are: <ul style="list-style-type: none"> <li>• <i>open</i> - Data is unprotected</li> <li>• <i>data</i> - Data protection only, without FIPS compliance</li> <li>• <i>part</i> - Data is unprotected; other FIPS compliance settings present</li> <li>• <i>full</i> - Full data and FIPS compliance protection</li> <li>• <i>miss</i> - Protection mode information is not available</li> </ul> |
| rated_life_used_percent | integer                                 | Percentage of rated life used   |

| Name                    | Type                         | Description  |
|-------------------------|------------------------------|--|
| right_size_sector_count | integer                      | Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk. |
| rpm                     | integer                      | Revolutions per minute   |
| sector_count            | integer                      | Number of sectors on the disk.   |
| self_encrypting         | boolean                      |  |
| serial_number           | string                       |  |
| shelf                   | <a href="#">shelf</a>        |  |
| state                   | string                       | State  |
| stats                   | <a href="#">stats</a>        |  |
| storage_pool            | <a href="#">storage_pool</a> | Shared Storage Pool  |
| type                    | string                       | Disk interface type  |
| uid                     | string                       | The unique identifier for a disk   |
| usable_size             | integer                      |  |
| vendor                  | string                       |  |
| virtual                 | <a href="#">virtual</a>      | Information about backing storage for disks on cloud platforms.                                      |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update disk ownership, change authentication keys, or sanitize disks

PATCH /storage/disks

**Introduced In:** 9.7

Updates disk ownership, changes authentication keys, or sanitizes disks.

### Related ONTAP commands

- `storage disk assign`
- `storage disk removeowner`
- `storage encryption disk modify -data-key-id`
- `storage encryption disk sanitize`
- `security key-manager key query -key-type NSE-AK`
- `storage disk unfailed`

### Learn more

- [DOC /storage/disks](#)

### Parameters

| Name | Type   | In    | Required | Description   |
|------|--------|-------|----------|---|
| name | string | query | False    | Disk name   |
| node | string | query | False    | Node to assign disk<br><ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul>     |
| pool | string | query | False    | Pool to assign disk to<br><ul style="list-style-type: none"><li>• Introduced in: 9.11</li></ul> |

| Name                 | Type   | In    | Required | Description   |
|----------------------|--------|-------|----------|---|
| encryption_operation | string | query | False    | <p>Name of the operation to apply to encrypting disks.</p> <ul style="list-style-type: none"> <li>• rekey_data_default changes the data authentication key (AK) to the drive-unique Manufacture Secure ID (MSID) value. Allows the drive to be attached to other clusters. Disables data-at-rest protection without erasing the data.</li> <li>• rekey_data_auto_id changes the data authentication key (AK) to an AK the cluster selects automatically. Enables data-at-rest protection.</li> <li>• sanitize_disk cryptographically erases all user data from a spare or broken drive by altering the data encryption key. Resets the data AK to the drive-unique MSID value and disables data-at-rest protection. Used when a drive is being repurposed or returned.</li> <li>• enum: ["rekey_data_default", "rekey_data_auto_id",</li> </ul> |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_records | boolean | query | False    | The default is false. If set to true, the records are returned. <ul style="list-style-type: none"> <li>• Default value:</li> </ul> |

### Request Body

| Name                 | Type                                     | Description  |
|----------------------|--|--|
| aggregates           | array[ <a href="#">aggregates</a> ]      | List of aggregates sharing this disk   |
| bay                  | integer                                  | Disk shelf bay   |
| bytes_per_sector     | integer                                  | Bytes per sector.  |
| class                | string                                   | Disk class   |
| compliance_standard  | string                                   | Security standard that the device is certified to.   |
| container_type       | string                                   | Type of overlying disk container   |
| control_standard     | string                                   | Standard that the device supports for encryption control.  |
| dr_node              | <a href="#">dr_node</a>                  |  |
| drawer               | <a href="#">drawer</a>                   |  |
| effective_type       | string                                   | Effective Disk type  |
| encryption_operation | string                                   | This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET. |
| error                | array[ <a href="#">disk_error_info</a> ] | List of disk errors information.   |
| fips_certified       | boolean                                  |  |
| firmware_version     | string                                   |  |
| home_node            | <a href="#">home_node</a>                |  |
| key_id               | <a href="#">key_id</a>                   |  |



| Name                    | Type                                    | Description   |
|-------------------------|---|---|
| local                   | boolean                                 | Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.   |
| model                   | string                                  |   |
| name                    | string                                  | Cluster-wide disk name  |
| node                    | <a href="#">node</a>                    |   |
| outage                  | <a href="#">outage</a>                  | Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.  |
| overall_security        | string                                  | Overall Security rating, for FIPS-certified devices.  |
| paths                   | array[ <a href="#">disk_path_info</a> ] | List of paths to a disk   |
| physical_size           | integer                                 | Physical size, in units of bytes  |
| pool                    | string                                  | Pool to which disk is assigned  |
| protection_mode         | string                                  | Mode of drive data protection and FIPS compliance. Possible values are: <ul style="list-style-type: none"> <li>• <i>open</i> - Data is unprotected</li> <li>• <i>data</i> - Data protection only, without FIPS compliance</li> <li>• <i>part</i> - Data is unprotected; other FIPS compliance settings present</li> <li>• <i>full</i> - Full data and FIPS compliance protection</li> <li>• <i>miss</i> - Protection mode information is not available</li> </ul> |
| rated_life_used_percent | integer                                 | Percentage of rated life used   |
| right_size_sector_count | integer                                 | Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk.  |

| Name            | Type                         | Description   |
|-----------------|------------------------------|---|
| rpm             | integer                      | Revolutions per minute  |
| sector_count    | integer                      | Number of sectors on the disk.                                  |
| self_encrypting | boolean                      |   |
| serial_number   | string                       |   |
| shelf           | <a href="#">shelf</a>        |   |
| state           | string                       | State   |
| stats           | <a href="#">stats</a>        |   |
| storage_pool    | <a href="#">storage_pool</a> | Shared Storage Pool   |
| type            | string                       | Disk interface type   |
| uid             | string                       | The unique identifier for a disk                                |
| usable_size     | integer                      |   |
| vendor          | string                       |   |
| virtual         | <a href="#">virtual</a>      | Information about backing storage for disks on cloud platforms. |

## Example request

```
{
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resource/1"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "bay": 1,
  "bytes_per_sector": 520,
  "class": "solid_state",
  "compliance_standard": "FIPS 140-2",
  "container_type": "spare",
  "control_standard": "TCG Enterprise",
  "dr_node": {
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "effective_type": "vmdisk",
  "error": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "type": "notallflashdisk"
  },
  "firmware_version": "NA51",
  "home_node": {
    "_links": {
      "self": {
        "href": "/api/resource/1"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "model": "X421_HCOBE450A10",
}
```

```

"name": "1.0.1",
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"outage": {
  "reason": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
},
"overall_security": "Level 2",
"paths": {
  "initiator": "3a",
  "node.name": "vsim4",
  "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
  "port_name": "A",
  "port_type": "sas",
  "vmdisk_hypervisor_file_name": "xvds vol10a0567ae156ca59f6",
  "wwnn": "5000c2971c1b2b8c",
  "wwpn": "5000c2971c1b2b8d"
},
"physical_size": 228930,
"pool": "pool0",
"protection_mode": "data",
"rated_life_used_percent": 10,
"right_size_sector_count": 1172123568,
"rpm": 15000,
"sector_count": 1172123568,
"serial_number": "KHG2VX8R",
"shelf": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},

```

```
    "uid": "7777841915827391056"
  },
  "state": "present",
  "stats": {
    "average_latency": 3,
    "iops_total": 12854,
    "path_error_count": 0,
    "power_on_hours": 21016,
    "throughput": 1957888
  },
  "storage_pool": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "storage_pool_1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "type": "ssd",
  "uid":
  "002538E5:71B00B2F:00000000:00000000:00000000:00000000:00000000:00000000:00000000:00000000",
  "usable_size": 959934889984,
  "vendor": "NETAPP",
  "virtual": {
    "container": "nviet12122018113936-rg",
    "object": "f1fu63se",
    "storage_account": "nviet12122018113936ps"
  }
}
```

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Codes

| <b>Error Code</b> | <b>Description</b>   |
|-------------------|--|
| 720951            | Unable to unvail the disk.   |
| 721066            | Node is outside the list of controllers for disk.  |
| 1441795           | Setting the data key ID to the manufacture secure ID is not allowed when in FIPS-compliance mode.          |
| 14155777          | The operation failed on one or more disks.   |
| 14155778          | No self-encrypting disks were specified.   |
| 14155779          | Status from a node shows that a conflicting operation has occurred. Some disk controls might have changed. |
| 14155780          | Could not retrieve the required key ID from the key manager.   |

## **Definitions**

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

dr\_node

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

drawer

| Name | Type    | Description |
|------|---------|-------------|
| id   | integer |             |
| slot | integer |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

The message and code detailing the error state of this disk.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### disk\_error\_info

| Name   | Type                  | Description  |
|--------|-----------------------|--|
| reason | <a href="#">error</a> | The message and code detailing the error state of this disk. |
| type   | string                | Disk error type.   |

#### home\_node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### key\_id

| Name | Type   | Description                           |
|------|--------|---------------------------------------|
| data | string | Key ID of the data authentication key |
| fips | string | Key ID of the FIPS authentication key |

#### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### error



This error message and code explaining the disk failure.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

| Name                | Type                  | Description  |
|---------------------|-----------------------|--|
| persistently_failed | boolean               | Indicates whether RAID maintains the state of this disk as failed accross reboots. |
| reason              | <a href="#">error</a> | This error message and code explaining the disk failure.                           |

disk\_path\_info

| Name                        | Type   | Description                                       |
|-----------------------------|--------|---|
| initiator                   | string | Initiator port.                                   |
| node.name                   | string | Controller with the initiator port for this path. |
| node.uuid                   | string | Controller UUID, to identify node for this path.  |
| port_name                   | string | Name of the disk port.                            |
| port_type                   | string | Disk port type.                                   |
| vmdisk_hypervisor_file_name | string | Virtual disk hypervisor file name.                |
| wwnn                        | string | Target device's World Wide Node Name.             |

| Name | Type   | Description                           |
|------|--------|---------------------------------------|
| wwpn | string | Target device's World Wide Port Name. |

#### shelf

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| uid    | string                 |             |

#### stats

| Name             | Type    | Description  |
|------------------|---------|--|
| average_latency  | integer | Average I/O latency across all active paths, in milliseconds.                          |
| iops_total       | integer | Total I/O operations per second read and written to this disk across all active paths. |
| path_error_count | integer | Disk path error count; failed I/O operations.  |
| power_on_hours   | integer | Hours powered on.  |
| throughput       | integer | Total disk throughput per second across all active paths, in bytes.                    |

#### storage\_pool

##### Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### virtual

Information about backing storage for disks on cloud platforms.

| Name            | Type   | Description                               |
|-----------------|--------|---|
| container       | string | Container name of the virtual disk.       |
| object          | string | Object name of the virtual disk.          |
| storage_account | string | Storage account name of the virtual disk. |

#### disk

| Name                 | Type                                     | Description  |
|----------------------|--|--|
| aggregates           | array[ <a href="#">aggregates</a> ]      | List of aggregates sharing this disk   |
| bay                  | integer                                  | Disk shelf bay   |
| bytes_per_sector     | integer                                  | Bytes per sector.  |
| class                | string                                   | Disk class   |
| compliance_standard  | string                                   | Security standard that the device is certified to.   |
| container_type       | string                                   | Type of overlying disk container   |
| control_standard     | string                                   | Standard that the device supports for encryption control.  |
| dr_node              | <a href="#">dr_node</a>                  |  |
| drawer               | <a href="#">drawer</a>                   |  |
| effective_type       | string                                   | Effective Disk type  |
| encryption_operation | string                                   | This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET. |
| error                | array[ <a href="#">disk_error_info</a> ] | List of disk errors information.   |
| fips_certified       | boolean                                  |  |
| firmware_version     | string                                   |  |
| home_node            | <a href="#">home_node</a>                |  |

| Name                    | Type                                    | Description   |
|-------------------------|---|---|
| key_id                  | <a href="#">key_id</a>                  |   |
| local                   | boolean                                 | Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.   |
| model                   | string                                  |   |
| name                    | string                                  | Cluster-wide disk name  |
| node                    | <a href="#">node</a>                    |   |
| outage                  | <a href="#">outage</a>                  | Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.  |
| overall_security        | string                                  | Overall Security rating, for FIPS-certified devices.  |
| paths                   | array[ <a href="#">disk_path_info</a> ] | List of paths to a disk   |
| physical_size           | integer                                 | Physical size, in units of bytes  |
| pool                    | string                                  | Pool to which disk is assigned  |
| protection_mode         | string                                  | Mode of drive data protection and FIPS compliance. Possible values are: <ul style="list-style-type: none"> <li>• <i>open</i> - Data is unprotected</li> <li>• <i>data</i> - Data protection only, without FIPS compliance</li> <li>• <i>part</i> - Data is unprotected; other FIPS compliance settings present</li> <li>• <i>full</i> - Full data and FIPS compliance protection</li> <li>• <i>miss</i> - Protection mode information is not available</li> </ul> |
| rated_life_used_percent | integer                                 | Percentage of rated life used   |

| Name                    | Type                         | Description  |
|-------------------------|------------------------------|--|
| right_size_sector_count | integer                      | Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk. |
| rpm                     | integer                      | Revolutions per minute   |
| sector_count            | integer                      | Number of sectors on the disk.   |
| self_encrypting         | boolean                      |  |
| serial_number           | string                       |  |
| shelf                   | <a href="#">shelf</a>        |  |
| state                   | string                       | State  |
| stats                   | <a href="#">stats</a>        |  |
| storage_pool            | <a href="#">storage_pool</a> | Shared Storage Pool  |
| type                    | string                       | Disk interface type  |
| uid                     | string                       | The unique identifier for a disk   |
| usable_size             | integer                      |  |
| vendor                  | string                       |  |
| virtual                 | <a href="#">virtual</a>      | Information about backing storage for disks on cloud platforms.                                      |

## Retrieve a specific disk

GET /storage/disks/{name}

**Introduced In:** 9.6

Retrieves a specific disk.

### Related ONTAP commands

- `storage disk show`

### Learn more

- [DOC /storage/disks](#)

## Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| name   | string        | path  | True     | Disk name                     |
| fields | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name                 | Type                                     | Description  |
|----------------------|--|--|
| aggregates           | array[ <a href="#">aggregates</a> ]      | List of aggregates sharing this disk   |
| bay                  | integer                                  | Disk shelf bay   |
| bytes_per_sector     | integer                                  | Bytes per sector.  |
| class                | string                                   | Disk class   |
| compliance_standard  | string                                   | Security standard that the device is certified to.   |
| container_type       | string                                   | Type of overlying disk container   |
| control_standard     | string                                   | Standard that the device supports for encryption control.  |
| dr_node              | <a href="#">dr_node</a>                  |  |
| drawer               | <a href="#">drawer</a>                   |  |
| effective_type       | string                                   | Effective Disk type  |
| encryption_operation | string                                   | This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET. |
| error                | array[ <a href="#">disk_error_info</a> ] | List of disk errors information.   |
| fips_certified       | boolean                                  |  |
| firmware_version     | string                                   |  |
| home_node            | <a href="#">home_node</a>                |  |

| Name                    | Type                                    | Description   |
|-------------------------|---|---|
| key_id                  | <a href="#">key_id</a>                  |   |
| local                   | boolean                                 | Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.   |
| model                   | string                                  |   |
| name                    | string                                  | Cluster-wide disk name  |
| node                    | <a href="#">node</a>                    |   |
| outage                  | <a href="#">outage</a>                  | Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.  |
| overall_security        | string                                  | Overall Security rating, for FIPS-certified devices.  |
| paths                   | array[ <a href="#">disk_path_info</a> ] | List of paths to a disk   |
| physical_size           | integer                                 | Physical size, in units of bytes  |
| pool                    | string                                  | Pool to which disk is assigned  |
| protection_mode         | string                                  | Mode of drive data protection and FIPS compliance. Possible values are: <ul style="list-style-type: none"> <li>• <i>open</i> - Data is unprotected</li> <li>• <i>data</i> - Data protection only, without FIPS compliance</li> <li>• <i>part</i> - Data is unprotected; other FIPS compliance settings present</li> <li>• <i>full</i> - Full data and FIPS compliance protection</li> <li>• <i>miss</i> - Protection mode information is not available</li> </ul> |
| rated_life_used_percent | integer                                 | Percentage of rated life used   |

| Name                    | Type                         | Description  |
|-------------------------|------------------------------|--|
| right_size_sector_count | integer                      | Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk. |
| rpm                     | integer                      | Revolutions per minute   |
| sector_count            | integer                      | Number of sectors on the disk.   |
| self_encrypting         | boolean                      |  |
| serial_number           | string                       |  |
| shelf                   | <a href="#">shelf</a>        |  |
| state                   | string                       | State  |
| stats                   | <a href="#">stats</a>        |  |
| storage_pool            | <a href="#">storage_pool</a> | Shared Storage Pool  |
| type                    | string                       | Disk interface type  |
| uid                     | string                       | The unique identifier for a disk   |
| usable_size             | integer                      |  |
| vendor                  | string                       |  |
| virtual                 | <a href="#">virtual</a>      | Information about backing storage for disks on cloud platforms.                                      |



## Example response

```
{
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resource/link"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "bay": 1,
  "bytes_per_sector": 520,
  "class": "solid_state",
  "compliance_standard": "FIPS 140-2",
  "container_type": "spare",
  "control_standard": "TCG Enterprise",
  "dr_node": {
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "effective_type": "vmdisk",
  "error": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "type": "notallflashdisk"
  },
  "firmware_version": "NA51",
  "home_node": {
    "_links": {
      "self": {
        "href": "/api/resource/link"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "model": "X421_HCOBE450A10",
}
```

```

"name": "1.0.1",
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"outage": {
  "reason": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
},
"overall_security": "Level 2",
"paths": {
  "initiator": "3a",
  "node.name": "vsim4",
  "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
  "port_name": "A",
  "port_type": "sas",
  "vmdisk_hypervisor_file_name": "xvds vol10a0567ae156ca59f6",
  "wwnn": "5000c2971c1b2b8c",
  "wwpn": "5000c2971c1b2b8d"
},
"physical_size": 228930,
"pool": "pool0",
"protection_mode": "data",
"rated_life_used_percent": 10,
"right_size_sector_count": 1172123568,
"rpm": 15000,
"sector_count": 1172123568,
"serial_number": "KHG2VX8R",
"shelf": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},

```

```

    "uid": "7777841915827391056"
  },
  "state": "present",
  "stats": {
    "average_latency": 3,
    "iops_total": 12854,
    "path_error_count": 0,
    "power_on_hours": 21016,
    "throughput": 1957888
  },
  "storage_pool": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "storage_pool_1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "type": "ssd",
  "uid":
"002538E5:71B00B2F:00000000:00000000:00000000:00000000:00000000:00000000:00000000:00000000",
  "usable_size": 959934889984,
  "vendor": "NETAPP",
  "virtual": {
    "container": "nviet12122018113936-rg",
    "object": "f1fu63se",
    "storage_account": "nviet12122018113936ps"
  }
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

dr\_node

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

drawer

| Name | Type    | Description |
|------|---------|-------------|
| id   | integer |             |
| slot | integer |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

The message and code detailing the error state of this disk.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### disk\_error\_info

| Name   | Type                  | Description  |
|--------|-----------------------|--|
| reason | <a href="#">error</a> | The message and code detailing the error state of this disk. |
| type   | string                | Disk error type.   |

#### home\_node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### key\_id

| Name | Type   | Description                           |
|------|--------|---------------------------------------|
| data | string | Key ID of the data authentication key |
| fips | string | Key ID of the FIPS authentication key |

#### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### error

This error message and code explaining the disk failure.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

| Name                | Type                  | Description  |
|---------------------|-----------------------|--|
| persistently_failed | boolean               | Indicates whether RAID maintains the state of this disk as failed accross reboots. |
| reason              | <a href="#">error</a> | This error message and code explaining the disk failure.                           |

disk\_path\_info

| Name                        | Type   | Description                                       |
|-----------------------------|--------|---|
| initiator                   | string | Initiator port.                                   |
| node.name                   | string | Controller with the initiator port for this path. |
| node.uuid                   | string | Controller UUID, to identify node for this path.  |
| port_name                   | string | Name of the disk port.                            |
| port_type                   | string | Disk port type.                                   |
| vmdisk_hypervisor_file_name | string | Virtual disk hypervisor file name.                |
| wwnn                        | string | Target device's World Wide Node Name.             |

| Name | Type   | Description                           |
|------|--------|---------------------------------------|
| wwpn | string | Target device's World Wide Port Name. |

shelf

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| uid    | string                 |             |

stats

| Name             | Type    | Description  |
|------------------|---------|--|
| average_latency  | integer | Average I/O latency across all active paths, in milliseconds.                          |
| iops_total       | integer | Total I/O operations per second read and written to this disk across all active paths. |
| path_error_count | integer | Disk path error count; failed I/O operations.  |
| power_on_hours   | integer | Hours powered on.  |
| throughput       | integer | Total disk throughput per second across all active paths, in bytes.                    |

storage\_pool

Shared Storage Pool

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

virtual

Information about backing storage for disks on cloud platforms.



| Name            | Type   | Description                               |
|-----------------|--------|---|
| container       | string | Container name of the virtual disk.       |
| object          | string | Object name of the virtual disk.          |
| storage_account | string | Storage account name of the virtual disk. |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage file clones

### Storage file clone endpoint overview

#### Overview

You can use these API's to create file clones, retrieve split status and manage split loads. These endpoints are used for cloning files within a volume, without taking much of extra space. Child and parent clones shares the unchanged blocks of data.

A file clone split operation detach child clone from its parent. Split operations use space. To ensure that file clone create operation is not affected by split, file clone tokens are use to reserve space. API endpoints can be used to update the validity and space reserved by token.

#### File clone APIs

The following APIs are used to perform the following operations:

&ndash; POST `/api/storage/file/clone`

&ndash; GET `/api/storage/file/clone/split-status`

&ndash; PATCH `/api/storage/file/clone/split-loads/{node.uuid}`

&ndash; GET `/api/storage/file/clone/split-loads/{node.uuid}`

&ndash; GET /api/storage/file/clone/split-loads

&ndash; GET /api/storage/file/clone/tokens/

&ndash; DELETE /api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

&ndash; PATCH /api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

## Create a clone of the file

POST /storage/file/clone

**Introduced In:** 9.6

Creates a clone of the file.

### Required Properties

- `source_path`
- `destination_path`
- `volume.uuid` and `volume.name` - Instance UUID and name of volume in which to create clone.

### Optional Properties

- `range` - Required only in the case of a sub file clone.
- `autodelete` - Marks a cloned file for auto deletion.
- `backup` - Cloned file is used as a backup.

### Related Ontap commands

- `volume file clone create`

### Creating file clones

The POST operation is used to create file clones with the specified attributes in body. Set the `volume.name` and `volume.uuid` to identify the volume.

Set `source_path` and `destination_path` to identify the file path of original and copied file. In case of full file clone, the new file is created using `destination_path`.<br> In case of a sub file clone, set `range` in the format `source-file-block-number:destination-file-block-number:block-count`. The API returns an error for the following overlapping conditions: (a) if source and destination files are same and any of the source ranges overlap with any of the destination ranges. (b) if any of the source ranges overlap amongst themselves. (c) if any of the destination ranges overlap amongst themselves. If not provided, full file cloning is assumed.

If set to `autodelete`, the cloned file is deleted when the volumes are full.<br>

```
# The API:
curl -X POST "https://<mgmt_ip>/api/storage/file/clone" -H "accept:
application/hal+json" -d '{"volume": {"name": "vol1", "uuid": "40e0fdc5-
c28f-11eb-8270-005056bbeb0b"}, "source_path": "f1", "destination_path":
"f2_c1"}'

# The response:
{
"job": {
  "uuid": "0d025fd9-c4dc-11eb-adb5-005056bbeb0b",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/0d025fd9-c4dc-11eb-adb5-005056bbeb0b"
    }
  }
}
}
```

## Learn More

- [\[DOC /storage/file/clone\]](#)

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul>  |

### Request Body

| Name             | Type    | Description  |
|------------------|---------|--|
| autodelete       | boolean | Mark clone file for auto deletion.                         |
| destination_path | string  | Relative path of the clone/destination file in the volume. |

| Name                  | Type                   | Description  |
|-----------------------|------------------------|--|
| is_backup             | boolean                | Mark clone file for backup.  |
| overwrite_destination | boolean                | Destination file gets overwritten.   |
| range                 | array[string]          | List of block ranges for sub-file cloning in the format "source-file-block-number:destination-file-block-number:block-count" |
| source_path           | string                 | Relative path of the source file in the volume.  |
| token_uuid            | string                 | UUID of existing clone token with reserved split load.   |
| volume                | <a href="#">volume</a> |  |

### Example request

```
{
  "destination_path": "dest_file1, dir1/dest_file2",
  "range": [
    "10:10:5",
    "20:20:10"
  ],
  "source_path": "src_file1, dir1/src_file2,
  ../.snapshot/snap1/src_file3",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

### Response

Status: 202, Accepted

| Name | Type     | Description |
|------|----------|-------------|
| job  | job_link |             |

### Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

### Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

file\_clone

File clone

| Name                  | Type    | Description  |
|-----------------------|---------|--|
| autodelete            | boolean | Mark clone file for auto deletion.                         |
| destination_path      | string  | Relative path of the clone/destination file in the volume. |
| is_backup             | boolean | Mark clone file for backup.                                |
| overwrite_destination | boolean | Destination file gets overwritten.                         |

| Name        | Type                   | Description  |
|-------------|------------------------|--|
| range       | array[string]          | List of block ranges for sub-file cloning in the format "source-file-block-number:destination-file-block-number:block-count" |
| source_path | string                 | Relative path of the source file in the volume.  |
| token_uuid  | string                 | UUID of existing clone token with reserved split load.   |
| volume      | <a href="#">volume</a> |  |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |



## Retrieve the clone split load of a node

GET /storage/file/clone/split-loads

**Introduced In:** 9.10

Retrieves the clone split load of a node.

### Related Ontap Commands

- `volume file clone split load show`

### Retrieving file clone split load related information

The GET operation can be used to retrieve information about clone split load data. Split load data is the data currently undergoing the split. There is a limit on split load data. This API communicates how much data is undergoing split and how much can still be processed.<br>

```
# The API:
/api/storage/file/clone/split-loads

# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/split-loads" -H
"accept: application/hal+json"

# The response:
{
  "records": [
    {
      "node": {
        "uuid": "158d592f-a829-11eb-a47b-005056bb46d7",
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/158d592f-a829-11eb-a47b-
005056bb46d7"
          }
        }
      },
      "load": {
        "maximum": 35184372088832,
        "current": 0,
        "token_reserved": 0,
        "allowable": 35184372088832
      },
      "_links": {
        "self": {
          "href": "/api/storage/file/clone/split-loads/158d592f-a829-11eb-
```

```

a47b-005056bb46d7"
  }
}
},
{
  "node": {
    "uuid": "9686b8d1-a828-11eb-80d8-005056bbe7b6",
    "name": "node2",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/9686b8d1-a828-11eb-80d8-005056bbe7b6"
      }
    }
  },
  "load": {
    "maximum": 35184372088832,
    "current": 0,
    "token_reserved": 0,
    "allowable": 35184372088832
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/clone/split-loads/9686b8d1-a828-11eb-80d8-005056bbe7b6"
    }
  }
}
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/storage/file/clone/split-loads"
  }
}
}
}

```

## Learn More

- [\[DOC /storage/file/clone\]](#)

## Parameters

| Name      | Type   | In    | Required | Description         |
|-----------|--------|-------|----------|---------------------|
| node.uuid | string | query | False    | Filter by node.uuid |

| Name                | Type          | In    | Required | Description   |
|---------------------|---------------|-------|----------|---|
| node.name           | string        | query | False    | Filter by node.name   |
| load.current        | integer       | query | False    | Filter by load.current  |
| load.token_reserved | integer       | query | False    | Filter by load.token_reserved   |
| load.allowable      | integer       | query | False    | Filter by load.allowable  |
| load.maximum        | integer       | query | False    | Filter by load.maximum  |
| fields              | array[string] | query | False    | Specify the fields to return.   |
| max_records         | integer       | query | False    | Limit the number of records returned.   |
| return_records      | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout      | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

| Name     | Type          | In    | Required | Description   |
|----------|---------------|-------|----------|---|
| order_by | array[string] | query | False    | Order results by specified fields and optional [asc |

## Response

Status: 200, Ok

| Name        | Type                                | Description        |
|-------------|-------------------------------------|--------------------|
| _links      | <a href="#">collection_links</a>    |                    |
| num_records | integer                             | Number of records. |
| records     | array[ <a href="#">split_load</a> ] |                    |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "load": {
      "allowable": 0,
      "current": 0,
      "token_reserved": 0
    },
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

collection\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

load

| Name           | Type    | Description   |
|----------------|---------|---|
| allowable      | integer | Specifies the available file clone split load on the node.                              |
| current        | integer | Specifies the current on-going file clone split load on the node.                       |
| maximum        | integer | Specifies the maximum allowable file clone split load on the node at any point in time. |
| token_reserved | integer | Specifies the file clone split load on the node reserved for tokens.                    |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

| Name | Type   | Description |
|------|--------|-------------|
| uuid | string |             |

split\_load

| Name   | Type                           | Description |
|--------|--------------------------------|-------------|
| _links | <a href="#">self_link</a>      |             |
| load   | <a href="#">load</a>           |             |
| node   | <a href="#">node_reference</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve the volume file clone split load rest

GET /storage/file/clone/split-loads/{node.uuid}

**Introduced In:** 9.10

Retrieve Volume File Clone Split Load REST

### Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node Uuid   |



| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| fields | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name   | Type                           | Description |
|--------|--------------------------------|-------------|
| _links | <a href="#">self_link</a>      |             |
| load   | <a href="#">load</a>           |             |
| node   | <a href="#">node_reference</a> |             |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "load": {
    "allowable": 0,
    "current": 0,
    "token_reserved": 0
  },
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

load

| Name           | Type    | Description   |
|----------------|---------|---|
| allowable      | integer | Specifies the available file clone split load on the node.                              |
| current        | integer | Specifies the current on-going file clone split load on the node.                       |
| maximum        | integer | Specifies the maximum allowable file clone split load on the node at any point in time. |
| token_reserved | integer | Specifies the file clone split load on the node reserved for tokens.                    |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

error\_arguments

| Name | Type   | Description   |
|------|--------|---------------|
| code | string | Argument code |

| Name    | Type   | Description      |
|---------|--------|------------------|
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update the maximum split load

PATCH /storage/file/clone/split-loads/{node.uuid}

**Introduced In:** 9.10

Updates the maximum split load.

### Related Ontap command

- `volume file clone split load modify`

### Learn More

- [[DOC /storage/file/clone](#)]

```
# The call:
curl -X PATCH "https://<mgmt_IP>/api/storage/file/clone/split-loads/9686b8d1-a828-11eb-80d8-005056bbe7b6" -d '{"load": {"maximum": "16TB" } }'
```

```
# The response to successful patch is empty body
```

### Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node UUID   |

## Request Body

| Name   | Type           | Description |
|--------|----------------|-------------|
| _links | self_link      |             |
| load   | load           |             |
| node   | node_reference |             |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "load": {
    "allowable": 0,
    "current": 0,
    "token_reserved": 0
  },
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

## Response

Status: 200, Ok

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

load

| Name           | Type    | Description   |
|----------------|---------|---|
| allowable      | integer | Specifies the available file clone split load on the node.                              |
| current        | integer | Specifies the current on-going file clone split load on the node.                       |
| maximum        | integer | Specifies the maximum allowable file clone split load on the node at any point in time. |
| token_reserved | integer | Specifies the file clone split load on the node reserved for tokens.                    |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

split\_load

| Name   | Type                      | Description |
|--------|---------------------------|-------------|
| _links | <a href="#">self_link</a> |             |

| Name | Type                           | Description |
|------|--------------------------------|-------------|
| load | <a href="#">load</a>           |             |
| node | <a href="#">node_reference</a> |             |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve the file clone split status of all volumes in the node

GET /storage/file/clone/split-status

**Introduced In:** 9.10

Retrieves file clone split status of all volumes in the node.

### Learn More

- [\[DOC /storage/file/clone\]](#)

```
# The API:
/api/storage/file/clone/split-status

# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/split-status" -H
"accept: application/hal+json"

# The response:
{
```



```
"records": [
  {
    "volume": {
      "uuid": "ac559964-57a3-40cf-b5cb-f3cb99151a7d",
      "name": "voll1",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/ac559964-57a3-40cf-b5cb-
f3cb99151a7d"
        }
      }
    },
    "svm": {
      "name": "vs1"
    },
    "pending_splits": 0,
    "unsplit_clone_size": 0,
    "_links": {
      "self": {
        "href": "/api/storage/file/clone/split-status/ac559964-57a3-40cf-
b5cb-f3cb99151a7d"
      }
    }
  },
  {
    "volume": {
      "uuid": "32d95d48-d8b7-11eb-a41d-005056bb3837",
      "name": "vs1_root",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/32d95d48-d8b7-11eb-a41d-
005056bb3837"
        }
      }
    },
    "svm": {
      "name": "vs1"
    },
    "pending_splits": 0,
    "unsplit_clone_size": 0,
    "_links": {
      "self": {
        "href": "/api/storage/file/clone/split-status/32d95d48-d8b7-11eb-
a41d-005056bb3837"
      }
    }
  }
]
```

```

    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/storage/file/clone/split-status"
    }
  }
}
}

```

## Parameters

| Name               | Type          | In    | Required | Description   |
|--------------------|---------------|-------|----------|---|
| pending_splits     | integer       | query | False    | Filter by pending_splits  |
| volume.name        | string        | query | False    | Filter by volume.name   |
| volume.uuid        | string        | query | False    | Filter by volume.uuid   |
| svm.uuid           | string        | query | False    | Filter by svm.uuid  |
| svm.name           | string        | query | False    | Filter by svm.name  |
| unsplit_clone_size | integer       | query | False    | Filter by unsplit_clone_size  |
| fields             | array[string] | query | False    | Specify the fields to return.   |
| max_records        | integer       | query | False    | Limit the number of records returned.   |
| return_records     | boolean       | query | False    | <p>The default is true for GET calls. When set to false, only the number of records is returned.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul> |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                                  | Description       |
|-------------|---------------------------------------|-------------------|
| _links      | <a href="#">collection_links</a>      |                   |
| num_records | integer                               | Number of Records |
| records     | array[ <a href="#">split_status</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "pending_splits": 0,
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "unsplit_clone_size": 0,
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

collection\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description             |
|--------|------------------------|-------------------------|
| _links | <a href="#">_links</a> |                         |
| name   | string                 | The name of the volume. |

| Name | Type   | Description  |
|------|--------|--|
| uuid | string | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### split\_status

| Name               | Type                      | Description  |
|--------------------|---------------------------|--|
| _links             | <a href="#">self_link</a> |  |
| pending_splits     | integer                   | Specifies the number of pending file clone split operations in the volume. |
| svm                | <a href="#">svm</a>       |  |
| unsplit_clone_size | integer                   | Specifies the space occupied by unsplit file clones in the volume.         |
| volume             | <a href="#">volume</a>    |  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve the file clone split status of all volumes

GET /storage/file/clone/split-status/{volume.uuid}

**Introduced In:** 9.10

Retrieves file clone split status of all volumes in the node.

### Related Ontap commands

- `volume file clone split status`

### Learn More

- [\[DOC /storage/file/clone\]](#)

### Retrieves the information of split status.

The GET operation retrieves information about split processes in the volume.<br> `pending-clone-splits` is the number of files for which file clone split is not yet completed.<br> `unsplit-size` is the sum of all sizes, in bytes in the volume that is not split.<br>



```

# The API:
/api/storage/file/clone/split-status/{volume.uuid}

# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/split-
status/ac559964-57a3-40cf-b5cb-f3cb99151a7d" -H "accept:
application/hal+json"

# The response:
{
  "volume": {
    "uuid": "ac559964-57a3-40cf-b5cb-f3cb99151a7d",
    "name": "vol1",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/ac559964-57a3-40cf-b5cb-f3cb99151a7d"
      }
    }
  },
  "svm": {
    "name": "vs1"
  },
  "pending_splits": 0,
  "unsplit_clone_size": 0,
  "_links": {
    "self": {
      "href": "/api/storage/file/clone/split-status/ac559964-57a3-40cf-b5cb-
f3cb99151a7d"
    }
  }
}

```

## Parameters

| Name        | Type          | In    | Required | Description                   |
|-------------|---------------|-------|----------|-------------------------------|
| volume.uuid | string        | path  | True     | Volume Instance UUID          |
| fields      | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name               | Type                      | Description  |
|--------------------|---------------------------|--|
| _links             | <a href="#">self_link</a> |  |
| pending_splits     | integer                   | Specifies the number of pending file clone split operations in the volume. |
| svm                | <a href="#">svm</a>       |  |
| unsplit_clone_size | integer                   | Specifies the space occupied by unsplit file clones in the volume.         |
| volume             | <a href="#">volume</a>    |  |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "pending_splits": 0,
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "unsplit_clone_size": 0,
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve information for a token

GET `/storage/file/clone/tokens`

**Introduced In:** 9.10

Retrieves information for the specified token.

### Related Ontap command

- `volume file clone token show`

### Learn More

- [\[DOC /storage/file/clone\]](#)

### Retrieving information on clone tokens

```

# The API:
/api/storage/file/clone/tokens

# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/tokens" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "node": {
        "uuid": "97255711-a1ad-11eb-92b2-0050568eb2ca",
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/97255711-a1ad-11eb-92b2-
0050568eb2ca"
          }
        }
      },
      "uuid": "905c42ce-a74b-11eb-bd86-0050568ec7ae",
      "reserve_size": 10240,
      "expiry_time": {
        "limit": "PT1H10M",
        "left": "PT1H9M"
      },
      "_links": {
        "self": {
          "href": "/api/storage/file/clone/tokens/97255711-a1ad-11eb-92b2-
0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"
        }
      }
    },
  ],
  "num_records": 1,
  "_links": {
    "self": {
      "href": "/api/storage/file/clone/tokens"
    }
  }
}

```

## Parameters

| Name              | Type          | In    | Required | Description   |
|-------------------|---------------|-------|----------|---|
| expiry_time.limit | string        | query | False    | Filter by expiry_time.limit   |
| expiry_time.left  | string        | query | False    | Filter by expiry_time.left  |
| reserve_size      | integer       | query | False    | Filter by reserve_size  |
| node.uuid         | string        | query | False    | Filter by node.uuid   |
| node.name         | string        | query | False    | Filter by node.name   |
| uuid              | string        | query | False    | Filter by uuid  |
| fields            | array[string] | query | False    | Specify the fields to return.   |
| max_records       | integer       | query | False    | Limit the number of records returned.   |
| return_records    | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned.<br><ul style="list-style-type: none"><li>• Default value: 1</li></ul> |



| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                             | Description        |
|-------------|----------------------------------|--------------------|
| _links      | <a href="#">collection_links</a> |                    |
| num_records | integer                          | Number of records. |
| records     | array[ <a href="#">token</a> ]   |                    |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

collection\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

expiry\_time

| Name  | Type   | Description   |
|-------|--------|---|
| left  | string | Specifies the time remaining before the given token expires in ISO-8601 format. |
| limit | string | Specifies when the given token expires in ISO-8601 format.                      |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

token

token

| Name         | Type                           | Description   |
|--------------|--------------------------------|---|
| _links       | <a href="#">self_link</a>      |   |
| expiry_time  | <a href="#">expiry_time</a>    |   |
| node         | <a href="#">node_reference</a> |   |
| reserve_size | integer                        | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string                         | Token UUID.   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Create a new token to reserve the split load

POST /storage/file/clone/tokens

**Introduced In:** 9.10

Creates a new token to reserve the split load.

### Required Properties

- `node.uuid`
- `reserve-size`

## Optional Properties

- `expiry_time.limit`
- `expiry_time.left`

## Related Ontap Commands

- `volume file clone token create`

## Learn More

- [DOC /storage/file/clone]

## Creating clone tokens to reserve space for clone creation on the node

There is a limit on the amount of clone data that can undergo a split at a point of time on the node (clone split load). Clone tokens are used to reserve space from clone split load for clone creation. The POST operation is used to create clone tokens with `reserve-size` and `expiry-time.limit` in the body.<br>

```
# The API
/api/storage/file/clone/tokens

# The call
curl -X POST "https://<mgmt_ip>/api/storage/file/clone/tokens" -H "accept:
application/hal+json" -d '{"node": {"uuid": "97255711-a1ad-11eb-92b2-
0050568eb2ca"}, "reserve_size": "40M", "expiry_time": { "limit": "4200"
} }'

# The response
{
  "num_records": 1,
  "records": [
    {
      "node": {
        "name": "node1"
      },
      "uuid": "286f6ae4-c94d-11eb-adb5-005056bbeb0b",
      "reserve_size": 41943040,
      "_links": {
        "self": {
          "href": "/api/storage/file/clone/tokens/97255711-a1ad-11eb-92b2-
0050568eb2ca"
        }
      }
    }
  ]
}
```

## Parameters

| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| return_records | boolean | query | False    | The default is false. If set to true, the records are returned.<br><ul style="list-style-type: none"><li>• Default value:</li></ul> |

## Request Body

| Name         | Type                           | Description   |
|--------------|--------------------------------|---|
| _links       | <a href="#">self_link</a>      |   |
| expiry_time  | <a href="#">expiry_time</a>    |   |
| node         | <a href="#">node_reference</a> |   |
| reserve_size | integer                        | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string                         | Token UUID.   |

## Response

Status: 201, Created

| Name        | Type                             | Description        |
|-------------|----------------------------------|--------------------|
| _links      | <a href="#">collection_links</a> |                    |
| num_records | integer                          | Number of records. |
| records     | array[ <a href="#">token</a> ]   |                    |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

expiry\_time

| Name  | Type   | Description   |
|-------|--------|---|
| left  | string | Specifies the time remaining before the given token expires in ISO-8601 format. |
| limit | string | Specifies when the given token expires in ISO-8601 format.                      |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

token

token

| Name        | Type                           | Description |
|-------------|--------------------------------|-------------|
| _links      | <a href="#">self_link</a>      |             |
| expiry_time | <a href="#">expiry_time</a>    |             |
| node        | <a href="#">node_reference</a> |             |



| Name         | Type    | Description   |
|--------------|---------|---|
| reserve_size | integer | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string  | Token UUID.   |

#### collection\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a specific file clone token

```
DELETE /storage/file/clone/tokens/{node.uuid}/{uuid}
```

**Introduced In:** 9.10

Deletes a specific file clone token.

### Related Ontap command

- `volume file clone token delete`

## Delete specific clone token.

```
# The API:
/api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

# The call:
curl -X DELETE "https://<mgmt_ip>/api/storage/file/clone/tokens/97255711-
alad-11eb-92b2-0050568eb2ca/909c42ce-a74b-11eb-bd86-0050568ec7ae"

# The successful response is empty body.
```

## Learn More

- [DOC /storage/file/clone]

## Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node UUID   |
| uuid      | string | path | True     | Token UUID  |

## Response

Status: 200, Ok

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a file clone token

GET /storage/file/clone/tokens/{node.uuid}/{uuid}

## Introduced In: 9.10

Retrieves a file clone token

### Related Ontap command

- `volume file clone token show`

### Retrieve information for single token.

```
# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/tokens/97255711-
a1ad-11eb-92b2-0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"

# The response:
{
  "node": {
    "uuid": "97255711-a1ad-11eb-92b2-0050568eb2ca",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/97255711-a1ad-11eb-92b2-0050568eb2ca"
      }
    }
  },
  "uuid": "905c42ce-a74b-11eb-bd86-0050568ec7ae",
  "reserve_size": 41943040,
  "expiry_time": {
    "limit": "PT1H10M",
    "left": "PT1H9M"
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/clone/tokens/97255711-a1ad-11eb-92b2-
0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"
    }
  }
}
```

### Learn More

- [\[DOC /storage/file/clone\]](#)

### Parameters

| Name      | Type          | In    | Required | Description                   |
|-----------|---------------|-------|----------|-------------------------------|
| node.uuid | string        | path  | True     | Node UUID                     |
| uuid      | string        | path  | True     | Token UUID                    |
| fields    | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name         | Type                           | Description   |
|--------------|--------------------------------|---|
| _links       | <a href="#">self_link</a>      |   |
| expiry_time  | <a href="#">expiry_time</a>    |   |
| node         | <a href="#">node_reference</a> |   |
| reserve_size | integer                        | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string                         | Token UUID.   |

## Error

Status: Default, Error

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

expiry\_time

| Name  | Type   | Description   |
|-------|--------|---|
| left  | string | Specifies the time remaining before the given token expires in ISO-8601 format. |
| limit | string | Specifies when the given token expires in ISO-8601 format.                      |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error



| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a file clone token

PATCH /storage/file/clone/tokens/{node.uuid}/{uuid}

**Introduced In:** 9.10

Updates a file clone token.

### Related Ontap commands

- `volume file clone token modify`

### Modify clone token

Use the PATCH API to update the expiry time associated with the clone token.<br>

```
# The call:
curl -X PATCH "https://<mgmt_ip>/api/storage/file/clone/tokens/97255711-
alad-11eb-92b2-0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae" -d
 '{"expiry_time": {"limit": "5400"} }'

# The response for successful PATCH is empty.
```

### Learn More

- [\[DOC /storage/file/clone\]](#)

### Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node UUID   |
| uuid      | string | path | True     | Token UUID  |

## Request Body

| Name         | Type                           | Description   |
|--------------|--------------------------------|---|
| _links       | <a href="#">self_link</a>      |   |
| expiry_time  | <a href="#">expiry_time</a>    |   |
| node         | <a href="#">node_reference</a> |   |
| reserve_size | integer                        | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string                         | Token UUID.   |

## Response

Status: 200, Ok

## Error

Status: Default, Error

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

self\_link

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

expiry\_time

| Name  | Type   | Description   |
|-------|--------|---|
| left  | string | Specifies the time remaining before the given token expires in ISO-8601 format. |
| limit | string | Specifies when the given token expires in ISO-8601 format.                      |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

token

token

| Name        | Type                           | Description |
|-------------|--------------------------------|-------------|
| _links      | <a href="#">self_link</a>      |             |
| expiry_time | <a href="#">expiry_time</a>    |             |
| node        | <a href="#">node_reference</a> |             |

| Name         | Type    | Description   |
|--------------|---------|---|
| reserve_size | integer | Specifies the available reserve in the file clone split load for the given token. |
| uuid         | string  | Token UUID.   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Start a file copy operation

POST /storage/file/copy

**Introduced In:** 9.8

Starts a file copy operation. Only supported on flexible volumes.

### Required properties

- `files_to_copy` - List of files with the destination they are to be copied to.

### Default property values

- `cutover_time` - *10*
- `hold_quiescence` - *false*
- `max_throughput` - *0*

- `reference_cutover_time - 10`

## Related ONTAP commands

- `volume file copy start`

## Examples

### Copying two files

The POST request is used to copy file(s).

```
# The API:
/api/storage/file/copy

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/copy" -H "accept:
application/hal+json" -d
'{"files_to_copy":[{"source":{"volume":{"name":"vol_a"},"svm":{"name":"vs0
"},"path":"d1/src_f1"},"destination":{"volume":{"name":"vol_a"},"svm":{"na
me":"vs0"},"path":"d1/dst_f1"}},
{"source":{"volume":{"name":"vol_a"},"svm":{"name":"vs0"},"path":"d1/src_f
2"},"destination":{"volume":{"name":"vol_a"},"svm":{"name":"vs0"},"path":"
d1/dst_f2"}}}]}'

# The response:
{
  "job": {
    "uuid": "b89bc5dd-94a3-11e8-a7a3-0050568edf84",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/b89bc5dd-94a3-11e8-a7a3-0050568edf84"
      }
    }
  }
}
```

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul>  |

### Request Body

| Name         | Type    | Description  |
|--------------|---------|--|
| cutover_time | integer | The maximum amount of time (in seconds) that the source can be quiesced before a destination file must be made available for read-write traffic. |

| Name                   | Type                                   | Description   |
|------------------------|--|---|
| files_to_copy          | array[ <a href="#">files_to_copy</a> ] | A list of source files along with the destinations they are copied to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. |
| hold_quiescence        | boolean                                | Specifies whether the source file should be held quiescent for the duration of the copy operation.  |
| max_throughput         | integer                                | The maximum amount of data (in bytes) that can be transferred per second in support of this operation.  |
| reference_cutover_time | integer                                | The maximum amount of time (in seconds) that the source reference file can be quiesced before the corresponding destination file must be made available for read-write traffic.                           |
| reference_file         | <a href="#">reference_file</a>         |   |

## Example request

```
{
  "cutover_time": 10,
  "files_to_copy": {
    "destination": {
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "volume": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "volumel",
        "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
      }
    },
    "source": {
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "volume": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "volumel",
        "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
      }
    }
  },
}
```



```
"reference_cutover_time": 10,
"reference_file": {
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 7012352    | File locations are inconsistent. All files must be on the same volume.                               |
| 7012353    | Exceeded the file operations supported number of files.  |
| 7012354    | Unable to pair the number of source files to destination files.                                      |
| 7012357    | Cannot start a file operation until all cluster nodes support the file operations capability.        |
| 7012358    | The specified source path is invalid.  |
| 7012359    | The specified destination path is invalid.   |
| 7012360    | The SVMs are not in an intracluster peering relationship.  |
| 7012361    | The SVMs peering relationship does not include application "file-copy".                              |
| 7012362    | The SVMs are not yet in a peered state yet.  |
| 7012363    | Cannot copy files. All file operations must be managed by the destination SVM's administrator.       |
| 7012365    | Copying a file between clusters is not supported.  |
| 7012367    | A reference path may only be specified if multiple source paths are specified.                       |
| 7012368    | The reference path must have a matching source path.   |
| 7012371    | The reference cutover time exceeds the maximum allowable time.                                       |
| 7012374    | Source volume and destination volume have different home clusters.                                   |
| 7012376    | Operation not allowed on a volume that is part of a SnapMirror Synchronous relationship.             |
| 7012377    | Cannot start a file copy operation on the volume because an active volume conversion is in progress. |
| 13107223   | Operation not supported for FlexGroup volumes or FlexGroup constituents.                             |
| 196608143  | Cannot start operation. The volume is undergoing a secure purge operation.                           |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

file\_reference

| Name   | Type                   | Description                    |
|--------|------------------------|--------------------------------|
| path   | string                 | Path of the file or directory. |
| svm    | <a href="#">svm</a>    |                                |
| volume | <a href="#">volume</a> |                                |

## files\_to\_copy

| Name        | Type                           | Description |
|-------------|--------------------------------|-------------|
| destination | <a href="#">file_reference</a> |             |
| source      | <a href="#">file_reference</a> |             |

## reference\_file

| Name   | Type                   | Description  |
|--------|------------------------|--|
| path   | string                 | The source reference file. If a reference file is specified, data for other files being copied will be transferred as a difference from the reference file. This can save bandwidth and destination storage if the specified source files share blocks. If provided, this input must match one of the source file paths. This input need not be provided if only one source file is specified. |
| volume | <a href="#">volume</a> |  |

## file\_copy

## File copy

| Name            | Type                                   | Description   |
|-----------------|--|---|
| cutover_time    | integer                                | The maximum amount of time (in seconds) that the source can be quiesced before a destination file must be made available for read-write traffic.  |
| files_to_copy   | array[ <a href="#">files_to_copy</a> ] | A list of source files along with the destinations they are copied to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. |
| hold_quiescence | boolean                                | Specifies whether the source file should be held quiescent for the duration of the copy operation.  |

| Name                   | Type                           | Description   |
|------------------------|--------------------------------|---|
| max_throughput         | integer                        | The maximum amount of data (in bytes) that can be transferred per second in support of this operation.  |
| reference_cutover_time | integer                        | The maximum amount of time (in seconds) that the source reference file can be quiesced before the corresponding destination file must be made available for read-write traffic. |
| reference_file         | <a href="#">reference_file</a> |   |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

# Manage storage file moves

## Storage file moves endpoint overview

### Overview

You can use this API to start a file move operation between two FlexVol volumes or within a FlexGroup volume, and view the status of all on-going file move operations in the cluster.

&ndash; GET /api/storage/file/moves

&ndash; POST /api/storage/file/moves

### Examples

#### Moving two files from one FlexVol volume to the other FlexVol volume

```
# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves" -H "accept:
application/hal+json" -d @move_between_fv.txt
move_between_fv.txt:
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f1.txt"
    },
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f2.txt"
    }
  ],
  "destinations":[
```

```
{
  "svm":{
    "name":"vs0"
  },
  "volume":{
    "name":"fv2"
  },
  "path":"dir2/f1.txt"
},
{
  "svm":{
    "name":"vs0"
  },
  "volume":{
    "name":"fv2"
  },
  "path":"dir2/f2.txt"
}
]
}
}

# The response:
{ }
```

**Moving two files from one FlexVol volume to the other FlexVol volume (only specifying the destination directory)**



```

# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves" -H "accept:
application/hal+json" -d @move_between_fv_dir.txt
move_between_fv_dir.txt:
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f3.txt"
    },
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f4.txt"
    }
  ],
  "destinations":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv2"
      },
      "path":"dir2/"
    }
  ]
}
}

# The response:
{ }

```

## Moving multiple files from one FlexVol volume to the other FlexVol volume and providing a source reference file

```
# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves" -H "accept:
application/hal+json" -d @move_between_fv_source.txt
move_between_fv_source.txt:
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f5.txt"
    },
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f6.txt"
    },
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fv1"
      },
      "path":"dir1/f7.txt"
    }
  ],
  "destinations":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
```

```

        "name": "fv2"
    },
    "path": "dir2/f5.txt"
},
{
    "svm": {
        "name": "vs0"
    },
    "volume": {
        "name": "fv2"
    },
    "path": "dir2/f6.txt"
},
{
    "svm": {
        "name": "vs0"
    },
    "volume": {
        "name": "fv2"
    },
    "path": "dir2/f700.txt"
}
]
},
"reference": {
    "svm": {
        "name": "vs0"
    },
    "volume": {
        "name": "fv1"
    },
    "path": "dir1/f6.txt"
}
}

# The response:
{ }

```

**Moving a file between two FlexGroup volume constituents in the same FlexGroup volume**

```

# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves" -H "accept:
application/hal+json" -d @move_between_fg.txt
move_between_fg.txt:
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fg2"
      },
      "path":"test/file.txt"
    }
  ],
  "destinations":[
    {
      "volume":{
        "name":"fg2__0008"
      }
    }
  ]
}
}

# The response:
{ }

```

**Automatically selecting a destination constituent to move a file in a FlexGroup volume for capacity rebalancing**

```
# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves?automatic=true" -H
"accept: application/hal+json" -d @move_between_fg_automatic.txt
move_between_fg_automatic.txt:
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fg2"
      },
      "path":"test/file2.txt"
    }
  ]
}
}

# The response:
{ }
```

**Moving a file between two FlexGroup volume constituents in the same FlexGroup volume using the "force" option**

```

# The API:
/api/storage/file/moves

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/file/moves?force=true" -H
"accept: application/hal+json" -d @move_between_fg_force.txt
move_between_fg_force.txt
{
"files_to_move":{
  "sources":[
    {
      "svm":{
        "name":"vs0"
      },
      "volume":{
        "name":"fg2"
      },
      "path":"test/file3.txt"
    }
  ],
  "destinations":[
    {
      "volume":{
        "name":"fg2__0008"
      }
    }
  ]
}
}

# The response:
{ }

```

### Retrieving file move operations

```

# The API:
/api/storage/file/moves

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/file/moves" -H 'accept:
application/hal+json'

# The response:
{
"records": [

```

```

{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  },
  "uuid": "e12bc78d-36bb-4274-8163-fb8c21d59c9b",
  "index": 0,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "4e919b6d-1c76-11ec-8e1b-005056acf2dd",
      "name": "fg2__0008"
    },
    "path": "test/file2.txt"
  },
  "destination": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "4d14f2f6-1c76-11ec-8e1b-005056acf2dd",
      "name": "fg2__0005"
    },
    "path": "test/file2.txt"
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/e12bc78d-36bb-4274-8163-fb8c21d59c9b/0"
    }
  }
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",

```

```

    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-
005056acf2dd"
      }
    },
    "uuid": "ce2af347-586d-4b31-b728-1e925f51fdfc",
    "index": 1,
    "source": {
      "svm": {
        "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
        "name": "vs0"
      },
      "volume": {
        "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
        "name": "fv1"
      },
      "path": "dir1/f2.txt"
    },
    "destination": {
      "svm": {
        "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
        "name": "vs0"
      },
      "volume": {
        "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
        "name": "fv2"
      },
      "path": "dir2/f2.txt"
    },
    "_links": {
      "self": {
        "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-
005056acf2dd/ce2af347-586d-4b31-b728-1e925f51fdfc/1"
      }
    }
  },
  {
    "node": {
      "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
      "name": "node1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-
005056acf2dd"
        }
      }
    }
  }
}

```



```

    }
  },
  "uuid": "ce2af347-586d-4b31-b728-1e925f51fdfc",
  "index": 0,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
      "name": "fv1"
    },
    "path": "dir1/f1.txt"
  },
  "destination": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
      "name": "fv2"
    },
    "path": "dir2/f1.txt"
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/ce2af347-586d-4b31-b728-1e925f51fdfc/0"
    }
  }
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  }
},
"uuid": "6d12601b-5377-43bf-99f0-b4bec37565e2",

```

```

"index": 0,
"source": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv1"
  },
  "path": "dir1/f3.txt"
},
"destination": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv2"
  },
  "path": "dir2/f3.txt"
},
"_links": {
  "self": {
    "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/6d12601b-5377-43bf-99f0-b4bec37565e2/0"
  }
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  },
  "uuid": "6d12601b-5377-43bf-99f0-b4bec37565e2",
  "index": 1,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",

```

```

    "name": "vs0"
  },
  "volume": {
    "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv1"
  },
  "path": "dir1/f4.txt"
},
"destination": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv2"
  },
  "path": "dir2/f4.txt"
},
"_links": {
  "self": {
    "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/6d12601b-5377-43bf-99f0-b4bec37565e2/1"
  }
}
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  },
  "uuid": "bbfdface-0d46-4f5f-9624-72f4869eba81",
  "index": 0,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",

```

```

    "name": "fv1"
  },
  "path": "dir1/f5.txt"
},
"destination": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv2"
  },
  "path": "dir2/f5.txt"
},
"_links": {
  "self": {
    "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/bbfdface-0d46-4f5f-9624-72f4869eba81/0"
  }
}
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  },
  "uuid": "bbfdface-0d46-4f5f-9624-72f4869eba81",
  "index": 2,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
      "name": "fv1"
    },
    "path": "dir1/f7.txt"
  },
},

```

```

"destination": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
    "name": "fv2"
  },
  "path": "dir2/f700.txt"
},
"_links": {
  "self": {
    "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/bbfdface-0d46-4f5f-9624-72f4869eba81/2"
  }
}
},
{
  "node": {
    "uuid": "76bc12d1-10aa-11ec-a5b5-005056acf2dd",
    "name": "node1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/76bc12d1-10aa-11ec-a5b5-005056acf2dd"
      }
    }
  },
  "uuid": "bbfdface-0d46-4f5f-9624-72f4869eba81",
  "index": 1,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "18fd9110-26f1-11ec-bf0d-005056acf2dd",
      "name": "fv1"
    },
    "path": "dir1/f6.txt"
  },
  "destination": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    }
  }
}

```

```

    },
    "volume": {
      "uuid": "220bdb3a-26f1-11ec-bf0d-005056acf2dd",
      "name": "fv2"
    },
    "path": "dir2/f6.txt"
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/moves/76bc12d1-10aa-11ec-a5b5-005056acf2dd/bbfdface-0d46-4f5f-9624-72f4869eba81/1"
    }
  }
},
{
  "node": {
    "uuid": "780255d2-10aa-11ec-a308-005056acf86d",
    "name": "node2",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/780255d2-10aa-11ec-a308-005056acf86d"
      }
    }
  },
  "uuid": "6591a42a-4ea2-4d40-bfb4-38959f6bd68e",
  "index": 0,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "438731dd-1c76-11ec-8e1b-005056acf2dd",
      "name": "fg2__0001"
    },
    "path": "test/file.txt"
  },
  "destination": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "4e919b6d-1c76-11ec-8e1b-005056acf2dd",
      "name": "fg2__0008"
    }
  }
}

```

```

    },
    "path": "/test/file.txt"
  },
  "_links": {
    "self": {
      "href": "/api/storage/file/moves/780255d2-10aa-11ec-a308-005056acf86d/6591a42a-4ea2-4d40-bfb4-38959f6bd68e/0"
    }
  }
},
{
  "node": {
    "uuid": "780255d2-10aa-11ec-a308-005056acf86d",
    "name": "node2",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/780255d2-10aa-11ec-a308-005056acf86d"
      }
    }
  },
  "uuid": "1a94e95a-346e-4eb3-969a-110e275cbf18",
  "index": 0,
  "source": {
    "svm": {
      "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
      "name": "vs0"
    },
    "volume": {
      "uuid": "438731dd-1c76-11ec-8e1b-005056acf2dd",
      "name": "fg2__0001"
    }
  },
  "path": "test/file3.txt"
},
"destination": {
  "svm": {
    "uuid": "5b2c8638-10bc-11ec-8e1b-005056acf2dd",
    "name": "vs0"
  },
  "volume": {
    "uuid": "4e919b6d-1c76-11ec-8e1b-005056acf2dd",
    "name": "fg2__0008"
  }
},
"path": "/test/file3.txt"
},
"_links": {

```

```

    "self": {
      "href": "/api/storage/file/moves/780255d2-10aa-11ec-a308-005056acf86d/1a94e95a-346e-4eb3-969a-110e275cbf18/0"
    }
  }
],
"num_records": 10,
"_links": {
  "self": {
    "href": "/api/storage/file/moves"
  }
}
}
}

```

## Retrieve all ongoing file move operations in the cluster

GET /storage/file/moves

**Introduced In:** 9.11

Retrieves all ongoing file move operations in the cluster.

### Related ONTAP commands

- volume file move show
- volume rebalance file-move show

### Parameters

| Name                      | Type    | In    | Required | Description                         |
|---------------------------|---------|-------|----------|-------------------------------------|
| is_flexgroup              | boolean | query | False    | Filter by is_flexgroup              |
| max_cutover_time          | integer | query | False    | Filter by max_cutover_time          |
| failure.arguments.message | string  | query | False    | Filter by failure.arguments.message |
| failure.arguments.code    | string  | query | False    | Filter by failure.arguments.code    |
| failure.target            | string  | query | False    | Filter by failure.target            |



| Name                 | Type    | In    | Required | Description                    |
|----------------------|---------|-------|----------|--------------------------------|
| failure.code         | string  | query | False    | Filter by failure.code         |
| failure.message      | string  | query | False    | Filter by failure.message      |
| elapsed_time         | integer | query | False    | Filter by elapsed_time         |
| is_destination_ready | boolean | query | False    | Filter by is_destination_ready |
| is_snapshot_fenced   | boolean | query | False    | Filter by is_snapshot_fenced   |
| svm.uuid             | string  | query | False    | Filter by svm.uuid             |
| svm.name             | string  | query | False    | Filter by svm.name             |
| max_throughput       | integer | query | False    | Filter by max_throughput       |
| index                | integer | query | False    | Filter by index                |
| node.uuid            | string  | query | False    | Filter by node.uuid            |
| node.name            | string  | query | False    | Filter by node.name            |
| source.path          | string  | query | False    | Filter by source.path          |
| source.volume.name   | string  | query | False    | Filter by source.volume.name   |
| source.volume.uuid   | string  | query | False    | Filter by source.volume.uuid   |
| source.svm.uuid      | string  | query | False    | Filter by source.svm.uuid      |
| source.svm.name      | string  | query | False    | Filter by source.svm.name      |
| destination.path     | string  | query | False    | Filter by destination.path     |

| Name                    | Type          | In    | Required | Description                           |
|-------------------------|---------------|-------|----------|---------------------------------------|
| destination.volume.name | string        | query | False    | Filter by destination.volume.name     |
| destination.volume.uuid | string        | query | False    | Filter by destination.volume.uuid     |
| destination.svm.uuid    | string        | query | False    | Filter by destination.svm.uuid        |
| destination.svm.name    | string        | query | False    | Filter by destination.svm.name        |
| volume.name             | string        | query | False    | Filter by volume.name                 |
| volume.uuid             | string        | query | False    | Filter by volume.uuid                 |
| scanner.progress        | integer       | query | False    | Filter by scanner.progress            |
| scanner.percent         | integer       | query | False    | Filter by scanner.percent             |
| scanner.total           | integer       | query | False    | Filter by scanner.total               |
| scanner.state           | string        | query | False    | Filter by scanner.state               |
| uuid                    | string        | query | False    | Filter by uuid                        |
| cutover_time            | integer       | query | False    | Filter by cutover_time                |
| fields                  | array[string] | query | False    | Specify the fields to return.         |
| max_records             | integer       | query | False    | Limit the number of records returned. |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                               | Description       |
|-------------|------------------------------------|-------------------|
| _links      | <a href="#">collection_links</a>   |                   |
| num_records | integer                            | Number of Records |
| records     | array[ <a href="#">file_move</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "cutover_time": 8,
    "destination": {
      "path": "d1/d2/file1",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "volume": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "volume1",
        "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
      }
    },
    "elapsed_time": 100,
    "failure": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "files_to_move": {
      "destinations": {
```

```
"path": "d1/d2/file1",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"sources": {
  "path": "d1/d2/file1",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
},
"index": 0,
"max_cutover_time": 10,
"max_throughput": 25000,
"node": {
```

```

    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "reference": {
    "max_cutover_time": 5,
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "scanner": {
    "percent": 80,
    "progress": 80000,
    "state": "allocation_map",
    "total": 100000
  },
  "source": {
    "path": "d1/d2/file1",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  },

```

```

    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volumel",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "4fcb3159-a4ee-42b5-bb16-f752f2c430fc",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volumel",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

collection\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

destination

Destination file information.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

Contains the most recent failure reason for move operation.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### destinations

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

#### sources

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

#### files\_to\_move

A list of source files along with the destination file they are moved to. If the terminal path component of

the destination is a directory, then the source file's basename is replicated in that directory. This is only used for FlexVol volume file move operations.

| Name         | Type                                  | Description                       |
|--------------|---------------------------------------|-----------------------------------|
| destinations | array[ <a href="#">destinations</a> ] | The destination file information. |
| sources      | array[ <a href="#">sources</a> ]      | The source file information.      |

node

Node hosting the destination of this move operation.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

svm

SVM of the source reference file.

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

volume

Volume of the source reference file.

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

## reference

| Name             | Type    | Description   |
|------------------|---------|---|
| max_cutover_time | integer | The maximum amount of time, in seconds that the source reference file can be quiesced before the corresponding destination file must be made available for read-write traffic. Not supported in FlexGroup volume file move operations.  |
| path             | string  | The source reference file. If a reference file is specified, data for other files being moved will be transferred as a difference from the reference file. This can save bandwidth and destination storage if the specified source files share blocks. If provided, this input must match one of the source file paths. This input need not be provided if only one source file is specified. Not supported in FlexGroup volume file move operations. |
| svm              | svm     | SVM of the source reference file.   |
| volume           | volume  | Volume of the source reference file.  |

## scanner

| Name     | Type    | Description                         |
|----------|---------|-------------------------------------|
| percent  | integer | Scanner progress, as a percentage.  |
| progress | integer | Scanner progress, in bytes scanned. |
| state    | string  | Status of the file move scanner.    |
| total    | integer | Total bytes to be scanned.          |

## source

Source file information.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

svm

SVM of the FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

file\_move

Details of a file move operation.

| Name         | Type                        | Description   |
|--------------|-----------------------------|---|
| cutover_time | integer                     | Time that the file move operation takes before cutover completes, in seconds. |
| destination  | <a href="#">destination</a> | Destination file information.   |

| Name                 | Type          | Description  |
|----------------------|---------------|--|
| elapsed_time         | integer       | Time elapsed since the start of the file move operation, in seconds.   |
| failure              | error         | Contains the most recent failure reason for move operation.  |
| files_to_move        | files_to_move | A list of source files along with the destination file they are moved to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. This is only used for FlexVol volume file move operations.                              |
| index                | integer       | An additional unique element identifying one file among many that could possibly be moved as part of a job. File index is an identifier ordered by the file path arrays provided during create. For file move operations that involve only one file, the file-index value of zero is always correct. |
| is_destination_ready | boolean       | Indicates whether the destination file is ready for use.   |
| is_flexgroup         | boolean       | Indicates whether this is a FlexGroup file move operation.   |
| is_snapshot_fenced   | boolean       | Indicates whether Snapshot copies are fenced.  |
| max_cutover_time     | integer       | The maximum amount of time, in seconds that the source can be quiesced before a destination file must be made available for read-write traffic. Not supported in FlexGroup volume file move operations.  |

| Name           | Type                      | Description   |
|----------------|---------------------------|---|
| max_throughput | integer                   | Maximum amount of data, in bytes that can be transferred per second in support of this operation. A non-zero value less than 1 MB/s is set to 1 MB/s. A non-zero value greater than 1 MB/s is truncated to the nearest integral megabyte value. If unspecified, the default value is "0" which means no range is set for the data transfer. |
| node           | <a href="#">node</a>      | Node hosting the destination of this move operation.  |
| reference      | <a href="#">reference</a> |   |
| scanner        | <a href="#">scanner</a>   |   |
| source         | <a href="#">source</a>    | Source file information.  |
| svm            | <a href="#">svm</a>       | SVM of the FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.  |
| uuid           | string                    | The UUID which uniquely identifies the job that started this move operation.  |
| volume         | <a href="#">volume</a>    | FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.   |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Start a file move operation

POST /storage/file/moves

**Introduced In:** 9.11

Starts a file move operation. This API can be used to move files from one FlexVol volume to another FlexVol volume or within a FlexGroup volume for capacity rebalancing. For a FlexGroup volume file move operation, only one source file can be specified in `files_to_move`. The source volume is the FlexGroup volume. The destination volume is the destination FlexGroup volume constituent to move the file to. When `automatic` is true, destination volume is not required. The source path is the path to the file to be moved within the FlexGroup volume. If the destination path is specified, it must be the same as the source path.

### Required properties for file move operation

- `files_to_move` - List of files with the destination they are to be moved to.

### Optional properties for file move operation

- `reference` - The source reference file for moving multiple files.

### Default property values

- `max_throughput` - 0
- `max_cutover_time` - 10
- `reference.max_cutover_time` - 10

### Related ONTAP commands

- `volume file move start`
- `volume rebalance file-move start`

### Parameters

| Name  | Type    | In    | Required | Description   |
|-------|---------|-------|----------|---|
| force | boolean | query | False    | If true, the FlexGroup volume file move operation breaks the existing lock state on the file being moved. Breaking the lock state may cause a disruption for some client applications. <ul style="list-style-type: none"><li>• Default value:</li></ul> |



| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| automatic      | boolean | query | False    | If true, the FlexGroup volume file move operation selects the destination constituent automatically. <ul style="list-style-type: none"> <li>• Default value:</li> </ul> |
| return_records | boolean | query | False    | The default is false. If set to true, the records are returned. <ul style="list-style-type: none"> <li>• Default value:</li> </ul>                                      |

### Request Body

| Name          | Type                          | Description   |
|---------------|-------------------------------|---|
| cutover_time  | integer                       | Time that the file move operation takes before cutover completes, in seconds.   |
| destination   | <a href="#">destination</a>   | Destination file information.   |
| elapsed_time  | integer                       | Time elapsed since the start of the file move operation, in seconds.  |
| failure       | <a href="#">error</a>         | Contains the most recent failure reason for move operation.   |
| files_to_move | <a href="#">files_to_move</a> | A list of source files along with the destination file they are moved to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. This is only used for FlexVol volume file move operations. |

| Name                 | Type                      | Description   |
|----------------------|---------------------------|---|
| index                | integer                   | An additional unique element identifying one file among many that could possibly be moved as part of a job. File index is an identifier ordered by the file path arrays provided during create. For file move operations that involve only one file, the file-index value of zero is always correct.  |
| is_destination_ready | boolean                   | Indicates whether the destination file is ready for use.  |
| is_flexgroup         | boolean                   | Indicates whether this is a FlexGroup file move operation.  |
| is_snapshot_fenced   | boolean                   | Indicates whether Snapshot copies are fenced.   |
| max_cutover_time     | integer                   | The maximum amount of time, in seconds that the source can be quiesced before a destination file must be made available for read-write traffic. Not supported in FlexGroup volume file move operations.   |
| max_throughput       | integer                   | Maximum amount of data, in bytes that can be transferred per second in support of this operation. A non-zero value less than 1 MB/s is set to 1 MB/s. A non-zero value greater than 1 MB/s is truncated to the nearest integral megabyte value. If unspecified, the default value is "0" which means no range is set for the data transfer. |
| node                 | <a href="#">node</a>      | Node hosting the destination of this move operation.  |
| reference            | <a href="#">reference</a> |   |
| scanner              | <a href="#">scanner</a>   |   |
| source               | <a href="#">source</a>    | Source file information.  |

| Name   | Type   | Description  |
|--------|--------|--|
| svm    | svm    | SVM of the FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation. |
| uuid   | string | The UUID which uniquely identifies the job that started this move operation.                             |
| volume | volume | FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.            |

## Example request

```
{
  "cutover_time": 8,
  "destination": {
    "path": "d1/d2/file1",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "elapsed_time": 100,
  "failure": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "files_to_move": {
    "destinations": {
      "path": "d1/d2/file1",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      }
    }
  }
}
```

```

    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "sources": {
    "path": "d1/d2/file1",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  }
},
"index": 0,
"max_cutover_time": 10,
"max_throughput": 250000,
"node": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"reference": {

```

```

"max_cutover_time": 5,
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"scanner": {
  "percent": 80,
  "progress": 80000,
  "state": "allocation_map",
  "total": 100000
},
"source": {
  "path": "d1/d2/file1",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}

```

```

},
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "4fcb3159-a4ee-42b5-bb16-f752f2c430fc",
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}

```

## Response

Status: 201, Created

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 7012352    | File locations are inconsistent. All files must be on the same volume.                        |
| 7012353    | Exceeded the file operations supported number of files.                                       |
| 7012354    | Unable to pair the number of source files to destination files.                               |
| 7012357    | Cannot start a file operation until all cluster nodes support the file operations capability. |
| 7012358    | The specified source path is invalid.   |

| Error Code | Description  |
|------------|--|
| 7012359    | The specified destination path is invalid.   |
| 7012360    | The SVMs are not in an intracluster peering relationship.  |
| 7012361    | The SVMs peering relationship does not include application "file-move".  |
| 7012362    | The SVMs are not yet in a peered state.  |
| 7012363    | Cannot move files. All file operations must be managed by the destination SVM's administrator.                                     |
| 7012365    | Copying a file between clusters is not supported.  |
| 7012367    | A reference path may only be specified if multiple source paths are specified.   |
| 7012368    | The reference path must have a matching source path.   |
| 7012371    | The reference cutover time exceeds the maximum allowable time.   |
| 7012374    | Source volume and destination volume have different home clusters.   |
| 7012376    | Operation not allowed on a volume that is part of a SnapMirror Synchronous relationship.   |
| 7012377    | Cannot start a file move operation on the volume because an active volume conversion is in progress.                               |
| 144179206  | Source file does not exist.  |
| 144179207  | Volume capacity balancing requires an effective cluster version of 9.10.1 or later.  |
| 144180200  | Destination constituent not a member of FlexGroup volume.  |
| 144180201  | Destination constituent not properly configured.   |
| 144180206  | File movement with automatic destination constituent selection only supported on FlexGroup volumes with more than one constituent. |
| 196608143  | Cannot start the operation. The volume is undergoing a secure purge operation.   |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |



## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

destination

Destination file information.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

## error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

## error

Contains the most recent failure reason for move operation.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## destinations

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

## sources

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

## files\_to\_move

A list of source files along with the destination file they are moved to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. This is only used for FlexVol volume file move operations.

| Name         | Type                                  | Description                       |
|--------------|---------------------------------------|-----------------------------------|
| destinations | array[ <a href="#">destinations</a> ] | The destination file information. |

| Name    | Type           | Description                  |
|---------|----------------|------------------------------|
| sources | array[sources] | The source file information. |

node

Node hosting the destination of this move operation.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

SVM of the source reference file.

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

Volume of the source reference file.

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

reference

| Name             | Type    | Description   |
|------------------|---------|---|
| max_cutover_time | integer | The maximum amount of time, in seconds that the source reference file can be quiesced before the corresponding destination file must be made available for read-write traffic. Not supported in FlexGroup volume file move operations.  |
| path             | string  | The source reference file. If a reference file is specified, data for other files being moved will be transferred as a difference from the reference file. This can save bandwidth and destination storage if the specified source files share blocks. If provided, this input must match one of the source file paths. This input need not be provided if only one source file is specified. Not supported in FlexGroup volume file move operations. |
| svm              | svm     | SVM of the source reference file.   |
| volume           | volume  | Volume of the source reference file.  |

#### scanner

| Name     | Type    | Description                         |
|----------|---------|-------------------------------------|
| percent  | integer | Scanner progress, as a percentage.  |
| progress | integer | Scanner progress, in bytes scanned. |
| state    | string  | Status of the file move scanner.    |
| total    | integer | Total bytes to be scanned.          |

#### source

Source file information.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| path   | string                 |             |
| svm    | <a href="#">svm</a>    |             |
| volume | <a href="#">volume</a> |             |

svm

SVM of the FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

file\_move

Details of a file move operation.

| Name         | Type                        | Description   |
|--------------|-----------------------------|---|
| cutover_time | integer                     | Time that the file move operation takes before cutover completes, in seconds. |
| destination  | <a href="#">destination</a> | Destination file information.   |

| Name                 | Type          | Description  |
|----------------------|---------------|--|
| elapsed_time         | integer       | Time elapsed since the start of the file move operation, in seconds.   |
| failure              | error         | Contains the most recent failure reason for move operation.  |
| files_to_move        | files_to_move | A list of source files along with the destination file they are moved to. If the terminal path component of the destination is a directory, then the source file's basename is replicated in that directory. This is only used for FlexVol volume file move operations.                              |
| index                | integer       | An additional unique element identifying one file among many that could possibly be moved as part of a job. File index is an identifier ordered by the file path arrays provided during create. For file move operations that involve only one file, the file-index value of zero is always correct. |
| is_destination_ready | boolean       | Indicates whether the destination file is ready for use.   |
| is_flexgroup         | boolean       | Indicates whether this is a FlexGroup file move operation.   |
| is_snapshot_fenced   | boolean       | Indicates whether Snapshot copies are fenced.  |
| max_cutover_time     | integer       | The maximum amount of time, in seconds that the source can be quiesced before a destination file must be made available for read-write traffic. Not supported in FlexGroup volume file move operations.  |

| Name           | Type                      | Description   |
|----------------|---------------------------|---|
| max_throughput | integer                   | Maximum amount of data, in bytes that can be transferred per second in support of this operation. A non-zero value less than 1 MB/s is set to 1 MB/s. A non-zero value greater than 1 MB/s is truncated to the nearest integral megabyte value. If unspecified, the default value is "0" which means no range is set for the data transfer. |
| node           | <a href="#">node</a>      | Node hosting the destination of this move operation.  |
| reference      | <a href="#">reference</a> |   |
| scanner        | <a href="#">scanner</a>   |   |
| source         | <a href="#">source</a>    | Source file information.  |
| svm            | <a href="#">svm</a>       | SVM of the FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.  |
| uuid           | string                    | The UUID which uniquely identifies the job that started this move operation.  |
| volume         | <a href="#">volume</a>    | FlexGroup volume in file move operation. Only used in a FlexGroup volume file move operation.   |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |



# Manage FlexCache volumes

## Storage flexcache flexcaches endpoint overview

### Overview

FlexCache is a persistent cache of an origin volume. An origin volume can only be a FlexVol while a FlexCache is always a FlexGroup.

The following relationship configurations are supported:

&ndash; Intra-Vserver where FlexCache and the corresponding origin volume reside in the same Vserver.

&ndash; Cross-Vserver but intra-cluster where FlexCache and the origin volume reside in the same cluster but belong to different Vservers.

&ndash; Cross-cluster where FlexCache and the origin volume reside in different clusters.

FlexCache supports fan-out and more than one FlexCache can be created from one origin volume. This API retrieves and manages FlexCache configurations in the cache cluster.

### FlexCache APIs

The following APIs can be used to perform operations related with FlexCache:

&ndash; GET /api/storage/flexcache/flexcaches

&ndash; GET /api/storage/flexcache/flexcaches/{uuid}

&ndash; POST /api/storage/flexcache/flexcaches

&ndash; DELETE /api/storage/flexcache/flexcaches/{uuid}

### Examples

#### Creating a FlexCache

The POST request is used to create a FlexCache.

```

# The API:
/api/storage/flexcache/flexcaches

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/flexcache/flexcaches" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
\"aggregates\": [ { \"name\": \"aggr_1\" } ], \"name\": \"fc_333\",
\"origins\": [ { \"svm\": { \"name\": \"vs_3\" }, \"volume\": {
\"name\": \"vol_o1\" } } ], \"svm\": { \"name\": \"vs_1\" } }"

# The response:
{
"job": {
  "uuid": "e751dd5d-0f3c-11e9-8b2b-0050568e0b79",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79"
    }
  }
}
}
}

```

```

curl -X POST "https://<mgmt-ip>/api/storage/flexcache/flexcaches" -H "accept: application/json" -H "Content-
Type: application/json" -d "{ \"aggregates\": [ { \"name\": \"aggr_1\" } ], \"name\": \"fc_333\", \"origins\": [ {
\"svm\": { \"name\": \"vs_3\" }, \"volume\": { \"name\": \"vol_o1\" } } ], \"svm\": { \"name\": \"vs_1\" }, \"path\":
\"/fc_333\", \"prepopulate\": { \"dir_paths\": [ \"/dir1\" ] } }" </mgmt-ip>

```

### The response:

```

{ "job": { "uuid": "e751dd5d-0f3c-11e9-8b2b-0050568e0b79", "_links": { "self": { "href":
"/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79" } } } }

```

```

curl -X POST "https://<mgmt-ip>/api/storage/flexcache/flexcaches" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
  \"aggregates\": [ { \"name\": \"aggr_1\" } ], \"name\":
  \"fc_333\", \"origins\": [ { \"svm\": { \"name\": \"vs_3\" },
  \"volume\": { \"name\": \"vol_o1\" } } ], \"svm\": { \"name\": \"vs_1\" },
  \"path\": \"/\
  fc_333\", \"prepopulate\": { \"dir_paths\": [
  \"/dir1\" ], \"exclude_dir_paths\": [ \"/dir1/dir11\" ] } }"

# The response:
{
  \"job\": {
    \"uuid\": \"5afe9ea4-1dcf-11eb-b006-005056ac6a93\",
    \"_links\": {
      \"self\": {
        \"href\": \"/api/cluster/jobs/5afe9ea4-1dcf-11eb-b006-005056ac6a93\"
      }
    }
  }
}

```

```

curl -X POST "https://<mgmt-ip>/api/storage/flexcache/flexcaches" -H "accept: application/json" -H "Content-Type: application/json" -d "{ \"aggregates\": [ { \"name\": \"aggr_1\" } ], \"name\": \"fc_333\", \"origins\": [ { \"svm\": { \"name\": \"vs_3\" }, \"volume\": { \"name\": \"vol_o1\" } } ], \"svm\": { \"name\": \"vs_1\" }, \"dr_cache\": true, \"path\": \"/\
fc_333\", \"prepopulate\": { \"dir_paths\": [ \"/dir1\" ] } }" </mgmt-ip>

```

## The response:

```

{ \"job\": { \"uuid\": \"e751dd5d-0f3c-11e9-8b2b-0050568e0b79\", \"_links\": { \"self\": { \"href\":
\"/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79\" } } } }

```

### ### Retrieving FlexCache attributes

The GET request is used to retrieve FlexCache attributes. The object includes a large set of fields which can be expensive to retrieve. Most notably, the fields size, guarantee.type, aggregates, path, origins.ip\_address, origins.size, and origins.state are expensive to retrieve. The recommended method to use this API is to filter and retrieve only the required fields.

## The API:

/api/storage/flexcache/flexcaches

## The call:

```

curl -X GET "https://<mgmt-ip>/api/storage/flexcache/flexcaches?" -H "accept: application/json" </mgmt-ip>

```

## The response:

```
{ "records": [ { "uuid": "04d5e07b-0ebe-11e9-8180-0050568e0b79", "name": "fc_322", "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/04d5e07b-0ebe-11e9-8180-0050568e0b79" } } }, { "uuid": "47902654-0ea4-11e9-8180-0050568e0b79", "name": "fc_321", "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/47902654-0ea4-11e9-8180-0050568e0b79" } } }, { "uuid": "77e911ff-0ebe-11e9-8180-0050568e0b79", "name": "fc_323", "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/77e911ff-0ebe-11e9-8180-0050568e0b79" } } }, { "uuid": "ddb42bbc-0e95-11e9-8180-0050568e0b79", "name": "fc_32", "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/ddb42bbc-0e95-11e9-8180-0050568e0b79" } } }, { "uuid": "ec774932-0f3c-11e9-8b2b-0050568e0b79", "name": "fc_333", "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" } } } ], "num_records": 5, "_links": { "self": { "href": "/api/storage/flexcache/flexcaches?" } } }
```

### Retrieving the attributes of a FlexCache

The GET request is used to retrieve the attributes of a FlexCache. The object includes a large set of fields which can be expensive to retrieve. Most notably, the fields `size`, `guarantee.type`, `aggregates`, `path`, `origins.ip_address`, `origins.size`, and `origins.state` are expensive to retrieve. The recommended method to use this API is to filter and retrieve only the required fields.

## The API:

```
/api/storage/flexcache/flexcaches/{uuid}
```

## The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" -H "accept: application/json"</mgmt-ip>
```

## The response:

```
{ "uuid": "ec774932-0f3c-11e9-8b2b-0050568e0b79", "name": "fc_333", "svm": { "name": "vs_1", "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79" }, "size": 4294967296, "guarantee": { "type": "volume" }, "dr_cache": "true", "aggregates": [ { "name": "aggr_1", "uuid": "26f34b76-88f8-4a47-b5e0-d8e901fb1114" } ], "origins": [ { "ip_address": "10.140.103.175", "size": 20971520, "create_time": "2019-01-03T15:19:55+05:30", "state": "online", "volume": { "name": "vol_o1", "uuid": "2bc957dd-2617-4afb-8d2f-66ac6070d313" }, "svm": { "name": "vs_3", "uuid": "8aa2cd28-0e92-11e9-b391-0050568e4115" }, "cluster": { "name": "node2", "uuid": "50733f81-0e90-11e9-b391-0050568e4115" } } ], "_links": { "self": { "href": "/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" } } }
```

### Deleting a FlexCache

The DELETE request is used to delete a FlexCache.

## The API:

```
/api/storage/flexcache/flexcaches
```

## The call:

```
curl -X DELETE "https://<mgmt-ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" -H "accept: application/json"</mgmt-ip>
```

## The response:

```
{ "job": { "uuid": "e17994f2-0f3e-11e9-8b2b-0050568e0b79", "_links": { "self": { "href": "/api/cluster/jobs/e17994f2-0f3e-11e9-8b2b-0050568e0b79" } } } }
```

```
### Modifying a FlexCache volume
Use the PATCH request to update a FlexCache volume.
```

## the API:

```
/api/storage/flexcache/flexcaches/{uuid}
```

## The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" -H "accept: application/json" -H "Content-Type: application/json" -d "{ \"prepopulate\": { \"dir_paths\": [ \"/dir1\" ] } }"</mgmt-ip>
```

## The response:

```
{ "job": { "uuid": "e751dd5d-0f3c-11e9-8b2b-0050568e0b79", "_links": { "self": { "href": "/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79" } } } }
```

```
# The call
curl -X PATCH "https://<mgmt-
ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79"
-H "accept: application/json" -H "Content-Type: application/json" -d "{
 \"prepopulate\": { \"dir_paths\": [ \"/dir1\" ], \"exclude_dir_paths\": [
 \"/dir1/dir11\" ] } }"

# The response:
{
  "job": {
    "uuid": "b574c48c-1da7-11eb-b006-005056ac6a93",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/b574c48c-1da7-11eb-b006-005056ac6a93"
      }
    }
  }
}
```

## Retrieve a FlexCache volume in the cluster

GET /storage/flexcache/flexcaches

**Introduced In:** 9.6

Retrieves FlexCache in the cluster.

### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `origins.ip_address` - IP address of origin.
- `origins.size` - Physical size of origin.
- `origins.state` - State of origin.
- `size` - Physical size of FlexCache.
- `guarantee.type` - Space guarantee style of FlexCache.
- `aggregates.name` or `aggregates.uuid` - Name or UUID of aggregate of FlexCache volume.
- `path` - Fully-qualified path of the owning SVM's namespace where the FlexCache is mounted.

### Related ONTAP commands

- `volume flexcache show`

### Learn more

- [DOC /storage/flexcache/flexcaches](#)

### Parameters

| Name                              | Type    | In    | Required | Description  |
|-----------------------------------|---------|-------|----------|--|
| <code>use_tiered_aggregate</code> | boolean | query | False    | Filter by <code>use_tiered_aggregate</code> <ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul> |
| <code>guarantee.type</code>       | string  | query | False    | Filter by <code>guarantee.type</code> <ul style="list-style-type: none"><li>• Introduced in: 9.7</li></ul>       |
| <code>svm.uuid</code>             | string  | query | False    | Filter by <code>svm.uuid</code>  |

| Name                 | Type    | In    | Required | Description   |
|----------------------|---------|-------|----------|---|
| svm.name             | string  | query | False    | Filter by svm.name  |
| aggregates.uuid      | string  | query | False    | Filter by aggregates.uuid   |
| aggregates.name      | string  | query | False    | Filter by aggregates.name   |
| size                 | integer | query | False    | Filter by size  |
| name                 | string  | query | False    | Filter by name <ul style="list-style-type: none"> <li>• maxLength: 203</li> <li>• minLength: 1</li> </ul> |
| origins.cluster.name | string  | query | False    | Filter by origins.cluster.name  |
| origins.cluster.uuid | string  | query | False    | Filter by origins.cluster.uuid  |
| origins.volume.name  | string  | query | False    | Filter by origins.volume.name   |
| origins.volume.uuid  | string  | query | False    | Filter by origins.volume.uuid   |
| origins.svm.uuid     | string  | query | False    | Filter by origins.svm.uuid  |
| origins.svm.name     | string  | query | False    | Filter by origins.svm.name  |
| origins.size         | integer | query | False    | Filter by origins.size  |
| origins.ip_address   | string  | query | False    | Filter by origins.ip_address  |
| origins.create_time  | string  | query | False    | Filter by origins.create_time   |
| origins.state        | string  | query | False    | Filter by origins.state   |
| path                 | string  | query | False    | Filter by path  |

| Name                        | Type          | In    | Required | Description  |
|-----------------------------|---------------|-------|----------|--|
| uuid                        | string        | query | False    | Filter by uuid   |
| global_file_locking_enabled | boolean       | query | False    | Filter by global_file_locking_enabled<br><br><ul style="list-style-type: none"> <li>Introduced in: 9.9</li> </ul>  |
| constituents_per_aggregate  | integer       | query | False    | Filter by constituents_per_aggregate   |
| dr_cache                    | boolean       | query | False    | Filter by dr_cache<br><br><ul style="list-style-type: none"> <li>Introduced in: 9.9</li> </ul>   |
| return_timeout              | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.<br><br><ul style="list-style-type: none"> <li>Default value: 1</li> <li>Max value: 120</li> <li>Min value: 0</li> </ul> |
| fields                      | array[string] | query | False    | Specify the fields to return.  |
| max_records                 | integer       | query | False    | Limit the number of records returned.  |
| order_by                    | array[string] | query | False    | Order results by specified fields and optional [asc  |



| Name  | Type           | In      | Required | Description |
|---|----------------|---------|----------|-------------|
| desc] direction.<br>Default direction is 'asc' for ascending. | return_records | boolean | query    | False       |

## Response

Status: 200, Ok

| Name        | Type                               | Description       |
|-------------|------------------------------------|-------------------|
| _links      | <a href="#">_links</a>             |                   |
| num_records | integer                            | Number of records |
| records     | array[ <a href="#">flexcache</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "aggregates": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "guarantee": {
      "type": "volume"
    },
    "name": "voll",
    "origins": {
      "cluster": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "cluster1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "create_time": "2018-06-04T19:00:00Z",
      "ip_address": "10.10.10.7",
      "size": 0,
      "state": "error",
      "svm": {
        "_links": {
```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volumel",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"path": "/user/my_fc",
"prepopulate": {
  "dir_paths": {
  },
  "exclude_dir_paths": {
  }
},
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
}

```

## Error

Status: Default, Error

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

guarantee

| Name | Type   | Description  |
|------|--------|--|
| type | string | The type of space guarantee of this volume in the aggregate. |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| name | string | The name of the SVM.              |
| uuid | string | The unique identifier of the SVM. |

#### volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### flexcache\_relationship

| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

#### prepopulate

##### FlexCache prepopulate

| Name      | Type          | Description |
|-----------|---------------|-------------|
| dir_paths | array[string] |             |

| Name              | Type          | Description  |
|-------------------|---------------|--|
| exclude_dir_paths | array[string] |  |
| recurse           | boolean       | Specifies whether or not the prepopulate action should search through the <code>dir_paths</code> recursively. If not set, the default value <code>true</code> is used. |

svm

FlexCache SVM

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

flexcache

Defines the cache endpoint of FlexCache.

| Name                        | Type                                | Description   |
|-----------------------------|-------------------------------------|---|
| <a href="#">_links</a>      | <a href="#">_links</a>              |   |
| aggregates                  | array[ <a href="#">aggregates</a> ] |   |
| constituents_per_aggregate  | integer                             | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.  |
| dr_cache                    | boolean                             | If set to true, a DR cache is created.  |
| global_file_locking_enabled | boolean                             | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>           |   |

| Name                 | Type  | Description   |
|----------------------|---|---|
| name                 | string  | FlexCache name  |
| origins              | array[ <a href="#">flexcache_relationship</a> ] |   |
| path                 | string  | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path. |
| prepopulate          | <a href="#">prepopulate</a>                     | FlexCache prepopulate   |
| size                 | integer   | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.  |
| svm                  | <a href="#">svm</a>                             | FlexCache SVM   |
| use_tiered_aggregate | boolean   | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume.   |
| uuid                 | string  | FlexCache UUID. Unique identifier for the FlexCache.  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error



| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Create a FlexCache volume in the cluster

POST /storage/flexcache/flexcaches

**Introduced In:** 9.6

Creates a FlexCache in the cluster.

### Required properties

- `name` - Name of FlexCache volume.
- `origins.volume.name` or `origins.volume.uuid` - Name or UUID of origin volume.
- `origins.svm.name` - Name of origin Vserver.
- `svm.name` or `svm.uuid` - Name or UUID of Vserver where FlexCache will be created.

### Recommended optional properties

- `path` - Path to mount the FlexCache volume
- `prepopulate.dir_paths` - List of directory-paths to be prepopulated for the FlexCache volume.
- `prepopulate.exclude_dir_paths` - List of directory-paths to be excluded from prepopulation for the FlexCache volume.

### Default property values

If not specified in POST, the following default property values are assigned:

- `size` - 10% of origin volume size or 1GB per constituent, whichever is greater.
- `guarantee.type` - none. FlexCache is thin provisioned by default.
- `constituents_per_aggregate` - 4 if `aggregates.name` or `aggregates.uuid` is used.
- `use_tiered_aggregate` - false if `aggr-list` is not used. This property is only used when auto-provisioning a FlexCache volume.
- `is_disconnected_mode_off_for_locks` - false. This property specifies if the origin will honor the cache side locks when doing the lock checks in the disconnected mode.

- `dr_cache` - false if FlexCache is not a DR cache. This property is used to create a DR FlexCache.
- `global_file_locking_enabled` - false. This property specifies whether global file locking is enabled on the FlexCache volume.

### Related ONTAP commands

- `volume flexcache create`
- `volume flexcache prepopulate start`

### Learn more

- [DOC /storage/flexcache/flexcaches](#)

### Parameters

| Name                        | Type    | In    | Required | Description  |
|-----------------------------|---------|-------|----------|--|
| <code>return_timeout</code> | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul> |

## Request Body

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| _links                      | <a href="#">_links</a>                          |   |
| aggregates                  | array[ <a href="#">aggregates</a> ]             |   |
| constituents_per_aggregate  | integer   | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.  |
| dr_cache                    | boolean   | If set to true, a DR cache is created.  |
| global_file_locking_enabled | boolean   | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>                       |   |
| name                        | string  | FlexCache name  |
| origins                     | array[ <a href="#">flexcache_relationship</a> ] |   |
| path                        | string  | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.   |

| Name                 | Type                        | Description   |
|----------------------|-----------------------------|---|
| prepopulate          | <a href="#">prepopulate</a> | FlexCache prepopulate   |
| size                 | integer                     | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.                            |
| svm                  | <a href="#">svm</a>         | FlexCache SVM   |
| use_tiered_aggregate | boolean                     | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume. |
| uuid                 | string                      | FlexCache UUID. Unique identifier for the FlexCache.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "guarantee": {
    "type": "volume"
  },
  "name": "vol1",
  "origins": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04T19:00:00Z",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"path": "/user/my_fc",
"prepopulate": {
  "dir_paths": {
  },
  "exclude_dir_paths": {
  }
},
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 66846870   | Either the SVM name or origin volume name is missing                       |
| 66846871   | Constituents per aggregate are specified but aggregate name is missing     |
| 66846872   | More than one origin volume is specified                                   |
| 66846873   | The specified SVM UUID is incorrect for the specified SVM name             |
| 66846874   | The specified aggregate UUID is incorrect for the specified aggregate name |
| 66846875   | The specified aggregate name does not exist                                |
| 66846876   | The specified SVM does not exist or is not peered                          |
| 66846877   | The specified origin SVM name is of zero length                            |
| 66846878   | The specified SVM UUID is invalid  |
| 66846730   | Failed to create a FlexCache volume  |
| 66846760   | The specified SVM is not a data Vserver                                    |
| 66846787   | The specified aggregate is a SnapLock aggregate                            |
| 66846812   | The specified aggregate is a Composite aggregate                           |
| 66846812   | The specified junction path is under a FlexCache volume                    |

| Error Code | Description  |
|------------|--|
| 66846834   | FlexCache encryption requires a cluster version of 9.6 or higher |
| 66846835   | A volume encryption license is not found                         |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

guarantee

| Name | Type   | Description  |
|------|--------|--|
| type | string | The type of space guarantee of this volume in the aggregate. |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name                | Type                   | Description  |
|---------------------|------------------------|--|
| <code>_links</code> | <a href="#">_links</a> |  |
| <code>name</code>   | string                 | The name of the volume.  |
| <code>uuid</code>   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### flexcache\_relationship

| Name                     | Type                    | Description                                  |
|--------------------------|-------------------------|--|
| <code>cluster</code>     | <a href="#">cluster</a> |  |
| <code>create_time</code> | string                  | Creation time of the relationship.           |
| <code>ip_address</code>  | string                  | Cluster management IP of the remote cluster. |
| <code>size</code>        | integer                 | Size of the remote volume.                   |
| <code>state</code>       | string                  | Volume state                                 |
| <code>svm</code>         | <a href="#">svm</a>     |  |
| <code>volume</code>      | <a href="#">volume</a>  |  |

#### prepopulate

##### FlexCache prepopulate

| Name                           | Type          | Description  |
|--------------------------------|---------------|--|
| <code>dir_paths</code>         | array[string] |  |
| <code>exclude_dir_paths</code> | array[string] |  |
| <code>recurse</code>           | boolean       | Specifies whether or not the prepopulate action should search through the <code>dir_paths</code> recursively. If not set, the default value <i>true</i> is used. |

#### svm

## FlexCache SVM

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

## flexcache

Defines the cache endpoint of FlexCache.

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| _links                      | <a href="#">_links</a>                          |   |
| aggregates                  | array[ <a href="#">aggregates</a> ]             |   |
| constituents_per_aggregate  | integer   | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.  |
| dr_cache                    | boolean   | If set to true, a DR cache is created.  |
| global_file_locking_enabled | boolean   | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>                       |   |
| name                        | string  | FlexCache name  |
| origins                     | array[ <a href="#">flexcache_relationship</a> ] |   |

| Name                 | Type                        | Description   |
|----------------------|-----------------------------|---|
| path                 | string                      | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path. |
| prepopulate          | <a href="#">prepopulate</a> | FlexCache prepopulate   |
| size                 | integer                     | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.  |
| svm                  | <a href="#">svm</a>         | FlexCache SVM   |
| use_tiered_aggregate | boolean                     | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume.   |
| uuid                 | string                      | FlexCache UUID. Unique identifier for the FlexCache.  |

#### job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a FlexCache volume

```
DELETE /storage/flexcache/flexcaches/{uuid}
```

**Introduced In:** 9.6

Deletes a FlexCache. If a FlexCache volume is online, it is offlined before deletion.

### Related ONTAP commands

- `volume flexcache delete`

### Learn more

- [DOC /storage/flexcache/flexcaches](#)

### Parameters

| Name | Type   | In   | Required | Description                         |
|------|--------|------|----------|-------------------------------------|
| uuid | string | path | True     | Unique identifier of the FlexCache. |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 66846879   | The specified volume UUID is not a FlexCache volume                                 |
| 66846731   | Failed to delete the FlexCache volume   |
| 524546     | Failed to delete the FlexCache volume because the FlexCache volume is not unmounted |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve attributes of the FlexCache volume in the cluster

GET /storage/flexcache/flexcaches/{uuid}

## Introduced In: 9.6

Retrieves attributes of the FlexCache in the cluster.

### Expensive properties

There is an added cost to retrieving values for these properties. They are included by default in GET. The recommended method to use this API is to filter and retrieve only the required fields. See [Requesting specific fields](#) to learn more.

- `origins.ip_address` - IP address of origin.
- `origins.size` - Physical size of origin.
- `origins.state` - State of origin.
- `size` - Physical size of FlexCache.
- `guarantee.type` - Space guarantee style of FlexCache.
- `aggregates.name` or `aggregates.uuid` - Name or UUID of aggregate of FlexCache volume.
- `path` - Fully-qualified path of the owning SVM's namespace where the FlexCache is mounted.

### Related ONTAP commands

- `volume flexcache show`

### Learn more

- [DOC /storage/flexcache/flexcaches](#)

### Parameters

| Name                | Type          | In    | Required | Description                     |
|---------------------|---------------|-------|----------|---------------------------------|
| <code>uuid</code>   | string        | path  | True     | Unique identifier of FlexCache. |
| <code>fields</code> | array[string] | query | False    | Specify the fields to return.   |

### Response

```
Status: 200, Ok
```

| Name                    | Type                                | Description |
|-------------------------|-------------------------------------|-------------|
| <code>_links</code>     | <a href="#">_links</a>              |             |
| <code>aggregates</code> | array[ <a href="#">aggregates</a> ] |             |

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| constituents_per_aggregate  | integer   | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.  |
| dr_cache                    | boolean   | If set to true, a DR cache is created.  |
| global_file_locking_enabled | boolean   | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>                       |   |
| name                        | string  | FlexCache name  |
| origins                     | array[ <a href="#">flexcache_relationship</a> ] |   |
| path                        | string  | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.   |
| prepopulate                 | <a href="#">prepopulate</a>                     | FlexCache prepopulate   |
| size                        | integer   | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.  |
| svm                         | <a href="#">svm</a>                             | FlexCache SVM   |

| <b>Name</b>          | <b>Type</b> | <b>Description</b>  |
|----------------------|-------------|---|
| use_tiered_aggregate | boolean     | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume. |
| uuid                 | string      | FlexCache UUID. Unique identifier for the FlexCache.  |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "guarantee": {
    "type": "volume"
  },
  "name": "vol1",
  "origins": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04T19:00:00Z",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"path": "/user/my_fc",
"prepopulate": {
  "dir_paths": {
  },
  "exclude_dir_paths": {
  }
},
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

guarantee

| Name | Type   | Description  |
|------|--------|--|
| type | string | The type of space guarantee of this volume in the aggregate. |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume



| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### flexcache\_relationship

| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

#### prepopulate

##### FlexCache prepopulate

| Name              | Type          | Description  |
|-------------------|---------------|--|
| dir_paths         | array[string] |  |
| exclude_dir_paths | array[string] |  |
| recurse           | boolean       | Specifies whether or not the prepopulate action should search through the <code>dir_paths</code> recursively. If not set, the default value <code>true</code> is used. |

#### svm

## FlexCache SVM

| Name                | Type                   | Description                       |
|---------------------|------------------------|-----------------------------------|
| <code>_links</code> | <a href="#">_links</a> |                                   |
| <code>name</code>   | string                 | The name of the SVM.              |
| <code>uuid</code>   | string                 | The unique identifier of the SVM. |

## error\_arguments

| Name                 | Type   | Description      |
|----------------------|--------|------------------|
| <code>code</code>    | string | Argument code    |
| <code>message</code> | string | Message argument |

## error

| Name                   | Type                                     | Description                                 |
|------------------------|--|---|
| <code>arguments</code> | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| <code>code</code>      | string                                   | Error code                                  |
| <code>message</code>   | string                                   | Error message                               |
| <code>target</code>    | string                                   | The target parameter that caused the error. |

## Pre-populate a FlexCache volume in the cluster

```
PATCH /storage/flexcache/flexcaches/{uuid}
```

**Introduced In:** 9.8

Prepopulates a FlexCache volume in the cluster.

### Required properties

- `uuid` - FlexCache volume UUID.
- `prepopulate.dir_paths` - List of directory-paths to be prepopulated for the FlexCache volume.

### Recommended optional properties

- `prepopulate.exclude_dir_paths` - List of directory-paths to be excluded from prepopulation for the FlexCache volume.

## Default property values

If not specified in PATCH, the following default property value is assigned:

- `prepopulate.recurse` - Default value is "true".

## Related ONTAP commands

- `volume flexcache prepopulate start`

## Learn more

- [DOC /storage/flexcache/flexcaches](#)

## Parameters

| Name | Type   | In   | Required | Description                                |
|------|--------|------|----------|--|
| uuid | string | path | True     | Unique identifier of the FlexCache volume. |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name                       | Type                                | Description  |
|----------------------------|-------------------------------------|--|
| _links                     | <a href="#">_links</a>              |  |
| aggregates                 | array[ <a href="#">aggregates</a> ] |  |
| constituents_per_aggregate | integer                             | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned. |
| dr_cache                   | boolean                             | If set to true, a DR cache is created.   |

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| global_file_locking_enabled | boolean   | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>                       |   |
| name                        | string  | FlexCache name  |
| origins                     | array[ <a href="#">flexcache_relationship</a> ] |   |
| path                        | string  | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.   |
| prepopulate                 | <a href="#">prepopulate</a>                     | FlexCache prepopulate   |
| size                        | integer   | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.  |
| svm                         | <a href="#">svm</a>                             | FlexCache SVM   |
| use_tiered_aggregate        | boolean   | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume.   |
| uuid                        | string  | FlexCache UUID. Unique identifier for the FlexCache.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "guarantee": {
    "type": "volume"
  },
  "name": "vol1",
  "origins": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04T19:00:00Z",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
},
"path": "/user/my_fc",
"prepopulate": {
  "dir_paths": {
  },
  "exclude_dir_paths": {
  }
},
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 66846922   | FlexCache volume does not exist in the SVM  |
| 66846923   | Failed to prepopulate FlexCache volume because the origin volume is not reachable   |
| 66846924   | FlexCache volume is offline   |
| 66846925   | FlexCache volume is not mounted or the junction-path is not active  |
| 66846926   | The junction-path of FlexCache volume is not active   |
| 66846927   | FlexCache volume does not have an origin volume   |
| 66846928   | FlexCache volume does not exist   |
| 66846929   | Using FlexCache prepopulate requires an effective cluster version of 9.8.0 or later   |
| 66846930   | Using FlexCache prepopulate in a MetroCluster configuration requires an effective cluster version of 9.8.0 or later on both the local and remote clusters |
| 66846931   | Internal Error. FlexCache prepopulate job queue failed. Wait a few minutes, and then try the operation again  |
| 66846936   | Failed to lookup root file handle for origin of FlexCache volume. Wait a few minutes, and then try the operation again                                    |



| Error Code | Description  |
|------------|--|
| 66846937   | Internal error. Failed to initialize thread  |
| 66846939   | Internal error. Failed to get the MSID of the origin volume for FlexCache volume               |
| 66846943   | Failed to prepopulate because dir_path does not exist  |
| 66846944   | Failed to get root constituent for FlexCache volume  |
| 66846945   | Origin of FlexCache volume is not mounted or the junction-path is not active                   |
| 66846946   | The junction-path of origin of FlexCache volume is not active                                  |
| 66846947   | FlexCache prepopulate job for FlexCache volume already exists                                  |
| 66846948   | FlexCache prepopulate job for FlexCache volume could not be queued because the node is offline |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

aggregates

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

guarantee

| Name | Type   | Description  |
|------|--------|--|
| type | string | The type of space guarantee of this volume in the aggregate. |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### flexcache\_relationship

| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

#### prepopulate

##### FlexCache prepopulate

| Name              | Type          | Description  |
|-------------------|---------------|--|
| dir_paths         | array[string] |  |
| exclude_dir_paths | array[string] |  |
| recurse           | boolean       | Specifies whether or not the prepopulate action should search through the <code>dir_paths</code> recursively. If not set, the default value <code>true</code> is used. |

#### svm

## FlexCache SVM

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

## flexcache

Defines the cache endpoint of FlexCache.

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| _links                      | <a href="#">_links</a>                          |   |
| aggregates                  | array[ <a href="#">aggregates</a> ]             |   |
| constituents_per_aggregate  | integer   | Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.  |
| dr_cache                    | boolean   | If set to true, a DR cache is created.  |
| global_file_locking_enabled | boolean   | Specifies whether or not a FlexCache volume has global file locking mode enabled. Global file locking mode is a mode where protocol read locking semantics are enforced across all FlexCaches and origins of a FlexCache volume. When global file locking mode is enabled, the "is_disconnected_mode_off_for_locks" flag is always set to "true". |
| guarantee                   | <a href="#">guarantee</a>                       |   |
| name                        | string  | FlexCache name  |
| origins                     | array[ <a href="#">flexcache_relationship</a> ] |   |

| Name                 | Type                        | Description   |
|----------------------|-----------------------------|---|
| path                 | string                      | The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path. |
| prepopulate          | <a href="#">prepopulate</a> | FlexCache prepopulate   |
| size                 | integer                     | Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.  |
| svm                  | <a href="#">svm</a>         | FlexCache SVM   |
| use_tiered_aggregate | boolean                     | Specifies whether or not a Fabricpool-enabled aggregate can be used in FlexCache creation. The use_tiered_aggregate is only used when auto-provisioning a FlexCache volume.   |
| uuid                 | string                      | FlexCache UUID. Unique identifier for the FlexCache.  |

#### job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage FlexCache origin volumes

### Storage flexcache origins endpoint overview

#### Overview

FlexCache is a persistent cache of an origin volume. An origin volume can only be a FlexVol while a FlexCache is always a FlexGroup.

The following relationship configurations are supported:

&ndash; Intra-Vserver where FlexCache and the corresponding origin volume reside in the same Vserver.

&ndash; Cross-Vserver but intra-cluster where FlexCache and the origin volume reside in the same cluster but belong to different Vservers.

&ndash; Cross-cluster where FlexCache and the origin volume reside in different clusters.

FlexCache supports fan-out and more than one FlexCache can be created from one origin volume. This API retrieves the origin of FlexCache onfigurations in the origin cluster.

#### FlexCache APIs

The following APIs can be used to perform operations related to the origin of a FlexCache:

&ndash; GET `/api/storage/flexcache/origins`

&ndash; GET `/api/storage/flexcache/origins/{uuid}`

&ndash; PATCH `/api/storage/flexcache/origins/{uuid}`

#### Examples

##### Retrieving origins of FlexCache attributes

The GET request is used to retrieve the origins of FlexCache attributes.

```

# The API:
/api/storage/flexcache/origins

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/flexcache/origins?" -H
"accept: application/json"

# The response:
{
  "records": [
    {
      "uuid": "2bc957dd-2617-4afb-8d2f-66ac6070d313",
      "name": "vol_01",
      "_links": {
        "self": {
          "href": "/api/storage/flexcache/origins/2bc957dd-2617-4afb-8d2f-
66ac6070d313"
        }
      }
    },
    {
      "uuid": "80fcaee4-0dc2-488b-afb8-86d28a34cda8",
      "name": "vol_1",
      "_links": {
        "self": {
          "href": "/api/storage/flexcache/origins/80fcaee4-0dc2-488b-afb8-
86d28a34cda8"
        }
      }
    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/origins?"
    }
  }
}

```

### Retrieving the attributes of an origin volume

The GET request is used to retrieve the attributes of an origin volume.

```

# The API:
/api/storage/flexcache/origins/{uuid}

```

```

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/flexcache/origins/80fcaee4-0dc2-488b-afb8-86d28a34cda8" -H "accept: application/json"

# The response:
{
  "uuid": "80fcaee4-0dc2-488b-afb8-86d28a34cda8",
  "name": "vol_1",
  "svm": {
    "name": "vs_3",
    "uuid": "8aa2cd28-0e92-11e9-b391-0050568e4115"
  },
  "block_level_invalidation": "false",
  "global_file_locking_enabled": "true",
  "flexcaches": [
    {
      "ip_address": "10.140.103.183",
      "create_time": "2019-01-02T19:27:22+05:30",
      "volume": {
        "name": "fc_42",
        "uuid": "4e7f9d49-0e96-11e9-aed0-0050568eddbe"
      },
      "svm": {
        "name": "vs_1_4",
        "uuid": "36f68322-0e93-11e9-aed0-0050568eddbe"
      },
      "cluster": {
        "name": "node4",
        "uuid": "c32f16b8-0e90-11e9-aed0-0050568eddbe"
      }
    },
    {
      "ip_address": "10.140.103.183",
      "create_time": "2019-01-02T21:08:34+05:30",
      "volume": {
        "name": "fc_421",
        "uuid": "71ee8f36-0ea4-11e9-aed0-0050568eddbe"
      },
      "svm": {
        "name": "vs_1_4",
        "uuid": "36f68322-0e93-11e9-aed0-0050568eddbe"
      },
      "cluster": {
        "name": "node4",
        "uuid": "c32f16b8-0e90-11e9-aed0-0050568eddbe"
      }
    }
  ]
}

```



```

    }
  },
  {
    "ip_address": "10.140.103.183",
    "create_time": "2019-01-03T11:14:38+05:30",
    "volume": {
      "name": "fc_422"
    },
    "svm": {
      "name": "vs_1_4",
      "uuid": "36f68322-0e93-11e9-aed0-0050568eddb"
    },
    "cluster": {
      "name": "node4",
      "uuid": "c32f16b8-0e90-11e9-aed0-0050568eddb"
    }
  },
  {
    "ip_address": "10.140.103.179",
    "size": 4294967296,
    "create_time": "2019-01-02T19:24:14+05:30",
    "state": "online",
    "volume": {
      "name": "fc_32",
      "uuid": "ddb42bbc-0e95-11e9-8180-0050568e0b79"
    },
    "svm": {
      "name": "vs_1",
      "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79"
    },
    "cluster": {
      "name": "node3",
      "uuid": "8eb21b3b-0e90-11e9-8180-0050568e0b79"
    }
  },
  {
    "ip_address": "10.140.103.179",
    "size": 4294967296,
    "create_time": "2019-01-02T21:07:23+05:30",
    "state": "online",
    "volume": {
      "name": "fc_321",
      "uuid": "47902654-0ea4-11e9-8180-0050568e0b79"
    },
    "svm": {
      "name": "vs_1",

```

```

    "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79"
  },
  "cluster": {
    "name": "node3",
    "uuid": "8eb21b3b-0e90-11e9-8180-0050568e0b79"
  }
},
{
  "ip_address": "10.140.103.179",
  "size": 4294967296,
  "create_time": "2019-01-03T00:11:38+05:30",
  "state": "online",
  "volume": {
    "name": "fc_322",
    "uuid": "04d5e07b-0ebe-11e9-8180-0050568e0b79"
  },
  "svm": {
    "name": "vs_1",
    "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79"
  },
  "cluster": {
    "name": "node3",
    "uuid": "8eb21b3b-0e90-11e9-8180-0050568e0b79"
  }
},
{
  "ip_address": "10.140.103.179",
  "size": 4294967296,
  "create_time": "2019-01-03T00:14:52+05:30",
  "state": "online",
  "volume": {
    "name": "fc_323",
    "uuid": "77e911ff-0ebe-11e9-8180-0050568e0b79"
  },
  "svm": {
    "name": "vs_1",
    "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79"
  },
  "cluster": {
    "name": "node3",
    "uuid": "8eb21b3b-0e90-11e9-8180-0050568e0b79"
  }
}
],
"_links": {
  "self": {

```

```
    "href": "/api/storage/flexcache/origins/80fcaee4-0dc2-488b-afb8-86d28a34cda8"
  }
}
```

### Modifying origin options of an origin volume

Use the PATCH request to update options of an origin volume.

```
# the API:
/api/storage/flexcache/origins/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/flexcache/origins/1fbc0ebb-2440-11eb-a86c-005056ac8ca0" -H "accept: application/json" -H "Content-Type: application/json" -d '{"block_level_invalidation": "true"}'

# The response:
{
  "job": {
    "uuid": "e751dd5d-0f3c-11e9-8b2b-0050568e0b79",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79"
      }
    }
  }
}
```

### Retrieve the origin of a FlexCache volume in the cluster

GET /storage/flexcache/origins

**Introduced In:** 9.6

Retrieves origin of FlexCache in the cluster.

#### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `flexcaches.ip_address` - IP address of FlexCache.
- `flexcaches.size` - Physical size of FlexCache.

- `flexcaches.guarantee.type` - Space guarantee style of FlexCache.
- `flexcaches.state` - State of FlexCache.

## Related ONTAP commands

- `volume flexcache origin show-caches`

## Learn more

- [DOC /storage/flexcache/origins](#)

## Parameters

| Name                                 | Type    | In    | Required | Description                                    |
|--------------------------------------|---------|-------|----------|--|
| <code>flexcaches.cluster.name</code> | string  | query | False    | Filter by <code>flexcaches.cluster.name</code> |
| <code>flexcaches.cluster.uuid</code> | string  | query | False    | Filter by <code>flexcaches.cluster.uuid</code> |
| <code>flexcaches.volume.name</code>  | string  | query | False    | Filter by <code>flexcaches.volume.name</code>  |
| <code>flexcaches.volume.uuid</code>  | string  | query | False    | Filter by <code>flexcaches.volume.uuid</code>  |
| <code>flexcaches.svm.uuid</code>     | string  | query | False    | Filter by <code>flexcaches.svm.uuid</code>     |
| <code>flexcaches.svm.name</code>     | string  | query | False    | Filter by <code>flexcaches.svm.name</code>     |
| <code>flexcaches.size</code>         | integer | query | False    | Filter by <code>flexcaches.size</code>         |
| <code>flexcaches.ip_address</code>   | string  | query | False    | Filter by <code>flexcaches.ip_address</code>   |
| <code>flexcaches.create_time</code>  | string  | query | False    | Filter by <code>flexcaches.create_time</code>  |

| Name                        | Type    | In    | Required | Description  |
|-----------------------------|---------|-------|----------|--|
| flexcaches.state            | string  | query | False    | Filter by flexcaches.state   |
| block_level_invalidation    | boolean | query | False    | Filter by block_level_invalidation<br><br>• Introduced in: 9.9   |
| name                        | string  | query | False    | Filter by name<br><br>• maxLength: 203<br>• minLength: 1   |
| uuid                        | string  | query | False    | Filter by uuid   |
| svm.uuid                    | string  | query | False    | Filter by svm.uuid   |
| svm.name                    | string  | query | False    | Filter by svm.name   |
| global_file_locking_enabled | boolean | query | False    | Filter by global_file_locking_enabled<br><br>• Introduced in: 9.9  |
| return_timeout              | integer | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.<br><br>• Default value: 1<br>• Max value: 120<br>• Min value: 0 |

| Name   | Type           | In      | Required | Description   |
|--|----------------|---------|----------|---|
| fields   | array[string]  | query   | False    | Specify the fields to return.                       |
| max_records  | integer        | query   | False    | Limit the number of records returned.               |
| order_by   | array[string]  | query   | False    | Order results by specified fields and optional [asc |
| desc] direction. Default direction is 'asc' for ascending. | return_records | boolean | query    | False   |

## Response

Status: 200, Ok

| Name        | Type                                      | Description       |
|-------------|---|-------------------|
| _links      | <a href="#">_links</a>                    |                   |
| num_records | integer                                   | Number of records |
| records     | array[ <a href="#">flexcache_origin</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "flexcaches": {
      "cluster": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "cluster1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "create_time": "2018-06-04T19:00:00Z",
      "ip_address": "10.10.10.7",
      "size": 0,
      "state": "error",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "volume": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        }
      }
    },
  },
}
```

```

    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "name": "voll, vol_2",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563512"
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```



**Definitions**

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description             |
|--------|------------------------|-------------------------|
| _links | <a href="#">_links</a> |                         |
| name   | string                 | The name of the volume. |

| Name | Type   | Description  |
|------|--------|--|
| uuid | string | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### flexcache\_relationship

| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

#### svm

##### Origin volume SVM

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

#### flexcache\_origin

Defines the origin endpoint of FlexCache.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |

| Name                        | Type  | Description  |
|-----------------------------|---|--|
| block_level_invalidation    | boolean   | Block level invalidation enables the FlexCache volume to retain blocks that are not changed at the FlexCache volume without having to evict them. This means that the FlexCache volume does not have to again incur the cost of fetching blocks over the WAN from the FlexCache volume origin on the next client access. Block level invalidation is a property of the origin volume. Without block level invalidation, any write at the origin volume would evict the whole file at the FlexCache volume, since by default, origin volume does a file level invalidation. |
| flexcaches                  | array[ <a href="#">flexcache_relationship</a> ] |  |
| global_file_locking_enabled | boolean   | Specifies whether a global file locking option is enabled for an origin volume of a FlexCache volume.  |
| name                        | string  | Origin volume name   |
| svm                         | <a href="#">svm</a>                             | Origin volume SVM  |
| uuid                        | string  | Origin volume UUID. Unique identifier for origin of FlexCache.   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Retrieve attributes of the origin of a FlexCache volume in the cluster

GET /storage/flexcache/origins/{uuid}

**Introduced In:** 9.6

Retrieves attributes of the origin of a FlexCache in the cluster.

### Expensive properties

There is an added cost to retrieving values for these properties. They are included by default in GET results. The recommended method to use this API is to filter and retrieve only the required fields. See [Requesting specific fields](#) to learn more.

- `flexcaches.ip_address` - IP address of FlexCache.
- `flexcaches.size` - Physical size of FlexCache.
- `flexcaches.guarantee.type` - Space guarantee style of FlexCache.
- `flexcaches.state` - State of FlexCache.
- `flexcaches.dr_cache` - True if the cache is a DR cache.

### Related ONTAP commands

- `volume flexcache origin show-caches`

### Learn more

- [DOC /storage/flexcache/origins](#)

### Parameters

| Name   | Type          | In    | Required | Description                               |
|--------|---------------|-------|----------|---|
| uuid   | string        | path  | True     | Unique identifier of origin of FlexCache. |
| fields | array[string] | query | False    | Specify the fields to return.             |

## Response

Status: 200, Ok

| Name                        | Type  | Description  |
|-----------------------------|---|--|
| <a href="#">_links</a>      | <a href="#">_links</a>                          |  |
| block_level_invalidation    | boolean   | Block level invalidation enables the FlexCache volume to retain blocks that are not changed at the FlexCache volume without having to evict them. This means that the FlexCache volume does not have to again incur the cost of fetching blocks over the WAN from the FlexCache volume origin on the next client access. Block level invalidation is a property of the origin volume. Without block level invalidation, any write at the origin volume would evict the whole file at the FlexCache volume, since by default, origin volume does a file level invalidation. |
| flexcaches                  | array[ <a href="#">flexcache_relationship</a> ] |  |
| global_file_locking_enabled | boolean   | Specifies whether a global file locking option is enabled for an origin volume of a FlexCache volume.  |
| name                        | string  | Origin volume name   |
| svm                         | <a href="#">svm</a>                             | Origin volume SVM  |
| uuid                        | string  | Origin volume UUID. Unique identifier for origin of FlexCache.   |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "flexcaches": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04T19:00:00Z",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "name": "vol1, vol_2",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  }
}
```

```
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563512"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

flexcache\_relationship

| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

svm

Origin volume SVM

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Modify origin options for a Flexcache origin volume in the cluster

PATCH /storage/flexcache/origins/{uuid}

**Introduced In:** 9.9

Modifies origin options for a origin volume in the cluster.

### Required properties

- `uuid` - Origin volume UUID.
- `block_level_invalidation` - Value for the Block Level Invalidation flag - options {true|false}.

### Related ONTAP commands

- `volume flexcache origin config modify`

### Learn more

- [DOC /storage/flexcache/origins](#)

### Parameters

| Name | Type   | In   | Required | Description  |
|------|--------|------|----------|--|
| uuid | string | path | True     | Unique identifier of the origin of the FlexCache volume. |

### Request Body

| Name                                  | Type                   | Description  |
|---------------------------------------|------------------------|--|
| <code>_links</code>                   | <a href="#">_links</a> |  |
| <code>block_level_invalidation</code> | boolean                | Block level invalidation enables the FlexCache volume to retain blocks that are not changed at the FlexCache volume without having to evict them. This means that the FlexCache volume does not have to again incur the cost of fetching blocks over the WAN from the FlexCache volume origin on the next client access. Block level invalidation is a property of the origin volume. Without block level invalidation, any write at the origin volume would evict the whole file at the FlexCache volume, since by default, origin volume does a file level invalidation. |

| Name                        | Type  | Description   |
|-----------------------------|---|---|
| flexcaches                  | array[ <a href="#">flexcache_relationship</a> ] |   |
| global_file_locking_enabled | boolean   | Specifies whether a global file locking option is enabled for an origin volume of a FlexCache volume. |
| name                        | string  | Origin volume name  |
| svm                         | <a href="#">svm</a>                             | Origin volume SVM   |
| uuid                        | string  | Origin volume UUID. Unique identifier for origin of FlexCache.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "flexcaches": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04T19:00:00Z",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "name": "voll, vol_2",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  }
}
```

```

    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563512"
}

```

## Response

Status: 200, Ok

| Name | Type     | Description |
|------|----------|-------------|
| job  | job_link |             |

## Example response

```

{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "uuid": "string"
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 66846870   | Either origin volume uuid or BLI option value is missing |
| 66847020   | Failed to get origin volume details using volume uuid    |
| 66847021   | Failed to modify origin volume options                   |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

cluster

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

volume

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

flexcache\_relationship



| Name        | Type                    | Description                                  |
|-------------|-------------------------|--|
| cluster     | <a href="#">cluster</a> |  |
| create_time | string                  | Creation time of the relationship.           |
| ip_address  | string                  | Cluster management IP of the remote cluster. |
| size        | integer                 | Size of the remote volume.                   |
| state       | string                  | Volume state                                 |
| svm         | <a href="#">svm</a>     |  |
| volume      | <a href="#">volume</a>  |  |

svm

Origin volume SVM

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

flexcache\_origin

Defines the origin endpoint of FlexCache.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |

| Name                        | Type  | Description  |
|-----------------------------|---|--|
| block_level_invalidation    | boolean   | Block level invalidation enables the FlexCache volume to retain blocks that are not changed at the FlexCache volume without having to evict them. This means that the FlexCache volume does not have to again incur the cost of fetching blocks over the WAN from the FlexCache volume origin on the next client access. Block level invalidation is a property of the origin volume. Without block level invalidation, any write at the origin volume would evict the whole file at the FlexCache volume, since by default, origin volume does a file level invalidation. |
| flexcaches                  | array[ <a href="#">flexcache_relationship</a> ] |  |
| global_file_locking_enabled | boolean   | Specifies whether a global file locking option is enabled for an origin volume of a FlexCache volume.  |
| name                        | string  | Origin volume name   |
| svm                         | <a href="#">svm</a>                             | Origin volume SVM  |
| uuid                        | string  | Origin volume UUID. Unique identifier for origin of FlexCache.   |

#### job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name | Type   | Description   |
|------|--------|---------------|
| code | string | Argument code |

| Name    | Type   | Description      |
|---------|--------|------------------|
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage pools

### Storage pools endpoint overview

#### Retrieving storage pool information

The Storage Pools GET API retrieves all shared storage pools in the cluster.

The collection GET returns the storage pool identifiers, UUID and name. The instance GET, by default, returns all of the properties defined in the `storage_pool` object.

#### Creating storage pools

Creating a shared storage pool is recommended when distributing flash capacity across the cache tiers of HDD aggregates across an HA pair. POST can be used with specific properties to create a storage pool as requested. At a minimum, the storage pool name, disk count, and the nodes where it should reside, are required to create a new instance.

When using POST with input properties, three properties are required. These are:

- name - Name of the storage pool.
- node.name or node.uuid - Node that can use capacity from the storage pool in their cache tiers.
- capacity.disk\_count - Number of disks to be used to create the storage pool.

#### Examples

##### Retrieving a list of storage pools from the cluster

The following example shows the response with a list of storage pools in the cluster:

```

{
"records": [
{
"uuid": "8255fef7-4737-11ec-bd1b-005056bbb879",
"nodes": [
{
"uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
"name": "node-1",
},
{
"uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
"name": "node-2",
}
],
"_links": {
"self": {
"href": "/api/storage/pools/8255fef7-4737-11ec-bd1b-005056bbb879"
}
}
}
],
"num_records": 1,
"_links": {
"self": {
"href": "/api/storage/pools"
}
}
}
}

```

```

# The API:
/api/storage/pools

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools?fields=*" -H "accept:
application/json"

# The response:
{
"records": [
{
"uuid": "8255fef7-4737-11ec-bd1b-005056bbb879",
"name": "new_sp",
"nodes": [
{

```

```

    "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
    "name": "node-1",
  },
  {
    "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
    "name": "node-2",
  }
],
"storage_type": "ssd",
"capacity": {
  "remaining": 1846542336,
  "total": 7386169344,
  "spare_allocation_units": [
    {
      "node": {
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
        "name": "node-1",
      },
      "count": 1,
      "syncmirror_pool": "pool0",
      "size": 1846542336,
      "available_size": 1846542336
    },
    {
      "node": {
        "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
        "name": "node-2",
      },
      "count": 0,
      "syncmirror_pool": "pool0",
      "size": 1846542336,
      "available_size": 0
    }
  ],
  "used_allocation_units": [
    {
      "aggregate": {
        "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
        "name": "test_a"
      },
      "allocated_unit_count": 2,
      "node": {
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
        "name": "node-1",
      },
      "capacity": 2769813504
    }
  ]
}

```

```

},
{
  "aggregate": {
    "uuid": "f4cc30d5-b052-493a-a49f-19781425f987",
    "name": "test_b"
  },
  "allocated_unit_count": 1,
  "node": {
    "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
    "name": "node-2",
  },
  "capacity": 1384906752
}
],
"disk_count": 4,
"disks": [
  {
    "disk": {
      "name": "VMw-1.11"
    },
    "usable_size": 1902379008,
    "total_size": 1908871168,
  },
  {
    "disk": {
      "name": "VMw-1.12"
    },
    "usable_size": 1902379008,
    "total_size": 1908871168,
  },
  {
    "disk": {
      "name": "VMw-1.23"
    },
    "usable_size": 1902379008,
    "total_size": 1908871168,
  },
  {
    "disk": {
      "name": "VMw-1.24"
    },
    "usable_size": 1902379008,
    "total_size": 1908871168,
  }
]
},

```

```

    "health": {
      "state": "normal",
      "is_healthy": true
    },
  ],
  "num_records": 1,
}

```

### Simulating the creation of a storage pool

The following example shows the response containing the simulated layout details of a new storage pool in the cluster.



Each storage pool UUID provided in this response is not guaranteed to be the same UUID for the storage pool if it is created.

```

# The API:
/api/storage/pools

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/pools?simulate=true&fields=*"
-d "{\"nodes\": [{\"name\": \"node1\"}, {\"name\": \"node2\"}], \"name\":
\"storage_pool_1\", \"capacity\": {\"disk_count\": \"4\"}}" -H "accept:
application/json"

# The response:
{
  "records": [
    {
      "uuid": "cae60cfe-deae-42bd-babb-ef437d118314",
      "name": "new_sp",
      "nodes": [
        {
          "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
          "name": "node-1",
        },
        {
          "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
          "name": "node-2",
        }
      ],
      "storage_type": "ssd",
      "capacity": {
        "total": 7386169344,
        "disk_count": 4,
      }
    }
  ]
}

```

```

    "disks": [
      {
        "disk": {
          "name": "VMw-1.11"
        },
      },
      {
        "disk": {
          "name": "VMw-1.12"
        },
      },
      {
        "disk": {
          "name": "VMw-1.23"
        },
      },
      {
        "disk": {
          "name": "VMw-1.24"
        },
      }
    ]
  }
]
}

```

## Retrieve storage pools for the entire cluster

GET /storage/pools

**Introduced In:** 9.11

Retrieves the collection of storage pools for the entire cluster.

### Related ONTAP commands

- storage pool show

### Parameters

| Name                                 | Type    | In    | Required | Description                                    |
|--------------------------------------|---------|-------|----------|--|
| capacity.used_allocation_units.count | integer | query | False    | Filter by capacity.used_allocation_units.count |



| Name  | Type    | In    | Required | Description   |
|---|---------|-------|----------|---|
| capacity.used_allocation_units.aggregate.uuid | string  | query | False    | Filter by capacity.used_allocation_units.aggregate.uuid |
| capacity.used_allocation_units.aggregate.name | string  | query | False    | Filter by capacity.used_allocation_units.aggregate.name |
| capacity.used_allocation_units.current_usage  | integer | query | False    | Filter by capacity.used_allocation_units.current_usage  |
| capacity.used_allocation_units.node.uuid      | string  | query | False    | Filter by capacity.used_allocation_units.node.uuid      |
| capacity.used_allocation_units.node.name      | string  | query | False    | Filter by capacity.used_allocation_units.node.name      |
| capacity.total                                | integer | query | False    | Filter by capacity.total                                |
| capacity.remaining                            | integer | query | False    | Filter by capacity.remaining                            |
| capacity.disks.disk.name                      | string  | query | False    | Filter by capacity.disks.disk.name                      |
| capacity.disks.total_size                     | integer | query | False    | Filter by capacity.disks.total_size                     |
| capacity.disks.usable_size                    | integer | query | False    | Filter by capacity.disks.usable_size                    |
| capacity.spare_allocation_units.size          | integer | query | False    | Filter by capacity.spare_allocation_units.size          |

| Name  | Type    | In    | Required | Description   |
|---|---------|-------|----------|---|
| capacity.spare_allocation_units.syncmirror_pool | string  | query | False    | Filter by capacity.spare_allocation_units.syncmirror_pool |
| capacity.spare_allocation_units.node.uuid       | string  | query | False    | Filter by capacity.spare_allocation_units.node.uuid       |
| capacity.spare_allocation_units.node.name       | string  | query | False    | Filter by capacity.spare_allocation_units.node.name       |
| capacity.spare_allocation_units.count           | integer | query | False    | Filter by capacity.spare_allocation_units.count           |
| capacity.spare_allocation_units.available_size  | integer | query | False    | Filter by capacity.spare_allocation_units.available_size  |
| capacity.disk_count                             | integer | query | False    | Filter by capacity.disk_count                             |
| nodes.uuid                                      | string  | query | False    | Filter by nodes.uuid                                      |
| nodes.name                                      | string  | query | False    | Filter by nodes.name                                      |
| storage_type                                    | string  | query | False    | Filter by storage_type                                    |
| name  | string  | query | False    | Filter by name  |
| uuid  | string  | query | False    | Filter by uuid  |
| health.unhealthy_reason.arguments.message       | string  | query | False    | Filter by health.unhealthy_reason.arguments.message       |

| Name                                   | Type          | In    | Required | Description   |
|--|---------------|-------|----------|---|
| health.unhealthy_reason.arguments.code | string        | query | False    | Filter by health.unhealthy_reason.arguments.code  |
| health.unhealthy_reason.target         | string        | query | False    | Filter by health.unhealthy_reason.target  |
| health.unhealthy_reason.code           | string        | query | False    | Filter by health.unhealthy_reason.code  |
| health.unhealthy_reason.message        | string        | query | False    | Filter by health.unhealthy_reason.message   |
| health.state                           | string        | query | False    | Filter by health.state  |
| health.is_healthy                      | boolean       | query | False    | Filter by health.is_healthy   |
| fields                                 | array[string] | query | False    | Specify the fields to return.   |
| max_records                            | integer       | query | False    | Limit the number of records returned.   |
| return_records                         | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned.<br><br>• Default value: 1 |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                                  | Description                                    |
|-------------|---------------------------------------|--|
| _links      | <a href="#">_links</a>                |  |
| error       | <a href="#">error</a>                 |  |
| num_records | integer                               | Number of shared storage pools in the cluster. |
| records     | array[ <a href="#">storage_pool</a> ] |  |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "capacity": {
    "disks": {
      "disk": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        }
      },
      "name": "1.0.1"
    },
    "total_size": 0,
    "usable_size": 0
  },
  "remaining": 0,
  "spare_allocation_units": {
    "available_size": 0,
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      }
    }
  }
}
```

```

    }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "size": 0,
  "syncmirror_pool": "pool0"
},
"total": 0,
"used_allocation_units": {
  "aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "current_usage": 0,
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
},
"health": {
  "state": "normal",
  "unhealthy_reason": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
},
"nodes": {
  "_links": {
    "self": {

```

```

        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "storage_type": "SSD",
  "uuid": "string"
}
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 11206662   | There is no storage pool matching the specified UUID or name. |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

## Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

disk

Reference to the constituent disk object.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |



## storage\_pool\_disk

| Name        | Type                 | Description                               |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> | Reference to the constituent disk object. |
| total_size  | integer              | Raw capacity of the disk, in bytes.       |
| usable_size | integer              | Usable capacity of this disk, in bytes.   |

## node

Specifies what node can use this set of allocation units.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

## storage\_pool\_spare\_allocation\_unit

| Name            | Type                 | Description   |
|-----------------|----------------------|---|
| available_size  | integer              | The usable capacity of this set of allocation units.                |
| count           | integer              | The number of spare allocation units on this node.                  |
| node            | <a href="#">node</a> | Specifies what node can use this set of allocation units.           |
| size            | integer              | Size of each allocation unit.                                       |
| syncmirror_pool | string               | The RAID SyncMirror Pool to which this allocation unit is assigned. |

## aggregate

The aggregate that is using this cache capacity.

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

node

The node hosting the aggregate using this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pool\_used\_allocation\_unit

| Name          | Type                      | Description  |
|---------------|---------------------------|--|
| aggregate     | <a href="#">aggregate</a> | The aggregate that is using this cache capacity.                   |
| count         | integer                   | The number of allocation units used by this aggregate.             |
| current_usage | integer                   | The amount of cache space used by this aggregate.                  |
| node          | <a href="#">node</a>      | The node hosting the aggregate using this set of allocation units. |

capacity

| Name                   | Type  | Description  |
|------------------------|---|--|
| disk_count             | integer   | The number of disks in the storage pool.                 |
| disks                  | array[ <a href="#">storage_pool_disk</a> ]                  | Properties of each disk used in the shared storage pool. |
| remaining              | integer   | Remaining usable capacity in the flash pool, in bytes.   |
| spare_allocation_units | array[ <a href="#">storage_pool_spare_allocation_unit</a> ] | Properties of spare allocation units.                    |

| Name                  | Type   | Description  |
|-----------------------|--|--|
| total                 | integer  | Total size of the flash pool, in bytes.  |
| used_allocation_units | array[ <a href="#">storage_pool_used_allocation_unit</a> ] | Information about the storage pool allocation units participating in the cache tier of an aggregate. |

#### error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### health

Properties that outline shared storage pool health.

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| is_healthy       | boolean               | Indicates whether the storage pool is able to participate in provisioning operations.                 |
| state            | string                | The state of the shared storage pool.   |
| unhealthy_reason | <a href="#">error</a> | Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools. |

#### node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

| Name | Type   | Description |
|------|--------|-------------|
| uuid | string |             |

storage\_pool

| Name         | Type                                    | Description   |
|--------------|---|---|
| _links       | <a href="#">_links</a>                  |   |
| capacity     | <a href="#">capacity</a>                |   |
| health       | <a href="#">health</a>                  | Properties that outline shared storage pool health.         |
| name         | string                                  | Storage pool name.  |
| nodes        | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates.  |
| storage_type | string                                  | Storage type for the disks used to create the storage pool. |
| uuid         | string                                  | Storage pool UUID.  |

## Create a new storage pool

POST /storage/pools

**Introduced In:** 9.11

Creates a new storage pool using available solid state capacity attached to the nodes specified.

### Required properties

The following properties are required in the POST body:

- `name` - Name of the new storage pool.
- `nodes[].name` or `nodes[].uuid` - Nodes that can use cache capacity from the new storage pool. Only nodes in the same HA pair can be specified for a given storage pool. Spare cache capacity will be distributed evenly among the specified nodes.
- `capacity.disk_count` - Number of SSDs to be used to create the storage pool.

### Related ONTAP commands

- `storage pool create`

### Example:

```
POST /api/storage/pools {"nodes": [{"name": "node1"}, {"name": "node2"}],
"name": "storage_pool_1", "capacity": {"disk_count": "4"}}
```

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| disk_size      | integer | query | False    | If set, POST only selects SSDs within five percent of the specified size.  |
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul> |

### Request Body

| Name         | Type                                    | Description   |
|--------------|---|---|
| _links       | <a href="#">_links</a>                  |   |
| capacity     | <a href="#">capacity</a>                |   |
| health       | <a href="#">health</a>                  | Properties that outline shared storage pool health.         |
| name         | string                                  | Storage pool name.  |
| nodes        | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates.  |
| storage_type | string                                  | Storage type for the disks used to create the storage pool. |
| uuid         | string                                  | Storage pool UUID.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "capacity": {
    "disks": {
      "disk": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "1.0.1"
      },
      "total_size": 0,
      "usable_size": 0
    },
    "remaining": 0,
    "spare_allocation_units": {
      "available_size": 0,
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "size": 0,
      "syncmirror_pool": "pool0"
    },
    "total": 0,
    "used_allocation_units": {
      "aggregate": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "aggr1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    }
  }
}
```

```

    },
    "current_usage": 0,
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "health": {
    "state": "normal",
    "unhealthy_reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "nodes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "storage_type": "SSD",
  "uuid": "string"
}

```

## Response

Status: 202, Accepted



| Name | Type     | Description |
|------|----------|-------------|
| job  | job_link |             |

### Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

### Response

Status: 201, Created

### Error

Status: Default

### ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 11206666   | Storage pool is unhealthy.                                    |
| 11208658   | A storage pool already uses the specified name.               |
| 11208660   | Disk does not exist.  |
| 11208661   | Disk is not a spare disk.                                     |
| 11208662   | Disk is not an SSD.   |
| 11208663   | Disk is reserved for core dump.                               |
| 11208664   | Could not determine checksum type of disk.                    |
| 11208666   | Could not determine usable size of disk.                      |
| 11208668   | Could not determine connectivity between controller and disk. |
| 11208670   | Could not determine original owner of disk.                   |

| <b>Error Code</b> | <b>Description</b>   |
|-------------------|--|
| 11208671          | Could not determine SyncMirror pool of disk.   |
| 11208673          | Could not determine HA mode of node.   |
| 11208674          | Could not determine HA partner of node.  |
| 11208675          | Disks specified in the disk list are not visible to node.                                      |
| 11208678          | The disk list contains disks from nodes which are not in HA pair.                              |
| 11208679          | Sharing disk is not enabled on node.   |
| 11208680          | Internal error. Cannot determine configuration for node.                                       |
| 11208681          | Node is not online.  |
| 11208682          | Internal error. Sharing configuration mismatch.  |
| 11208684          | Unable to share disk.  |
| 11208686          | Disk cannot be shared.   |
| 11208687          | Unable to retrieve expected sharing configuration.   |
| 11208688          | Storage pool create job failed.  |
| 11208690          | Not all nodes sharing the storage pool view disk as a shared disk.                             |
| 11208691          | Not enough matching spares available.  |
| 11208692          | A disk list or count is a required parameter for storage pool creation.                        |
| 11208693          | Invalid number of disks specified.   |
| 11208698          | Internal error. Missing node name.   |
| 11208699          | Internal error. Missing partner name for node configured for HA.                               |
| 11208701          | Node is a standalone node. Do not specify other nodes with a standalone node.                  |
| 11208703          | Incorrect number of nodes specified. Specify one node or both nodes in an HA pair.             |
| 11208704          | Specified nodes are not part of HA relationship. Specify one node or both nodes in an HA pair. |
| 11208705          | Disk is a data center SSD, which cannot be used in storage pools.                              |
| 11208706          | Disk is a SSD-ZNS, which cannot be used in storage pools.                                      |
| 11215756          | Missing a required field for POST request.   |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

disk

Reference to the constituent disk object.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

storage\_pool\_disk

| Name        | Type                 | Description                               |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> | Reference to the constituent disk object. |
| total_size  | integer              | Raw capacity of the disk, in bytes.       |
| usable_size | integer              | Usable capacity of this disk, in bytes.   |

node

Specifies what node can use this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pool\_spare\_allocation\_unit

| Name            | Type                 | Description   |
|-----------------|----------------------|---|
| available_size  | integer              | The usable capacity of this set of allocation units.                |
| count           | integer              | The number of spare allocation units on this node.                  |
| node            | <a href="#">node</a> | Specifies what node can use this set of allocation units.           |
| size            | integer              | Size of each allocation unit.                                       |
| syncmirror_pool | string               | The RAID SyncMirror Pool to which this allocation unit is assigned. |

#### aggregate

The aggregate that is using this cache capacity.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### node

The node hosting the aggregate using this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### storage\_pool\_used\_allocation\_unit

| Name      | Type                      | Description  |
|-----------|---------------------------|--|
| aggregate | <a href="#">aggregate</a> | The aggregate that is using this cache capacity.       |
| count     | integer                   | The number of allocation units used by this aggregate. |

| Name          | Type                 | Description  |
|---------------|----------------------|--|
| current_usage | integer              | The amount of cache space used by this aggregate.                  |
| node          | <a href="#">node</a> | The node hosting the aggregate using this set of allocation units. |

#### capacity

| Name                   | Type  | Description  |
|------------------------|---|--|
| disk_count             | integer   | The number of disks in the storage pool.   |
| disks                  | array[ <a href="#">storage_pool_disk</a> ]                  | Properties of each disk used in the shared storage pool.   |
| remaining              | integer   | Remaining usable capacity in the flash pool, in bytes.   |
| spare_allocation_units | array[ <a href="#">storage_pool_spare_allocation_unit</a> ] | Properties of spare allocation units.  |
| total                  | integer   | Total size of the flash pool, in bytes.  |
| used_allocation_units  | array[ <a href="#">storage_pool_used_allocation_unit</a> ]  | Information about the storage pool allocation units participating in the cache tier of an aggregate. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## health

Properties that outline shared storage pool health.

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| is_healthy       | boolean               | Indicates whether the storage pool is able to participate in provisioning operations.                 |
| state            | string                | The state of the shared storage pool.   |
| unhealthy_reason | <a href="#">error</a> | Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools. |

## node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

## storage\_pool

| Name     | Type                                    | Description  |
|----------|---|--|
| _links   | <a href="#">_links</a>                  |  |
| capacity | <a href="#">capacity</a>                |  |
| health   | <a href="#">health</a>                  | Properties that outline shared storage pool health.        |
| name     | string                                  | Storage pool name.   |
| nodes    | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates. |

| Name         | Type   | Description   |
|--------------|--------|---|
| storage_type | string | Storage type for the disks used to create the storage pool. |
| uuid         | string | Storage pool UUID.  |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage specific storage pools

### Storage pools UUID endpoint overview

#### Updating storage pools

The PATCH operation is used to modify properties of the storage pool. There are several properties that can be modified on a storage pool. PATCH operations on a storage pool are restricted when another PATCH operation is in progress. The following is a list of properties that can be modified using the PATCH operation including a brief description for each:

- name - Can be updated to rename the storage pool.
- capacity.disk\_count - Can be updated to increase the number of disks in a storage pool.
- capacity.spare\_allocation\_units[].count - Modifying this value requires that the user specify capacity.spare\_allocation\_units[].node as well. Modifying this value redistributes spare cache capacity among the nodes specified in the operation. When expanding a storage pool, the cache tiers of all aggregates using the storage pool's allocation units are expanded automatically.



## Simulated storage pool expansion

The PATCH operation also supports simulated expansion of a storage pool. Running PATCH with the query "simulate" set to "true", and "capacity.disk\_count" set to the final disk count will return a response containing the projected new capacity and the new constituent disk list for the storage pool.

## Deleting storage pools

If cache capacity from a storage pool is being used in an aggregate, it cannot be deleted. See the /storage/aggregates API for details on deleting aggregates.

## Examples

### Retrieving a specific pool from the cluster

The following example shows the response of the requested storage pool. If there is no storage pool with the requested UUID, an error is returned.

```
# The API:
/api/storage/pools/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools/870dd9f2-bdfa-4167-b692-57d1cec874d4" -H "accept: application/json"

# The response:
{
  "uuid": "8255fef7-4737-11ec-bd1b-005056bbb879",
  "name": "new_sp",
  "storage_type": "ssd",
  "nodes": [
    {
      "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
      "name": "node-1",
    },
    {
      "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
      "name": "node-2",
    }
  ],
  "capacity": {
    "remaining": 1846542336,
    "total": 7386169344,
    "spare_allocation_units": [
      {
        "node": {
          "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
```

```

    "name": "node-1",
  },
  "count": 1,
  "syncmirror_pool": "pool0",
  "size": 1846542336,
  "available_size": 1846542336
},
{
  "node": {
    "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
    "name": "node-2",
  },
  "count": 0,
  "syncmirror_pool": "pool0",
  "size": 1846542336,
  "available_size": 0
}
],
"used_allocation_units": [
{
  "aggregate": {
    "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
    "name": "test_a"
  },
  "allocated_unit_count": 2,
  "node": {
    "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
    "name": "node-1",
  },
  "capacity": 2769813504
},
{
  "aggregate": {
    "uuid": "f4cc30d5-b052-493a-a49f-19781425f987",
    "name": "test_b"
  },
  "allocated_unit_count": 1,
  "node": {
    "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
    "name": "node-2",
  },
  "capacity": 1384906752
}
],
"disk_count": 4,
"disks": [

```

```

{
  "disk": {
    "name": "VMw-1.11"
  },
  "usable_size": 1902379008,
  "total_size": 1908871168,
},
{
  "disk": {
    "name": "VMw-1.12"
  },
  "usable_size": 1902379008,
  "total_size": 1908871168,
},
{
  "disk": {
    "name": "VMw-1.23"
  },
  "usable_size": 1902379008,
  "total_size": 1908871168,
},
{
  "disk": {
    "name": "VMw-1.24"
  },
  "usable_size": 1902379008,
  "total_size": 1908871168,
}
]
},
"health": {
  "state": "normal",
  "is_healthy": true
},
}

```

### Simulating storage pool expansion

The following example shows the response for a simulated storage pool expansion based on the values of the 'capacity.disk\_count' attribute passed in. The query does not modify the existing storage pool, but rather returns how it will look after the expansion. This will be reflected in the following attributes:

- capacity.total- Total space, in bytes.
- capacity.remaining - New remaining capacity, in bytes.
- capacity.disks.disk - New list of constituent disks.
- capacity.disk\_count - New number of disks in the pool.

```

# The API:
/api/storage/pools/{uuid}?simulate=true

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/pools/cae60cfe-deae-42bd-
babb-ef437d118314?simulate=true" -H "accept: application/json" -d
"{\"capacity\": {\"disk_count\": 6}}"

# The response:
{
  "records": [
    {
      "uuid": "cae60cfe-deae-42bd-babb-ef437d118314",
      "name": "new_sp",
      "nodes": [
        {
          "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
          "name": "node-1",
        },
        {
          "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
          "name": "node-2",
        }
      ],
      "storage_type": "ssd",
      "capacity": {
        "remaining": 1846542336,
        "total": 7386169344,
        "used_allocation_units": [
          {
            "aggregate": {
              "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
              "name": "test_a"
            },
            "allocated_unit_count": 2,
            "node": {
              "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
              "name": "node-1",
            },
            "capacity": 2769813504
          },
          {
            "aggregate": {
              "uuid": "f4cc30d5-b052-493a-a49f-19781425f987",
              "name": "test_b"
            }
          }
        ]
      }
    }
  ]
}

```

```

    },
    "allocated_unit_count": 1,
    "node": {
      "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
      "name": "node-2",
    },
    "capacity": 1384906752
  }
],
"disk_count": 6,
"disks": [
  {
    "disk": {
      "name": "VMw-1.11"
    },
  },
  {
    "disk": {
      "name": "VMw-1.12"
    },
  },
  {
    "disk": {
      "name": "VMw-1.23"
    },
  },
  {
    "disk": {
      "name": "VMw-1.24"
    },
  },
  {
    "disk": {
      "name": "VMw-1.13"
    },
  },
  {
    "disk": {
      "name": "VMw-1.14"
    },
  }
]
}
]
}

```

## Adding capacity to a storage pool

The following example shows the workflow of adding disks to the storage pool.

Step 1: Check the current disk count on the storage pool.

```
# The API:
/api/storage/pools

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools/19425837-f2fa-4a9f-8f01-712f626c983c?fields=capacity.disk_count" -H "accept: application/json"

# The response:
{"uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
 "name": "sp1",
 "capacity": {
   "disk_count": 4
 }
}
```

Step 2: Update the pool with the new disk count in 'capacity.disk\_count'. The response to PATCH is a job unless the request is invalid.

```
# The API:
/api/storage/pools

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/pools/19425837-f2fa-4a9f-8f01-712f626c983c" -H "accept: application/hal+json" -d "{\"capacity\": {\"disk_count\": 6}}\"

# The response:
{
  "job": {
    "uuid": "c103d15e-730b-11e8-a57f-005056b465d6",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/c103d15e-730b-11e8-a57f-005056b465d6"
      }
    }
  }
}
```

Step 3: Wait for the job to finish, then call GET to see the reflected change.

```
# The API:
/api/storage/pools

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools/19425837-f2fa-4a9f-8f01-712f626c983c?fields=capacity.disk_count" -H "accept: application/json"

# The response:
{
  "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
  "name": "sp1",
  "capacity": {
    "disk_count": 6
  }
}
```

The following example shows the workflow to redistribute spare capacity among nodes sharing the storage pool Step 1: Check the current spare capacity distribution of the pool.

```

# The API:
/api/storage/pools

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools/f3aafdc6-be35-4d93-9590-5a402bffb4b?fields=capacity.spare_allocation_units" -H "accept: application/json"

# The response:
{
  "uuid": "f3aafdc6-be35-4d93-9590-5a402bffb4b",
  "name": "sp1",
  "capacity": {
    "spare_allocation_units": [
      {
        "node": {
          "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
          "name": "node-1",
        },
        "count": 1,
        "syncmirror_pool": "pool0",
        "size": 1846542336,
        "available_size": 1846542336
      },
      {
        "node": {
          "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
          "name": "node-2",
        },
        "count": 0,
        "syncmirror_pool": "pool0",
        "size": 1846542336,
        "available_size": 0
      }
    ],
  }
}

```

Step 2: Update the pool so that the spare allocation unit count is symmetrically modified for each node. The response to PATCH is a job unless the request is invalid.



```
# The API:
/api/storage/pools

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/pools/f3aafdc6-be35-4d93-9590-5a402bffb4b" -H "accept: application/hal+json" -d '{ "capacity" : { "spare_allocation_units": [{"node": {"name": "node-1"}, "count":0}, {"node": {"name": "node-2"}, "count": 1}]}}'
```

```
# The response:
{
  "job": {
    "uuid": "6b7ab28e-168d-11ea-8a50-0050568eca76",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/6b7ab28e-168d-11ea-8a50-0050568eca76"
      }
    }
  }
}
```

Step 3: Wait for the job to finish, then call GET to see the reflected change.

```

# The API:
/api/storage/pools

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools/f3aafdc6-be35-4d93-9590-5a402bffb4b?fields=capacity.spare_allocation_units" -H "accept: application/json"

# The response:
{
  "uuid": "f3aafdc6-be35-4d93-9590-5a402bffb4b",
  "name": "sp1",
  "capacity": {
    "spare_allocation_units": [
      {
        "node": {
          "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
          "name": "node-1",
        },
        "count": 0,
        "syncmirror_pool": "pool0",
        "size": 1846542336,
        "available_size": 0
      },
      {
        "node": {
          "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
          "name": "node-2",
        },
        "count": 1,
        "syncmirror_pool": "pool0",
        "size": 1846542336,
        "available_size": 1846542336
      }
    ],
  }
}

```

## Delete a storage pool specified by the UUID

DELETE /storage/pools/{uuid}

**Introduced In:** 9.11

Deletes the storage pool specified by the UUID. This request starts a job and returns a link to that job.

## Related ONTAP commands

- `storage pool delete`

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| uuid           | string  | path  | True     | Storage Pool UUID.   |
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 11209668   | Capacity from pool is being used by one or more aggregates.      |
| 11209670   | Unable to stop sharing a constituent disk of the storage pool.   |
| 11209671   | Cannot find a node sharing this storage pool.                    |
| 11209672   | Disk is not shared.  |
| 11209673   | Unable to assign shared capacity from a constituent disk.        |
| 11209675   | A constituent disk of the storage pool has non-spare capacity.   |
| 11209676   | A constituent disk of the storage pool is reserved for coredump. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a storage pool specified by the UUID

GET /storage/pools/{uuid}

## Introduced In: 9.11

Retrieves the storage pool specified by the UUID.

### Related ONTAP commands

- `storage pool show -storage-pool-uuid`

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| uuid   | string        | path  | True     | Storage pool UUID.            |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name                         | Type                                    | Description   |
|------------------------------|---|---|
| <a href="#">_links</a>       | <a href="#">_links</a>                  |   |
| <a href="#">capacity</a>     | <a href="#">capacity</a>                |   |
| <a href="#">health</a>       | <a href="#">health</a>                  | Properties that outline shared storage pool health.         |
| <a href="#">name</a>         | string                                  | Storage pool name.  |
| <a href="#">nodes</a>        | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates.  |
| <a href="#">storage_type</a> | string                                  | Storage type for the disks used to create the storage pool. |
| <a href="#">uuid</a>         | string                                  | Storage pool UUID.  |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "capacity": {
    "disks": {
      "disk": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "1.0.1"
      },
      "total_size": 0,
      "usable_size": 0
    },
    "remaining": 0,
    "spare_allocation_units": {
      "available_size": 0,
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "size": 0,
      "syncmirror_pool": "pool0"
    },
    "total": 0,
    "used_allocation_units": {
      "aggregate": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "aggr1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    }
  }
}
```



```

    },
    "current_usage": 0,
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "health": {
    "state": "normal",
    "unhealthy_reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "nodes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "storage_type": "SSD",
  "uuid": "string"
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 11206662   | There is no storage pool matching the specified UUID or name. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

disk

Reference to the constituent disk object.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

storage\_pool\_disk

| Name        | Type                 | Description                               |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> | Reference to the constituent disk object. |
| total_size  | integer              | Raw capacity of the disk, in bytes.       |
| usable_size | integer              | Usable capacity of this disk, in bytes.   |

node

Specifies what node can use this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pool\_spare\_allocation\_unit

| Name            | Type                 | Description   |
|-----------------|----------------------|---|
| available_size  | integer              | The usable capacity of this set of allocation units.                |
| count           | integer              | The number of spare allocation units on this node.                  |
| node            | <a href="#">node</a> | Specifies what node can use this set of allocation units.           |
| size            | integer              | Size of each allocation unit.                                       |
| syncmirror_pool | string               | The RAID SyncMirror Pool to which this allocation unit is assigned. |

#### aggregate

The aggregate that is using this cache capacity.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### node

The node hosting the aggregate using this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### storage\_pool\_used\_allocation\_unit

| Name      | Type                      | Description  |
|-----------|---------------------------|--|
| aggregate | <a href="#">aggregate</a> | The aggregate that is using this cache capacity.       |
| count     | integer                   | The number of allocation units used by this aggregate. |

| Name          | Type                 | Description  |
|---------------|----------------------|--|
| current_usage | integer              | The amount of cache space used by this aggregate.                  |
| node          | <a href="#">node</a> | The node hosting the aggregate using this set of allocation units. |

#### capacity

| Name                   | Type  | Description  |
|------------------------|---|--|
| disk_count             | integer   | The number of disks in the storage pool.   |
| disks                  | array[ <a href="#">storage_pool_disk</a> ]                  | Properties of each disk used in the shared storage pool.   |
| remaining              | integer   | Remaining usable capacity in the flash pool, in bytes.   |
| spare_allocation_units | array[ <a href="#">storage_pool_spare_allocation_unit</a> ] | Properties of spare allocation units.  |
| total                  | integer   | Total size of the flash pool, in bytes.  |
| used_allocation_units  | array[ <a href="#">storage_pool_used_allocation_unit</a> ]  | Information about the storage pool allocation units participating in the cache tier of an aggregate. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## health

Properties that outline shared storage pool health.

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| is_healthy       | boolean               | Indicates whether the storage pool is able to participate in provisioning operations.                 |
| state            | string                | The state of the shared storage pool.   |
| unhealthy_reason | <a href="#">error</a> | Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools. |

## node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

## error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a storage pool specified by the UUID

PATCH /storage/pools/{uuid}

**Introduced In:** 9.11

Updates the storage pool specified by the UUID with the properties in the body. This request starts a job and returns a link to that job.

### Related ONTAP commands

- storage pool rename
- storage pool reassign
- storage pool add

### Parameters

| Name | Type   | In   | Required | Description        |
|------|--------|------|----------|--------------------|
| uuid | string | path | True     | Storage pool UUID. |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name     | Type                                    | Description  |
|----------|---|--|
| _links   | <a href="#">_links</a>                  |  |
| capacity | <a href="#">capacity</a>                |  |
| health   | <a href="#">health</a>                  | Properties that outline shared storage pool health.        |
| name     | string                                  | Storage pool name.   |
| nodes    | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates. |



| Name         | Type   | Description   |
|--------------|--------|---|
| storage_type | string | Storage type for the disks used to create the storage pool. |
| uuid         | string | Storage pool UUID.  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "capacity": {
    "disks": {
      "disk": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "1.0.1"
      },
      "total_size": 0,
      "usable_size": 0
    },
    "remaining": 0,
    "spare_allocation_units": {
      "available_size": 0,
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "size": 0,
      "syncmirror_pool": "pool0"
    },
    "total": 0,
    "used_allocation_units": {
      "aggregate": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "aggr1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    }
  }
}
```

```
    },
    "current_usage": 0,
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "health": {
    "state": "normal",
    "unhealthy_reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "nodes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "storage_type": "SSD",
  "uuid": "string"
}
```

## Response

Status: 200, Ok

| Name        | Type                                  | Description                                    |
|-------------|---------------------------------------|--|
| job         | <a href="#">job_link</a>              |  |
| num_records | integer                               | Number of shared storage pools in the cluster. |
| records     | array[ <a href="#">storage_pool</a> ] |  |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "capacity": {
      "disks": {
        "disk": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "1.0.1"
        },
        "total_size": 0,
        "usable_size": 0
      },
      "remaining": 0,
      "spare_allocation_units": {
        "available_size": 0,
        "node": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "size": 0,
        "syncmirror_pool": "pool0"
      },
      "total": 0,

```

```

"used_allocation_units": {
  "aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "current_usage": 0,
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"health": {
  "state": "normal",
  "unhealthy_reason": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
},
"nodes": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"storage_type": "SSD",
"uuid": "string"
}

```

```
}
```

## Response

Status: 202, Accepted

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 11211658   | Node does not have enough spare capacity.  |
| 11211659   | Valid allocation unit input is required.   |
| 11211662   | Specified node is not part of the storage pool.  |
| 11211663   | Failed to reassign available capacity in the storage pool.   |
| 11211664   | Could not fix the broken allocation unit for the storage pool.   |
| 11212673   | Could not grow one or more aggregates.   |
| 11212679   | Adding specified number of disks will expand storage pool beyond maximum supported disk limit.   |
| 11212680   | Incorrect node specified.  |
| 11212681   | 0 is an invalid value for disk_count.  |
| 11212682   | Adding the specified number of disks will result in the storage pool reaching the maximum disk limit reserved for RAID-TEC use only. At this limit, the storage pool can only allocate capacity to aggregates containing RAID-TEC RAID groups. Existing aggregates containing RAID groups other than RAID-TEC will not automatically grow to the new capacity. |
| 11212683   | Renaming storage pool to new name failed.  |
| 11212763   | Storage pool add job failed.   |
| 11215657   | Storage pool PATCH request have missing parameters.  |
| 11215658   | Storage pool PATCH request for reassign is invalid.  |
| 11215659   | Storage pool PATCH request for reassign have invalid allocation unit count.  |

| Error Code | Description   |
|------------|---|
| 11215660   | Storage pool PATCH request for reassign have invalid node name. |
| 11215662   | Storage pool PATCH request have invalid disk count.             |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

disk

Reference to the constituent disk object.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |

storage\_pool\_disk

| Name        | Type                 | Description                               |
|-------------|----------------------|---|
| disk        | <a href="#">disk</a> | Reference to the constituent disk object. |
| total_size  | integer              | Raw capacity of the disk, in bytes.       |
| usable_size | integer              | Usable capacity of this disk, in bytes.   |

node

Specifies what node can use this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_pool\_spare\_allocation\_unit

| Name            | Type                 | Description   |
|-----------------|----------------------|---|
| available_size  | integer              | The usable capacity of this set of allocation units.                |
| count           | integer              | The number of spare allocation units on this node.                  |
| node            | <a href="#">node</a> | Specifies what node can use this set of allocation units.           |
| size            | integer              | Size of each allocation unit.                                       |
| syncmirror_pool | string               | The RAID SyncMirror Pool to which this allocation unit is assigned. |

#### aggregate

The aggregate that is using this cache capacity.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### node

The node hosting the aggregate using this set of allocation units.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

#### storage\_pool\_used\_allocation\_unit

| Name      | Type                      | Description  |
|-----------|---------------------------|--|
| aggregate | <a href="#">aggregate</a> | The aggregate that is using this cache capacity.       |
| count     | integer                   | The number of allocation units used by this aggregate. |

| Name          | Type                 | Description  |
|---------------|----------------------|--|
| current_usage | integer              | The amount of cache space used by this aggregate.                  |
| node          | <a href="#">node</a> | The node hosting the aggregate using this set of allocation units. |

#### capacity

| Name                   | Type  | Description  |
|------------------------|---|--|
| disk_count             | integer   | The number of disks in the storage pool.   |
| disks                  | array[ <a href="#">storage_pool_disk</a> ]                  | Properties of each disk used in the shared storage pool.   |
| remaining              | integer   | Remaining usable capacity in the flash pool, in bytes.   |
| spare_allocation_units | array[ <a href="#">storage_pool_spare_allocation_unit</a> ] | Properties of spare allocation units.  |
| total                  | integer   | Total size of the flash pool, in bytes.  |
| used_allocation_units  | array[ <a href="#">storage_pool_used_allocation_unit</a> ]  | Information about the storage pool allocation units participating in the cache tier of an aggregate. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## health

Properties that outline shared storage pool health.

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| is_healthy       | boolean               | Indicates whether the storage pool is able to participate in provisioning operations.                 |
| state            | string                | The state of the shared storage pool.   |
| unhealthy_reason | <a href="#">error</a> | Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools. |

## node\_reference

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

## storage\_pool

| Name     | Type                                    | Description  |
|----------|---|--|
| _links   | <a href="#">_links</a>                  |  |
| capacity | <a href="#">capacity</a>                |  |
| health   | <a href="#">health</a>                  | Properties that outline shared storage pool health.        |
| name     | string                                  | Storage pool name.   |
| nodes    | array[ <a href="#">node_reference</a> ] | Nodes that can use this storage pool for their aggregates. |

| Name         | Type   | Description   |
|--------------|--------|---|
| storage_type | string | Storage type for the disks used to create the storage pool. |
| uuid         | string | Storage pool UUID.  |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage ports

### Storage ports endpoint overview


#### Retrieving storage port information

The storage port GET API retrieves all of the storage ports in the cluster.

#### Examples

##### 1) Retrieve a list of storage ports from the cluster

The following example shows the response with a list of storage ports in the cluster:



```

# The API:
/api/storage/ports

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/ports" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
        }
      }
    },
    "name": "0a",
    "_links": {
      "self": {
        "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0a"
      }
    }
  },
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
        }
      }
    },
    "name": "0b",
    "_links": {
      "self": {
        "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0b"
      }
    }
  }
]
}

```

```

    }
  },
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
        }
      }
    },
    "name": "0c",
    "_links": {
      "self": {
        "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0c"
      }
    }
  },
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
        }
      }
    },
    "name": "0d",
    "_links": {
      "self": {
        "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0d"
      }
    }
  },
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {

```

```

    "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
  }
}
},
"name": "0e",
"_links": {
  "self": {
    "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0e"
  }
}
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
      }
    }
  },
  "name": "0f",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0f"
    }
  }
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
      }
    }
  },
  "name": "0g",
  "_links": {
    "self": {

```



```
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0g"
    }
  },
],
"num_records": 7,
"_links": {
  "self": {
    "href": "/api/storage/ports"
  }
}
}
```

---

## 2) Retrieve a specific storage port from the cluster

The following example shows the response of the requested storage port. If there is no storage port with the requested node uuid and name, an error is returned.

---

```
# The API:
/api/storage/ports/{node.uuid}/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0a" -H "accept: application/hal+json"

# The response:
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0a",
  "description": "SAS Host Adapter 0a (PMC-Sierra PM8001 rev. C)",
  "wwn": "500a098003633df0",
  "speed": 6,
  "cable": {
    "part_number": "112-00429+A0",
    "serial_number": "629230774",
    "identifier": "500a0980066e2c01-500a098003633df0",
    "length": "0.5m"
  },
  "state": "online",
  "enabled": true,
  "firmware_version": "01.12.09.00",
  "type": "sas",
  "redundant": true,
  "in_use": true,
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0a"
    }
  }
}
```

## Updating a storage port

The storage port PATCH API modifies the port mode for storage/network use and allows the port to be enabled/disabled.

### Examples

#### 1) Using an Ethernet port for storage

The following example sets an Ethernet port mode for storage use:

```
# The API:
/api/storage/ports/{node.uuid}/{name}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/ports/0530d6c1-8c6d-11e8-
907f-00a0985a72ee/e3a" -H "accept: application/hal+json" -H "Content-Type:
application/hal_json" -d '{"mode": "storage"}'

# The response:
{
}
```

#### 2) Disabling a storage port

The following example disables an unused storage port:

```
# The API:
/api/storage/ports/{node.uuid}/{name}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/ports/0530d6c1-8c6d-11e8-
907f-00a0985a72ee/e3a" -H "accept: application/hal+json" -H "Content-Type:
application/hal_json" -d '{"enabled": "false"}'

# The response:
{
}
```

## Retrieve storage ports

GET /storage/ports

**Introduced In:** 9.6

Retrieves a collection of storage ports.

### Related ONTAP commands

- `storage port show`

### Learn more

- [DOC /storage/ports](#)

### Parameters

| Name          | Type    | In    | Required | Description  |
|---------------|---------|-------|----------|--|
| mode          | string  | query | False    | Filter by mode <ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul>    |
| name          | string  | query | False    | Filter by name   |
| enabled       | boolean | query | False    | Filter by enabled <ul style="list-style-type: none"><li>• Introduced in: 9.9</li></ul> |
| speed         | number  | query | False    | Filter by speed  |
| board_name    | string  | query | False    | Filter by board_name   |
| state         | string  | query | False    | Filter by state  |
| serial_number | string  | query | False    | Filter by serial_number  |
| part_number   | string  | query | False    | Filter by part_number  |
| error.message | string  | query | False    | Filter by error.message  |

| Name                    | Type    | In    | Required | Description   |
|-------------------------|---------|-------|----------|---|
| error.corrective_action | string  | query | False    | Filter by error.corrective_action   |
| mac_address             | string  | query | False    | Filter by mac_address   |
| type                    | string  | query | False    | Filter by type <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>             |
| cable.length            | string  | query | False    | Filter by cable.length  |
| cable.identifier        | string  | query | False    | Filter by cable.identifier  |
| cable.part_number       | string  | query | False    | Filter by cable.part_number   |
| cable.serial_number     | string  | query | False    | Filter by cable.serial_number   |
| in_use                  | boolean | query | False    | Filter by in_use <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>           |
| redundant               | boolean | query | False    | Filter by redundant <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>        |
| node.uuid               | string  | query | False    | Filter by node.uuid   |
| node.name               | string  | query | False    | Filter by node.name   |
| wwpn                    | string  | query | False    | Filter by wwpn <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>             |
| firmware_version        | string  | query | False    | Filter by firmware_version <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul> |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| wwn            | string        | query | False    | Filter by wwn   |
| description    | string        | query | False    | Filter by description   |
| fields         | array[string] | query | False    | Specify the fields to return.   |
| max_records    | integer       | query | False    | Limit the number of records returned.   |
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                                  | Description       |
|-------------|---------------------------------------|-------------------|
| _links      | <a href="#">_links</a>                |                   |
| num_records | integer                               | Number of records |
| records     | array[ <a href="#">storage_port</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "board_name": "string",
    "cable": {
      "identifier": "500a098000b6c3f-50000d1703544b80",
      "length": "2m",
      "part_number": "112-00431+A0",
      "serial_number": "616930439"
    },
    "description": "SAS Host Adapter 2a (PMC-Sierra PM8072 rev. C)",
    "firmware_version": "03.08.09.00",
    "mac_address": "string",
    "mode": "storage",
    "name": "2a",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "part_number": "111-03801",
    "serial_number": "7A2463CC45B",
    "speed": "6",
    "state": "online",
    "type": "sas",
    "wwn": "50000d1703544b80",
    "wwpn": "string"
  }
}
```



## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

cable

| Name          | Type   | Description |
|---------------|--------|-------------|
| identifier    | string |             |
| length        | string |             |
| part_number   | string |             |
| serial_number | string |             |

error

| Name              | Type   | Description             |
|-------------------|--------|-------------------------|
| corrective_action | string | Error corrective action |
| message           | string | Error message           |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_port

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| board_name       | string                |   |
| cable            | <a href="#">cable</a> |   |
| description      | string                |   |
| enabled          | boolean               |   |
| error            | <a href="#">error</a> |   |
| firmware_version | string                |   |
| force            | boolean               |   |
| in_use           | boolean               | Specifies whether any devices are connected through this port                                     |
| mac_address      | string                |   |
| mode             | string                | Operational mode of a non-dedicated Ethernet port   |
| name             | string                |   |
| node             | <a href="#">node</a>  |   |
| part_number      | string                |   |
| redundant        | boolean               | Specifies whether all devices connected through this port have a redundant path from another port |
| serial_number    | string                |   |
| speed            | number                | Operational port speed in Gbps  |
| state            | string                |   |
| type             | string                |   |
| wwn              | string                | World Wide Name   |
| wwpn             | string                | World Wide Port Name  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a storage port

GET /storage/ports/{node.uuid}/{name}

**Introduced In:** 9.6

Retrieves a specific storage port.

### Related ONTAP commands

- `storage port show`

### Learn more

- [DOC /storage/ports](#)

### Parameters

| Name      | Type          | In    | Required | Description                   |
|-----------|---------------|-------|----------|-------------------------------|
| node.uuid | string        | path  | True     | Node UUID                     |
| name      | string        | path  | True     | Port name                     |
| fields    | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name       | Type                  | Description |
|------------|-----------------------|-------------|
| board_name | string                |             |
| cable      | <a href="#">cable</a> |             |

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| description      | string                |   |
| enabled          | boolean               |   |
| error            | <a href="#">error</a> |   |
| firmware_version | string                |   |
| force            | boolean               |   |
| in_use           | boolean               | Specifies whether any devices are connected through this port                                     |
| mac_address      | string                |   |
| mode             | string                | Operational mode of a non-dedicated Ethernet port   |
| name             | string                |   |
| node             | <a href="#">node</a>  |   |
| part_number      | string                |   |
| redundant        | boolean               | Specifies whether all devices connected through this port have a redundant path from another port |
| serial_number    | string                |   |
| speed            | number                | Operational port speed in Gbps  |
| state            | string                |   |
| type             | string                |   |
| wwn              | string                | World Wide Name   |
| wwpn             | string                | World Wide Port Name  |

## Example response

```
{
  "board_name": "string",
  "cable": {
    "identifier": "500a0980000b6c3f-50000d1703544b80",
    "length": "2m",
    "part_number": "112-00431+A0",
    "serial_number": "616930439"
  },
  "description": "SAS Host Adapter 2a (PMC-Sierra PM8072 rev. C)",
  "firmware_version": "03.08.09.00",
  "mac_address": "string",
  "mode": "storage",
  "name": "2a",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "part_number": "111-03801",
  "serial_number": "7A2463CC45B",
  "speed": "6",
  "state": "online",
  "type": "sas",
  "wwn": "50000d1703544b80",
  "wwpn": "string"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

cable

| Name          | Type   | Description |
|---------------|--------|-------------|
| identifier    | string |             |
| length        | string |             |
| part_number   | string |             |
| serial_number | string |             |

error

| Name              | Type   | Description             |
|-------------------|--------|-------------------------|
| corrective_action | string | Error corrective action |
| message           | string | Error message           |

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error



| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a storage port

PATCH /storage/ports/{node.uuid}/{name}

**Introduced In:** 9.11

Updates a storage port.

### Related ONTAP commands

- `storage port modify`
- `storage port enable`
- `storage port disable`

### Learn more

- [DOC /storage/ports](#)

### Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node UUID   |
| name      | string | path | True     | Port name   |

### Request Body

| Name        | Type                  | Description |
|-------------|-----------------------|-------------|
| board_name  | string                |             |
| cable       | <a href="#">cable</a> |             |
| description | string                |             |
| enabled     | boolean               |             |
| error       | <a href="#">error</a> |             |

| Name             | Type                 | Description   |
|------------------|----------------------|---|
| firmware_version | string               |   |
| force            | boolean              |   |
| in_use           | boolean              | Specifies whether any devices are connected through this port                                     |
| mac_address      | string               |   |
| mode             | string               | Operational mode of a non-dedicated Ethernet port   |
| name             | string               |   |
| node             | <a href="#">node</a> |   |
| part_number      | string               |   |
| redundant        | boolean              | Specifies whether all devices connected through this port have a redundant path from another port |
| serial_number    | string               |   |
| speed            | number               | Operational port speed in Gbps  |
| state            | string               |   |
| type             | string               |   |
| wwn              | string               | World Wide Name   |
| wwpn             | string               | World Wide Port Name  |

## Example request

```
{
  "board_name": "string",
  "cable": {
    "identifier": "500a0980000b6c3f-50000d1703544b80",
    "length": "2m",
    "part_number": "112-00431+A0",
    "serial_number": "616930439"
  },
  "description": "SAS Host Adapter 2a (PMC-Sierra PM8072 rev. C)",
  "firmware_version": "03.08.09.00",
  "mac_address": "string",
  "mode": "storage",
  "name": "2a",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "part_number": "111-03801",
  "serial_number": "7A2463CC45B",
  "speed": "6",
  "state": "online",
  "type": "sas",
  "wwn": "50000d1703544b80",
  "wwpn": "string"
}
```

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 17891328   | Port operation "<operation>\\" failed on port \\"<name>\". This might indicate a hardware error, an illegal request, or an aborted command.</name></operation>  |
| 17891329   | Port "<name>\\" is invalid.</name>  |
| 17891330   | Port operation "<operation>\\" failed on port \\"<port>\\" because it is not supported on this port type.</port></operation>  |
| 17891331   | Cannot complete operation on port "<port>\\". The status of the port is not available.</port>   |
| 17891332   | Port operation "<operation>\\" failed on port \\"<port>\\". The port is not offline.</port></operation>   |
| 17891333   | Port operation "<operation>\\" failed on port \\"<port>\\". The port is already offline.</port></operation>   |
| 17891334   | Port operation "<operation>\\" failed on port \\"<port>\\". One or more devices on the port is currently being sanitized.</port></operation>  |
| 17891338   | Device operation "<operation>\\" failed on port \\"<name>\\". Some devices can only be accessed through this port. Disabling this port might cause multiple device failures.</name></operation>   |
| 17891339   | Device operation "<operation>\\" failed on port \\"<name>\\". Some devices can only be accessed through this port. Disabling this port might cause multiple device failures. Use the \\"-force\" parameter to ignore checks and <operation>the port.</operation></name></operation> |
| 17891344   | Device operation "<operation>\\" failed on port \\"<name>\\" because the port is in use.</name></operation>   |
| 17891345   | Device operation "<operation>\\" failed on port \\"<name>\\" because the port is in use. Use the \\"-force\" parameter to ignore checks and <operation>the port.</operation></name></operation>   |
| 17891346   | Port "<name>\\" is already enabled.</name>  |
| 17891347   | Port "<name>\\" is already disabled.</name>   |
| 17891350   | Port "<name>\\" is not a valid storage Ethernet port.</name>  |
| 17891350   | Port "<port>\\" is not a valid storage Ethernet port.</port>  |

| Error Code | Description   |
|------------|---|
| 17891352   | Port operation "<operation>" failed on port \"<name>\". Reboot node \"<node>\" to recover.</node></name></operation>      |
| 17891353   | Unable to enable port "<port>" because it is in network mode.</port>  |
| 17891354   | Unable to disable port "<port>" because it is in network mode.</port>   |
| 17891355   | Port operation "<operation>" failed on port \"<name>\" because it is not supported on dedicated ports.</name></operation> |
| 17891356   | Unable to <operation>port \"<port>\" when setting mode to \"<mode>\".</mode></port></operation>                           |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

### Definitions

## See Definitions

cable

| Name          | Type   | Description |
|---------------|--------|-------------|
| identifier    | string |             |
| length        | string |             |
| part_number   | string |             |
| serial_number | string |             |

error

| Name              | Type   | Description             |
|-------------------|--------|-------------------------|
| corrective_action | string | Error corrective action |
| message           | string | Error message           |

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

storage\_port

| Name        | Type                  | Description |
|-------------|-----------------------|-------------|
| board_name  | string                |             |
| cable       | <a href="#">cable</a> |             |
| description | string                |             |
| enabled     | boolean               |             |

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| error            | <a href="#">error</a> |   |
| firmware_version | string                |   |
| force            | boolean               |   |
| in_use           | boolean               | Specifies whether any devices are connected through this port                                     |
| mac_address      | string                |   |
| mode             | string                | Operational mode of a non-dedicated Ethernet port   |
| name             | string                |   |
| node             | <a href="#">node</a>  |   |
| part_number      | string                |   |
| redundant        | boolean               | Specifies whether all devices connected through this port have a redundant path from another port |
| serial_number    | string                |   |
| speed            | number                | Operational port speed in Gbps  |
| state            | string                |   |
| type             | string                |   |
| wwn              | string                | World Wide Name   |
| wwpn             | string                | World Wide Port Name  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |

| Name    | Type   | Description                                 |
|---------|--------|---|
| code    | string | Error code                                  |
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Manage QoS policies

### Storage Qos policies endpoint overview

#### Quality of Service Configuration

A QoS policy defines measurable service level objectives (SLOs) that apply to the storage objects with which the policy is associated. There are two types of policies that can be configured: fixed, which defines a fixed SLO, or adaptive which defines a variable SLO for a storage object. Adaptive policies vary the SLO depending on the space usage of the storage object. A policy can be either a fixed policy or an adaptive one, not both. Service level objectives include minimum and maximum limits on throughput in terms of IOPS. Only maximum limits can be set in terms of both IOPS and/or throughput (MB/s). A QoS policy can be used to enforce SLOs for multiple storage objects by specifying "capacity\_shared" to true. For example, if a QoS policy with "capacity\_shared" is set to true and it has maximum\_throughput\_iops set to 1000, and this policy is assigned to four volumes, then the combined throughput of all four volumes is limited to 1000 IOPS. If "capacity\_shared" is set to false then, each storage object will have it's SLOs enforced individually. For example, in the previous case if the same policy was applied to four volumes but with "capacity\_shared" set to false, then each of the volumes would be limited to 1000 IOPS individually. Once "capacity\_shared" is set, it cannot be modified. Adaptive parameters can specify the variable SLOs in terms of IOPS/TB. The actual IOPS enforced on the storage object can be calculated using the allocated space on the storage object. The policies are enforced individually amongst storage objects.

#### Examples

##### 1) Create a fixed QoS policy

The following example shows how to create a fixed QoS policy to limit throughput for a storage object between 5000 IOPS and 10000 IOPS which has capacity\_shared set to false. This QoS policy can be used as a template to apply on multiple storage objects to provide individual SLOs to each object.

```
curl -X POST
"https://172.21.69.245/api/storage/qos/policies?return_timeout=0" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
\"fixed\": { \"capacity_shared\": false, \"max_throughput_iops\": 10000,
\"min_throughput_iops\": 5000 }, \"name\":
\"qos_policy_5000_to_10000_iops\", \"svm\": { \"name\": \"vs0\" }}"
```



## 2) Create an adaptive QoS policy

The following example shows how to create an adaptive QoS policy which provides 5000 IOPS per GB of allocated space for a storage object with a peak of 6000 IOPS. Minimum IOPS regardless of allocated space are 1000 IOPS.

```
curl -X POST
"https://172.21.69.245/api/storage/qos/policies?return_timeout=0" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
\"adaptive\": { \"absolute_min_iops\": 1000, \"expected_iops\": 5000,
\"expected_iops_allocation\": \"used_space\", \"peak_iops\": 6000,
\"peak_iops_allocation\": \"allocated_space\" }, \"name\":
\"adaptive_pg_5k_to_6k\", \"svm\": { \"name\": \"vs0\" }}"
```

-

## 3) Update an existing QoS policy

The following example shows how to update SLOs of an existing QoS policy and also rename it.

```
curl -X PATCH "https://172.21.69.245/api/storage/qos/policies/d38bafc0-
5a51-11e9-bd5b-005056ac6f1f?return_timeout=0" -H "accept:
application/json" -H "Content-Type: application/json" -d "{ \"fixed\": {
\"max_throughput_iops\": 15000, \"min_throughput_iops\": 10000 },
\"name\": \"qos_policy_10k_to_15k_iops\"}"
```

## 4) Delete an existing QoS policy

When a QoS policy is deleted any associations of the policy with a storage objects are also removed.

```
curl -X DELETE "https://172.21.69.245/api/storage/qos/policies/d38bafc0-
5a51-11e9-bd5b-005056ac6f1f?return_timeout=0" -H "accept:
application/json"
```

## Retrieve QoS policies

GET /storage/qos/policies

**Introduced In:** 9.6

Retrieves a collection of QoS policies.

### Parameters

| Name                              | Type    | In    | Required | Description   |
|-----------------------------------|---------|-------|----------|---|
| policy_class                      | string  | query | False    | Filter by policy_class <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>                      |
| svm.uuid                          | string  | query | False    | Filter by svm.uuid  |
| svm.name                          | string  | query | False    | Filter by svm.name  |
| scope                             | string  | query | False    | Filter by scope <ul style="list-style-type: none"><li>• Introduced in: 9.11</li></ul>                             |
| object_count                      | integer | query | False    | Filter by object_count  |
| name                              | string  | query | False    | Filter by name  |
| uuid                              | string  | query | False    | Filter by uuid  |
| adaptive.expected_iops_allocation | string  | query | False    | Filter by adaptive.expected_iops_allocation <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul> |
| adaptive.block_size               | string  | query | False    | Filter by adaptive.block_size <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>               |

| Name                          | Type          | In    | Required | Description  |
|-------------------------------|---------------|-------|----------|--|
| adaptive.peak_iops_allocation | string        | query | False    | Filter by adaptive.peak_iops_allocation<br><br>• Introduced in: 9.10 |
| adaptive.absolute_min_iops    | integer       | query | False    | Filter by adaptive.absolute_min_iops                                 |
| adaptive.expected_iops        | integer       | query | False    | Filter by adaptive.expected_iops                                     |
| adaptive.peak_iops            | integer       | query | False    | Filter by adaptive.peak_iops   |
| pgid                          | integer       | query | False    | Filter by pgid<br><br>• Introduced in: 9.10                          |
| fixed.max_throughput_iops     | integer       | query | False    | Filter by fixed.max_throughput_iops                                  |
| fixed.capacity_shared         | boolean       | query | False    | Filter by fixed.capacity_shared                                      |
| fixed.min_throughput_iops     | integer       | query | False    | Filter by fixed.min_throughput_iops                                  |
| fixed.max_throughput_mbps     | integer       | query | False    | Filter by fixed.max_throughput_mbps                                  |
| fixed.min_throughput_mbps     | integer       | query | False    | Filter by fixed.min_throughput_mbps<br><br>• Introduced in: 9.8      |
| fields                        | array[string] | query | False    | Specify the fields to return.  |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| max_records    | integer       | query | False    | Limit the number of records returned.   |
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                              | Description       |
|-------------|-----------------------------------|-------------------|
| _links      | <a href="#">_links</a>            |                   |
| error       | <a href="#">error</a>             |                   |
| num_records | integer                           | Number of records |
| records     | <a href="#">array[qos_policy]</a> |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "adaptive": {
    "block_size": "any",
    "expected_iops_allocation": "used_space",
    "peak_iops_allocation": "used_space"
  },
  "name": "extreme",
  "object_count": 0,
  "pgid": 0,
  "policy_class": "undefined",
  "scope": "cluster",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

```
}  
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{  
  "error": {  
    "arguments": {  
      "code": "string",  
      "message": "string"  
    },  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

adaptive

Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space.

| Name                     | Type    | Description   |
|--------------------------|---------|---|
| absolute_min_iops        | integer | Specifies the absolute minimum IOPS that is used as an override when the expected_iops is less than this value. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| block_size               | string  | Specifies the block size  |
| expected_iops            | integer | Expected IOPS. Specifies the minimum expected IOPS per TB allocated based on the storage object allocated size. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| expected_iops_allocation | string  | Specifies the size to be used to calculate expected IOPS per TB. The size options are either the storage object allocated space or the storage object used space.   |
| peak_iops                | integer | Peak IOPS. Specifies the maximum possible IOPS per TB allocated based on the storage object allocated size or the storage object used size.   |
| peak_iops_allocation     | string  | Specifies the size to be used to calculate peak IOPS per TB. The size options are either the storage object allocated space or the storage object used space.   |

fixed

QoS policy-groups define a fixed service level objective (SLO) for a storage object.

| Name            | Type    | Description  |
|-----------------|---------|--|
| capacity_shared | boolean | Specifies whether the capacities are shared across all objects that use this QoS policy-group. Default is false. |



| Name                | Type    | Description   |
|---------------------|---------|---|
| max_throughput_iops | integer | Maximum throughput defined by this policy. It is specified in terms of IOPS. 0 means no maximum throughput is enforced.   |
| max_throughput_mbps | integer | Maximum throughput defined by this policy. It is specified in terms of Mbps. 0 means no maximum throughput is enforced.   |
| min_throughput_iops | integer | Minimum throughput defined by this policy. It is specified in terms of IOPS. 0 means no minimum throughput is enforced. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| min_throughput_mbps | integer | Minimum throughput defined by this policy. It is specified in terms of Mbps. 0 means no minimum throughput is enforced.   |

#### svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

#### qos\_policy

| Name     | Type                     | Description   |
|----------|--------------------------|---|
| _links   | <a href="#">_links</a>   |   |
| adaptive | <a href="#">adaptive</a> | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| fixed    | <a href="#">fixed</a>    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |

| Name         | Type    | Description   |
|--------------|---------|---|
| name         | string  | Name of the QoS policy.   |
| object_count | integer | Number of objects attached to this policy.  |
| pgid         | integer | Policy group ID of the QoS policy.  |
| policy_class | string  | Class of the QoS policy.  |
| scope        | string  | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects. |
| svm          | svm     |   |
| uuid         | string  |   |

## Create a QoS policy

POST /storage/qos/policies

**Introduced In:** 9.6

Creates a QoS policy.

### Required properties

- `svm.uuid` or `svm.name` - The existing SVM owning the QoS policy.
- `name` - The name of the QoS policy.
- `fixed.*` or `adaptive.*` - Either of the fixed or adaptive parameters.

### Default property values

- If `fixed.*` parameters are specified, then `capacity.shared` is set to `false` by default.

### Related ONTAP commands

- `qos policy-group create`
- `qos adaptive-policy-group create`

### Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul>  |
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |

| Name         | Type     | Description   |
|--------------|----------|---|
| adaptive     | adaptive | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| fixed        | fixed    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |
| name         | string   | Name of the QoS policy.   |
| object_count | integer  | Number of objects attached to this policy.  |
| pgid         | integer  | Policy group ID of the QoS policy.  |
| policy_class | string   | Class of the QoS policy.  |
| scope        | string   | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects.   |
| svm          | svm      |   |
| uuid         | string   |   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "adaptive": {
    "block_size": "any",
    "expected_iops_allocation": "used_space",
    "peak_iops_allocation": "used_space"
  },
  "name": "extreme",
  "object_count": 0,
  "pgid": 0,
  "policy_class": "undefined",
  "scope": "cluster",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 8454147    | The maximum limit for QoS policies has been reached.   |
| 8454154    | The name specified for creating conflicts with an existing QoS policy name.  |
| 8454260    | Invalid value for maximum and minimum fields. Valid values for max_throughput_iops and max_throughput_mbps combination is for the ratio of max_throughput_mbps and max_throughput_iops to be within 1 to 4096. |
| 8454273    | Invalid value for an adaptive field. Value should be non-zero.   |
| 8454277    | The name specified for creating an adaptive QoS policy conflicts with an existing fixed QoS policy name.   |
| 8454278    | The name specified for creating a fixed QoS policy conflicts with an existing adaptive QoS policy name.  |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

adaptive

Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space.

| Name                     | Type    | Description   |
|--------------------------|---------|---|
| absolute_min_iops        | integer | Specifies the absolute minimum IOPS that is used as an override when the expected_iops is less than this value. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| block_size               | string  | Specifies the block size  |
| expected_iops            | integer | Expected IOPS. Specifies the minimum expected IOPS per TB allocated based on the storage object allocated size. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| expected_iops_allocation | string  | Specifies the size to be used to calculate expected IOPS per TB. The size options are either the storage object allocated space or the storage object used space.   |
| peak_iops                | integer | Peak IOPS. Specifies the maximum possible IOPS per TB allocated based on the storage object allocated size or the storage object used size.   |



| Name                 | Type   | Description   |
|----------------------|--------|---|
| peak_iops_allocation | string | Specifies the size to be used to calculate peak IOPS per TB. The size options are either the storage object allocated space or the storage object used space. |

fixed

QoS policy-groups define a fixed service level objective (SLO) for a storage object.

| Name                | Type    | Description   |
|---------------------|---------|---|
| capacity_shared     | boolean | Specifies whether the capacities are shared across all objects that use this QoS policy-group. Default is false.  |
| max_throughput_iops | integer | Maximum throughput defined by this policy. It is specified in terms of IOPS. 0 means no maximum throughput is enforced.   |
| max_throughput_mbps | integer | Maximum throughput defined by this policy. It is specified in terms of Mbps. 0 means no maximum throughput is enforced.   |
| min_throughput_iops | integer | Minimum throughput defined by this policy. It is specified in terms of IOPS. 0 means no minimum throughput is enforced. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| min_throughput_mbps | integer | Minimum throughput defined by this policy. It is specified in terms of Mbps. 0 means no minimum throughput is enforced.   |

svm

| Name   | Type                   | Description          |
|--------|------------------------|----------------------|
| _links | <a href="#">_links</a> |                      |
| name   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

#### qos\_policy

| Name                   | Type                     | Description   |
|------------------------|--------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a>   |   |
| adaptive               | <a href="#">adaptive</a> | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| fixed                  | <a href="#">fixed</a>    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |
| name                   | string                   | Name of the QoS policy.   |
| object_count           | integer                  | Number of objects attached to this policy.  |
| pgid                   | integer                  | Policy group ID of the QoS policy.  |
| policy_class           | string                   | Class of the QoS policy.  |
| scope                  | string                   | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects.   |
| svm                    | <a href="#">svm</a>      |   |
| uuid                   | string                   |   |

#### job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a QoS policy

DELETE /storage/qos/policies/{uuid}

**Introduced In:** 9.6

Deletes a QoS policy. All QoS workloads associated with the policy are removed.

### Related ONTAP commands

- `qos policy-group delete`
- `qos adaptive-policy-group delete`

### Parameters

| Name | Type   | In   | Required | Description  |
|------|--------|------|----------|--|
| uuid | string | path | True     | <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul> |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a QoS policy

GET /storage/qos/policies/{uuid}

## Introduced In: 9.6

Retrieves a specific QoS policy.

### Related ONTAP commands

- `qos policy-group show`
- `qos adaptive-policy-group show`

### Parameters

| Name   | Type          | In    | Required | Description  |
|--------|---------------|-------|----------|--|
| uuid   | string        | path  | True     | <ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul> |
| fields | array[string] | query | False    | Specify the fields to return.  |

### Response

Status: 200, Ok

| Name                     | Type                     | Description   |
|--------------------------|--------------------------|---|
| <a href="#">_links</a>   | <a href="#">_links</a>   |   |
| <a href="#">adaptive</a> | <a href="#">adaptive</a> | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| <a href="#">fixed</a>    | <a href="#">fixed</a>    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |
| name                     | string                   | Name of the QoS policy.   |
| object_count             | integer                  | Number of objects attached to this policy.  |
| pgid                     | integer                  | Policy group ID of the QoS policy.  |
| policy_class             | string                   | Class of the QoS policy.  |

| Name  | Type   | Description   |
|-------|--------|---|
| scope | string | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects. |
| svm   | svm    |   |
| uuid  | string |   |

### Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "adaptive": {
    "block_size": "any",
    "expected_iops_allocation": "used_space",
    "peak_iops_allocation": "used_space"
  },
  "name": "extreme",
  "object_count": 0,
  "pgid": 0,
  "policy_class": "undefined",
  "scope": "cluster",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

### Error

Status: Default, Error



| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

adaptive

Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space.

| Name                     | Type    | Description   |
|--------------------------|---------|---|
| absolute_min_iops        | integer | Specifies the absolute minimum IOPS that is used as an override when the expected_iops is less than this value. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| block_size               | string  | Specifies the block size  |
| expected_iops            | integer | Expected IOPS. Specifies the minimum expected IOPS per TB allocated based on the storage object allocated size. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| expected_iops_allocation | string  | Specifies the size to be used to calculate expected IOPS per TB. The size options are either the storage object allocated space or the storage object used space.   |
| peak_iops                | integer | Peak IOPS. Specifies the maximum possible IOPS per TB allocated based on the storage object allocated size or the storage object used size.   |

| Name                 | Type   | Description   |
|----------------------|--------|---|
| peak_iops_allocation | string | Specifies the size to be used to calculate peak IOPS per TB. The size options are either the storage object allocated space or the storage object used space. |

fixed

QoS policy-groups define a fixed service level objective (SLO) for a storage object.

| Name                | Type    | Description   |
|---------------------|---------|---|
| capacity_shared     | boolean | Specifies whether the capacities are shared across all objects that use this QoS policy-group. Default is false.  |
| max_throughput_iops | integer | Maximum throughput defined by this policy. It is specified in terms of IOPS. 0 means no maximum throughput is enforced.   |
| max_throughput_mbps | integer | Maximum throughput defined by this policy. It is specified in terms of Mbps. 0 means no maximum throughput is enforced.   |
| min_throughput_iops | integer | Minimum throughput defined by this policy. It is specified in terms of IOPS. 0 means no minimum throughput is enforced. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| min_throughput_mbps | integer | Minimum throughput defined by this policy. It is specified in terms of Mbps. 0 means no minimum throughput is enforced.   |

svm

| Name                   | Type                   | Description          |
|------------------------|------------------------|----------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                      |
| name                   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a QoS policy

PATCH /storage/qos/policies/{uuid}

**Introduced In:** 9.6

Update a specific QoS policy.

### Related ONTAP commands

- `qos policy-group modify`
- `qos adaptive-policy-group modify`

### Parameters

| Name | Type   | In   | Required | Description  |
|------|--------|------|----------|--|
| uuid | string | path | True     | <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul> |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name                   | Type                     | Description   |
|------------------------|--------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a>   |   |
| adaptive               | <a href="#">adaptive</a> | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| fixed                  | <a href="#">fixed</a>    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |

| Name         | Type                | Description   |
|--------------|---------------------|---|
| name         | string              | Name of the QoS policy.   |
| object_count | integer             | Number of objects attached to this policy.  |
| pgid         | integer             | Policy group ID of the QoS policy.  |
| policy_class | string              | Class of the QoS policy.  |
| scope        | string              | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects. |
| svm          | <a href="#">svm</a> |   |
| uuid         | string              |   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "adaptive": {
    "block_size": "any",
    "expected_iops_allocation": "used_space",
    "peak_iops_allocation": "used_space"
  },
  "name": "extreme",
  "object_count": 0,
  "pgid": 0,
  "policy_class": "undefined",
  "scope": "cluster",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 8454147    | The maximum limit for QoS policies has been reached.   |
| 8454154    | The name specified for creating conflicts with an existing QoS policy name.  |
| 8454260    | Invalid value for maximum and minimum fields. Valid values for max_throughput_iops and max_throughput_mbps combination is for the ratio of max_throughput_mbps and max_throughput_iops to be within 1 to 4096. |
| 8454273    | Invalid value for an adaptive field. Value should be non-zero.   |
| 8454277    | The name specified for creating an adaptive QoS policy conflicts with an existing fixed QoS policy name.   |
| 8454278    | The name specified for creating a fixed QoS policy conflicts with an existing adaptive QoS policy name.  |
| 8454286    | Modifications on these cluster scoped preset policies is prohibited.   |
| 8454327    | The existing fixed QoS policy cannot be modified to an adaptive QoS policy.  |
| 8454328    | The existing adaptive QoS policy cannot be modified to a fixed QoS policy.   |



| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

adaptive

Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space.

| Name                     | Type    | Description   |
|--------------------------|---------|---|
| absolute_min_iops        | integer | Specifies the absolute minimum IOPS that is used as an override when the expected_iops is less than this value. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| block_size               | string  | Specifies the block size  |
| expected_iops            | integer | Expected IOPS. Specifies the minimum expected IOPS per TB allocated based on the storage object allocated size. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| expected_iops_allocation | string  | Specifies the size to be used to calculate expected IOPS per TB. The size options are either the storage object allocated space or the storage object used space.   |
| peak_iops                | integer | Peak IOPS. Specifies the maximum possible IOPS per TB allocated based on the storage object allocated size or the storage object used size.   |

| Name                 | Type   | Description   |
|----------------------|--------|---|
| peak_iops_allocation | string | Specifies the size to be used to calculate peak IOPS per TB. The size options are either the storage object allocated space or the storage object used space. |

fixed

QoS policy-groups define a fixed service level objective (SLO) for a storage object.

| Name                | Type    | Description   |
|---------------------|---------|---|
| capacity_shared     | boolean | Specifies whether the capacities are shared across all objects that use this QoS policy-group. Default is false.  |
| max_throughput_iops | integer | Maximum throughput defined by this policy. It is specified in terms of IOPS. 0 means no maximum throughput is enforced.   |
| max_throughput_mbps | integer | Maximum throughput defined by this policy. It is specified in terms of Mbps. 0 means no maximum throughput is enforced.   |
| min_throughput_iops | integer | Minimum throughput defined by this policy. It is specified in terms of IOPS. 0 means no minimum throughput is enforced. These floors are not guaranteed on non-AFF platforms or when FabricPool tiering policies are set. |
| min_throughput_mbps | integer | Minimum throughput defined by this policy. It is specified in terms of Mbps. 0 means no minimum throughput is enforced.   |

svm

| Name   | Type                   | Description          |
|--------|------------------------|----------------------|
| _links | <a href="#">_links</a> |                      |
| name   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

#### qos\_policy

| Name                   | Type                     | Description   |
|------------------------|--------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a>   |   |
| adaptive               | <a href="#">adaptive</a> | Adaptive QoS policy-groups define measurable service level objectives (SLOs) that adjust based on the storage object used space and the storage object allocated space. |
| fixed                  | <a href="#">fixed</a>    | QoS policy-groups define a fixed service level objective (SLO) for a storage object.  |
| name                   | string                   | Name of the QoS policy.   |
| object_count           | integer                  | Number of objects attached to this policy.  |
| pgid                   | integer                  | Policy group ID of the QoS policy.  |
| policy_class           | string                   | Class of the QoS policy.  |
| scope                  | string                   | Scope of the entity. Set to "cluster" for cluster owned objects and to "svm" for SVM owned objects.   |
| svm                    | <a href="#">svm</a>      |   |
| uuid                   | string                   |   |

#### job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage QoS workloads

### Storage QoS workloads endpoint overview

#### Quality of Service Workloads

A QoS workload represents a storage object that is tracked by QoS.

#### Examples

##### Retrieving a list of QoS workloads from the cluster

The following example retrieves all the workloads in the cluster.

```
curl -X GET "https://<mgmt-ip>/api/storage/qos/workloads" -H "accept: application/hal+json"
```

##### Retrieving a specific QoS workload from the cluster

The following example retrieves a requested workload from the cluster.

```
curl -X GET "https://<mgmt-ip>/api/storage/qos/workloads/77b68b1c-a458-11eb-baaa-005056bb873e" -H "accept: application/hal+json"
```

## Retrieve QoS workloads

GET /storage/qos/workloads

**Introduced In:** 9.10

Retrieves a collection of QoS workloads.

### Parameters

| Name           | Type          | In    | Required | Description                   |
|----------------|---------------|-------|----------|-------------------------------|
| file           | string        | query | False    | Filter by file                |
| lun            | string        | query | False    | Filter by lun                 |
| policy.name    | string        | query | False    | Filter by policy.name         |
| policy.uuid    | string        | query | False    | Filter by policy.uuid         |
| workload_class | string        | query | False    | Filter by workload_class      |
| uuid           | string        | query | False    | Filter by uuid                |
| wid            | integer       | query | False    | Filter by wid                 |
| name           | string        | query | False    | Filter by name                |
| qtree          | string        | query | False    | Filter by qtree               |
| svm.uuid       | string        | query | False    | Filter by svm.uuid            |
| svm.name       | string        | query | False    | Filter by svm.name            |
| volume         | string        | query | False    | Filter by volume              |
| fields         | array[string] | query | False    | Specify the fields to return. |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| max_records    | integer       | query | False    | Limit the number of records returned.   |
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                                  | Description       |
|-------------|---------------------------------------|-------------------|
| _links      | <a href="#">_links</a>                |                   |
| error       | <a href="#">error</a>                 |                   |
| num_records | integer                               | Number of records |
| records     | array[ <a href="#">qos_workload</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "file": "string",
    "lun": "string",
    "name": "volumel-widl23",
    "policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "performance",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "qtree": "string",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",

```



```
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "volume": "volume1",
  "wid": 123,
  "workload_class": "autovolume"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

policy

QoS policy group reference.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description   |
|------|--------|---|
| name | string | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |
| uuid | string | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

svm

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

qos\_workload

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| file                   | string                 | Name of the file.  |
| lun                    | string                 | Name of the LUN. The name of the LUN will be displayed as "(unknown)" if the name cannot be retrieved.       |
| name                   | string                 | Name of the QoS workload.  |
| policy                 | <a href="#">policy</a> | QoS policy group reference.  |
| qtree                  | string                 | Name of the Qtree.   |
| svm                    | <a href="#">svm</a>    |  |
| uuid                   | string                 |  |
| volume                 | string                 | Name of the volume. The name of the volume will be displayed as "(unknown)" if the name cannot be retrieved. |

| Name           | Type    | Description                      |
|----------------|---------|----------------------------------|
| wid            | integer | Workload ID of the QoS workload. |
| workload_class | string  | Class of the QoS workload.       |

## Retrieve a QoS workload

GET /storage/qos/workloads/{uuid}

**Introduced In:** 9.10

Retrieves a specific QoS workload.

### Related ONTAP command

- qos workload show

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| uuid   | string        | path  | True     |                               |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| file   | string                 | Name of the file.  |
| lun    | string                 | Name of the LUN. The name of the LUN will be displayed as "(unknown)" if the name cannot be retrieved. |
| name   | string                 | Name of the QoS workload.  |
| policy | <a href="#">policy</a> | QoS policy group reference.  |

| Name           | Type                | Description  |
|----------------|---------------------|--|
| qtree          | string              | Name of the Qtree.   |
| svm            | <a href="#">svm</a> |  |
| uuid           | string              |  |
| volume         | string              | Name of the volume. The name of the volume will be displayed as "(unknown)" if the name cannot be retrieved. |
| wid            | integer             | Workload ID of the QoS workload.   |
| workload_class | string              | Class of the QoS workload.   |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "file": "string",
  "lun": "string",
  "name": "volume1-wid123",
  "policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "performance",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "qtree": "string",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "volume": "volume1",
  "wid": 123,
  "workload_class": "autovolume"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

policy

QoS policy group reference.

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| name   | string                 | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |
| uuid   | string                 | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error



| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage qtrees

### Storage qtrees endpoint overview

#### Overview

A qtree is a logically defined file system that can exist as a special subdirectory of the root directory within a FlexVol volume or a FlexGroup volume.

#### Qtree QoS policy

Qtree QoS policy and settings enforce Service Level Objectives (SLOs) on a qtree. SLOs can be set by specifying "qos\_policy.max\_throughput\_iops" and/or "qos\_policy.max\_throughput\_mbps" or "qos\_policy.min\_throughput\_iops" and/or "qos\_policy.min\_throughput\_mbps". Specifying "min\_throughput\_iops" or "min\_throughput\_mbps" is only supported on volumes hosted on a node that is flash optimized. A pre-created QoS policy can also be used by specifying "qos\_policy.name" or "qos\_policy.uuid" properties. Setting or assigning a QoS policy to a qtree is not supported if its containing volume or SVM has a QoS policy attached, or a file or LUN in its containing volume already has a QoS policy attached.

#### Qtree APIs

The following APIs are used to create, retrieve, modify, and delete qtrees.

&ndash; POST /api/storage/qtrees

&ndash; GET /api/storage/qtrees

&ndash; GET /api/storage/qtrees/{volume-uuid}/{qtree-id}

&ndash; PATCH /api/storage/qtrees/{volume-uuid}/{qtree-id}

&ndash; DELETE /api/storage/qtrees/{volume-uuid}/{qtree-id}

#### Examples

##### Creating a qtree inside a volume for an SVM

This API is used to create a qtree inside a volume for an SVM.

The following example shows how to create a qtree in a FlexVol volume with a given security style, user,

```
# The API:
POST /api/storage/qtrees

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/qtrees?return_records=true' -H
'accept: application/hal+json' -d @test_qtree_post.txt
test_qtree_post.txt (body):
{
  "svm": {
    "name": "svm1"
  },
  "volume": {
    "name": "fv"
  },
  "name": "qt1",
  "security_style": "unix",
  "user": {
    "name": "unix_user1"
  },
  "group": {
    "name": "unix_group1"
  },
  "unix_permissions": 744,
  "export_policy": {
    "name": "default"
  },
  "qos_policy": {
    "max_throughput_iops": 1000
  }
}

# The response:
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "name": "svm1"
      },
      "volume": {
        "name": "fv"
      }
    }
  ]
}
```

```

"name": "qt1",
"security_style": "unix",
"user": {
  "name": "unix_user1"
},
"group": {
  "name": "unix_group1"
},
"unix_permissions": 744,
"export_policy": {
  "name": "default"
},
"qos_policy": {
  "min_throughput_iops": 0,
  "min_throughput_mbps": 0,
  "max_throughput_iops": 1000,
  "max_throughput_mbps": 0,
  "uuid": "39ac471f-ff35-11e9-b0f9-005056a7ab52",
  "name": "vs0_auto_gen_policy_39a9522f_ff35_11e9_b0f9_005056a7ab52"
},
"_links": {
  "self": {
    "href": "/api/storage/qtrees/?volume.name=fv&name=qt1"
  }
}
],
"job": {
  "uuid": "84edef3c-4f6d-11e9-9a71-005056a7f717",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/84edef3c-4f6d-11e9-9a71-005056a7f717"
    }
  }
}
}

```

## Retrieving qtrees

This API is used to retrieve qtrees.

The following example shows how to retrieve qtrees belonging to SVM *svm1* and volume *fv*. The `svm.name` and `volume.name` query parameters are used to find the required qtrees.

```

# The API:
GET /api/storage/qtrees

# The call:
curl -X GET "https://<mgmt-
ip>/api/storage/qtrees/?svm.name=svml&volume.name=fv" -H 'accept:
application/hal+json'

# The response
{
  "records": [
    {
      "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svml",
        "_links": {
          "self": {
            "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
          }
        }
      },
      "volume": {
        "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
        "name": "fv",
        "_links": {
          "self": {
            "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
          }
        }
      },
      "id": 0,
      "name": "",
      "_links": {
        "self": {
          "href": "/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-
005056a7f717/0"
        }
      }
    },
    {
      "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svml",
        "_links": {

```

```

        "self": {
            "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
    },
    "volume": {
        "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
        "name": "fv",
        "_links": {
            "self": {
                "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
            }
        }
    },
    "id": 1,
    "name": "qt1",
    "_links": {
        "self": {
            "href": "/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-
005056a7f717/1"
        }
    }
},
{
    "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svm1",
        "_links": {
            "self": {
                "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
            }
        }
    },
    "volume": {
        "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
        "name": "fv",
        "_links": {
            "self": {
                "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
            }
        }
    },
    "id": 2,
    "name": "qt2",

```

```

    "_links": {
      "self": {
        "href": "/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2"
      }
    }
  ],
  "num_records": 3,
  "_links": {
    "self": {
      "href": "/api/storage/qtrees/?svm.name=svm1&volume.name=fv"
    }
  }
}

```

### Retrieving properties of a specific qtree using a qtree identifier

This API is used to retrieve properties of a specific qtree using qtree.id.

The following example shows how to use the qtree identifier to retrieve all properties of the qtree using the `fields` query parameter.

```

# The API:
GET /api/storage/qtrees/{volume.uuid}/{id}

# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2?fields=*' -H 'accept: application/hal+json'
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
    "name": "fv",
    "_links": {

```

```
    "self": {
      "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717"
    }
  },
  "id": 2,
  "name": "qt2",
  "security_style": "unix",
  "user": {
    "name": "unix_user1"
  },
  "group": {
    "name": "unix_group1"
  },
  "unix_permissions": 744,
  "export_policy": {
    "name": "default",
    "id": 12884901889,
    "_links": {
      "self": {
        "href": "/api/protocols/nfs/export-policies/12884901889"
      }
    }
  },
  "qos_policy": {
    "min_throughput_iops": 0,
    "min_throughput_mbps": 0,
    "max_throughput_iops": 1000,
    "max_throughput_mbps": 0,
    "uuid": "39ac471f-ff35-11e9-b0f9-005056a7ab52",
    "name": "vs0_auto_gen_policy_39a9522f_ff35_11e9_b0f9_005056a7ab52",
    "_links": {
      "self": {
        "href": "/api/storage/qos/policies/39ac471f-ff35-11e9-b0f9-005056a7ab52"
      }
    }
  },
  "statistics": {
    "timestamp": "2019-04-09T05:50:42Z",
    "status": "ok",
    "iops_raw": {
      "read": 0,
      "write": 0,
      "other": 3,
```

```

    "total": 3
  },
  "throughput_raw": {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  }
},
"path": "/fv/qt2",
"nas": {
  "path": "/fv/qt2",
},
"_links": {
  "self": {
    "href": "/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2"
  }
}
}
}

```

### Retrieving properties of a specific qtree using the qtree name

This API is used to retrieve properties of a specific qtree using "qtree.name". The following example shows how to retrieve all of the properties belonging to qtree "qt2". The `svm.name` and `volume.name` query parameters are used here along with the qtree name.

```

# The API:
GET /api/storage/qtrees/

# The call:
curl -X GET 'https://<mgmt-
ip>/api/storage/qtrees/?svm.name=svml&volume.name=fv&name=qt2&fields=*' -H
'accept: application/hal+json'
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  }
},

```



```
"volume": {
  "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
  "name": "fv",
  "_links": {
    "self": {
      "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717"
    }
  }
},
"id": 2,
"name": "qt2",
"security_style": "unix",
"user": {
  "name": "unix_user1"
},
"group": {
  "name": "unix_group1"
},
"unix_permissions": 744,
"export_policy": {
  "name": "default",
  "id": 12884901889,
  "_links": {
    "self": {
      "href": "/api/protocols/nfs/export-policies/12884901889"
    }
  }
},
"qos_policy": {
  "min_throughput_iops": 0,
  "min_throughput_mbps": 0,
  "max_throughput_iops": 1000,
  "max_throughput_mbps": 0,
  "uuid": "39ac471f-ff35-11e9-b0f9-005056a7ab52",
  "name": "vs0_auto_gen_policy_39a9522f_ff35_11e9_b0f9_005056a7ab52",
  "_links": {
    "self": {
      "href": "/api/storage/qos/policies/39ac471f-ff35-11e9-b0f9-005056a7ab52"
    }
  }
},
"statistics": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
```

```
"iops_raw": {
  "read": 0,
  "write": 0,
  "other": 3,
  "total": 3
},
"throughput_raw": {
  "read": 0,
  "write": 0,
  "other": 0,
  "total": 0
}
},
"_links": {
  "self": {
    "href": "/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2"
  }
}
}
```

---

### Updating a qtree

This API is used to update a qtree.

The following example shows how to update properties in a qtree.

---

```
# The API:
PATCH /api/storage/qtrees/{volume.uuid}/{id}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2' -H 'accept: application/hal+json' -d
 '@test_qtree_patch.txt'
test_qtree_patch.txt (body):
{
  "security_style": "mixed",
  "user": {
    "name": "unix_user1"
  },
  "group": {
    "name": "unix_group1"
  },
  "unix_permissions": 777,
  "export_policy": {
    "id": "9",
    "name": "exp1"
  },
  "qos_policy": {
    "uuid": "39ac471f-ff35-11e9-b0f9-005056a7ab53"
  }
}
```

---

### Renaming a qtree

This API is used to rename a qtree.

The following example below shows how to rename a qtree with a new name.

```
# The API:
PATCH /api/storage/qtrees/{volume.uuid}/{id}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/1' -H 'accept: application/hal+json' -d '{ "name":
 "new_qt1" }'
```

## Deleting a qtree inside a volume of an SVM

This API is used to delete a qtree inside a volume of an SVM.

The following example shows how to delete a qtree.

```
# The API:
DELETE /api/storage/qtrees/{volume.uuid}/{id}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/qtrees/cb20da45-4f6b-11e9-9a71-005056a7f717/2" -H 'accept: application/hal+json'
```

## Retrieve qtrees

GET /storage/qtrees

**Introduced In:** 9.6

Retrieves qtrees configured for all FlexVol volumes or FlexGroup volumes.

Use the `fields` query parameter to retrieve all properties of the qtree. If the `fields` query parameter is not used, then GET returns the qtree name and qtree id only.

### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `statistics.*`

### Related ONTAP commands

- `qtree show`

### Parameters

| Name                 | Type   | In    | Required | Description   |
|----------------------|--------|-------|----------|---|
| statistics.timestamp | string | query | False    | Filter by statistics.timestamp <ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul> |

| Name                            | Type    | In    | Required | Description   |
|---------------------------------|---------|-------|----------|---|
| statistics.iops_raw.other       | integer | query | False    | Filter by statistics.iops_raw.other<br><br>• Introduced in: 9.8       |
| statistics.iops_raw.read        | integer | query | False    | Filter by statistics.iops_raw.read<br><br>• Introduced in: 9.8        |
| statistics.iops_raw.write       | integer | query | False    | Filter by statistics.iops_raw.write<br><br>• Introduced in: 9.8       |
| statistics.iops_raw.total       | integer | query | False    | Filter by statistics.iops_raw.total<br><br>• Introduced in: 9.8       |
| statistics.status               | string  | query | False    | Filter by statistics.status<br><br>• Introduced in: 9.8               |
| statistics.throughput_raw.other | integer | query | False    | Filter by statistics.throughput_raw.other<br><br>• Introduced in: 9.8 |
| statistics.throughput_raw.read  | integer | query | False    | Filter by statistics.throughput_raw.read<br><br>• Introduced in: 9.8  |

| Name                            | Type    | In    | Required | Description   |
|---------------------------------|---------|-------|----------|---|
| statistics.throughput_raw.write | integer | query | False    | Filter by statistics.throughput_raw.write<br><br>• Introduced in: 9.8 |
| statistics.throughput_raw.total | integer | query | False    | Filter by statistics.throughput_raw.total<br><br>• Introduced in: 9.8 |
| group.id                        | string  | query | False    | Filter by group.id<br><br>• Introduced in: 9.9                        |
| group.name                      | string  | query | False    | Filter by group.name<br><br>• Introduced in: 9.9                      |
| path                            | string  | query | False    | Filter by path  |
| filesystem_path                 | string  | query | False    | Filter by filesystem_path<br><br>• Introduced in: 9.10                |
| security_style                  | string  | query | False    | Filter by security_style  |
| name                            | string  | query | False    | Filter by name  |
| export_policy.id                | integer | query | False    | Filter by export_policy.id  |
| export_policy.name              | string  | query | False    | Filter by export_policy.name  |
| volume.name                     | string  | query | False    | Filter by volume.name   |
| volume.uuid                     | string  | query | False    | Filter by volume.uuid   |

| Name                           | Type    | In    | Required | Description  |
|--------------------------------|---------|-------|----------|--|
| svm.uuid                       | string  | query | False    | Filter by svm.uuid   |
| svm.name                       | string  | query | False    | Filter by svm.name   |
| qos_policy.uuid                | string  | query | False    | Filter by qos_policy.uuid<br><br>• Introduced in: 9.8                |
| qos_policy.min_throughput_mbps | integer | query | False    | Filter by qos_policy.min_throughput_mbps<br><br>• Introduced in: 9.8 |
| qos_policy.name                | string  | query | False    | Filter by qos_policy.name<br><br>• Introduced in: 9.8                |
| qos_policy.max_throughput_mbps | integer | query | False    | Filter by qos_policy.max_throughput_mbps<br><br>• Introduced in: 9.8 |
| qos_policy.min_throughput_iops | integer | query | False    | Filter by qos_policy.min_throughput_iops<br><br>• Introduced in: 9.8 |
| qos_policy.max_throughput_iops | integer | query | False    | Filter by qos_policy.max_throughput_iops<br><br>• Introduced in: 9.8 |
| user.id                        | string  | query | False    | Filter by user.id<br><br>• Introduced in: 9.9                        |

| Name             | Type          | In    | Required | Description  |
|------------------|---------------|-------|----------|--|
| user.name        | string        | query | False    | Filter by user.name <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>   |
| nas.path         | string        | query | False    | Filter by nas.path <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>  |
| unix_permissions | integer       | query | False    | Filter by unix_permissions   |
| id               | integer       | query | False    | Filter by id <ul style="list-style-type: none"> <li>• Max value: 4994</li> <li>• Min value: 0</li> </ul>   |
| fields           | array[string] | query | False    | Specify the fields to return.  |
| max_records      | integer       | query | False    | Limit the number of records returned.  |
| return_records   | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul> |



| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Max value: 120</li> <li>• Min value: 0</li> <li>• Default value: 1</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                           | Description       |
|-------------|--------------------------------|-------------------|
| _links      | <a href="#">_links</a>         |                   |
| num_records | integer                        | Number of records |
| records     | array[ <a href="#">qtree</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "export_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 100,
      "name": "default"
    },
    "filesystem_path": "/dir1/qtree1",
    "group": {
      "id": "20001",
      "name": "unix_group1"
    },
    "id": 1,
    "nas": {
      "path": "/volume3/qtree1"
    },
    "path": "/volume3/qtree1",
    "qos_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "max_throughput_iops": 10000,
      "max_throughput_mbps": 500,
      "min_throughput_iops": 2000,
      "min_throughput_mbps": 500,

```

```
    "name": "performance",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "security_style": "unix",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "unix_permissions": 755,
  "user": {
    "id": "10001",
    "name": "unix_user1"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

export\_policy

Export Policy

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| id     | integer                |             |
| name   | string                 |             |

group

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the group that owns the qtree. Valid in POST or PATCH.      |
| name | string | Alphanumeric group name of group that owns the qtree. Valid in POST or PATCH. |

nas

| Name | Type   | Description   |
|------|--------|---|
| path | string | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. |

qos\_policy

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| max_throughput_iops    | integer                | Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.  |
| max_throughput_mbps    | integer                | Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| min_throughput_iops    | integer                | Specifies the minimum throughput in IOPS, 0 means none. Setting "min_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH. |
| min_throughput_mbps    | integer                | Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| name                   | string                 | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH.   |
| uuid                   | string                 | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH.   |

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

## statistics

These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name           | Type                           | Description  |
|----------------|--------------------------------|--|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| status         | string                         | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled with the next closest collection and tagged with "backfilled_data".<br>"inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "negative_delta" is returned when an expected monotonically increasing value has decreased in value.<br>"inconsistent_old_data" is returned when one or more nodes does not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.   |

svm

Required in POST

| Name                   | Type                   | Description          |
|------------------------|------------------------|----------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                      |
| name                   | string                 | The name of the SVM. |



| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

user

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the user who owns the qtree. Valid in POST or PATCH.    |
| name | string | Alphanumeric username of user who owns the qtree. Valid in POST or PATCH. |

volume

Required in POST

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

qtree

A qtree is a directory at the top level of a volume to which a custom export policy (for fine-grained access control) and a quota rule can be applied, if required.

| Name                   | Type                          | Description   |
|------------------------|-------------------------------|---------------|
| <a href="#">_links</a> | <a href="#">_links</a>        |               |
| export_policy          | <a href="#">export_policy</a> | Export Policy |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| filesystem_path  | string                     | Path of the qtree directory. This path is relative to the volume root directory.   |
| group            | <a href="#">group</a>      | The user set as owner of the qtree.  |
| id               | integer                    | The identifier for the qtree, unique within the qtree's volume.  |
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Create a qtree in a FlexVol or FlexGroup volume

POST /storage/qtrees

**Introduced In:** 9.6

Creates a qtree in a FlexVol volume or a FlexGroup volume.

After a qtree is created, the new qtree is assigned an identifier. This identifier is obtained using a qtree GET request. This identifier is used in the API path for the qtree PATCH and DELETE operations.

### Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the qtree.
- `volume.uuid` or `volume.name` - Existing volume in which to create the qtree.
- `name` - Name for the qtree.

### Recommended optional properties

If not specified in POST, the values are inherited from the volume.

- `security_style` - Security style for the qtree.
- `unix_permissions` - UNIX permissions for the qtree.
- `export_policy.name` or `export_policy.id` - Export policy of the SVM for the qtree.

### Related ONTAP commands

- `qtree create`

## Parameters

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul>  |

## Request Body

| Name          | Type                          | Description   |
|---------------|-------------------------------|---------------|
| _links        | <a href="#">_links</a>        |               |
| export_policy | <a href="#">export_policy</a> | Export Policy |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| filesystem_path  | string                     | Path of the qtree directory. This path is relative to the volume root directory.   |
| group            | <a href="#">group</a>      | The user set as owner of the qtree.  |
| id               | integer                    | The identifier for the qtree, unique within the qtree's volume.  |
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "export_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 100,
    "name": "default"
  },
  "filesystem_path": "/dir1/qtreen1",
  "group": {
    "id": "20001",
    "name": "unix_group1"
  },
  "id": 1,
  "nas": {
    "path": "/volume3/qtreen1"
  },
  "path": "/volume3/qtreen1",
  "qos_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "max_throughput_iops": 10000,
    "max_throughput_mbps": 500,
    "min_throughput_iops": 2000,
    "min_throughput_mbps": 500,
    "name": "performance",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "security_style": "unix",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    }
  }
}
```

```

    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "unix_permissions": 755,
  "user": {
    "id": "10001",
    "name": "unix_user1"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}

```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 917927     | The specified volume was not found.   |
| 918232     | Either <code>volume.name</code> or <code>volume.uuid</code> must be provided.                   |
| 918236     | The specified <code>volume.uuid</code> and <code>volume.name</code> refer to different volumes. |
| 2621462    | The specified SVM does not exist.   |
| 2621706    | The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM.     |
| 2621707    | No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be provided.   |
| 5242886    | Failed to create qtree.   |
| 5242951    | Export Policy supplied does not belong to the specified Export Policy ID.                       |
| 5242952    | Export Policy ID specified is invalid.  |
| 5242953    | Qtree name must be provided.  |
| 5242967    | UNIX user or group ID must be 32-bit unsigned integer.  |



| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

export\_policy

Export Policy

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| id     | integer                |             |
| name   | string                 |             |

group

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the group that owns the qtree. Valid in POST or PATCH.      |
| name | string | Alphanumeric group name of group that owns the qtree. Valid in POST or PATCH. |

nas

| Name | Type   | Description   |
|------|--------|---|
| path | string | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. |

qos\_policy

| Name                             | Type                | Description   |
|----------------------------------|---------------------|---|
| <code>_links</code>              | <code>_links</code> |   |
| <code>max_throughput_iops</code> | integer             | Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.  |
| <code>max_throughput_mbps</code> | integer             | Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| <code>min_throughput_iops</code> | integer             | Specifies the minimum throughput in IOPS, 0 means none. Setting "min_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH. |
| <code>min_throughput_mbps</code> | integer             | Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| <code>name</code>                | string              | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH.   |
| <code>uuid</code>                | string              | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH.   |

`iops_raw`

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name           | Type                           | Description  |
|----------------|--------------------------------|--|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| status         | string                         | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled with the next closest collection and tagged with "backfilled_data".<br>"inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "negative_delta" is returned when an expected monotonically increasing value has decreased in value.<br>"inconsistent_old_data" is returned when one or more nodes does not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.   |

svm

Required in POST

| Name                   | Type                   | Description          |
|------------------------|------------------------|----------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                      |
| name                   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

user

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the user who owns the qtree. Valid in POST or PATCH.    |
| name | string | Alphanumeric username of user who owns the qtree. Valid in POST or PATCH. |

volume

Required in POST

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

qtree

A qtree is a directory at the top level of a volume to which a custom export policy (for fine-grained access control) and a quota rule can be applied, if required.

| Name          | Type                          | Description   |
|---------------|-------------------------------|---------------|
| _links        | <a href="#">_links</a>        |               |
| export_policy | <a href="#">export_policy</a> | Export Policy |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| filesystem_path  | string                     | Path of the qtree directory. This path is relative to the volume root directory.   |
| group            | <a href="#">group</a>      | The user set as owner of the qtree.  |
| id               | integer                    | The identifier for the qtree, unique within the qtree's volume.  |
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |

job\_link

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| uuid                   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a qtree

DELETE /storage/qtrees/{volume.uuid}/{id}

**Introduced In:** 9.6

Deletes a qtree.

### Related ONTAP commands

- `qtree delete`

### Parameters

| Name        | Type   | In   | Required | Description |
|-------------|--------|------|----------|-------------|
| volume.uuid | string | path | True     | Volume UUID |
| id          | string | path | True     | Qtree ID    |



| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 918235     | A volume with UUID was not found.                     |
| 5242955    | The UUID of the volume is required.                   |
| 5242957    | Failed to delete qtree with ID in the volume and SVM. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

### See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve qtree properties

GET /storage/qtrees/{volume.uuid}/{id}

Introduced In: 9.6

Retrieves properties for a specific qtree identified by the `volume.uuid` and the `id` in the API path.

### Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `statistics.*`

### Related ONTAP commands

- `qtree show`

### Parameters

| Name                     | Type          | In    | Required | Description                   |
|--------------------------|---------------|-------|----------|-------------------------------|
| <code>volume.uuid</code> | string        | path  | True     | Volume UUID                   |
| <code>id</code>          | string        | path  | True     | Qtree ID                      |
| <code>fields</code>      | array[string] | query | False    | Specify the fields to return. |

### Response

```
Status: 200, Ok
```

| Name                         | Type                          | Description  |
|------------------------------|-------------------------------|--|
| <code>_links</code>          | <a href="#">_links</a>        |  |
| <code>export_policy</code>   | <a href="#">export_policy</a> | Export Policy  |
| <code>filesystem_path</code> | string                        | Path of the qtree directory. This path is relative to the volume root directory. |
| <code>group</code>           | <a href="#">group</a>         | The user set as owner of the qtree.  |
| <code>id</code>              | integer                       | The identifier for the qtree, unique within the qtree's volume.                  |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "export_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 100,
    "name": "default"
  },
  "filesystem_path": "/dir1/qtreen1",
  "group": {
    "id": "20001",
    "name": "unix_group1"
  },
  "id": 1,
  "nas": {
    "path": "/volume3/qtreen1"
  },
  "path": "/volume3/qtreen1",
  "qos_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "max_throughput_iops": 10000,
    "max_throughput_mbps": 500,
    "min_throughput_iops": 2000,
    "min_throughput_mbps": 500,
    "name": "performance",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "security_style": "unix",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    }
  }
}
```

```

    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "unix_permissions": 755,
  "user": {
    "id": "10001",
    "name": "unix_user1"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description                       |
|------------|-----------------------------------|
| 918235     | A volume with UUID was not found. |
| 5242956    | Failed to obtain a qtree with ID. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

export\_policy

Export Policy

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| id     | integer                |             |
| name   | string                 |             |

group

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the group that owns the qtree. Valid in POST or PATCH.      |
| name | string | Alphanumeric group name of group that owns the qtree. Valid in POST or PATCH. |

nas

| Name | Type   | Description   |
|------|--------|---|
| path | string | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. |

qos\_policy

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| max_throughput_iops    | integer                | Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.  |
| max_throughput_mbps    | integer                | Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| min_throughput_iops    | integer                | Specifies the minimum throughput in IOPS, 0 means none. Setting "min_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH. |
| min_throughput_mbps    | integer                | Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| name                   | string                 | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH.   |
| uuid                   | string                 | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH.   |

iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name           | Type                           | Description  |
|----------------|--------------------------------|--|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| status         | string                         | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled with the next closest collection and tagged with "backfilled_data".<br>"inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "negative_delta" is returned when an expected monotonically increasing value has decreased in value.<br>"inconsistent_old_data" is returned when one or more nodes does not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.   |

svm

Required in POST

| Name                   | Type                   | Description          |
|------------------------|------------------------|----------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                      |
| name                   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

user

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the user who owns the qtree. Valid in POST or PATCH.    |
| name | string | Alphanumeric username of user who owns the qtree. Valid in POST or PATCH. |

volume

Required in POST

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

### Update properties for a qtree

```
PATCH /storage/qtrees/{volume.uuid}/{id}
```

**Introduced In:** 9.6

Updates properties for a specific qtree.

#### Related ONTAP commands

- `qtree modify`
- `qtree rename`

#### Parameters

| Name        | Type   | In   | Required | Description |
|-------------|--------|------|----------|-------------|
| volume.uuid | string | path | True     | Volume UUID |
| id          | string | path | True     | Qtree ID    |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Request Body

| Name            | Type                          | Description  |
|-----------------|-------------------------------|--|
| _links          | <a href="#">_links</a>        |  |
| export_policy   | <a href="#">export_policy</a> | Export Policy  |
| filesystem_path | string                        | Path of the qtree directory. This path is relative to the volume root directory. |
| group           | <a href="#">group</a>         | The user set as owner of the qtree.  |
| id              | integer                       | The identifier for the qtree, unique within the qtree's volume.                  |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |



## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "export_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 100,
    "name": "default"
  },
  "filesystem_path": "/dir1/qtreen1",
  "group": {
    "id": "20001",
    "name": "unix_group1"
  },
  "id": 1,
  "nas": {
    "path": "/volume3/qtreen1"
  },
  "path": "/volume3/qtreen1",
  "qos_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "max_throughput_iops": 10000,
    "max_throughput_mbps": 500,
    "min_throughput_iops": 2000,
    "min_throughput_mbps": 500,
    "name": "performance",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "security_style": "unix",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    }
  }
}
```

```

    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "unix_permissions": 755,
  "user": {
    "id": "10001",
    "name": "unix_user1"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}

```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 918235     | A volume with UUID was not found.   |
| 5242951    | Export policy supplied does not belong to the specified export policy ID. |
| 5242955    | The UUID of the volume is required.                                       |
| 5242956    | Failed to obtain a qtree with ID.   |
| 5242958    | Failed to rename the qtree with ID in the volume and SVM.                 |
| 5242959    | Successfully renamed qtree but the modify operation failed.               |
| 5242967    | UNIX user or group ID must be 32-bit unsigned integer.                    |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

export\_policy

Export Policy

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| id     | integer                |             |
| name   | string                 |             |

group

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the group that owns the qtree. Valid in POST or PATCH.      |
| name | string | Alphanumeric group name of group that owns the qtree. Valid in POST or PATCH. |

nas

| Name | Type   | Description   |
|------|--------|---|
| path | string | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. |

qos\_policy

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| max_throughput_iops    | integer                | Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.  |
| max_throughput_mbps    | integer                | Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| min_throughput_iops    | integer                | Specifies the minimum throughput in IOPS, 0 means none. Setting "min_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH. |
| min_throughput_mbps    | integer                | Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.   |
| name                   | string                 | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH.   |
| uuid                   | string                 | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH.   |

iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name  | Type    | Description  |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read  | integer | Performance metric for read I/O operations.  |
| total | integer | Performance metric aggregated over all types of I/O operations.  |
| write | integer | Performance metric for write I/O operations.   |

#### statistics

These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name           | Type                           | Description  |
|----------------|--------------------------------|--|
| iops_raw       | <a href="#">iops_raw</a>       | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.   |
| status         | string                         | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled with the next closest collection and tagged with "backfilled_data".<br>"inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "negative_delta" is returned when an expected monotonically increasing value has decreased in value.<br>"inconsistent_old_data" is returned when one or more nodes does not have the latest data. |
| throughput_raw | <a href="#">throughput_raw</a> | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.   |
| timestamp      | string                         | The timestamp of the performance data.   |

svm

Required in POST

| Name                   | Type                   | Description          |
|------------------------|------------------------|----------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                      |
| name                   | string                 | The name of the SVM. |



| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

user

The user set as owner of the qtree.

| Name | Type   | Description   |
|------|--------|---|
| id   | string | The numeric ID of the user who owns the qtree. Valid in POST or PATCH.    |
| name | string | Alphanumeric username of user who owns the qtree. Valid in POST or PATCH. |

volume

Required in POST

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| name   | string                 | The name of the volume.  |
| uuid   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

qtree

A qtree is a directory at the top level of a volume to which a custom export policy (for fine-grained access control) and a quota rule can be applied, if required.

| Name          | Type                          | Description   |
|---------------|-------------------------------|---------------|
| _links        | <a href="#">_links</a>        |               |
| export_policy | <a href="#">export_policy</a> | Export Policy |

| Name             | Type                       | Description  |
|------------------|----------------------------|--|
| filesystem_path  | string                     | Path of the qtree directory. This path is relative to the volume root directory.   |
| group            | <a href="#">group</a>      | The user set as owner of the qtree.  |
| id               | integer                    | The identifier for the qtree, unique within the qtree's volume.  |
| name             | string                     | The name of the qtree. Required in POST; optional in PATCH.  |
| nas              | <a href="#">nas</a>        |  |
| path             | string                     | Client visible path to the qtree. This field is not available if the volume does not have a junction-path configured. Not valid in POST or PATCH. This field is to be deprecated and replaced with nas.path. |
| qos_policy       | <a href="#">qos_policy</a> |  |
| security_style   | string                     | Security style. Valid in POST or PATCH.  |
| statistics       | <a href="#">statistics</a> | These are raw IOPS and throughput performance numbers. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.   |
| svm              | <a href="#">svm</a>        | Required in POST   |
| unix_permissions | integer                    | The UNIX permissions for the qtree. Valid in POST or PATCH.  |
| user             | <a href="#">user</a>       | The user set as owner of the qtree.  |
| volume           | <a href="#">volume</a>     | Required in POST   |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Storage quota

### Storage quota endpoint overview

#### Overview

Quotas provide a way to restrict or track the files and space usage by a user, group, or qtree. Quotas are enabled for a specific FlexVol or a FlexGroup volume.

Quotas can have soft or hard limits. Soft limits cause ONTAP to send a notification when specified limits are exceeded. Hard limits prevent a write operation from succeeding when specified limits are exceeded.

#### Quota policy rule APIs

Quotas are defined as quota policy rules specific to FlexVol or FlexGroup volumes. Each quota rule has a type. The type can be either "user", "group", or "tree".

The following APIs can be used to perform create, retrieve, modify, and delete operations related to quota policy rules for a FlexVol or a FlexGroup volume.

&ndash; POST /api/storage/quota/rules

&ndash; GET /api/storage/quota/rules

&ndash; GET /api/storage/quota/rules/{rule-uuid}

&ndash; PATCH /api/storage/quota/rules/{rule-uuid}

&ndash; DELETE /api/storage/quota/rules/{rule-uuid}

### Enabling and disabling quotas

After the quota rules are created, the quota rules need to be enabled on each FlexVol or FlexGroup volume for soft or hard limits to take effect in the filesystem. Enabling quotas can be done on a volume-by-volume basis.

The following APIs can be used to enable and disable and obtain the quota state for a FlexVol or a FlexGroup volume.

&ndash; PATCH /api/storage/volumes/{volume-uuid} -d '{"quota.enabled":"true"}

&ndash; PATCH /api/storage/volumes/{volume-uuid} -d '{"quota.enabled":"false"}

&ndash; GET /api/storage/volumes/{volume-uuid}/?fields=quota.state

### Quota report APIs

Quota report records provide usage information for a user, group, or qtree against the quota limits configured on a FlexVol or a FlexGroup volume. The following APIs can be used to retrieve quota reports associated with a FlexVol or a FlexGroup volume.

&ndash; GET /api/storage/quota/reports

&ndash; GET /api/storage/quota/reports/{volume-uuid}/{index}

### Quota resize

Quota resize allows you to modify the quota limits directly in the filesystem.

It is important to note that quota must be enabled on a FlexVol or a FlexGroup volume for `quota resize` to take effect. You can perform a `quota resize` using the quota policy rule PATCH API. If the quota is disabled on the volume, the quota policy rule PATCH API modifies the rule, but this does not affect the limits in the filesystem. The following API can be used to perform `quota resize` provided quota is enabled on the volume.

&ndash; PATCH /api/storage/quota/rules/{rule-uuid} The changed limits in the filesystem can be confirmed using the quota report REST API.

&ndash; GET /api/storage/quota/reports

## Manage storage quota reports

### Storage quota reports endpoint overview

## Overview

Quota reports provide the current file and space consumption for a user, group, or qtree in a FlexVol or a FlexGroup volume.

## Quota report APIs

The following APIs can be used to retrieve quota reports associated with a volume in ONTAP.

&ndash; GET /api/storage/quota/reports

&ndash; GET /api/storage/quota/reports/{volume\_uuid}/{index}

## Examples

### Retrieving all the quota report records

This API is used to retrieve all the quota report records.

The following example shows how to retrieve quota report records for all FlexVol volumes and FlexGroup volumes.

```
# The API:
GET /api/storage/quota/reports

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports" -H 'accept:
application/hal+json'

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
          }
        }
      },
    },
    "volume": {
      "uuid": "314a328f-502d-11e9-8771-005056a7f717",
      "name": "fg",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/314a328f-502d-11e9-8771-
```

```

005056a7f717"
    }
  }
},
"index": 0,
"_links": {
  "self": {
    "href": "/api/storage/quota/reports/314a328f-502d-11e9-8771-
005056a7f717/0"
  }
}
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "314a328f-502d-11e9-8771-005056a7f717",
    "name": "fg",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/314a328f-502d-11e9-8771-
005056a7f717"
      }
    }
  },
  "index": 1152921504606846976,
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/314a328f-502d-11e9-8771-
005056a7f717/1152921504606846976"
    }
  }
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svml",
    "_links": {
      "self": {

```

```

        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    },
    "volume": {
      "uuid": "314a328f-502d-11e9-8771-005056a7f717",
      "name": "fg",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/314a328f-502d-11e9-8771-
005056a7f717"
        }
      }
    },
    "index": 3458764513820540928,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/314a328f-502d-11e9-8771-
005056a7f717/3458764513820540928"
      }
    }
  },
  {
    "svm": {
      "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
      }
    },
    "volume": {
      "uuid": "314a328f-502d-11e9-8771-005056a7f717",
      "name": "fg",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/314a328f-502d-11e9-8771-
005056a7f717"
        }
      }
    },
    "index": 4611686018427387904,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/314a328f-502d-11e9-8771-

```

```

005056a7f717/4611686018427387904"
    }
  }
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "314a328f-502d-11e9-8771-005056a7f717",
    "name": "fg",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/314a328f-502d-11e9-8771-
005056a7f717"
      }
    }
  },
  "index": 5764607523034234880,
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/314a328f-502d-11e9-8771-
005056a7f717/5764607523034234880"
    }
  }
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
    "name": "fv",
    "_links": {

```



```

        "self": {
            "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
        }
    },
    "index": 0,
    "_links": {
        "self": {
            "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/0"
        }
    }
},
{
    "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svm1",
        "_links": {
            "self": {
                "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
            }
        }
    },
    "volume": {
        "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
        "name": "fv",
        "_links": {
            "self": {
                "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
            }
        }
    },
    "index": 281474976710656,
    "_links": {
        "self": {
            "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/281474976710656"
        }
    }
},
{
    "svm": {
        "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
        "name": "svm1",

```

```

    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    },
    "volume": {
      "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
      "name": "fv",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
        }
      }
    },
    "index": 1152921504606846976,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/1152921504606846976"
      }
    }
  },
  {
    "svm": {
      "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
      }
    },
    "volume": {
      "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
      "name": "fv",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
        }
      }
    },
    "index": 1153202979583557632,
    "_links": {

```

```

    "self": {
      "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-005056a7f717/1153202979583557632"
    }
  },
  {
    "svm": {
      "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
      "name": "svml",
      "_links": {
        "self": {
          "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
      }
    },
    "volume": {
      "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
      "name": "fv",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717"
        }
      }
    },
    "index": 2305843013508661248,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-005056a7f717/2305843013508661248"
      }
    }
  },
  {
    "svm": {
      "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
      "name": "svml",
      "_links": {
        "self": {
          "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
      }
    },
    "volume": {
      "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",

```

```

    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
      }
    }
  },
  "index": 3458764513820540928,
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/3458764513820540928"
    }
  }
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  }
},
  "volume": {
    "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
      }
    }
  }
},
  "index": 3459045988797251584,
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/3459045988797251584"
    }
  }
}
},
{
  "svm": {

```

```

    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
      }
    }
  },
  "index": 4611686018427387904,
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-
005056a7f717/4611686018427387904"
    }
  }
},
{
  "svm": {
    "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
      }
    }
  },
  "volume": {
    "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-
005056a7f717"
      }
    }
  }
},

```

```
    "index": 4611967493404098560,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-005056a7f717/4611967493404098560"
      }
    }
  },
  {
    "svm": {
      "uuid": "b68f961b-4cee-11e9-930a-005056a7f717",
      "name": "svml",
      "_links": {
        "self": {
          "href": "/api/svm/svms/b68f961b-4cee-11e9-930a-005056a7f717"
        }
      }
    },
    "volume": {
      "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
      "name": "fv",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717"
        }
      }
    },
    "index": 5764607523034234880,
    "_links": {
      "self": {
        "href": "/api/storage/quota/reports/cb20da45-4f6b-11e9-9a71-005056a7f717/5764607523034234880"
      }
    }
  }
],
"num_records": 15,
"_links": {
  "self": {
    "href": "/api/storage/quota/reports/"
  }
}
}
```

## Retrieving a specific quota report record

This API is used to retrieve a specific quota report record.

The following example shows how to retrieve a single quota report user record.

```
# The API:
GET /api/storage/quota/reports/{volume.uuid}/{index}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/281474976710656" -H 'accept: application/hal+json'

# Response for quota report user record:
{
  "svm": {
    "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
      }
    }
  },
  "volume": {
    "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
      }
    }
  },
  "index": 281474976710656,
  "type": "user",
  "users": [
    {
      "name": "fred",
      "id" : "300008"
    }
  ],
  "qtree": {
    "name": "qt1",
    "id": 1,
    "_links": {
```

```

    "self": {
      "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
    }
  },
  "space": {
    "hard_limit": 41943040,
    "soft_limit": 31457280,
    "used": {
      "total": 10567680,
      "soft_limit_percent": 34,
      "hard_limit_percent": 25
    }
  },
  "files": {
    "soft_limit": 30,
    "hard_limit": 40,
    "used": {
      "total": 11,
      "soft_limit_percent": 37,
      "hard_limit_percent": 28
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/281474976710656"
    }
  }
}

```

---

### Retrieving a single quota report multi-user record

---

```

# The API:
GET /api/storage/quota/reports/{volume.uuid}/{index}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/281474976710656" -H 'accept: application/hal+json'

# Response for quota report multi-user record:
{

```



```
"svm": {
  "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
  "name": "svml",
  "_links": {
    "self": {
      "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
    }
  }
},
"volume": {
  "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
  "name": "fv",
  "_links": {
    "self": {
      "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
    }
  }
},
"index": 1153484454560268288,
"type": "user",
"users": [
  {
    "name": "fred",
    "id" : "300008"
  },
  {
    "name": "john",
    "id" : "300009"
  },
  {
    "name": "smith",
    "id" : "300010"
  }
],
"qtree": {
  "name": "qt1",
  "id": 1,
  "_links": {
    "self": {
      "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
    }
  }
},
"space": {
  "hard_limit": 41943040,
  "soft_limit": 31457280,
```

```

    "used": {
      "total": 10567680,
      "soft_limit_percent": 34,
      "hard_limit_percent": 25
    }
  },
  "files": {
    "soft_limit": 30,
    "hard_limit": 40,
    "used": {
      "total": 11,
      "soft_limit_percent": 37,
      "hard_limit_percent": 28
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/1153484454560268288"
    }
  }
}

```

### Retrieving a single quota report group record

```

# The API:
GET /api/storage/quota/reports/{volume.uuid}/{index}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/3459045988797251584" -H 'accept: application/hal+json'

# Response for quota report group record:
{
  "svm": {
    "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
      }
    }
  }
}

```

```
    }
  },
  "volume": {
    "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
      }
    }
  },
  "index": 3459045988797251584,
  "type": "group",
  "group": {
    "name" : "test_group",
    "id"   : "500009"
  },
  "qtree": {
    "name": "qt1",
    "id": 1,
    "_links": {
      "self": {
        "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
      }
    }
  },
  "space": {
    "hard_limit": 41943040,
    "soft_limit": 31457280,
    "used": {
      "total": 10567680,
      "soft_limit_percent": 34,
      "hard_limit_percent": 25
    }
  },
  "files": {
    "soft_limit": 30,
    "hard_limit": 40,
    "used": {
      "total": 11,
      "soft_limit_percent": 37,
      "hard_limit_percent": 28
    }
  },
  "_links": {
    "self": {
```

```
    "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/3459045988797251584"
  }
}
}
```

## Retrieving a single quota report tree record

```
# The API:
GET /api/storage/quota/reports/{volume.uuid}/{index}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/4612248968380809216" -H 'accept: application/hal+json'

# Response for quota report tree record:
{
  "svm": {
    "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
      }
    }
  },
  "volume": {
    "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
      }
    }
  },
  "index": 4612248968380809216,
  "type": "tree",
  "qtree": {
    "name": "qt1",
    "id": 1,
    "_links": {
```

```

    "self": {
      "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
    }
  },
  "space": {
    "hard_limit": 41943040,
    "soft_limit": 31457280,
    "used": {
      "total": 10567680,
      "soft_limit_percent": 34,
      "hard_limit_percent": 25
    }
  },
  "files": {
    "soft_limit": 30,
    "hard_limit": 40,
    "used": {
      "total": 11,
      "soft_limit_percent": 37,
      "hard_limit_percent": 28
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/4612248968380809216"
    }
  }
}

```

---

### Retrieving only records enforced by non-default rules

---

```

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports?show_default_records=false" -H 'accept: application/hal+json'

# Response from only non-default records
{
  "records": [
    {

```

```
"svm": {
  "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
  "name": "svm1",
  "_links": {
    "self": {
      "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
    }
  }
},
"volume": {
  "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
  "name": "fv",
  "_links": {
    "self": {
      "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
    }
  }
},
"index": 4612248968380809216,
"type": "tree",
"qtree": {
  "name": "qt1",
  "id": 1,
  "_links": {
    "self": {
      "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
    }
  }
},
"space": {
  "hard_limit": 41943040,
  "soft_limit": 31457280,
  "used": {
    "total": 10567680,
    "soft_limit_percent": 34,
    "hard_limit_percent": 25
  }
},
"files": {
  "soft_limit": 30,
  "hard_limit": 40,
  "used": {
    "total": 11,
    "soft_limit_percent": 37,
```

```

    "hard_limit_percent": 28
  }
},
"_links": {
  "self": {
    "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/4612248968380809216"
  }
}
},
{
  "svm": {
    "uuid": "5093e722-248e-11e9-96ee-005056a7657c",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/5093e722-248e-11e9-96ee-005056a7657c"
      }
    }
  },
  "volume": {
    "uuid": "cf480c37-2a6b-11e9-8513-005056a7657c",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cf480c37-2a6b-11e9-8513-005056a7657c"
      }
    }
  },
  "index": 1153484454560268288,
  "type": "user",
  "users": [
    {
      "name": "fred",
      "id" : "300008"
    },
    {
      "name": "john",
      "id" : "300009"
    },
    {
      "name": "smith",
      "id" : "300010"
    }
  ],

```

```
"qtree": {
  "name": "qt1",
  "id": 1,
  "_links": {
    "self": {
      "href": "/api/storage/qtrees/cf480c37-2a6b-11e9-8513-005056a7657c/1"
    }
  }
},
"space": {
  "hard_limit": 41943040,
  "soft_limit": 31457280,
  "used": {
    "total": 10567680,
    "soft_limit_percent": 34,
    "hard_limit_percent": 25
  }
},
"files": {
  "soft_limit": 30,
  "hard_limit": 40,
  "used": {
    "total": 11,
    "soft_limit_percent": 37,
    "hard_limit_percent": 28
  }
},
"_links": {
  "self": {
    "href": "/api/storage/quota/reports/cf480c37-2a6b-11e9-8513-005056a7657c/1153484454560268288"
  }
}
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/storage/quota/reports?show_default_records=false"
  }
}
}
```



## Retrieving quota report records with query parameters

The following example shows how to retrieve tree type quota report records.

```
# The API:
GET /api/storage/quota/reports

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/quota/reports?type=tree" -H
'accept: application/hal+json'

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "903e54ee-6ccf-11ea-bc35-005056823577",
        "name": "svml",
        "_links": {
          "self": {
            "href": "/api/svm/svms/903e54ee-6ccf-11ea-bc35-005056823577"
          }
        }
      },
      "volume": {
        "uuid": "8812b000-6e1e-11ea-9bad-00505682cd5c",
        "name": "fv",
        "_links": {
          "self": {
            "href": "/api/storage/volumes/8812b000-6e1e-11ea-9bad-
00505682cd5c"
          }
        }
      },
      "index": 2305843013508661248,
      "type": "tree",
      "_links": {
        "self": {
          "href": "/api/storage/quota/reports/8812b000-6e1e-11ea-9bad-
00505682cd5c/2305843013508661248"
        }
      }
    },
    {
      "svm": {
```

```

    "uuid": "903e54ee-6ccf-11ea-bc35-005056823577",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/903e54ee-6ccf-11ea-bc35-005056823577"
      }
    }
  },
  "volume": {
    "uuid": "a5ceebd2-6ccf-11ea-bc35-005056823577",
    "name": "fg",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/a5ceebd2-6ccf-11ea-bc35-005056823577"
      }
    }
  },
  "index": 2305843013508661248,
  "type": "tree",
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/a5ceebd2-6ccf-11ea-bc35-005056823577/2305843013508661248"
    }
  }
},
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/storage/quota/reports?type=tree"
  }
}
}

```

### Retrieving all the quota reports of a specific volume and the files fields

```

# The API:
GET /api/storage/quota/reports

# The call:

```

```
curl -X GET "https://<mgmt-  
ip>/api/storage/quota/reports?volume.name=fv&fields=files" -H 'accept:  
application/hal+json'  
  
# The response:  
{  
  "records": [  
    {  
      "svm": {  
        "uuid": "903e54ee-6ccf-11ea-bc35-005056823577",  
        "name": "svm1",  
        "_links": {  
          "self": {  
            "href": "/api/svm/svms/903e54ee-6ccf-11ea-bc35-005056823577"  
          }  
        }  
      },  
      "volume": {  
        "uuid": "8812b000-6e1e-11ea-9bad-00505682cd5c",  
        "name": "fv",  
        "_links": {  
          "self": {  
            "href": "/api/storage/volumes/8812b000-6e1e-11ea-9bad-  
00505682cd5c"  
          }  
        }  
      },  
      "index": 410328290557952,  
      "files": {  
        "soft_limit": 20,  
        "hard_limit": 30,  
        "used": {  
          "total": 0,  
          "soft_limit_percent": 0,  
          "hard_limit_percent": 0  
        }  
      },  
      "_links": {  
        "self": {  
          "href": "/api/storage/quota/reports/8812b000-6e1e-11ea-9bad-  
00505682cd5c/410328290557952"  
        }  
      }  
    },  
    {  
      "svm": {
```

```

    "uuid": "903e54ee-6ccf-11ea-bc35-005056823577",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/903e54ee-6ccf-11ea-bc35-005056823577"
      }
    }
  },
  "volume": {
    "uuid": "8812b000-6e1e-11ea-9bad-00505682cd5c",
    "name": "fv",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/8812b000-6e1e-11ea-9bad-
00505682cd5c"
      }
    }
  },
  "index": 2305843013508661248,
  "files": {
    "soft_limit": 200,
    "hard_limit": 400,
    "used": {
      "total": 4,
      "soft_limit_percent": 2,
      "hard_limit_percent": 1
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/reports/8812b000-6e1e-11ea-9bad-
00505682cd5c/2305843013508661248"
    }
  }
},
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/storage/quota/reports?volume.name=fv&fields=files"
  }
}
}
}

```

## Retrieve the quota report records for all FlexVol and FlexGroup volumes

GET /storage/quota/reports

**Introduced In:** 9.6

Retrieves the quota report records for all FlexVol volumes and FlexGroup volumes.

### Related ONTAP commands

- `quota report`

### Parameters

| Name                          | Type    | In    | Required | Description                             |
|-------------------------------|---------|-------|----------|---|
| specifier                     | string  | query | False    | Filter by specifier                     |
| index                         | integer | query | False    | Filter by index                         |
| files.soft_limit              | integer | query | False    | Filter by files.soft_limit              |
| files.used.hard_limit_percent | integer | query | False    | Filter by files.used.hard_limit_percent |
| files.used.total              | integer | query | False    | Filter by files.used.total              |
| files.used.soft_limit_percent | integer | query | False    | Filter by files.used.soft_limit_percent |
| files.hard_limit              | integer | query | False    | Filter by files.hard_limit              |
| space.soft_limit              | integer | query | False    | Filter by space.soft_limit              |
| space.used.hard_limit_percent | integer | query | False    | Filter by space.used.hard_limit_percent |
| space.used.total              | integer | query | False    | Filter by space.used.total              |

| Name                          | Type          | In    | Required | Description   |
|-------------------------------|---------------|-------|----------|---|
| space.used.soft_limit_percent | integer       | query | False    | Filter by space.used.soft_limit_percent   |
| space.hard_limit              | integer       | query | False    | Filter by space.hard_limit  |
| svm.uuid                      | string        | query | False    | Filter by svm.uuid  |
| svm.name                      | string        | query | False    | Filter by svm.name  |
| volume.name                   | string        | query | False    | Filter by volume.name   |
| volume.uuid                   | string        | query | False    | Filter by volume.uuid   |
| qtree.id                      | integer       | query | False    | Filter by qtree.id  |
| qtree.name                    | string        | query | False    | Filter by qtree.name  |
| users.id                      | string        | query | False    | Filter by users.id  |
| users.name                    | string        | query | False    | Filter by users.name  |
| group.name                    | string        | query | False    | Filter by group.name  |
| group.id                      | string        | query | False    | Filter by group.id  |
| type                          | string        | query | False    | Filter by type  |
| show_default_records          | boolean       | query | False    | <p>The default is true for GET calls. When set to false, the default records are not reported.</p> <ul style="list-style-type: none"> <li>• Introduced in: 9.7</li> <li>• Default value: 1</li> </ul> |
| fields                        | array[string] | query | False    | Specify the fields to return.   |
| max_records                   | integer       | query | False    | Limit the number of records returned.   |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                                  | Description       |
|-------------|---------------------------------------|-------------------|
| _links      | <a href="#">_links</a>                |                   |
| num_records | integer                               | Number of records |
| records     | array[ <a href="#">quota_report</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "files": {
      "hard_limit": 0,
      "soft_limit": 0,
      "used": {
        "hard_limit_percent": 0,
        "soft_limit_percent": 0,
        "total": 0
      }
    },
    "group": {
      "id": "string",
      "name": "string"
    },
    "index": 0,
    "qtree": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 1,
      "name": "qt1"
    },
    "space": {
      "hard_limit": 0,
      "soft_limit": 0,
      "used": {
        "hard_limit_percent": 0,
        "soft_limit_percent": 0,

```



```

    "total": 0
  }
},
"specifier": "string",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"type": "tree",
"users": {
  "id": "string",
  "name": "string"
},
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

used

| Name               | Type    | Description   |
|--------------------|---------|---|
| hard_limit_percent | integer | Total files used as a percentage of file hard limit |
| soft_limit_percent | integer | Total files used as a percentage of file soft limit |
| total              | integer | Total files used                                    |

files

| Name       | Type                 | Description     |
|------------|----------------------|-----------------|
| hard_limit | integer              | File hard limit |
| soft_limit | integer              | File soft limit |
| used       | <a href="#">used</a> |                 |

group

This parameter specifies the target group associated with the given quota report record. This parameter is available for group quota records and is not available for user or tree quota records. The target group is identified by a UNIX group name and UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

#### qtree

This parameter specifies the target qtree associated with the user, group, or tree record. For a user/group quota policy rule at volume level, this parameter is not valid. For a default tree quota policy rule, this parameter is specified as "" or "\*". For a tree quota policy rule at qtree level, this parameter specifies a qtree name and a qtree identifier.

| Name   | Type                   | Description                        |
|--------|------------------------|------------------------------------|
| _links | <a href="#">_links</a> |                                    |
| id     | integer                | The unique identifier for a qtree. |
| name   | string                 | The name of the qtree.             |

#### used

| Name               | Type    | Description  |
|--------------------|---------|--|
| hard_limit_percent | integer | Total space used as a percentage of space hard limit |
| soft_limit_percent | integer | Total space used as a percentage of space soft limit |
| total              | integer | Total space used                                     |

#### space

| Name       | Type                 | Description               |
|------------|----------------------|---------------------------|
| hard_limit | integer              | Space hard limit in bytes |
| soft_limit | integer              | Space soft limit in bytes |
| used       | <a href="#">used</a> |                           |

#### svm

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| name | string | The name of the SVM.              |
| uuid | string | The unique identifier of the SVM. |

#### users

| Name | Type   | Description            |
|------|--------|------------------------|
| id   | string | Quota target user ID   |
| name | string | Quota target user name |

#### volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### quota\_report

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| <a href="#">files</a>  | <a href="#">files</a>  |   |
| <a href="#">group</a>  | <a href="#">group</a>  | <p>This parameter specifies the target group associated with the given quota report record. This parameter is available for group quota records and is not available for user or tree quota records. The target group is identified by a UNIX group name and UNIX group identifier.</p> |

| Name      | Type         | Description  |
|-----------|--------------|--|
| index     | integer      | Index that identifies a unique quota record. Valid in URL.   |
| qtree     | qtree        | This parameter specifies the target qtree associated with the user, group, or tree record. For a user/group quota policy rule at volume level, this parameter is not valid. For a default tree quota policy rule, this parameter is specified as "" or "*". For a tree quota policy rule at qtree level, this parameter specifies a qtree name and a qtree identifier.   |
| space     | space        |  |
| specifier | string       | Quota specifier  |
| svm       | svm          |  |
| type      | string       | Quota type associated with the quota record.   |
| users     | array[users] | This parameter specifies the target user or users associated with the given quota report record. This parameter is available for user quota records and is not available for group or tree quota records. The target user or users are identified by a user name and user identifier. The user name can be a UNIX user name or a Windows user name, and the identifier can be a UNIX user identifier or a Windows security identifier. |
| volume    | volume       |  |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a specific quota report record

GET /storage/quota/reports/{volume.uuid}/{index}

**Introduced In:** 9.6

Retrieves a specific quota report record.

### Related ONTAP commands

- `quota report`

### Parameters

| Name        | Type          | In    | Required | Description                   |
|-------------|---------------|-------|----------|-------------------------------|
| volume.uuid | string        | path  | True     | Volume UUID                   |
| index       | integer       | path  | True     | Quota report index            |
| fields      | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| <a href="#">files</a>  | <a href="#">files</a>  |             |

| Name      | Type         | Description  |
|-----------|--------------|--|
| group     | group        | This parameter specifies the target group associated with the given quota report record. This parameter is available for group quota records and is not available for user or tree quota records. The target group is identified by a UNIX group name and UNIX group identifier.   |
| index     | integer      | Index that identifies a unique quota record. Valid in URL.   |
| qtree     | qtree        | This parameter specifies the target qtree associated with the user, group, or tree record. For a user/group quota policy rule at volume level, this parameter is not valid. For a default tree quota policy rule, this parameter is specified as "" or "*". For a tree quota policy rule at qtree level, this parameter specifies a qtree name and a qtree identifier.   |
| space     | space        |  |
| specifier | string       | Quota specifier  |
| svm       | svm          |  |
| type      | string       | Quota type associated with the quota record.   |
| users     | array[users] | This parameter specifies the target user or users associated with the given quota report record. This parameter is available for user quota records and is not available for group or tree quota records. The target user or users are identified by a user name and user identifier. The user name can be a UNIX user name or a Windows user name, and the identifier can be a UNIX user identifier or a Windows security identifier. |
| volume    | volume       |  |



## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "files": {
    "hard_limit": 0,
    "soft_limit": 0,
    "used": {
      "hard_limit_percent": 0,
      "soft_limit_percent": 0,
      "total": 0
    }
  },
  "group": {
    "id": "string",
    "name": "string"
  },
  "index": 0,
  "qtree": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 1,
    "name": "qt1"
  },
  "space": {
    "hard_limit": 0,
    "soft_limit": 0,
    "used": {
      "hard_limit_percent": 0,
      "soft_limit_percent": 0,
      "total": 0
    }
  },
  "specifier": "string",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  }
}
```

```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "type": "tree",
  "users": {
    "id": "string",
    "name": "string"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}

```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description                       |
|------------|-----------------------------------|
| 918235     | A volume with UUID was not found. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

used

| Name               | Type    | Description   |
|--------------------|---------|---|
| hard_limit_percent | integer | Total files used as a percentage of file hard limit |
| soft_limit_percent | integer | Total files used as a percentage of file soft limit |
| total              | integer | Total files used                                    |

files

| Name       | Type                 | Description     |
|------------|----------------------|-----------------|
| hard_limit | integer              | File hard limit |
| soft_limit | integer              | File soft limit |
| used       | <a href="#">used</a> |                 |

group

This parameter specifies the target group associated with the given quota report record. This parameter is available for group quota records and is not available for user or tree quota records. The target group is identified by a UNIX group name and UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

qtree

This parameter specifies the target qtree associated with the user, group, or tree record. For a user/group

quota policy rule at volume level, this parameter is not valid. For a default tree quota policy rule, this parameter is specified as "" or "\*\*\*". For a tree quota policy rule at qtree level, this parameter specifies a qtree name and a qtree identifier.

| Name   | Type                   | Description                        |
|--------|------------------------|------------------------------------|
| _links | <a href="#">_links</a> |                                    |
| id     | integer                | The unique identifier for a qtree. |
| name   | string                 | The name of the qtree.             |

#### used

| Name               | Type    | Description  |
|--------------------|---------|--|
| hard_limit_percent | integer | Total space used as a percentage of space hard limit |
| soft_limit_percent | integer | Total space used as a percentage of space soft limit |
| total              | integer | Total space used                                     |

#### space

| Name       | Type                 | Description               |
|------------|----------------------|---------------------------|
| hard_limit | integer              | Space hard limit in bytes |
| soft_limit | integer              | Space soft limit in bytes |
| used       | <a href="#">used</a> |                           |

#### svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

#### users

| Name | Type   | Description          |
|------|--------|----------------------|
| id   | string | Quota target user ID |

| Name | Type   | Description            |
|------|--------|------------------------|
| name | string | Quota target user name |

volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage quota policy rules

## Storage quota rules endpoint overview

### Overview

Quotas are defined in quota rules specific to FlexVol volumes or FlexGroup volumes. Each quota rule has a type. The type can be "user", "group", or "tree".

&ndash; User rules must have the user property and qtree property.

&ndash; Group rules must have the group property and qtree property.

&ndash; Tree rules must have the qtree property and not have the user or group property.

### Quota policy rule APIs

The following APIs can be used to perform create, retrieve, modify, and delete operations related to quota policy rules.

&ndash; POST /api/storage/quota/rules

&ndash; GET /api/storage/quota/rules

&ndash; GET /api/storage/quota/rules/{rule-uuid}

&ndash; PATCH /api/storage/quota/rules/{rule-uuid}

&ndash; DELETE /api/storage/quota/rules/{rule-uuid}

### Examples

#### Retrieving all quota policy rules

This API is used to retrieve all quota policy rules.

The following example shows how to retrieve quota policy rules for FlexVol volumes and FlexGroup volumes.

```
# The API:
GET /api/storage/quota/rules

# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules' -H 'accept:
application/hal+json'

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "038545f8-9ff8-11e8-bce6-005056a73bed",
        "name": "svm1",
```

```

    "_links": {
      "self": {
        "href": "/api/svm/svms/038545f8-9ff8-11e8-bce6-005056a73bed"
      }
    },
    "volume": {
      "uuid": "ab3df793-0f02-43c6-9514-4f142fc8cc92",
      "name": "voll1",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/ab3df793-0f02-43c6-9514-4f142fc8cc92"
        }
      }
    },
    "uuid": "66319cbe-b837-11e8-9c5a-005056a7e88c",
    "_links": {
      "self": {
        "href": "/api/storage/quota/rules/66319cbe-b837-11e8-9c5a-005056a7e88c"
      }
    }
  },
  {
    "svm": {
      "uuid": "038545f8-9ff8-11e8-bce6-005056a73bed",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/038545f8-9ff8-11e8-bce6-005056a73bed"
        }
      }
    },
    "volume": {
      "uuid": "ab3df793-0f02-43c6-9514-4f142fc8cc92",
      "name": "voll1",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/ab3df793-0f02-43c6-9514-4f142fc8cc92"
        }
      }
    },
    "uuid": "dbd5b443-b7a4-11e8-bc58-005056a7e88c",
    "_links": {

```



```

    "self": {
      "href": "/api/storage/quota/rules/dbd5b443-b7a4-11e8-bc58-005056a7e88c"
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/storage/quota/rules"
  }
}
}

```

### Retrieving a specific quota policy rule

This API is used to retrieve a quota policy rule for a specific qtree.

The following example shows how to retrieve a quota policy user rule for a specific qtree.

```

# The API:
GET /api/storage/quota/rules/{uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules/264a9e0b-2e03-11e9-a610-005056a7b72d' -H 'accept: application/hal+json'

# Response for a user rule at a qtree level:
{
  "svm": {
    "uuid": "fd5db15a-15b9-11e9-a6ad-005056a760e0",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/fd5db15a-15b9-11e9-a6ad-005056a760e0"
      }
    }
  },
  "volume": {
    "uuid": "c1b64eea-ca8b-45ec-9397-ab489830d268",
    "name": "vol1",
    "_links": {

```

```

    "self": {
      "href": "/api/storage/volumes/c1b64eea-ca8b-45ec-9397-
ab489830d268"
    }
  },
  "uuid": "264a9e0b-2e03-11e9-a610-005056a7b72d",
  "type": "user",
  "users": [ {"name" : "fred"} ],
  "qtree": {
    "name": "qt1",
    "id": 1,
    "_links": {
      "self": {
        "href": "/api/storage/qtrees/c1b64eea-ca8b-45ec-9397-
ab489830d268/1"
      }
    }
  },
  "user_mapping": on,
  "space": {
    "hard_limit": 1222800,
    "soft_limit": 51200
  },
  "files": {
    "hard_limit": 100,
    "soft_limit": 80
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/rules/264a9e0b-2e03-11e9-a610-
005056a7b72d"
    }
  }
}

```

### Retrieving a quota policy multi-user rule at the volume level

```

# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules/0ab84fba-19aa-11e9-
a04d-005056a72f42' -H 'accept: application/hal+json'

```

```
# Response for a multi-user rule at volume level:
{
  "svm": {
    "uuid": "fd5db15a-15b9-11e9-a6ad-005056a760e0",
    "name": "svml",
    "_links": {
      "self": {
        "href": "/api/svm/svms/fd5db15a-15b9-11e9-a6ad-005056a760e0"
      }
    }
  },
  "volume": {
    "uuid": "c1b64eea-ca8b-45ec-9397-ab489830d268",
    "name": "voll",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/c1b64eea-ca8b-45ec-9397-
ab489830d268"
      }
    }
  },
  "uuid": "0ab84fba-19aa-11e9-a04d-005056a72f42",
  "type": "user",
  "users": [
    {
      "name": "sam",
    },
    {
      "name": "smith",
    },
    {
      "id": "300010",
    },
  ],
  "space": {
    "hard_limit": 1222800,
    "soft_limit": 51200
  },
  "files": {
    "hard_limit": 100,
    "soft_limit": 80
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/rules/0ab84fba-19aa-11e9-a04d-
005056a72f42"
    }
  }
}
```

```
}  
  }  
}
```

---

### Retrieving a quota policy default tree rule

---

```
# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules/4a276b8c-1753-11e9-8101-005056a760e0' -H 'accept: application/hal+json'

# Response for a default tree rule:
{
  "svm": {
    "uuid": "fd5db15a-15b9-11e9-a6ad-005056a760e0",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/fd5db15a-15b9-11e9-a6ad-005056a760e0"
      }
    }
  },
  "volume": {
    "uuid": "c1b64eea-ca8b-45ec-9397-ab489830d268",
    "name": "voll1",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/c1b64eea-ca8b-45ec-9397-ab489830d268"
      }
    }
  },
  "uuid": "4a276b8c-1753-11e9-8101-005056a760e0",
  "type": "tree",
  "qtree": {
    "name": ""
  },
  "space": {
    "hard_limit": 1034000,
    "soft_limit": 51200
  },
  "files": {
    "hard_limit": 20,
    "soft_limit": 10
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/rules/4a276b8c-1753-11e9-8101-005056a760e0"
    }
  }
}
```

```
# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules/49b1134f-19ab-11e9-
a04d-005056a72f42' -H 'accept: application/hal+json'

# Response for a tree rule for a specific qtree:
{
  "svm": {
    "uuid": "fd5db15a-15b9-11e9-a6ad-005056a760e0",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/fd5db15a-15b9-11e9-a6ad-005056a760e0"
      }
    }
  },
  "volume": {
    "uuid": "c1b64eea-ca8b-45ec-9397-ab489830d268",
    "name": "vol1",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/c1b64eea-ca8b-45ec-9397-
ab489830d268"
      }
    }
  },
  "uuid": "49b1134f-19ab-11e9-a04d-005056a72f42",
  "type": "tree",
  "qtree": {
    "name": "qt1",
    "id": 1,
    "_links": {
      "self": {
        "href": "/api/storage/qtrees/c1b64eea-ca8b-45ec-9397-
ab489830d268/1"
      }
    }
  },
  "space": {
    "hard_limit": 1048576,
    "soft_limit": 838861
  },
  "files": {
    "hard_limit": 100,
```

```
    "soft_limit": 40
  },
  "_links": {
    "self": {
      "href": "/api/storage/quota/rules/49b1134f-19ab-11e9-a04d-005056a72f42"
    }
  }
}
```

### Retrieving a quota policy group rule for a specific qtree

```
# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/quota/rules/b9236852-19ab-11e9-a04d-005056a72f42' -H 'accept: application/hal+json'

# Response for a group rule:
{
  "svm": {
    "uuid": "fd5db15a-15b9-11e9-a6ad-005056a760e0",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/fd5db15a-15b9-11e9-a6ad-005056a760e0"
      }
    }
  },
  "volume": {
    "uuid": "c1b64eea-ca8b-45ec-9397-ab489830d268",
    "name": "voll1",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/c1b64eea-ca8b-45ec-9397-ab489830d268"
      }
    }
  },
  "uuid": "b9236852-19ab-11e9-a04d-005056a72f42",
  "type": "group",
  "group": {"name" : "group1"},
  "qtree": {
    "name": "qt1",
```

```

    "id": 1,
    "_links": {
      "self": {
        "href": "/api/storage/qtrees/clb64eea-ca8b-45ec-9397-
ab489830d268/1"
      }
    },
    "space": {
      "hard_limit": 2097152,
      "soft_limit": 1572864
    },
    "files": {
      "hard_limit": 250,
      "soft_limit": 200
    },
    "_links": {
      "self": {
        "href": "/api/storage/quota/rules/b9236852-19ab-11e9-a04d-
005056a72f42"
      }
    }
  }
}

```

### Creating a quota policy rule

This API is used to create a new quota policy rule. When an explicit rule or a qtree-scoped rule of a type is created on a volume, a default rule of the same type is automatically added if it does not already exist on the volume.

The following example shows how to create a quota policy user rule using POST.

```

# The API:
POST /api/storage/quota/rules

# The call:
curl -X POST 'https://<mgmt-
ip>/api/storage/quota/rules?return_records=true' -H 'accept:
application/hal+json' -d @test_quota_post.txt
test_quota_post.txt (body):
{
  "svm": {
    "name": "svm1"
  }
}

```



```

},
"volume": {
  "name": "voll1"
},
"type": "user",
"users": [ {"name" : "jsmith"} ],
"qtree": {
  "name": "qt1"
},
"user_mapping": "on",
"space": {
  "hard_limit": 8192,
  "soft_limit": 1024
},
"files": {
  "hard_limit": 20,
  "soft_limit": 10
}
}

# The response
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "name": "svml1"
      },
      "volume": {
        "name": "fv"
      },
      "uuid": "3220eea6-5049-11e9-bfb7-005056a7f717",
      "type": "user",
      "users": [
        {
          "name" : "jsmith"
        }
      ],
      "qtree": {
        "name": "qt1"
      },
      "user_mapping": "on",
      "space": {
        "hard_limit": 8192,
        "soft_limit": 1024
      },
    }
  ]
}

```

```

    "files": {
      "hard_limit": 20,
      "soft_limit": 10
    },
    "_links": {
      "self": {
        "href": "/api/storage/quota/rules/3220eea6-5049-11e9-bfb7-005056a7f717"
      }
    }
  ],
  "job": {
    "uuid": "32223924-5049-11e9-bfb7-005056a7f717",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/32223924-5049-11e9-bfb7-005056a7f717"
      }
    }
  }
}

```

---

### Creating a quota policy group rule using POST.

---

```

# The API:
POST /api/storage/quota/rules

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/quota/rules?return_records=true' -H 'accept: application/hal+json' -d @test_quota_post.txt
test_quota_post.txt (body):
{
  "svm": {
    "name": "svm1"
  },
  "volume": {
    "name": "voll1"
  },
  "type": "group",
  "group": {
    "name": "test_group1"
  }
}

```

```

},
"qtree": {
  "name": "qt1"
},
"space": {
  "hard_limit": 8192,
  "soft_limit": 1024
},
"files": {
  "hard_limit": 20,
  "soft_limit": 10
}
}

# The response
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "name": "svm1"
      },
      "volume": {
        "name": "fv"
      },
      "uuid": "3b130f7d-504a-11e9-bfb7-005056a7f717",
      "type": "group",
      "group": {
        "name" : "test_group1"
      },
      "qtree": {
        "name": "qt1"
      },
      "space": {
        "hard_limit": 8192,
        "soft_limit": 1024
      },
      "files": {
        "hard_limit": 20,
        "soft_limit": 10
      },
      "_links": {
        "self": {
          "href": "/api/storage/quota/rules/3b130f7d-504a-11e9-bfb7-005056a7f717"
        }
      }
    }
  ]
}

```

```

    }
  }
],
"job": {
  "uuid": "32223924-5049-11e9-bfb7-005056a7f717",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/32223924-5049-11e9-bfb7-005056a7f717"
    }
  }
}
}
}

```

### Creating a quota policy tree rule using POST

```

# The API:
POST /api/storage/quota/rules

# The call:
curl -X POST 'https://<mgmt-
ip>/api/storage/quota/rules?return_records=true' -H 'accept:
application/hal+json' -d @test_quota_post.txt
test_quota_post.txt (body):
{
  "svm": {
    "name": "svm1"
  },
  "volume": {
    "name": "voll1"
  },
  "type": "tree",
  "qtree": {
    "name": "qt1"
  },
  "space": {
    "hard_limit": 8192,
    "soft_limit": 1024
  },
  "files": {
    "hard_limit": 20,
    "soft_limit": 10
  }
}

```

```

}

# The response
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "name": "svm1"
      },
      "volume": {
        "name": "fv"
      },
      "uuid": "e5eb03be-504a-11e9-bfb7-005056a7f717",
      "type": "tree",
      "qtree": {
        "name": "qt1"
      },
      "space": {
        "hard_limit": 8192,
        "soft_limit": 1024
      },
      "files": {
        "hard_limit": 20,
        "soft_limit": 10
      },
      "_links": {
        "self": {
          "href": "/api/storage/quota/rules/e5eb03be-504a-11e9-bfb7-
005056a7f717"
        }
      }
    },
    {
      "job": {
        "uuid": "32223924-5049-11e9-bfb7-005056a7f717",
        "_links": {
          "self": {
            "href": "/api/cluster/jobs/32223924-5049-11e9-bfb7-005056a7f717"
          }
        }
      }
    }
  ]
}

```

## Updating the quota policy rule

This API is used to update a quota policy rule.

The following example shows how to update a quota policy rule.

```
# The API:
PATCH /storage/quota/rules/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/quota/rules/364d38eb-8e87-11e8-a806-005056a7e73a" -H 'accept: application/hal+json' -d
"@test_quota_patch.txt"
test_quota_patch.txt(body):
{
  "space": {
    "hard_limit": 16554,
    "soft_limit": 8192
  },
  "files": {
    "hard_limit": 40,
    "soft_limit": 20
  }
}
```

## Deleting the quota policy rule

This API is used to delete a quota policy rule.

The following example shows how to delete a quota policy rule.

```
# The API:
DELETE /storage/quota/rules/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/quota/rules/364d38eb-8e87-11e8-a806-005056a7e73a" -H 'accept: application/hal+json'
```

## Retrieve quota policy rules for all FlexVol and FlexGroup volumes

GET /storage/quota/rules

**Introduced In:** 9.6

Retrieves quota policy rules configured for all FlexVol volumes and FlexGroup volumes.

### Related ONTAP commands

- `quota policy rule show`

### Parameters

| Name             | Type    | In    | Required | Description                |
|------------------|---------|-------|----------|----------------------------|
| uuid             | string  | query | False    | Filter by uuid             |
| type             | string  | query | False    | Filter by type             |
| group.name       | string  | query | False    | Filter by group.name       |
| group.id         | string  | query | False    | Filter by group.id         |
| user_mapping     | boolean | query | False    | Filter by user_mapping     |
| users.name       | string  | query | False    | Filter by users.name       |
| users.id         | string  | query | False    | Filter by users.id         |
| qtree.id         | integer | query | False    | Filter by qtree.id         |
| qtree.name       | string  | query | False    | Filter by qtree.name       |
| svm.uuid         | string  | query | False    | Filter by svm.uuid         |
| svm.name         | string  | query | False    | Filter by svm.name         |
| volume.name      | string  | query | False    | Filter by volume.name      |
| volume.uuid      | string  | query | False    | Filter by volume.uuid      |
| space.hard_limit | integer | query | False    | Filter by space.hard_limit |

| Name             | Type          | In    | Required | Description   |
|------------------|---------------|-------|----------|---|
| space.soft_limit | integer       | query | False    | Filter by space.soft_limit  |
| files.soft_limit | integer       | query | False    | Filter by files.soft_limit  |
| files.hard_limit | integer       | query | False    | Filter by files.hard_limit  |
| fields           | array[string] | query | False    | Specify the fields to return.   |
| max_records      | integer       | query | False    | Limit the number of records returned.   |
| return_records   | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout   | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by         | array[string] | query | False    | Order results by specified fields and optional [asc   |



## Response

Status: 200, Ok

| Name        | Type                                | Description       |
|-------------|-------------------------------------|-------------------|
| _links      | <a href="#">_links</a>              |                   |
| num_records | integer                             | Number of records |
| records     | array[ <a href="#">quota_rule</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "qtree": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 1,
      "name": "qt1"
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "type": "tree",
    "users": {
    },
    "uuid": "5f1d13a7-f401-11e8-ac1a-005056a7c3b9",
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",

```

```
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

files

| Name       | Type    | Description  |
|------------|---------|--|
| hard_limit | integer | This parameter specifies the hard limit for files. This is valid in POST or PATCH. |
| soft_limit | integer | This parameter specifies the soft limit for files. This is valid in POST or PATCH. |

group

This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

qtree

This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.

| Name   | Type                   | Description                        |
|--------|------------------------|------------------------------------|
| _links | <a href="#">_links</a> |                                    |
| id     | integer                | The unique identifier for a qtree. |
| name   | string                 | The name of the qtree.             |

#### space

| Name       | Type    | Description   |
|------------|---------|---|
| hard_limit | integer | This parameter specifies the space hard limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |
| soft_limit | integer | This parameter specifies the space soft limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |

#### svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

## users

| Name | Type   | Description            |
|------|--------|------------------------|
| id   | string | Quota target user ID   |
| name | string | Quota target user name |

## volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none"><li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li><li>• Introduced in: 9.6</li></ul> |

## quota\_rule

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| files                  | <a href="#">files</a>  |             |

| Name  | Type   | Description  |
|-------|--------|--|
| group | group  | <p>This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.</p> |
| qtree | qtree  | <p>This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.</p>  |
| space | space  |  |
| svm   | svm    |  |
| type  | string | <p>This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.</p>   |

| Name         | Type         | Description   |
|--------------|--------------|---|
| user_mapping | boolean      | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.   |
| users        | array[users] | This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma. |
| uuid         | string       | Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.   |
| volume       | volume       |   |

error\_arguments



| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Create a quota policy rule for a FlexVol or a FlexGroup volume

POST /storage/quota/rules

**Introduced In:** 9.6

Creates a quota policy rule for a FlexVol or a FlexGroup volume.

Important notes:

- Unlike CLI/ONTAPI, the `quota_policy` input is not needed for POST.

### Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the qtree.
- `volume.uuid` or `volume.name` - Existing volume in which to create the qtree.
- `type` - Quota type for the rule. This type can be `user`, `group`, or `tree`.
- `users.name` or `user.id` - If the quota type is `user`, this property takes the user name or user ID. For default user quota rules, the user name must be specified as `""`.
- `group.name` or `group.id` - If the quota type is `group`, this property takes the group name or group ID. For default group quota rules, the group name must be specified as `""`.
- `qtree.name` - Qtree for which to create the rule. For default tree rules, the qtree name must be specified as `""`.

### Recommended optional properties

- `space.hard_limit` - Specifies the space hard limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes.

- `space.soft_limit` - Specifies the space soft limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes.
- `files.hard_limit` - Specifies the hard limit for files.
- `files.soft_limit` - Specifies the soft limit for files.
- `user_mapping` - Specifies the `user_mapping`. This property is valid only for quota policy rules of type `user`.

### Related ONTAP commands

- `quota policy rule create`

### Parameters

| Name                        | Type    | In    | Required | Description  |
|-----------------------------|---------|-------|----------|--|
| <code>return_timeout</code> | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| return_records | boolean | query | False    | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none"> <li>• Default value:</li> </ul> |

### Request Body

| Name   | Type                   | Description  |
|--------|------------------------|--|
| _links | <a href="#">_links</a> |  |
| files  | <a href="#">files</a>  |  |
| group  | <a href="#">group</a>  | <p>This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.</p> |

| Name         | Type    | Description  |
|--------------|---------|--|
| qtree        | qtree   | This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. |
| space        | space   |  |
| svm          | svm     |  |
| type         | string  | This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.  |
| user_mapping | boolean | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.  |

| Name   | Type         | Description  |
|--------|--------------|--|
| users  | array[users] | <p>This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma.</p> |
| uuid   | string       | <p>Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.</p>   |
| volume | volume       |  |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "qtree": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 1,
    "name": "qt1"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "type": "tree",
  "users": {
  },
  "uuid": "5f1d13a7-f401-11e8-ac1a-005056a7c3b9",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |

### Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

### Error

Status: Default

### ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 917927     | The specified volume was not found.   |
| 918232     | Either <code>volume.name</code> or <code>volume.uuid</code> must be provided.                   |
| 918236     | The specified <code>volume.uuid</code> and <code>volume.name</code> refer to different volumes. |
| 2621462    | The specified SVM does not exist.   |
| 2621706    | The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM.     |
| 2621707    | No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be supplied.   |
| 5308501    | Mapping from Windows user to UNIX user for user rule was unsuccessful.                          |
| 5308502    | Mapping from UNIX user to Windows user for user rule was unsuccessful.                          |

| Error Code | Description   |
|------------|---|
| 5308552    | Failed to get default quota policy name for SVM.  |
| 5308561    | Failed to obtain volume quota state or invalid quota state obtained for volume.   |
| 5308562    | users is a required input for creating a user rule and group is not allowed.  |
| 5308563    | group is a required input for creating a group rule and users is not allowed.   |
| 5308564    | qtree.name is a required input for creating a tree rule and users and group are not allowed.  |
| 5308565    | Only one of name or id is allowed for each entry in the users array.  |
| 5308566    | Only one of name or id is allowed for group.  |
| 5308568    | Quota policy rule create operation succeeded, but quota resize failed due to internal error. To activate the rule, disable and enable quotas for this volume. |
| 5308571    | Quota policy rule create operation succeeded, but quota resize is skipped. To activate the rule, disable and enable quotas for this volume.                   |
| 5308573    | Input value is greater than limit for field.  |
| 5308574    | Input value is out of range for field.  |
| 5308575    | Input value is incorrectly larger than listed field.  |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```



## Definitions

## See Definitions

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### files

| Name       | Type    | Description  |
|------------|---------|--|
| hard_limit | integer | This parameter specifies the hard limit for files. This is valid in POST or PATCH. |
| soft_limit | integer | This parameter specifies the soft limit for files. This is valid in POST or PATCH. |

### group

This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

### qtree

This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.

| Name                   | Type                   | Description                        |
|------------------------|------------------------|------------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                    |
| id                     | integer                | The unique identifier for a qtree. |
| name                   | string                 | The name of the qtree.             |

#### space

| Name       | Type    | Description   |
|------------|---------|---|
| hard_limit | integer | This parameter specifies the space hard limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |
| soft_limit | integer | This parameter specifies the space soft limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |

#### svm

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

#### users

| Name | Type   | Description            |
|------|--------|------------------------|
| id   | string | Quota target user ID   |
| name | string | Quota target user name |

#### volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### quota\_rule

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| <a href="#">files</a>  | <a href="#">files</a>  |  |
| <a href="#">group</a>  | <a href="#">group</a>  | <p>This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.</p> |

| Name         | Type    | Description  |
|--------------|---------|--|
| qtree        | qtree   | This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. |
| space        | space   |  |
| svm          | svm     |  |
| type         | string  | This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.  |
| user_mapping | boolean | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.  |

| Name   | Type         | Description   |
|--------|--------------|---|
| users  | array[users] | This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma. |
| uuid   | string       | Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.   |
| volume | volume       |   |

job\_link

| Name   | Type   | Description   |
|--------|--------|---|
| _links | _links |   |
| uuid   | string | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

## error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

## error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a quota policy rule

```
DELETE /storage/quota/rules/{uuid}
```

**Introduced In:** 9.7

Deletes a quota policy rule.

### Related ONTAP commands

- `quota policy rule delete`

### Parameters

| Name | Type   | In   | Required | Description |
|------|--------|------|----------|-------------|
| uuid | string | path | True     | Rule UUID   |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

## Response

Status: 202, Accepted

| Name | Type                     | Description |
|------|--------------------------|-------------|
| job  | <a href="#">job_link</a> |             |



## Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description   |
|------------|---|
| 5308545    | The specified quota rule UUID is invalid.   |
| 5308561    | Failed to obtain volume quota state or invalid quota state obtained for volume.   |
| 5308569    | Quota policy rule delete operation succeeded, but quota resize failed due to internal error.  |
| 5308572    | Quota policy rule delete operation succeeded, however the rule is still being enforced. To stop enforcing the rule, disable quotas and enable them again for this volume. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

job\_link

| Name   | Type                   | Description   |
|--------|------------------------|---|
| _links | <a href="#">_links</a> |   |
| uuid   | string                 | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve quota policy rule properties

GET /storage/quota/rules/{uuid}

## Introduced In: 9.7

Retrieves properties for a specific quota policy rule.

### Related ONTAP commands

- `quota policy rule show`

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| uuid   | string        | path  | True     | Rule UUID                     |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name                   | Type                   | Description   |
|------------------------|------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a> |   |
| <a href="#">files</a>  | <a href="#">files</a>  |   |
| <a href="#">group</a>  | <a href="#">group</a>  | This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier. |

| Name         | Type    | Description  |
|--------------|---------|--|
| qtree        | qtree   | This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. |
| space        | space   |  |
| svm          | svm     |  |
| type         | string  | This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.  |
| user_mapping | boolean | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.  |

| Name   | Type         | Description  |
|--------|--------------|--|
| users  | array[users] | <p>This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma.</p> |
| uuid   | string       | <p>Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.</p>   |
| volume | volume       |  |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "qtree": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 1,
    "name": "qt1"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "type": "tree",
  "users": {
  },
  "uuid": "5f1d13a7-f401-11e8-ac1a-005056a7c3b9",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 5308544    | The specified quota rule UUID is invalid.                                    |
| 5308545    | Unable to retrieve rule for the specified quota rule UUID.                   |
| 5308576    | Parameter <code>show_default_records</code> only allowed for GET collection. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### files

| Name       | Type    | Description  |
|------------|---------|--|
| hard_limit | integer | This parameter specifies the hard limit for files. This is valid in POST or PATCH. |
| soft_limit | integer | This parameter specifies the soft limit for files. This is valid in POST or PATCH. |

### group

This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

### qtree

This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.

| Name                   | Type                   | Description                        |
|------------------------|------------------------|------------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                    |
| id                     | integer                | The unique identifier for a qtree. |
| name                   | string                 | The name of the qtree.             |

#### space

| Name       | Type    | Description   |
|------------|---------|---|
| hard_limit | integer | This parameter specifies the space hard limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |
| soft_limit | integer | This parameter specifies the space soft limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |

#### svm

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

#### users

| Name | Type   | Description            |
|------|--------|------------------------|
| id   | string | Quota target user ID   |
| name | string | Quota target user name |

#### volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update quota policy rule properties

PATCH /storage/quota/rules/{uuid}

**Introduced In:** 9.7

Updates properties of a specific quota policy rule.

Important notes:

- The quota resize functionality is supported with the PATCH operation.
- Quota resize allows you to modify the quota limits, directly in the filesystem.
- The quota must be enabled on a FlexVol or a FlexGroup volume for `quota resize` to take effect.
- If the quota is disabled on the volume, the quota policy rule PATCH API modifies the rule, but this does not affect the limits in the filesystem.

### Related ONTAP commands

- `quota policy rule modify`
- `quota resize`

### Parameters

| Name | Type   | In   | Required | Description |
|------|--------|------|----------|-------------|
| uuid | string | path | True     | Rule UUID   |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| files  | <a href="#">files</a>  |             |

| Name  | Type   | Description  |
|-------|--------|--|
| group | group  | <p>This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.</p> |
| qtree | qtree  | <p>This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.</p>  |
| space | space  |  |
| svm   | svm    |  |
| type  | string | <p>This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.</p>   |

| Name         | Type         | Description   |
|--------------|--------------|---|
| user_mapping | boolean      | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.   |
| users        | array[users] | This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma. |
| uuid         | string       | Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.   |
| volume       | volume       |   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "qtree": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 1,
    "name": "qt1"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "type": "tree",
  "users": {
  },
  "uuid": "5f1d13a7-f401-11e8-ac1a-005056a7c3b9",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

## Response



Status: 202, Accepted

| Name | Type     | Description |
|------|----------|-------------|
| job  | job_link |             |

### Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

### Error

Status: Default

### ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 5308501    | Mapping from Windows user to UNIX user for user rule was unsuccessful.                       |
| 5308502    | Mapping from UNIX user to Windows user for user rule was unsuccessful.                       |
| 5308545    | The specified quota rule UUID is invalid.  |
| 5308561    | Failed to obtain volume quota state or invalid quota state obtained for volume.              |
| 5308567    | Quota policy rule modify operation succeeded, but quota resize failed due to internal error. |
| 5308573    | Input value is greater than limit for field.   |
| 5308574    | Input value is out of range for field.   |
| 5308575    | Input value is incorrectly larger than listed field.   |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### files

| Name       | Type    | Description  |
|------------|---------|--|
| hard_limit | integer | This parameter specifies the hard limit for files. This is valid in POST or PATCH. |
| soft_limit | integer | This parameter specifies the soft limit for files. This is valid in POST or PATCH. |

### group

This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.

| Name | Type   | Description             |
|------|--------|-------------------------|
| id   | string | Quota target group ID   |
| name | string | Quota target group name |

### qtree

This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST.

| Name                   | Type                   | Description                        |
|------------------------|------------------------|------------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                    |
| id                     | integer                | The unique identifier for a qtree. |
| name                   | string                 | The name of the qtree.             |

#### space

| Name       | Type    | Description   |
|------------|---------|---|
| hard_limit | integer | This parameter specifies the space hard limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |
| soft_limit | integer | This parameter specifies the space soft limit, in bytes. If less than 1024 bytes, the value is rounded up to 1024 bytes. Valid in POST or PATCH. For a POST operation where the parameter is either empty or set to -1, no limit is applied. For a PATCH operation where a limit is configured, use a value of -1 to clear the limit. |

#### svm

| Name                   | Type                   | Description                       |
|------------------------|------------------------|-----------------------------------|
| <a href="#">_links</a> | <a href="#">_links</a> |                                   |
| name                   | string                 | The name of the SVM.              |
| uuid                   | string                 | The unique identifier of the SVM. |

#### users

| Name | Type   | Description            |
|------|--------|------------------------|
| id   | string | Quota target user ID   |
| name | string | Quota target user name |

#### volume

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| name                   | string                 | The name of the volume.  |
| uuid                   | string                 | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> <li>• example: 028baa66-41bd-11e9-81d5-00a0986138f7</li> <li>• Introduced in: 9.6</li> </ul> |

#### quota\_rule

| Name                   | Type                   | Description  |
|------------------------|------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a> |  |
| files                  | <a href="#">files</a>  |  |
| group                  | <a href="#">group</a>  | <p>This parameter specifies the target group to which the group quota policy rule applies. This parameter takes a group name or identifier. This parameter is only valid for the POST operation of a group quota policy rule. The POST operation will fail with an appropriate error if this parameter is used as an input to create a user or a tree quota policy rule. This input parameter for POST takes either a group name or a group identifier, but not both. For default quota rules, the group name must be chosen and should be specified as "". For explicit group quota rules, this parameter can contain a UNIX group name or a UNIX group identifier.</p> |

| Name         | Type    | Description  |
|--------------|---------|--|
| qtree        | qtree   | This parameter specifies the target qtree to which the user/group/tree quota policy rule applies. For a user/group quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. For a user/group quota policy rule at volume level, this parameter is not valid in GET or POST. For a tree quota policy rule, this parameter is mandatory and is valid in both POST and GET. For a default tree quota policy rule, this parameter needs to be specified as "". For a tree quota policy rule at qtree level, this parameter takes a qtree name and is valid in GET or POST. |
| space        | space   |  |
| svm          | svm     |  |
| type         | string  | This parameter specifies the quota policy rule type. This is required in POST only and can take either one of the "user", "group" or "tree" values.  |
| user_mapping | boolean | This parameter enables user mapping for user quota policy rules. This is valid in POST or PATCH for user quota policy rules only.  |

| Name   | Type         | Description   |
|--------|--------------|---|
| users  | array[users] | This parameter specifies the target user to which the user quota policy rule applies. This parameter takes single or multiple user names or identifiers. This parameter is valid only for the POST operation of a user quota policy rule. If this parameter is used as an input to create a group or a tree quota policy rule, the POST operation will fail with an appropriate error. For POST, this input parameter takes either a user name or a user identifier, not both. For default quota rules, the user name must be chosen and specified as "". For explicit user quota rules, this parameter can indicate either a user name or user identifier. The user name can be a UNIX user name or a Windows user name. If a name contains a space, enclose the entire value in quotes. A UNIX user name cannot include a backslash ( ) or an @ sign; user names with these characters are treated as Windows names. The user identifier can be a UNIX user identifier or a Windows security identifier. For multi-user quota, this parameter can contain multiple user targets separated by a comma. |
| uuid   | string       | Unique identifier for the quota policy rule. This field is generated when the quota policy rule is created.   |
| volume | volume       |   |

job\_link

| Name   | Type   | Description   |
|--------|--------|---|
| _links | _links |   |
| uuid   | string | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

## error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

## error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

# Manage shelves

## Storage shelves endpoint overview

### Retrieving storage shelf information

The storage shelf GET API retrieves all of the shelves in the cluster.

### Examples

#### 1) Retrieve a list of shelves from the cluster

The following example shows the response with a list of shelves in the cluster:

```
# The API:
/api/storage/shelves

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/shelves" -H "accept:
application/hal+json"

# The response:
```



```
{
  "records": [
    {
      "uid": "3109174803597886800",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/3109174803597886800"
        }
      }
    },
    {
      "uid": "9237728366621690448",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/9237728366621690448"
        }
      }
    },
    {
      "uid": "9946762738829886800",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/9946762738829886800"
        }
      }
    },
    {
      "uid": "10318311901725526608",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/10318311901725526608"
        }
      }
    },
    {
      "uid": "13477584846688355664",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/13477584846688355664"
        }
      }
    }
  ],
  "num_records": 5,
  "_links": {
    "self": {
```

```
    "href": "/api/storage/shelves/"
  }
}
}
```

## 2) Retrieve a specific shelf from the cluster

The following example shows the response of the requested shelf. If there is no shelf with the requested uid, an error is returned.

```
# The API:
/api/storage/shelves/{uid}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/shelves/3109174803597886800" -H
"accept: application/hal+json"

# The response:
{
  "uid": "3109174803597886800",
  "name": "6.10",
  "id": "10",
  "serial_number": "SHU0954292N0HAH",
  "model": "DS4246",
  "module_type": "iom6",
  "internal": false,
  "local": true,
  "manufacturer": {
    "name": "NETAPP"
  },
  "state": "ok",
  "connection_type": "sas",
  "disk_count": 24,
  "location_led": "off",
  "paths": [
    {
      "name": "0e",
      "node": {
        "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
        "name": "node-1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
```

```

00a0985a72ee"
    }
  }
},
"_links": {
  "self": {
    "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0e"
  }
}
},
{
  "name": "0g",
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
      }
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0g"
    }
  }
}
],
"bays": [
  {
    "id": 0,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 1,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 2,

```

```
"has_disk": true,
"type": "single_disk",
"state": "ok"
},
{
  "id": 3,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 4,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 5,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 6,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 7,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 8,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 9,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
},
```

```
{
  "id": 10,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 11,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 12,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 13,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 14,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 15,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 16,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 17,
  "has_disk": true,
  "type": "single_disk",
```

```
    "state": "ok"
  },
  {
    "id": 18,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 19,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 20,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 21,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 22,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 23,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  }
],
"frus": [
  {
    "type": "module",
    "id": 0,
    "state": "ok",
    "part_number": "111-00690+B2",
    "serial_number": "8001900099",
```

```

    "firmware_version": "0191",
    "installed": true
  },
  {
    "type": "module",
    "id": 1,
    "state": "ok",
    "part_number": "111-00190+B0",
    "serial_number": "7903785183",
    "firmware_version": "0191",
    "installed": true
  },
  {
    "type": "psu",
    "id": 1,
    "state": "ok",
    "part_number": "0082562-12",
    "serial_number": "PMW82562007513E",
    "firmware_version": "0311",
    "installed": true,
    "psu": {
      "model": "9C"
    }
  },
  {
    "type": "psu",
    "id": 2,
    "state": "ok",
    "part_number": "0082562-12",
    "serial_number": "PMW825620075138",
    "firmware_version": "0311",
    "installed": true,
    "psu": {
      "model": "9C"
    }
  },
  {
    "type": "psu",
    "id": 3,
    "state": "ok",
    "part_number": "0082562-12",
    "serial_number": "PMW8256200750BA",
    "firmware_version": "0311",
    "installed": true,
    "psu": {
      "model": "9C"
    }
  }

```

```

    }
  },
  {
    "type": "psu",
    "id": 4,
    "state": "ok",
    "part_number": "0082562-12",
    "serial_number": "PMW8256200750A2",
    "firmware_version": "0311",
    "installed": true,
    "psu": {
      "model": "9C"
    }
  }
],
"ports": [
  {
    "id": 0,
    "module_id": "a",
    "designator": "square",
    "state": "connected",
    "internal": false,
    "wwn": "500A098000C9EDBF",
    "cable": {
      "identifier": "5001086000702488-500a098000c9edbf",
      "part_number": "112-00430+A0",
      "length": "2m",
      "serial_number": "APF16510229807"
    },
    "remote": {
      "wwn": "5001086000702488",
      "phy": "08"
    }
  },
  {
    "id": 1,
    "module_id": "a",
    "designator": "circle",
    "state": "connected",
    "internal": false,
    "wwn": "500A098000C9EDBF",
    "cable": {
      "identifier": "500a098000d5c4bf-500a098000c9edbf",
      "part_number": "112-00176+A0",
      "length": "0.5-1.0m",
      "serial_number": "APF133917610YT"
    }
  }
]

```



```

    },
    "remote": {
      "wwn": "500A098000D5C4BF",
      "phy": "00"
    }
  },
  {
    "id": 2,
    "module_id": "b",
    "designator": "square",
    "state": "connected",
    "internal": false,
    "wwn": "500A098004F208BF",
    "cable": {
      "identifier": "5001086000702648-500a098004f208bf",
      "part_number": "112-00430+A0",
      "length": "2m",
      "serial_number": "APF16510229540"
    },
    "remote": {
      "wwn": "5001086000702648",
      "phy": "08"
    }
  },
  {
    "id": 3,
    "module_id": "b",
    "designator": "circle",
    "state": "connected",
    "internal": false,
    "wwn": "500A098004F208BF",
    "cable": {
      "identifier": "500a0980062ba33f-500a098004f208bf",
      "part_number": "112-00176+20",
      "length": "0.5-1.0m",
      "serial_number": "832210017"
    },
    "remote": {
      "wwn": "500A0980062BA33F",
      "phy": "00"
    }
  }
],
"fans": [
  {
    "id": 1,

```

```
"location": "rear of the shelf on the upper left power supply",
"rpm": 3150,
"state": "ok"
},
{
  "id": 2,
  "location": "rear of the shelf on the upper left power supply",
  "rpm": 3000,
  "state": "ok"
},
{
  "id": 3,
  "location": "rear of the shelf on the upper right power supply",
  "rpm": 3220,
  "state": "ok"
},
{
  "id": 4,
  "location": "rear of the shelf on the upper right power supply",
  "rpm": 3000,
  "state": "ok"
},
{
  "id": 5,
  "location": "rear of the shelf on the lower left power supply",
  "rpm": 3000,
  "state": "ok"
},
{
  "id": 6,
  "location": "rear of the shelf on the lower left power supply",
  "rpm": 3150,
  "state": "ok"
},
{
  "id": 7,
  "location": "rear of the shelf on the lower right power supply",
  "rpm": 3150,
  "state": "ok"
},
{
  "id": 8,
  "location": "rear of the shelf on the lower right power supply",
  "rpm": 3000,
  "state": "ok"
}
```

```
],
"temperature_sensors": [
  {
    "id": 1,
    "location": "front of the shelf on the left, on the OPS panel",
    "temperature": 20,
    "ambient": true,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 42,
        "warning": 40
      },
      "low": {
        "critical": 0,
        "warning": 5
      }
    }
  },
  {
    "id": 2,
    "location": "inside of the shelf on the midplane",
    "temperature": 29,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 55,
        "warning": 50
      },
      "low": {
        "critical": 5,
        "warning": 10
      }
    }
  },
  {
    "id": 3,
    "location": "rear of the shelf on the upper left power supply",
    "temperature": 33,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 55,
        "warning": 50
      }
    }
  }
]
```

```

    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  },
  {
    "id": 4,
    "location": "rear of the shelf on the upper left power supply",
    "temperature": 41,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 70,
        "warning": 65
      },
      "low": {
        "critical": 5,
        "warning": 10
      }
    }
  },
  {
    "id": 5,
    "location": "rear of the shelf on the upper right power supply",
    "temperature": 32,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 55,
        "warning": 50
      },
      "low": {
        "critical": 5,
        "warning": 10
      }
    }
  },
  {
    "id": 6,
    "location": "rear of the shelf on the upper right power supply",
    "temperature": 41,
    "ambient": false,

```

```
"state": "ok",
"threshold": {
  "high": {
    "critical": 70,
    "warning": 65
  },
  "low": {
    "critical": 5,
    "warning": 10
  }
}
},
{
  "id": 7,
  "location": "rear of the shelf on the lower left power supply",
  "temperature": 34,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 55,
      "warning": 50
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}
},
{
  "id": 8,
  "location": "rear of the shelf on the lower left power supply",
  "temperature": 45,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 70,
      "warning": 65
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}
},
```

```
{
  "id": 9,
  "location": "rear of the shelf on the lower right power supply",
  "temperature": 30,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 55,
      "warning": 50
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
},
{
  "id": 10,
  "location": "rear of the shelf on the lower right power supply",
  "temperature": 40,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 70,
      "warning": 65
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
},
{
  "id": 11,
  "location": "rear of the shelf at the top left, on shelf module A",
  "temperature": 30,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 60,
      "warning": 55
    },
    "low": {
```

```
        "critical": 5,
        "warning": 10
    }
}
},
{
    "id": 12,
    "location": "rear of the shelf at the top right, on shelf module B",
    "temperature": 33,
    "ambient": false,
    "state": "ok",
    "threshold": {
        "high": {
            "critical": 60,
            "warning": 55
        },
        "low": {
            "critical": 5,
            "warning": 10
        }
    }
}
],
"voltage_sensors": [
    {
        "id": 1,
        "location": "rear of the shelf on the upper left power supply",
        "voltage": 5.11,
        "state": "ok"
    },
    {
        "id": 2,
        "location": "rear of the shelf on the upper left power supply",
        "voltage": 12.38,
        "state": "ok"
    },
    {
        "id": 3,
        "location": "rear of the shelf on the upper right power supply",
        "voltage": 5.11,
        "state": "ok"
    },
    {
        "id": 4,
        "location": "rear of the shelf on the upper right power supply",
        "voltage": 12.26,
```

```
    "state": "ok"
  },
  {
    "id": 5,
    "location": "rear of the shelf on the lower left power supply",
    "voltage": 5.7,
    "state": "ok"
  },
  {
    "id": 6,
    "location": "rear of the shelf on the lower left power supply",
    "voltage": 12.26,
    "state": "ok"
  },
  {
    "id": 7,
    "location": "rear of the shelf on the lower right power supply",
    "voltage": 5.15,
    "state": "ok"
  },
  {
    "id": 8,
    "location": "rear of the shelf on the lower right power supply",
    "voltage": 12.3,
    "state": "ok"
  }
],
"current_sensors": [
  {
    "id": 1,
    "location": "rear of the shelf on the upper left power supply",
    "current": 6990,
    "state": "ok"
  },
  {
    "id": 2,
    "location": "rear of the shelf on the upper left power supply",
    "current": 5150,
    "state": "ok"
  },
  {
    "id": 3,
    "location": "rear of the shelf on the upper right power supply",
    "current": 4600,
    "state": "ok"
  },
  {
```



```

{
  "id": 4,
  "location": "rear of the shelf on the upper right power supply",
  "current": 4800,
  "state": "ok"
},
{
  "id": 5,
  "location": "rear of the shelf on the lower left power supply",
  "current": 4140,
  "state": "ok"
},
{
  "id": 6,
  "location": "rear of the shelf on the lower left power supply",
  "current": 7770,
  "state": "ok"
},
{
  "id": 7,
  "location": "rear of the shelf on the lower right power supply",
  "current": 4140,
  "state": "ok"
},
{
  "id": 8,
  "location": "rear of the shelf on the lower right power supply",
  "current": 4720,
  "state": "ok"
}
],
"acps": [
  {
    "enabled": true,
    "channel": "in_band",
    "connection_state": "active",
    "node": {
      "uuid": "cf62d23c-6100-11eb-9852-00a098fd725d",
      "name": "cat33-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/cf62d23c-6100-11eb-9852-00a098fd725d"
        }
      }
    }
  }
]

```

```
},
{
  "enabled": true,
  "channel": "in_band",
  "connection_state": "active",
  "node": {
    "uuid": "d0892dd7-6100-11eb-9cdb-d039ea010238",
    "name": "cat33-02",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/d0892dd7-6100-11eb-9cdb-
d039ea010238"
      }
    }
  }
},
"_links": {
  "self": {
    "href": "/api/storage/shelves/3109174803597886800"
  }
}
}
```

## Modifying storage shelf

The storage shelf PATCH API modifies the shelf location LED.

## Example

```
# The API:
/api/storage/shelves

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/shelves/3109174803597886800"
-H "accept: application/hal+json" -H "Content-Type: application/hal+json"
-d '{"location_led": "on"}'

# The response:
{
}
```

## Retrieve shelves

GET /storage/shelves

**Introduced In:** 9.6

Retrieves a collection of shelves.

### Related ONTAP commands

- storage shelf show
- storage shelf port show
- storage shelf drawer show
- storage shelf drawer show-slot
- storage shelf acp show

### Learn more

- [DOC /storage/shelves](#)

### Parameters

| Name                   | Type   | In    | Required | Description                      |
|------------------------|--------|-------|----------|----------------------------------|
| name                   | string | query | False    | Filter by name                   |
| ports.cable.identifier | string | query | False    | Filter by ports.cable.identifier |
| ports.cable.length     | string | query | False    | Filter by ports.cable.length     |

| Name                      | Type    | In    | Required | Description   |
|---------------------------|---------|-------|----------|---|
| ports.cable.part_number   | string  | query | False    | Filter by ports.cable.part_number                         |
| ports.cable.serial_number | string  | query | False    | Filter by ports.cable.serial_number                       |
| ports.remote.chassis      | string  | query | False    | Filter by ports.remote.chassis                            |
| ports.remote.wwn          | string  | query | False    | Filter by ports.remote.wwn                                |
| ports.remote.port         | string  | query | False    | Filter by ports.remote.port                               |
| ports.remote.phy          | string  | query | False    | Filter by ports.remote.phy                                |
| ports.remote.mac_address  | string  | query | False    | Filter by ports.remote.mac_address                        |
| ports.remote.device       | string  | query | False    | Filter by ports.remote.device<br><br>• Introduced in: 9.8 |
| ports.wwn                 | string  | query | False    | Filter by ports.wwn                                       |
| ports.state               | string  | query | False    | Filter by ports.state                                     |
| ports.designator          | string  | query | False    | Filter by ports.designator                                |
| ports.id                  | integer | query | False    | Filter by ports.id  |
| ports.internal            | boolean | query | False    | Filter by ports.internal                                  |
| ports.module_id           | string  | query | False    | Filter by ports.module_id                                 |

| Name                  | Type    | In    | Required | Description  |
|-----------------------|---------|-------|----------|--|
| ports.mac_address     | string  | query | False    | Filter by ports.mac_address                                  |
| frus.installed        | boolean | query | False    | Filter by frus.installed<br><br>• Introduced in: 9.10        |
| frus.psu.power_rating | integer | query | False    | Filter by frus.psu.power_rating<br><br>• Introduced in: 9.10 |
| frus.psu.crest_factor | integer | query | False    | Filter by frus.psu.crest_factor<br><br>• Introduced in: 9.10 |
| frus.psu.power_drawn  | integer | query | False    | Filter by frus.psu.power_drawn<br><br>• Introduced in: 9.10  |
| frus.psu.model        | string  | query | False    | Filter by frus.psu.model<br><br>• Introduced in: 9.10        |
| frus.firmware_version | string  | query | False    | Filter by frus.firmware_version                              |
| frus.state            | string  | query | False    | Filter by frus.state   |
| frus.serial_number    | string  | query | False    | Filter by frus.serial_number                                 |
| frus.id               | integer | query | False    | Filter by frus.id  |
| frus.part_number      | string  | query | False    | Filter by frus.part_number                                   |

| Name                            | Type    | In    | Required | Description  |
|---------------------------------|---------|-------|----------|--|
| frus.type                       | string  | query | False    | Filter by frus.type  |
| module_type                     | string  | query | False    | Filter by module_type  |
| bays.type                       | string  | query | False    | Filter by bays.type  |
| bays.state                      | string  | query | False    | Filter by bays.state   |
| bays.drawer.slot                | integer | query | False    | Filter by bays.drawer.slot<br><br>• Introduced in: 9.11                |
| bays.drawer.id                  | integer | query | False    | Filter by bays.drawer.id<br><br>• Introduced in: 9.11                  |
| bays.id                         | integer | query | False    | Filter by bays.id  |
| bays.has_disk                   | boolean | query | False    | Filter by bays.has_disk  |
| connection_type                 | string  | query | False    | Filter by connection_type  |
| errors.reason.arguments.message | string  | query | False    | Filter by errors.reason.arguments.message<br><br>• Introduced in: 9.10 |
| errors.reason.arguments.code    | string  | query | False    | Filter by errors.reason.arguments.code<br><br>• Introduced in: 9.10    |

| Name                  | Type    | In    | Required | Description  |
|-----------------------|---------|-------|----------|--|
| errors.reason.target  | string  | query | False    | Filter by errors.reason.target<br><br>• Introduced in: 9.10  |
| errors.reason.code    | string  | query | False    | Filter by errors.reason.code<br><br>• Introduced in: 9.9     |
| errors.reason.message | string  | query | False    | Filter by errors.reason.message<br><br>• Introduced in: 9.9  |
| acps.connection_state | string  | query | False    | Filter by acps.connection_state<br><br>• Introduced in: 9.10 |
| acps.enabled          | boolean | query | False    | Filter by acps.enabled<br><br>• Introduced in: 9.10          |
| acps.netmask          | string  | query | False    | Filter by acps.netmask<br><br>• Introduced in: 9.10          |
| acps.port             | string  | query | False    | Filter by acps.port<br><br>• Introduced in: 9.10             |
| acps.error.type       | string  | query | False    | Filter by acps.error.type<br><br>• Introduced in: 9.10       |

| Name                                | Type   | In    | Required | Description  |
|-------------------------------------|--------|-------|----------|--|
| acps.error.severity                 | string | query | False    | Filter by acps.error.severity<br><br>• Introduced in: 9.10                 |
| acps.error.reason.arguments.message | string | query | False    | Filter by acps.error.reason.arguments.message<br><br>• Introduced in: 9.10 |
| acps.error.reason.arguments.code    | string | query | False    | Filter by acps.error.reason.arguments.code<br><br>• Introduced in: 9.10    |
| acps.error.reason.target            | string | query | False    | Filter by acps.error.reason.target<br><br>• Introduced in: 9.10            |
| acps.error.reason.code              | string | query | False    | Filter by acps.error.reason.code<br><br>• Introduced in: 9.10              |
| acps.error.reason.message           | string | query | False    | Filter by acps.error.reason.message<br><br>• Introduced in: 9.10           |
| acps.channel                        | string | query | False    | Filter by acps.channel<br><br>• Introduced in: 9.10                        |



| Name               | Type    | In    | Required | Description   |
|--------------------|---------|-------|----------|---|
| acps.subnet        | string  | query | False    | Filter by acps.subnet<br><br>• Introduced in: 9.10        |
| acps.node.uuid     | string  | query | False    | Filter by acps.node.uuid<br><br>• Introduced in: 9.10     |
| acps.node.name     | string  | query | False    | Filter by acps.node.name<br><br>• Introduced in: 9.10     |
| acps.address       | string  | query | False    | Filter by acps.address<br><br>• Introduced in: 9.10       |
| state              | string  | query | False    | Filter by state   |
| serial_number      | string  | query | False    | Filter by serial_number                                   |
| id                 | string  | query | False    | Filter by id  |
| internal           | boolean | query | False    | Filter by internal  |
| local              | boolean | query | False    | Filter by local<br><br>• Introduced in: 9.8               |
| model              | string  | query | False    | Filter by model   |
| voltage_sensors.id | integer | query | False    | Filter by voltage_sensors.id<br><br>• Introduced in: 9.10 |

| Name                     | Type    | In    | Required | Description   |
|--------------------------|---------|-------|----------|---|
| voltage_sensors.location | string  | query | False    | Filter by voltage_sensors.location<br><br>• Introduced in: 9.10 |
| voltage_sensors.voltage  | number  | query | False    | Filter by voltage_sensors.voltage<br><br>• Introduced in: 9.10  |
| voltage_sensors.state    | string  | query | False    | Filter by voltage_sensors.state<br><br>• Introduced in: 9.10    |
| paths.node.uuid          | string  | query | False    | Filter by paths.node.uuid                                       |
| paths.node.name          | string  | query | False    | Filter by paths.node.name                                       |
| paths.name               | string  | query | False    | Filter by paths.name  |
| disk_count               | integer | query | False    | Filter by disk_count  |
| drawers.closed           | boolean | query | False    | Filter by drawers.closed  |
| drawers.state            | string  | query | False    | Filter by drawers.state   |
| drawers.serial_number    | string  | query | False    | Filter by drawers.serial_number                                 |
| drawers.disk_count       | integer | query | False    | Filter by drawers.disk_count                                    |
| drawers.id               | integer | query | False    | Filter by drawers.id  |

| Name                     | Type    | In    | Required | Description   |
|--------------------------|---------|-------|----------|---|
| drawers.error            | string  | query | False    | Filter by drawers.error   |
| drawers.part_number      | string  | query | False    | Filter by drawers.part_number                                   |
| manufacturer.name        | string  | query | False    | Filter by manufacturer.name<br><br>• Introduced in: 9.10        |
| current_sensors.state    | string  | query | False    | Filter by current_sensors.state<br><br>• Introduced in: 9.10    |
| current_sensors.current  | integer | query | False    | Filter by current_sensors.current<br><br>• Introduced in: 9.10  |
| current_sensors.location | string  | query | False    | Filter by current_sensors.location<br><br>• Introduced in: 9.10 |
| current_sensors.id       | integer | query | False    | Filter by current_sensors.id<br><br>• Introduced in: 9.10       |
| fans.state               | string  | query | False    | Filter by fans.state<br><br>• Introduced in: 9.9                |
| fans.id                  | integer | query | False    | Filter by fans.id<br><br>• Introduced in: 9.9                   |

| Name  | Type    | In    | Required | Description  |
|---|---------|-------|----------|--|
| fans.location                               | string  | query | False    | Filter by fans.location<br><br>• Introduced in: 9.9                                |
| fans.rpm                                    | integer | query | False    | Filter by fans.rpm<br><br>• Introduced in: 9.9                                     |
| temperature_sensors.state                   | string  | query | False    | Filter by temperature_sensors.state<br><br>• Introduced in: 9.10                   |
| temperature_sensors.ambient                 | boolean | query | False    | Filter by temperature_sensors.ambient<br><br>• Introduced in: 9.10                 |
| temperature_sensors.threshold.high.critical | integer | query | False    | Filter by temperature_sensors.threshold.high.critical<br><br>• Introduced in: 9.10 |
| temperature_sensors.threshold.high.warning  | integer | query | False    | Filter by temperature_sensors.threshold.high.warning<br><br>• Introduced in: 9.10  |
| temperature_sensors.threshold.low.critical  | integer | query | False    | Filter by temperature_sensors.threshold.low.critical<br><br>• Introduced in: 9.10  |

| Name                                      | Type    | In    | Required | Description  |
|---|---------|-------|----------|--|
| temperature_sensors.threshold.low.warning | integer | query | False    | Filter by temperature_sensors.threshold.low.warning<br><br>• Introduced in: 9.10 |
| temperature_sensors.id                    | integer | query | False    | Filter by temperature_sensors.id<br><br>• Introduced in: 9.10                    |
| temperature_sensors.location              | string  | query | False    | Filter by temperature_sensors.location<br><br>• Introduced in: 9.10              |
| temperature_sensors.temperature           | integer | query | False    | Filter by temperature_sensors.temperature<br><br>• Introduced in: 9.10           |
| uid                                       | string  | query | False    | Filter by uid  |
| location_led                              | string  | query | False    | Filter by location_led<br><br>• Introduced in: 9.10                              |
| vendor.serial_number                      | string  | query | False    | Filter by vendor.serial_number<br><br>• Introduced in: 9.8                       |
| vendor.part_number                        | string  | query | False    | Filter by vendor.part_number<br><br>• Introduced in: 9.8                         |

| Name                | Type          | In    | Required | Description  |
|---------------------|---------------|-------|----------|--|
| vendor.product      | string        | query | False    | Filter by vendor.product <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul>  |
| vendor.manufacturer | string        | query | False    | Filter by vendor.manufacturer <ul style="list-style-type: none"> <li>• Introduced in: 9.8</li> </ul>   |
| vendor.name         | string        | query | False    | Filter by vendor.name <ul style="list-style-type: none"> <li>• Introduced in: 9.10</li> </ul>  |
| fields              | array[string] | query | False    | Specify the fields to return.  |
| max_records         | integer       | query | False    | Limit the number of records returned.  |
| return_records      | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul> |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                           | Description       |
|-------------|--------------------------------|-------------------|
| _links      | <a href="#">_links</a>         |                   |
| num_records | integer                        | Number of records |
| records     | array[ <a href="#">shelf</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "acps": {
      "address": "192.168.1.104",
      "channel": "out_of_band",
      "connection_state": "full_connectivity",
      "error": {
        "reason": {
          "arguments": {
            "code": "string",
            "message": "string"
          },
          "code": "4",
          "message": "entry doesn't exist",
          "target": "uuid"
        },
        "severity": "unknown",
        "type": "not_applicable"
      },
      "netmask": "255.255.252.0",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "port": "e0P",
      "subnet": "192.168.0.1"
    },
    "bays": {
      "drawer": {
        "id": 1,
        "slot": 0
      }
    }
  }
}
```



```

    },
    "id": 0,
    "state": "ok",
    "type": "single_disk"
  },
  "connection_type": "sas",
  "current_sensors": {
    "current": 14410,
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "state": "ok"
  },
  "disk_count": 12,
  "drawers": {
    "disk_count": 12,
    "part_number": "111-03071",
    "serial_number": "021604008263",
    "state": "ok"
  },
  "errors": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "fans": {
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "rpm": 3020,
    "state": "ok"
  },
  "frus": {
    "firmware_version": "0191",
    "installed": 1,
    "part_number": "111-00690+A2",
    "psu": {
      "crest_factor": 92,
      "model": "00",
      "power_drawn": 210,
      "power_rating": 1600
    }
  },

```

```

    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
  },
  "id": "1",
  "location_led": "off",
  "manufacturer": {
    "name": "NETAPP"
  },
  "model": "DS2246",
  "module_type": "iom6",
  "name": "1.1",
  "paths": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "2a",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "ports": {
    "cable": {
      "identifier": "500a0980000b6c3f-50000d1703544b80",
      "length": "2m",
      "part_number": "112-00431+A0",
      "serial_number": "616930439"
    },
    "designator": "square",
    "id": 0,
    "module_id": "a",
    "remote": {
      "phy": "12",
      "wwn": "50000D1703544B80"
    },
    "state": "connected",
    "wwn": "500A0980000B6C3F"
  },
},

```

```

"serial_number": "SHFMS1514000895",
"state": "ok",
"temperature_sensors": {
  "ambient": "",
  "id": 1,
  "location": "temp sensor on midplane left",
  "state": "ok",
  "temperature": 32,
  "threshold": {
    "high": {
      "critical": 60,
      "warning": 55
    },
    "low": {
      "critical": 0,
      "warning": 5
    }
  }
},
"uid": "7777841915827391056",
"vendor": {
  "manufacturer": "XYZ",
  "name": "XYZ",
  "part_number": "A92831142733",
  "product": "LS2246",
  "serial_number": "891234572210221"
},
"voltage_sensors": {
  "id": 1,
  "location": "rear of the shelf on the lower left power supply",
  "state": "ok",
  "voltage": "12.18"
}
}
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

error

Error object is populated when connection\_state becomes non-optimal

| Name     | Type                  | Description |
|----------|-----------------------|-------------|
| reason   | <a href="#">error</a> |             |
| severity | string                |             |
| type     | string                |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

acps

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| address          | string                |   |
| channel          | string                |   |
| connection_state | string                |   |
| enabled          | boolean               |   |
| error            | <a href="#">error</a> | Error object is populated when connection_state becomes non-optimal |
| netmask          | string                |   |
| node             | <a href="#">node</a>  |   |
| port             | string                |   |
| subnet           | string                |   |

drawer

| Name | Type    | Description                    |
|------|---------|--------------------------------|
| id   | integer | The drawer containing this bay |
| slot | integer | The drawer slot for this bay   |

bays

| Name     | Type                   | Description |
|----------|------------------------|-------------|
| drawer   | <a href="#">drawer</a> |             |
| has_disk | boolean                |             |
| id       | integer                |             |
| state    | string                 |             |

| Name | Type   | Description |
|------|--------|-------------|
| type | string |             |

#### current\_sensors

| Name     | Type    | Description           |
|----------|---------|-----------------------|
| current  | integer | Current, in milliamps |
| id       | integer |                       |
| location | string  |                       |
| state    | string  |                       |

#### drawers

| Name          | Type    | Description |
|---------------|---------|-------------|
| closed        | boolean |             |
| disk_count    | integer |             |
| error         | string  |             |
| id            | integer |             |
| part_number   | string  |             |
| serial_number | string  |             |
| state         | string  |             |

#### errors

| Name   | Type                  | Description |
|--------|-----------------------|-------------|
| reason | <a href="#">error</a> |             |

#### fans

| Name     | Type    | Description |
|----------|---------|-------------|
| id       | integer |             |
| location | string  |             |
| rpm      | integer |             |
| state    | string  |             |

#### psu

| Name         | Type    | Description   |
|--------------|---------|---|
| crest_factor | integer | The ratio of the peak voltage to the root-mean-square voltage |
| model        | string  |   |
| power_drawn  | integer | Power drawn, in watts   |
| power_rating | integer | Power rating, in watts  |

frus

| Name             | Type                | Description |
|------------------|---------------------|-------------|
| firmware_version | string              |             |
| id               | integer             |             |
| installed        | boolean             |             |
| part_number      | string              |             |
| psu              | <a href="#">psu</a> |             |
| serial_number    | string              |             |
| state            | string              |             |
| type             | string              |             |

manufacturer

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

paths

Storage port

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| node   | <a href="#">node</a>   |             |

cable

| Name       | Type   | Description |
|------------|--------|-------------|
| identifier | string |             |
| length     | string |             |



| Name          | Type   | Description |
|---------------|--------|-------------|
| part_number   | string |             |
| serial_number | string |             |

remote

| Name        | Type   | Description |
|-------------|--------|-------------|
| chassis     | string |             |
| device      | string |             |
| mac_address | string |             |
| phy         | string |             |
| port        | string |             |
| wwn         | string |             |

ports

| Name        | Type                   | Description |
|-------------|------------------------|-------------|
| cable       | <a href="#">cable</a>  |             |
| designator  | string                 |             |
| id          | integer                |             |
| internal    | boolean                |             |
| mac_address | string                 |             |
| module_id   | string                 |             |
| remote      | <a href="#">remote</a> |             |
| state       | string                 |             |
| wwn         | string                 |             |

high

| Name     | Type    | Description                                 |
|----------|---------|---|
| critical | integer | High critical threshold, in degrees Celsius |
| warning  | integer | High warning threshold, in degrees Celsius  |

low

| Name     | Type    | Description                                |
|----------|---------|--|
| critical | integer | Low critical threshold, in degrees Celsius |
| warning  | integer | Low warning threshold, in degrees Celsius  |

threshold

| Name | Type                 | Description |
|------|----------------------|-------------|
| high | <a href="#">high</a> |             |
| low  | <a href="#">low</a>  |             |

temperature\_sensors

| Name        | Type                      | Description                                  |
|-------------|---------------------------|--|
| ambient     | boolean                   | Sensor that measures the ambient temperature |
| id          | integer                   |  |
| location    | string                    |  |
| state       | string                    |  |
| temperature | integer                   | Temperature, in degrees Celsius              |
| threshold   | <a href="#">threshold</a> |  |

vendor

| Name          | Type   | Description  |
|---------------|--------|--|
| manufacturer  | string | Support for this field will be removed in a future release. Please use vendor.name for this field. |
| name          | string |  |
| part_number   | string | Part number  |
| product       | string | Product name   |
| serial_number | string | Serial number  |

voltage\_sensors

| Name     | Type    | Description       |
|----------|---------|-------------------|
| id       | integer |                   |
| location | string  |                   |
| state    | string  |                   |
| voltage  | number  | Voltage, in volts |

#### shelf

| Name                | Type   | Description  |
|---------------------|--|--|
| acps                | array[ <a href="#">acps</a> ]                | Alternate Control Paths to ACP processors/functions in shelf modules and expanders |
| bays                | array[ <a href="#">bays</a> ]                |  |
| connection_type     | string                                       |  |
| current_sensors     | array[ <a href="#">current_sensors</a> ]     |  |
| disk_count          | integer                                      |  |
| drawers             | array[ <a href="#">drawers</a> ]             |  |
| errors              | array[ <a href="#">errors</a> ]              |  |
| fans                | array[ <a href="#">fans</a> ]                |  |
| frus                | array[ <a href="#">frus</a> ]                |  |
| id                  | string                                       |  |
| internal            | boolean                                      |  |
| local               | boolean                                      |  |
| location_led        | string                                       |  |
| manufacturer        | <a href="#">manufacturer</a>                 |  |
| model               | string                                       |  |
| module_type         | string                                       |  |
| name                | string                                       |  |
| paths               | array[ <a href="#">paths</a> ]               |  |
| ports               | array[ <a href="#">ports</a> ]               |  |
| serial_number       | string                                       |  |
| state               | string                                       |  |
| temperature_sensors | array[ <a href="#">temperature_sensors</a> ] |  |
| uid                 | string                                       |  |
| vendor              | <a href="#">vendor</a>                       |  |

| Name            | Type                   | Description |
|-----------------|------------------------|-------------|
| voltage_sensors | array[voltage_sensors] |             |

## Retrieve a shelf

GET /storage/shelves/{uid}

**Introduced In:** 9.6

Retrieves a specific shelf.

### Related ONTAP commands

- `storage shelf show`
- `storage shelf port show`
- `storage shelf drawer show`
- `storage shelf drawer show-slot`
- `storage shelf acp show`

### Learn more

- [DOC /storage/shelves](#)

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| uid    | string        | path  | True     | Shelf UID                     |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name            | Type        | Description  |
|-----------------|-------------|--|
| acps            | array[acps] | Alternate Control Paths to ACP processors/functions in shelf modules and expanders |
| bays            | array[bays] |  |
| connection_type | string      |  |

| Name                | Type                       | Description |
|---------------------|----------------------------|-------------|
| current_sensors     | array[current_sensors]     |             |
| disk_count          | integer                    |             |
| drawers             | array[drawers]             |             |
| errors              | array[errors]              |             |
| fans                | array[fans]                |             |
| frus                | array[frus]                |             |
| id                  | string                     |             |
| internal            | boolean                    |             |
| local               | boolean                    |             |
| location_led        | string                     |             |
| manufacturer        | manufacturer               |             |
| model               | string                     |             |
| module_type         | string                     |             |
| name                | string                     |             |
| paths               | array[paths]               |             |
| ports               | array[ports]               |             |
| serial_number       | string                     |             |
| state               | string                     |             |
| temperature_sensors | array[temperature_sensors] |             |
| uid                 | string                     |             |
| vendor              | vendor                     |             |
| voltage_sensors     | array[voltage_sensors]     |             |

## Example response

```
{
  "acps": {
    "address": "192.168.1.104",
    "channel": "out_of_band",
    "connection_state": "full_connectivity",
    "error": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      },
      "severity": "unknown",
      "type": "not_applicable"
    },
    "netmask": "255.255.252.0",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": "e0P",
    "subnet": "192.168.0.1"
  },
  "bays": {
    "drawer": {
      "id": 1,
      "slot": 0
    },
    "id": 0,
    "state": "ok",
    "type": "single_disk"
  },
  "connection_type": "sas",
  "current_sensors": {
    "current": 14410,
    "id": 1,
```

```
    "location": "rear of the shelf on the lower left power supply",
    "state": "ok"
  },
  "disk_count": 12,
  "drawers": {
    "disk_count": 12,
    "part_number": "111-03071",
    "serial_number": "021604008263",
    "state": "ok"
  },
  "errors": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "fans": {
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "rpm": 3020,
    "state": "ok"
  },
  "frus": {
    "firmware_version": "0191",
    "installed": 1,
    "part_number": "111-00690+A2",
    "psu": {
      "crest_factor": 92,
      "model": "00",
      "power_drawn": 210,
      "power_rating": 1600
    },
    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
  },
  "id": "1",
  "location_led": "off",
  "manufacturer": {
    "name": "NETAPP"
  },
}
```

```

"model": "DS2246",
"module_type": "iom6",
"name": "1.1",
"paths": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "2a",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"ports": {
  "cable": {
    "identifier": "500a0980000b6c3f-50000d1703544b80",
    "length": "2m",
    "part_number": "112-00431+A0",
    "serial_number": "616930439"
  },
  "designator": "square",
  "id": 0,
  "module_id": "a",
  "remote": {
    "phy": "12",
    "wwn": "50000D1703544B80"
  },
  "state": "connected",
  "wwn": "500A0980000B6C3F"
},
"serial_number": "SHFMS1514000895",
"state": "ok",
"temperature_sensors": {
  "ambient": "",
  "id": 1,
  "location": "temp sensor on midplane left",
  "state": "ok",
  "temperature": 32,
  "threshold": {

```



```
"high": {
  "critical": 60,
  "warning": 55
},
"low": {
  "critical": 0,
  "warning": 5
}
},
"uid": "7777841915827391056",
"vendor": {
  "manufacturer": "XYZ",
  "name": "XYZ",
  "part_number": "A92831142733",
  "product": "LS2246",
  "serial_number": "891234572210221"
},
"voltage_sensors": {
  "id": 1,
  "location": "rear of the shelf on the lower left power supply",
  "state": "ok",
  "voltage": "12.18"
}
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

### error

Error object is populated when connection\_state becomes non-optimal

| Name     | Type                  | Description |
|----------|-----------------------|-------------|
| reason   | <a href="#">error</a> |             |
| severity | string                |             |
| type     | string                |             |

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### acps

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| address          | string                |   |
| channel          | string                |   |
| connection_state | string                |   |
| enabled          | boolean               |   |
| error            | <a href="#">error</a> | Error object is populated when connection_state becomes non-optimal |
| netmask          | string                |   |
| node             | <a href="#">node</a>  |   |
| port             | string                |   |
| subnet           | string                |   |

#### drawer

| Name | Type    | Description                    |
|------|---------|--------------------------------|
| id   | integer | The drawer containing this bay |
| slot | integer | The drawer slot for this bay   |

#### bays

| Name     | Type                   | Description |
|----------|------------------------|-------------|
| drawer   | <a href="#">drawer</a> |             |
| has_disk | boolean                |             |
| id       | integer                |             |
| state    | string                 |             |
| type     | string                 |             |

#### current\_sensors

| Name    | Type    | Description           |
|---------|---------|-----------------------|
| current | integer | Current, in milliamps |

| Name     | Type    | Description |
|----------|---------|-------------|
| id       | integer |             |
| location | string  |             |
| state    | string  |             |

#### drawers

| Name          | Type    | Description |
|---------------|---------|-------------|
| closed        | boolean |             |
| disk_count    | integer |             |
| error         | string  |             |
| id            | integer |             |
| part_number   | string  |             |
| serial_number | string  |             |
| state         | string  |             |

#### errors

| Name   | Type                  | Description |
|--------|-----------------------|-------------|
| reason | <a href="#">error</a> |             |

#### fans

| Name     | Type    | Description |
|----------|---------|-------------|
| id       | integer |             |
| location | string  |             |
| rpm      | integer |             |
| state    | string  |             |

#### psu

| Name         | Type    | Description   |
|--------------|---------|---|
| crest_factor | integer | The ratio of the peak voltage to the root-mean-square voltage |
| model        | string  |   |
| power_drawn  | integer | Power drawn, in watts   |
| power_rating | integer | Power rating, in watts  |

#### frus

| Name             | Type                | Description |
|------------------|---------------------|-------------|
| firmware_version | string              |             |
| id               | integer             |             |
| installed        | boolean             |             |
| part_number      | string              |             |
| psu              | <a href="#">psu</a> |             |
| serial_number    | string              |             |
| state            | string              |             |
| type             | string              |             |

manufacturer

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

paths

Storage port

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| node   | <a href="#">node</a>   |             |

cable

| Name          | Type   | Description |
|---------------|--------|-------------|
| identifier    | string |             |
| length        | string |             |
| part_number   | string |             |
| serial_number | string |             |

remote

| Name        | Type   | Description |
|-------------|--------|-------------|
| chassis     | string |             |
| device      | string |             |
| mac_address | string |             |
| phy         | string |             |
| port        | string |             |

| Name | Type   | Description |
|------|--------|-------------|
| wwn  | string |             |

#### ports

| Name        | Type                   | Description |
|-------------|------------------------|-------------|
| cable       | <a href="#">cable</a>  |             |
| designator  | string                 |             |
| id          | integer                |             |
| internal    | boolean                |             |
| mac_address | string                 |             |
| module_id   | string                 |             |
| remote      | <a href="#">remote</a> |             |
| state       | string                 |             |
| wwn         | string                 |             |

#### high

| Name     | Type    | Description                                 |
|----------|---------|---|
| critical | integer | High critical threshold, in degrees Celsius |
| warning  | integer | High warning threshold, in degrees Celsius  |

#### low

| Name     | Type    | Description                                |
|----------|---------|--|
| critical | integer | Low critical threshold, in degrees Celsius |
| warning  | integer | Low warning threshold, in degrees Celsius  |

#### threshold

| Name | Type                 | Description |
|------|----------------------|-------------|
| high | <a href="#">high</a> |             |
| low  | <a href="#">low</a>  |             |

#### temperature\_sensors

| Name        | Type                      | Description                                  |
|-------------|---------------------------|--|
| ambient     | boolean                   | Sensor that measures the ambient temperature |
| id          | integer                   |  |
| location    | string                    |  |
| state       | string                    |  |
| temperature | integer                   | Temperature, in degrees Celsius              |
| threshold   | <a href="#">threshold</a> |  |

vendor

| Name          | Type   | Description  |
|---------------|--------|--|
| manufacturer  | string | Support for this field will be removed in a future release. Please use vendor.name for this field. |
| name          | string |  |
| part_number   | string | Part number  |
| product       | string | Product name   |
| serial_number | string | Serial number  |

voltage\_sensors

| Name     | Type    | Description       |
|----------|---------|-------------------|
| id       | integer |                   |
| location | string  |                   |
| state    | string  |                   |
| voltage  | number  | Voltage, in volts |

## Update a shelf location LED

PATCH /storage/shelves/{uid}

**Introduced In:** 9.10

Updates a shelf location LED.



## Related ONTAP commands

- `storage shelf location-led modify`

## Learn more

- [DOC /storage/shelves](#)

## Parameters

| Name | Type   | In   | Required | Description |
|------|--------|------|----------|-------------|
| uid  | string | path | True     | Shelf UID   |

## Request Body

| Name            | Type                                     | Description  |
|-----------------|--|--|
| acps            | array[ <a href="#">acps</a> ]            | Alternate Control Paths to ACP processors/functions in shelf modules and expanders |
| bays            | array[ <a href="#">bays</a> ]            |  |
| connection_type | string                                   |  |
| current_sensors | array[ <a href="#">current_sensors</a> ] |  |
| disk_count      | integer                                  |  |
| drawers         | array[ <a href="#">drawers</a> ]         |  |
| errors          | array[ <a href="#">errors</a> ]          |  |
| fans            | array[ <a href="#">fans</a> ]            |  |
| frus            | array[ <a href="#">frus</a> ]            |  |
| id              | string                                   |  |
| internal        | boolean                                  |  |
| local           | boolean                                  |  |
| location_led    | string                                   |  |
| manufacturer    | <a href="#">manufacturer</a>             |  |
| model           | string                                   |  |
| module_type     | string                                   |  |
| name            | string                                   |  |
| paths           | array[ <a href="#">paths</a> ]           |  |
| ports           | array[ <a href="#">ports</a> ]           |  |
| serial_number   | string                                   |  |
| state           | string                                   |  |

| Name                | Type   | Description |
|---------------------|--|-------------|
| temperature_sensors | array[ <a href="#">temperature_sensors</a> ] |             |
| uid                 | string                                       |             |
| vendor              | <a href="#">vendor</a>                       |             |
| voltage_sensors     | array[ <a href="#">voltage_sensors</a> ]     |             |

## Example request

```
{
  "acps": {
    "address": "192.168.1.104",
    "channel": "out_of_band",
    "connection_state": "full_connectivity",
    "error": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      },
      "severity": "unknown",
      "type": "not_applicable"
    },
    "netmask": "255.255.252.0",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": "e0P",
    "subnet": "192.168.0.1"
  },
  "bays": {
    "drawer": {
      "id": 1,
      "slot": 0
    },
    "id": 0,
    "state": "ok",
    "type": "single_disk"
  },
  "connection_type": "sas",
  "current_sensors": {
    "current": 14410,
    "id": 1,
```

```

    "location": "rear of the shelf on the lower left power supply",
    "state": "ok"
  },
  "disk_count": 12,
  "drawers": {
    "disk_count": 12,
    "part_number": "111-03071",
    "serial_number": "021604008263",
    "state": "ok"
  },
  "errors": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  },
  "fans": {
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "rpm": 3020,
    "state": "ok"
  },
  "frus": {
    "firmware_version": "0191",
    "installed": 1,
    "part_number": "111-00690+A2",
    "psu": {
      "crest_factor": 92,
      "model": "00",
      "power_drawn": 210,
      "power_rating": 1600
    },
    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
  },
  "id": "1",
  "location_led": "off",
  "manufacturer": {
    "name": "NETAPP"
  },
  },

```

```
"model": "DS2246",
"module_type": "iom6",
"name": "1.1",
"paths": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "2a",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"ports": {
  "cable": {
    "identifier": "500a0980000b6c3f-50000d1703544b80",
    "length": "2m",
    "part_number": "112-00431+A0",
    "serial_number": "616930439"
  },
  "designator": "square",
  "id": 0,
  "module_id": "a",
  "remote": {
    "phy": "12",
    "wwn": "50000D1703544B80"
  },
  "state": "connected",
  "wwn": "500A0980000B6C3F"
},
"serial_number": "SHFMS1514000895",
"state": "ok",
"temperature_sensors": {
  "ambient": "",
  "id": 1,
  "location": "temp sensor on midplane left",
  "state": "ok",
  "temperature": 32,
  "threshold": {
```

```

    "high": {
      "critical": 60,
      "warning": 55
    },
    "low": {
      "critical": 0,
      "warning": 5
    }
  },
  "uid": "7777841915827391056",
  "vendor": {
    "manufacturer": "XYZ",
    "name": "XYZ",
    "part_number": "A92831142733",
    "product": "LS2246",
    "serial_number": "891234572210221"
  },
  "voltage_sensors": {
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "state": "ok",
    "voltage": "12.18"
  }
}

```

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 17825872   | Shelf locate request failed because shelf "<name>" was not found.</name>                 |
| 17825873   | Shelf locate request failed because shelf "<name>" does not support this command.</name> |

| Error Code | Description  |
|------------|--|
| 17825874   | Shelf locate request failed for shelf "<name>" with an unknown error.</name>                 |
| 17825875   | Shelf locate request failed for shelf "<name>" because shelf modules are unreachable.</name> |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

### error

Error object is populated when connection\_state becomes non-optimal

| Name     | Type                  | Description |
|----------|-----------------------|-------------|
| reason   | <a href="#">error</a> |             |
| severity | string                |             |
| type     | string                |             |

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |



| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### acps

| Name             | Type                  | Description   |
|------------------|-----------------------|---|
| address          | string                |   |
| channel          | string                |   |
| connection_state | string                |   |
| enabled          | boolean               |   |
| error            | <a href="#">error</a> | Error object is populated when connection_state becomes non-optimal |
| netmask          | string                |   |
| node             | <a href="#">node</a>  |   |
| port             | string                |   |
| subnet           | string                |   |

#### drawer

| Name | Type    | Description                    |
|------|---------|--------------------------------|
| id   | integer | The drawer containing this bay |
| slot | integer | The drawer slot for this bay   |

#### bays

| Name     | Type                   | Description |
|----------|------------------------|-------------|
| drawer   | <a href="#">drawer</a> |             |
| has_disk | boolean                |             |
| id       | integer                |             |
| state    | string                 |             |
| type     | string                 |             |

#### current\_sensors

| Name    | Type    | Description           |
|---------|---------|-----------------------|
| current | integer | Current, in milliamps |

| Name     | Type    | Description |
|----------|---------|-------------|
| id       | integer |             |
| location | string  |             |
| state    | string  |             |

#### drawers

| Name          | Type    | Description |
|---------------|---------|-------------|
| closed        | boolean |             |
| disk_count    | integer |             |
| error         | string  |             |
| id            | integer |             |
| part_number   | string  |             |
| serial_number | string  |             |
| state         | string  |             |

#### errors

| Name   | Type                  | Description |
|--------|-----------------------|-------------|
| reason | <a href="#">error</a> |             |

#### fans

| Name     | Type    | Description |
|----------|---------|-------------|
| id       | integer |             |
| location | string  |             |
| rpm      | integer |             |
| state    | string  |             |

#### psu

| Name         | Type    | Description   |
|--------------|---------|---|
| crest_factor | integer | The ratio of the peak voltage to the root-mean-square voltage |
| model        | string  |   |
| power_drawn  | integer | Power drawn, in watts   |
| power_rating | integer | Power rating, in watts  |

#### frus

| Name             | Type                | Description |
|------------------|---------------------|-------------|
| firmware_version | string              |             |
| id               | integer             |             |
| installed        | boolean             |             |
| part_number      | string              |             |
| psu              | <a href="#">psu</a> |             |
| serial_number    | string              |             |
| state            | string              |             |
| type             | string              |             |

manufacturer

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |

paths

Storage port

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| node   | <a href="#">node</a>   |             |

cable

| Name          | Type   | Description |
|---------------|--------|-------------|
| identifier    | string |             |
| length        | string |             |
| part_number   | string |             |
| serial_number | string |             |

remote

| Name        | Type   | Description |
|-------------|--------|-------------|
| chassis     | string |             |
| device      | string |             |
| mac_address | string |             |
| phy         | string |             |
| port        | string |             |

| Name | Type   | Description |
|------|--------|-------------|
| wwn  | string |             |

#### ports

| Name        | Type                   | Description |
|-------------|------------------------|-------------|
| cable       | <a href="#">cable</a>  |             |
| designator  | string                 |             |
| id          | integer                |             |
| internal    | boolean                |             |
| mac_address | string                 |             |
| module_id   | string                 |             |
| remote      | <a href="#">remote</a> |             |
| state       | string                 |             |
| wwn         | string                 |             |

#### high

| Name     | Type    | Description                                 |
|----------|---------|---|
| critical | integer | High critical threshold, in degrees Celsius |
| warning  | integer | High warning threshold, in degrees Celsius  |

#### low

| Name     | Type    | Description                                |
|----------|---------|--|
| critical | integer | Low critical threshold, in degrees Celsius |
| warning  | integer | Low warning threshold, in degrees Celsius  |

#### threshold

| Name | Type                 | Description |
|------|----------------------|-------------|
| high | <a href="#">high</a> |             |
| low  | <a href="#">low</a>  |             |

#### temperature\_sensors

| Name        | Type                      | Description                                  |
|-------------|---------------------------|--|
| ambient     | boolean                   | Sensor that measures the ambient temperature |
| id          | integer                   |  |
| location    | string                    |  |
| state       | string                    |  |
| temperature | integer                   | Temperature, in degrees Celsius              |
| threshold   | <a href="#">threshold</a> |  |

#### vendor

| Name          | Type   | Description  |
|---------------|--------|--|
| manufacturer  | string | Support for this field will be removed in a future release. Please use vendor.name for this field. |
| name          | string |  |
| part_number   | string | Part number  |
| product       | string | Product name   |
| serial_number | string | Serial number  |

#### voltage\_sensors

| Name     | Type    | Description       |
|----------|---------|-------------------|
| id       | integer |                   |
| location | string  |                   |
| state    | string  |                   |
| voltage  | number  | Voltage, in volts |

#### shelf

| Name | Type                          | Description  |
|------|-------------------------------|--|
| acps | array[ <a href="#">acps</a> ] | Alternate Control Paths to ACP processors/functions in shelf modules and expanders |
| bays | array[ <a href="#">bays</a> ] |  |

| Name                | Type   | Description |
|---------------------|--|-------------|
| connection_type     | string                                       |             |
| current_sensors     | array[ <a href="#">current_sensors</a> ]     |             |
| disk_count          | integer                                      |             |
| drawers             | array[ <a href="#">drawers</a> ]             |             |
| errors              | array[ <a href="#">errors</a> ]              |             |
| fans                | array[ <a href="#">fans</a> ]                |             |
| frus                | array[ <a href="#">frus</a> ]                |             |
| id                  | string                                       |             |
| internal            | boolean                                      |             |
| local               | boolean                                      |             |
| location_led        | string                                       |             |
| manufacturer        | <a href="#">manufacturer</a>                 |             |
| model               | string                                       |             |
| module_type         | string                                       |             |
| name                | string                                       |             |
| paths               | array[ <a href="#">paths</a> ]               |             |
| ports               | array[ <a href="#">ports</a> ]               |             |
| serial_number       | string                                       |             |
| state               | string                                       |             |
| temperature_sensors | array[ <a href="#">temperature_sensors</a> ] |             |
| uid                 | string                                       |             |
| vendor              | <a href="#">vendor</a>                       |             |
| voltage_sensors     | array[ <a href="#">voltage_sensors</a> ]     |             |

## Manage Snapshot copy policies

### Storage snapshot-policies endpoint overview

#### Overview

In ONTAP, scheduled Snapshot copy creation works based on Snapshot copy policies. ONTAP provides three cluster-wide Snapshot copy policies: "default", "default-1weekly" and "none". A Snapshot copy policy can have more than one schedule associated with it. A Snapshot copy policy can be linked to a storage object and based on the schedule in the policy, Snapshot copies will be created on the object at that interval. Each schedule in a Snapshot copy policy has a Snapshot copy name prefix attached to it. Every Snapshot copy created using this policy will have this prefix in its name. There is also a retention count associated with every schedule. This count indicates the maximum number of Snapshot copies that can exist for a given schedule.

Once the Snapshot copy count reaches the retention count, on the next create operation, the oldest Snapshot copy is deleted.

### **Snapshot copy policy APIs**

The following APIs are used to perform operations related to Snapshot copy policy information:

&ndash; POST /api/storage/snapshot-policies

&ndash; GET /api/storage/snapshot-policies

&ndash; GET /api/storage/snapshot-policies/{uuid}

&ndash; PATCH /api/storage/snapshot-policies/{uuid}

&ndash; DELETE /api/storage/snapshot-policies/{uuid}

### **Examples**

#### **Creating a Snapshot copy policy**

The POST operation is used to create a Snapshot copy policy with the specified attributes.

```

# The API:
/api/storage/snapshot-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/snapshot-policies" -H
"accept: application/hal+json" -d '{"name": "new_policy", "enabled":
"true", "comment": "policy comment", "copies": [{ "schedule": { "name":
"5min" }}, {"count": "5", "prefix": "xyz" }], "svm": { "name": "vs0"}}'

# The response:
HTTP/1.1 201 Created
Date: Tue, 12 Mar 2019 21:20:24 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Location: /api/storage/snapshot-policies/a69d8173-450c-11e9-aa44-
005056bbc848
Content-Length: 369
Content-Type: application/json
{
  "num_records": 1,
  "records": [
    {
      "uuid": "a69d8173-450c-11e9-aa44-005056bbc848",
      "svm": {
        "name": "vs0"
      },
      "name": "new_policy",
      "comment": "This is a 5min schedule policy",
      "enabled": true,
      "copies": [
        {
          "count": 5,
          "schedule": {
            "name": "5min"
          }
        }
      ]
    }
  ]
}

```

### Retrieving Snapshot copy policy attributes

The GET operation is used to retrieve Snapshot copy policy attributes.



```
# The API:
/api/storage/snapshot-policies

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/snapshot-policies/" -H "accept:
application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Tue, 12 Mar 2019 21:17:17 GMT
Server: libzapid-http
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 686
Content-Type: application/json
{
"records": [
  {
    "uuid": "0fa7a554-348d-11e9-b55e-005056bbf1c8",
    "name": "spsv0",
    "_links": {
      "self": {
        "href": "/api/storage/snapshot-policies/0fa7a554-348d-11e9-b55e-
005056bbf1c8"
      }
    }
  },
  {
    "uuid": "3c112527-2fe8-11e9-b55e-005056bbf1c8",
    "name": "default",
    "_links": {
      "self": {
        "href": "/api/storage/snapshot-policies/3c112527-2fe8-11e9-b55e-
005056bbf1c8"
      }
    }
  },
  {
    "uuid": "3c1c1656-2fe8-11e9-b55e-005056bbf1c8",
    "name": "default-1weekly",
    "_links": {
      "self": {
        "href": "/api/storage/snapshot-policies/3c1c1656-2fe8-11e9-b55e-
005056bbf1c8"
      }
    }
  }
]
```

```

    },
    {
      "uuid": "3c228b82-2fe8-11e9-b55e-005056bbf1c8",
      "name": "none",
      "_links": {
        "self": {
          "href": "/api/storage/snapshot-policies/3c228b82-2fe8-11e9-b55e-005056bbf1c8"
        }
      }
    }
  ],
  "num_records": 4,
  "_links": {
    "self": {
      "href": "/api/storage/snapshot-policies/"
    }
  }
}

```

#### Retrieving the attributes of a specific Snapshot copy policy

The GET operation is used to retrieve the attributes of a specific Snapshot copy policy.

```

# The API:
/api/storage/snapshot-policies/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/snapshot-policies/3c112527-2fe8-11e9-b55e-005056bbf1c8" -H "accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Tue, 12 Mar 2019 21:24:48 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 381
Content-Type: application/json
{
  "uuid": "3c112527-2fe8-11e9-b55e-005056bbf1c8",
  "name": "default",
  "comment": "Default policy with hourly, daily & weekly schedules.",
  "enabled": true,
  "scope": "cluster",
  "copies": [

```

```
{
  "count": 6,
  "prefix": "hourly",
  "schedule": {
    "name": "hourly"
  }
},
{
  "count": 2,
  "prefix": "daily",
  "schedule": {
    "name": "daily"
  }
},
{
  "count": 2,
  "prefix": "weekly",
  "schedule": {
    "name": "weekly"
  }
}
],
"_links": {
  "self": {
    "href": "/api/storage/snapshot-policies/3c112527-2fe8-11e9-b55e-005056bbf1c8"
  }
}
}
```

### Updating a Snapshot copy policy

The PATCH operation is used to update the specific attributes of a Snapshot copy policy.

```
# The API:
/api/storage/snapshot-policies/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/snapshot-policies/ae9e65c4-4506-11e9-aa44-005056bbc848" -d '{"enabled": "false" }' -H "accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Tue, 12 Mar 2019 21:27:04 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 3
Content-Type: application/json
```

### Deleting a Snapshot copy policy

The DELETE operation is used to delete a Snapshot copy policy.

```
# The API:
/api/storage/snapshot-policies/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/snapshot-policies/ae9e65c4-4506-11e9-aa44-005056bbc848" -H "accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Tue, 12 Mar 2019 21:19:04 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 3
Content-Type: application/json
```

### Retrieve Snapshot copy policies

GET /storage/snapshot-policies

**Introduced In:** 9.6

Retrieves a collection of Snapshot copy policies.

## Related ONTAP commands

- `snapshot policy show`

## Learn more

- [DOC /storage/snapshot-policies](#)

## Parameters

| Name                    | Type          | In    | Required | Description                           |
|-------------------------|---------------|-------|----------|---------------------------------------|
| svm.uuid                | string        | query | False    | Filter by svm.uuid                    |
| svm.name                | string        | query | False    | Filter by svm.name                    |
| scope                   | string        | query | False    | Filter by scope                       |
| enabled                 | boolean       | query | False    | Filter by enabled                     |
| name                    | string        | query | False    | Filter by name                        |
| comment                 | string        | query | False    | Filter by comment                     |
| uuid                    | string        | query | False    | Filter by uuid                        |
| copies.prefix           | string        | query | False    | Filter by copies.prefix               |
| copies.count            | integer       | query | False    | Filter by copies.count                |
| copies.snapmirror_label | string        | query | False    | Filter by copies.snapmirror_label     |
| copies.schedule.name    | string        | query | False    | Filter by copies.schedule.name        |
| fields                  | array[string] | query | False    | Specify the fields to return.         |
| max_records             | integer       | query | False    | Limit the number of records returned. |

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc   |

## Response

Status: 200, Ok

| Name        | Type                                     | Description       |
|-------------|--|-------------------|
| _links      | <a href="#">_links</a>                   |                   |
| num_records | integer                                  | Number of records |
| records     | array[ <a href="#">snapshot_policy</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "comment": "string",
    "copies": {
      "prefix": "string",
      "schedule": {
        "name": "hourly"
      }
    },
    "enabled": 1,
    "name": "default",
    "scope": "svm",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions



## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name | Type   | Description   |
|------|--------|---|
| name | string | Schedule at which Snapshot copies are captured on the volume. Some common schedules already defined in the system are hourly, daily, weekly, at 15 minute intervals, and at 5 minute intervals. Snapshot copy policies with custom schedules can be referenced. |

copies

| Name             | Type                     | Description  |
|------------------|--------------------------|--|
| count            | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix           | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule         | <a href="#">schedule</a> |  |
| snapmirror_label | string                   | Label for SnapMirror operations  |

svm

| Name   | Type                   | Description                       |
|--------|------------------------|-----------------------------------|
| _links | <a href="#">_links</a> |                                   |
| name   | string                 | The name of the SVM.              |
| uuid   | string                 | The unique identifier of the SVM. |

#### snapshot\_policy

The Snapshot copy policy object is associated with a read-write volume used to create and delete Snapshot copies at regular intervals.

| Name    | Type                            | Description   |
|---------|---------------------------------|---|
| _links  | <a href="#">_links</a>          |   |
| comment | string                          | A comment associated with the Snapshot copy policy.                         |
| copies  | array[ <a href="#">copies</a> ] |   |
| enabled | boolean                         | Is the Snapshot copy policy enabled?  |
| name    | string                          | Name of the Snapshot copy policy.   |
| scope   | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm     | <a href="#">svm</a>             |   |
| uuid    | string                          |   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Create a Snapshot copy policy

POST /storage/snapshot-policies

**Introduced In:** 9.6

Creates a Snapshot copy policy.

### Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the Snapshot copy policy.
- `name` - Name for the Snapshot copy policy.
- `copies.schedule` - Schedule at which Snapshot copies are captured on the volume.
- `copies.count` - Number of Snapshot copies to maintain for this schedule.

### Recommended optional properties

- `copies.prefix` - Prefix to use when creating Snapshot copies at regular intervals.

### Default property values

If not specified in POST, the following default property values are assigned:

- `enabled` - *true*
- `copies.prefix` - Value of `schedule.name`

### Related ONTAP commands

- `snapshot policy create`

### Learn more

- [DOC /storage/snapshot-policies](#)

### Parameters

| Name           | Type    | In    | Required | Description   |
|----------------|---------|-------|----------|---|
| return_records | boolean | query | False    | The default is false. If set to true, the records are returned.<br><br>• Default value: |

### Request Body

| Name    | Type                            | Description   |
|---------|---------------------------------|---|
| _links  | <a href="#">_links</a>          |   |
| comment | string                          | A comment associated with the Snapshot copy policy.                         |
| copies  | array[ <a href="#">copies</a> ] |   |
| enabled | boolean                         | Is the Snapshot copy policy enabled?  |
| name    | string                          | Name of the Snapshot copy policy.   |
| scope   | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm     | <a href="#">svm</a>             |   |
| uuid    | string                          |   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "copies": {
    "prefix": "string",
    "schedule": {
      "name": "hourly"
    }
  },
  "enabled": 1,
  "name": "default",
  "scope": "svm",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Response

Status: 201, Created

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 1638407    | When adding schedule to a Snapshot copy policy, the count for that schedule must be specified.             |
| 1638408    | When adding schedule to a Snapshot copy policy, the schedule name must be specified.                       |
| 1638413    | Schedule not found.  |
| 1638417    | Specified policy name is invalid.  |
| 1638451    | This operation would result in total Snapshot copy count for the policy to exceed maximum supported count. |
| 1638508    | Another schedule has the same prefix within this policy.   |
| 1638526    | This operation is not supported on a node Vserver.   |
| 1638527    | Policy name already exists.  |
| 1638528    | This operation is not supported in a mixed-version cluster.  |
| 1638531    | This operation is not supported because specified policy is owned by the cluster admin.                    |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name | Type   | Description   |
|------|--------|---|
| name | string | Schedule at which Snapshot copies are captured on the volume. Some common schedules already defined in the system are hourly, daily, weekly, at 15 minute intervals, and at 5 minute intervals. Snapshot copy policies with custom schedules can be referenced. |

copies

| Name             | Type                     | Description  |
|------------------|--------------------------|--|
| count            | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix           | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule         | <a href="#">schedule</a> |  |
| snapmirror_label | string                   | Label for SnapMirror operations  |

svm

| Name   | Type                   | Description          |
|--------|------------------------|----------------------|
| _links | <a href="#">_links</a> |                      |
| name   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

#### snapshot\_policy

The Snapshot copy policy object is associated with a read-write volume used to create and delete Snapshot copies at regular intervals.

| Name    | Type                            | Description   |
|---------|---------------------------------|---|
| _links  | <a href="#">_links</a>          |   |
| comment | string                          | A comment associated with the Snapshot copy policy.                         |
| copies  | array[ <a href="#">copies</a> ] |   |
| enabled | boolean                         | Is the Snapshot copy policy enabled?  |
| name    | string                          | Name of the Snapshot copy policy.   |
| scope   | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm     | <a href="#">svm</a>             |   |
| uuid    | string                          |   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |
| message   | string                                   | Error message     |



| Name   | Type   | Description                                 |
|--------|--------|---|
| target | string | The target parameter that caused the error. |

## Delete a Snapshot copy policy

DELETE /storage/snapshot-policies/{uuid}

**Introduced In:** 9.6

Deletes a Snapshot copy policy

### Related ONTAP commands

- `snapshot policy delete`

### Learn more

- [DOC /storage/snapshot-policies](#)

### Parameters

| Name | Type   | In   | Required | Description               |
|------|--------|------|----------|---------------------------|
| uuid | string | path | True     | Snapshot copy policy UUID |

### Response

Status: 200, Ok

### Error

Status: Default

### ONTAP Error Response Code

| Error Code | Description   |
|------------|---|
| 1638415    | Cannot delete policy. Reason: Policy is in use by at least one volume.  |
| 1638416    | Cannot delete policy. Reason: Cannot verify whether policy is in use.   |
| 1638430    | Cannot delete policy. Reason: Policy is in use by at least one Vserver. |

| Error Code | Description                    |
|------------|--------------------------------|
| 1638430    | Cannot delete built-in policy. |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve Snapshot copy policy details

GET /storage/snapshot-policies/{uuid}

**Introduced In:** 9.6

Retrieves details of a specific Snapshot copy policy.

### Related ONTAP commands

- `snapshot policy show`

### Learn more

- [DOC /storage/snapshot-policies](#)

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| uuid   | string        | path  | True     | Snapshot copy policy UUID     |
| fields | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name    | Type                            | Description   |
|---------|---------------------------------|---|
| _links  | <a href="#">_links</a>          |   |
| comment | string                          | A comment associated with the Snapshot copy policy.                         |
| copies  | array[ <a href="#">copies</a> ] |   |
| enabled | boolean                         | Is the Snapshot copy policy enabled?  |
| name    | string                          | Name of the Snapshot copy policy.   |
| scope   | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm     | <a href="#">svm</a>             |   |
| uuid    | string                          |   |

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "copies": {
    "prefix": "string",
    "schedule": {
      "name": "hourly"
    }
  },
  "enabled": 1,
  "name": "default",
  "scope": "svm",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name | Type   | Description   |
|------|--------|---|
| name | string | Schedule at which Snapshot copies are captured on the volume. Some common schedules already defined in the system are hourly, daily, weekly, at 15 minute intervals, and at 5 minute intervals. Snapshot copy policies with custom schedules can be referenced. |

copies

| Name             | Type                     | Description  |
|------------------|--------------------------|--|
| count            | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix           | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule         | <a href="#">schedule</a> |  |
| snapmirror_label | string                   | Label for SnapMirror operations  |

svm

| Name   | Type                   | Description          |
|--------|------------------------|----------------------|
| _links | <a href="#">_links</a> |                      |
| name   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a Snapshot copy policy

PATCH /storage/snapshot-policies/{uuid}

**Introduced In:** 9.6

Updates a Snapshot copy policy

### Related ONTAP commands

- `snapshot policy modify`
- `snapshot policy modify-schedule`
- `snapshot policy add-schedule`

### Learn more

- [DOC /storage/snapshot-policies](#)

### Parameters



| Name | Type   | In   | Required | Description               |
|------|--------|------|----------|---------------------------|
| uuid | string | path | True     | Snapshot copy policy UUID |

### Request Body

| Name                   | Type                            | Description   |
|------------------------|---------------------------------|---|
| <a href="#">_links</a> | <a href="#">_links</a>          |   |
| comment                | string                          | A comment associated with the Snapshot copy policy.                         |
| copies                 | array[ <a href="#">copies</a> ] |   |
| enabled                | boolean                         | Is the Snapshot copy policy enabled?  |
| name                   | string                          | Name of the Snapshot copy policy.   |
| scope                  | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm                    | <a href="#">svm</a>             |   |
| uuid                   | string                          |   |

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "copies": {
    "prefix": "string",
    "schedule": {
      "name": "hourly"
    }
  },
  "enabled": 1,
  "name": "default",
  "scope": "svm",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Code

| Error Code | Description   |
|------------|---|
| 1638414    | Cannot enable policy. Reason: Specified schedule not found. |

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name | Type   | Description   |
|------|--------|---|
| name | string | Schedule at which Snapshot copies are captured on the volume. Some common schedules already defined in the system are hourly, daily, weekly, at 15 minute intervals, and at 5 minute intervals. Snapshot copy policies with custom schedules can be referenced. |

copies

| Name             | Type                     | Description  |
|------------------|--------------------------|--|
| count            | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix           | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule         | <a href="#">schedule</a> |  |
| snapmirror_label | string                   | Label for SnapMirror operations  |

svm

| Name   | Type                   | Description          |
|--------|------------------------|----------------------|
| _links | <a href="#">_links</a> |                      |
| name   | string                 | The name of the SVM. |

| Name | Type   | Description                       |
|------|--------|-----------------------------------|
| uuid | string | The unique identifier of the SVM. |

#### snapshot\_policy

The Snapshot copy policy object is associated with a read-write volume used to create and delete Snapshot copies at regular intervals.

| Name    | Type                            | Description   |
|---------|---------------------------------|---|
| _links  | <a href="#">_links</a>          |   |
| comment | string                          | A comment associated with the Snapshot copy policy.                         |
| copies  | array[ <a href="#">copies</a> ] |   |
| enabled | boolean                         | Is the Snapshot copy policy enabled?  |
| name    | string                          | Name of the Snapshot copy policy.   |
| scope   | string                          | Set to "svm" when the request is on a data SVM, otherwise set to "cluster". |
| svm     | <a href="#">svm</a>             |   |
| uuid    | string                          |   |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |
| message   | string                                   | Error message     |

| Name   | Type   | Description                                 |
|--------|--------|---|
| target | string | The target parameter that caused the error. |

## Manage Snapshot copy policies and schedules

### Storage snapshot-policies snapshot\_policy.uuid schedules endpoint overview

#### Overview

In ONTAP, scheduled Snapshot copy creation works based on the schedules associated with Snapshot copy policies. ONTAP provides six cluster-wide schedules: "5min", "8hour", "hourly", "daily", "weekly" and "monthly". A Snapshot copy policy is created using at least one of these schedules and up to 5 schedules can be associated with a Snapshot copy policy. A Snapshot copy policy can be linked to a storage object and based on the schedule in the policy, Snapshot copies are created on the object at that interval. Each schedule in a Snapshot copy policy has a Snapshot copy name prefix attached to it. Every Snapshot copy created using this policy has this prefix in its name. There is also a retention count associated with every schedule. This count indicates the maximum number of Snapshot copies that can exist for a given schedule. Once the Snapshot copy count reaches the retention count, on the next create operation, the oldest Snapshot copy is deleted. A schedule can be added, modified or deleted from a Snapshot copy policy.

#### Snapshot copy policy schedule APIs

The following APIs are used to perform operations related to Snapshot copy policy schedules:

&ndash; POST /api/storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/

&ndash; GET /api/storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/

&ndash; GET /api/storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/{schedule.uuid}

&ndash; PATCH /api/storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/{schedule.uuid}

&ndash; DELETE /api/storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/{schedule.uuid}

#### Examples

##### Adding schedule to a Snapshot copy policy

The POST operation is used to create a schedule for a Snapshot copy policy with the specified attributes.

```

# The API:
/api/storage/snapshot-policies/{snapshot_policy.uuid}/schedules/

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/snapshot-policies/32a0841a-818e-11e9-b4f4-005056bbab9c/schedules" -H "accept: application/hal+json" -d '{"schedule.uuid": "7c985d80-818a-11e9-b4f4-005056bbab9c", "count": "5", "prefix": "new_hourly" }'

# The response:
HTTP/1.1 201 Created
Date: Wed, 29 May 2019 22:41:33 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Location: /api/storage/snapshot-policies/32a0841a-818e-11e9-b4f4-005056bbab9c/schedules
Content-Length: 271
Content-Type: application/json
{
  "num_records": 1,
  "records": [
    {
      "snapshot_policy": {
        "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"
      },
      "schedule": {
        "uuid": "7c985d80-818a-11e9-b4f4-005056bbab9c"
      },
      "count": 5,
      "prefix": "new_monthly"
    }
  ]
}

```

### Retrieving Snapshot copy policy schedules

The GET operation is used to retrieve Snapshot copy policy schedules.

```

# The API:
/api/storage/snapshot-policies/{snapshot_policy.uuid}/schedules/

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/snapshot-policies/32a0841a-818e-11e9-b4f4-005056bbab9c/schedules" -H "accept: application/hal+json"

```

```
# The response:
HTTP/1.1 200 OK
Date: Wed, 29 May 2019 22:49:58 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 898
Content-Type: application/json
{
  "records": [
    {
      "snapshot_policy": {
        "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"
      },
      "schedule": {
        "uuid": "63d017dc-818a-11e9-b4f4-005056bbab9c",
        "name": "5min"
      }
    },
    {
      "snapshot_policy": {
        "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"
      },
      "schedule": {
        "uuid": "64a5c5da-818a-11e9-b4f4-005056bbab9c",
        "name": "8hour"
      }
    },
    {
      "snapshot_policy": {
        "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"
      },
      "schedule": {
        "uuid": "63e21a3e-818a-11e9-b4f4-005056bbab9c",
        "name": "daily"
      }
    },
    {
      "snapshot_policy": {
        "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"
      },
      "schedule": {
        "uuid": "7c985d80-818a-11e9-b4f4-005056bbab9c",
        "name": "monthly"
      }
    }
  ]
}
```



```
    }  
  ],  
  "num_records": 4  
}
```

### Retrieving the attributes of a specific Snapshot copy policy schedule

The GET operation is used to retrieve the attributes of a specific Snapshot copy policy schedule.

```
# The API:  
/api/storage/snapshot-  
policies/{snapshot_policy.uuid}/schedules/{schedule.uuid}  
  
# The call:  
curl -X GET "https://<mgmt-ip>/api/storage/snapshot-policies/32a0841a-  
818e-11e9-b4f4-005056bbab9c/schedules/7c985d80-818a-11e9-b4f4-  
005056bbab9c" -H "accept: application/hal+json"  
  
# The response:  
HTTP/1.1 200 OK  
Date: Wed, 29 May 2019 22:54:06 GMT  
Server: libzapid-httpd  
X-Content-Type-Options: nosniff  
Cache-Control: no-cache,no-store,must-revalidate  
Content-Length: 238  
Content-Type: application/json  
{  
  "snapshot_policy": {  
    "uuid": "32a0841a-818e-11e9-b4f4-005056bbab9c"  
  },  
  "schedule": {  
    "uuid": "7c985d80-818a-11e9-b4f4-005056bbab9c",  
    "name": "monthly"  
  },  
  "count": 5,  
  "prefix": "new_monthly",  
  "snapmirror_label": "-"  
}
```

### Updating a Snapshot copy policy schedule

The PATCH operation is used to update the specific attributes of a Snapshot copy policy.

```
# The API:
/api/storage/snapshot-
policies/{snapshot_policy.uuid}/schedules/{schedule.uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/snapshot-policies/32a0841a-
818e-11e9-b4f4-005056bbab9c/schedules/7c985d80-818a-11e9-b4f4-
005056bbab9c" -d '{"count": "10" }' -H "accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Wed, 29 May 2019 23:08:00 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 3
Content-Type: application/json
```

### Deleting a Snapshot copy policy

The DELETE operation is used to delete a Snapshot copy policy.

```
# The API:
/api/storage/snapshot-
policies/{snapshot_policy.uuid}/schedules/{schedule.uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/snapshot-policies/32a0841a-
818e-11e9-b4f4-005056bbab9c/schedules/7c985d80-818a-11e9-b4f4-
005056bbab9c" -H "accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Wed, 29 May 2019 23:12:32 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 3
Content-Type: application/json
```

### Retrieve Snapshot copy policy schedules

GET /storage/snapshot-policies/{snapshot\_policy.uuid}/schedules

Introduced In: 9.8

Retrieves a collection of Snapshot copy policy schedules.

### Related ONTAP commands

- `snapshot policy show`

### Learn more

- [DOC /storage/snapshot-policies/{snapshot\\_policy.uuid}/schedules](#)

### Parameters

| Name                 | Type          | In    | Required | Description   |
|----------------------|---------------|-------|----------|---|
| snapshot_policy.uuid | string        | path  | True     | Snapshot copy policy UUID   |
| snapshot_policy.name | string        | query | False    | Filter by snapshot_policy.name  |
| count                | integer       | query | False    | Filter by count   |
| snapmirror_label     | string        | query | False    | Filter by snapmirror_label  |
| schedule.uuid        | string        | query | False    | Filter by schedule.uuid   |
| schedule.name        | string        | query | False    | Filter by schedule.name   |
| prefix               | string        | query | False    | Filter by prefix  |
| fields               | array[string] | query | False    | Specify the fields to return.   |
| max_records          | integer       | query | False    | Limit the number of records returned.   |
| return_records       | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned.<br><ul style="list-style-type: none"><li>• Default value: 1</li></ul> |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type  | Description       |
|-------------|---|-------------------|
| _links      | <a href="#">_links</a>                            |                   |
| num_records | integer   | Number of records |
| records     | array[ <a href="#">snapshot_policy_schedule</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "prefix": "string",
    "schedule": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "weekly",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "snapshot_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "default",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name   | Type                   | Description       |
|--------|------------------------|-------------------|
| _links | <a href="#">_links</a> |                   |
| name   | string                 | Job schedule name |
| uuid   | string                 | Job schedule UUID |

snapshot\_policy

This is a reference to the Snapshot copy policy.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

snapshot\_policy\_schedule

The Snapshot copy policy schedule object is associated with a Snapshot copy policy and it defines the interval at which Snapshot copies are created and deleted.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name             | Type                            | Description  |
|------------------|---------------------------------|--|
| count            | integer                         | The number of Snapshot copies to maintain for this schedule.           |
| prefix           | string                          | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule         | <a href="#">schedule</a>        |  |
| snapmirror_label | string                          | Label for SnapMirror operations  |
| snapshot_policy  | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy.                       |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Add a schedule to a Snapshot copy policy

POST /storage/snapshot-policies/{snapshot\_policy.uuid}/schedules

**Introduced In:** 9.8

Adds a schedule to a Snapshot copy policy.

### Required properties

- `schedule.uuid` or `schedule.name` - Schedule at which Snapshot copies are captured on the volume.



- `count` - Number of Snapshot copies to maintain for this schedule.

### Recommended optional properties

- `prefix` - Prefix to use when creating Snapshot copies at regular intervals.

### Default property values

If not specified in POST, the following default property values are assigned:

- `prefix` - Value of `schedule.name`

### Related ONTAP commands

- `snapshot policy add-schedule`

### Learn more

- [DOC /storage/snapshot-policies/{snapshot\\_policy.uuid}/schedules](#)

### Parameters

| Name                              | Type    | In    | Required | Description   |
|-----------------------------------|---------|-------|----------|---|
| <code>snapshot_policy.uuid</code> | string  | path  | True     | Snapshot copy policy UUID   |
| <code>return_records</code>       | boolean | query | False    | The default is false. If set to true, the records are returned.<br><br>• Default value: |

### Request Body

| Name                          | Type                     | Description  |
|-------------------------------|--------------------------|--|
| <code>_links</code>           | <a href="#">_links</a>   |  |
| <code>count</code>            | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| <code>prefix</code>           | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| <code>schedule</code>         | <a href="#">schedule</a> |  |
| <code>snapmirror_label</code> | string                   | Label for SnapMirror operations  |

| Name            | Type                            | Description                                      |
|-----------------|---------------------------------|--|
| snapshot_policy | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy. |

### Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "prefix": "string",
  "schedule": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "weekly",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "snapshot_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

### Response

Status: 201, Created

### Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 1638407    | When adding schedule to a Snapshot copy policy, the count for that schedule must be specified.             |
| 1638410    | Specified schedule already exists in snapshot policy.  |
| 1638413    | Schedule not found.  |
| 1638451    | This operation would result in total Snapshot copy count for the policy to exceed maximum supported count. |
| 1638508    | Another schedule has the same prefix within this policy.   |
| 1638528    | This operation is not supported in a mixed-version cluster.  |
| 1638531    | This operation is not supported because specified policy is owned by the cluster admin.                    |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name   | Type                   | Description       |
|--------|------------------------|-------------------|
| _links | <a href="#">_links</a> |                   |
| name   | string                 | Job schedule name |
| uuid   | string                 | Job schedule UUID |

snapshot\_policy

This is a reference to the Snapshot copy policy.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

snapshot\_policy\_schedule

The Snapshot copy policy schedule object is associated with a Snapshot copy policy and it defines the interval at which Snapshot copies are created and deleted.

| Name     | Type                     | Description  |
|----------|--------------------------|--|
| _links   | <a href="#">_links</a>   |  |
| count    | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix   | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule | <a href="#">schedule</a> |  |

| Name             | Type                            | Description                                      |
|------------------|---------------------------------|--|
| snapmirror_label | string                          | Label for SnapMirror operations                  |
| snapshot_policy  | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy. |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Delete a schedule from a Snapshot copy policy

```
DELETE /storage/snapshot-policies/{snapshot_policy.uuid}/schedules/{schedule.uuid}
```

**Introduced In:** 9.8

Deletes a schedule from a Snapshot copy policy

### Related ONTAP commands

- `snapshot policy remove-schedule`

### Learn more

- [DOC /storage/snapshot-policies/{snapshot\\_policy.uuid}/schedules](#)

### Parameters

| Name                 | Type   | In   | Required | Description                        |
|----------------------|--------|------|----------|------------------------------------|
| snapshot_policy.uuid | string | path | True     | Snapshot copy policy UUID          |
| schedule.uuid        | string | path | True     | Snapshot copy policy schedule UUID |

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Code

| Error Code | Description                                 |
|------------|---|
| 1638412    | Schedule does not exist in Snapshot policy. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve Snapshot copy policy schedule details

GET /storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/{schedule.uuid}

**Introduced In:** 9.8

Retrieves details of a specific Snapshot copy policy schedule.

### Related ONTAP commands

- `snapshot policy show`

### Learn more

- [DOC /storage/snapshot-policies/{snapshot\\_policy.uuid}/schedules](#)

### Parameters

| Name                 | Type   | In   | Required | Description                      |
|----------------------|--------|------|----------|----------------------------------|
| snapshot_policy.uuid | string | path | True     | Snapshot copy policy UUID        |
| schedule.uuid        | string | path | True     | Snapshot copy policy schedule ID |

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| fields | array[string] | query | False    | Specify the fields to return. |

## Response

Status: 200, Ok

| Name                   | Type                            | Description  |
|------------------------|---------------------------------|--|
| <a href="#">_links</a> | <a href="#">_links</a>          |  |
| count                  | integer                         | The number of Snapshot copies to maintain for this schedule.           |
| prefix                 | string                          | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule               | <a href="#">schedule</a>        |  |
| snapmirror_label       | string                          | Label for SnapMirror operations  |
| snapshot_policy        | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy.                       |



## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "prefix": "string",
  "schedule": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "weekly",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "snapshot_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

## Error

Status: Default, Error

| Name  | Type                  | Description |
|-------|-----------------------|-------------|
| error | <a href="#">error</a> |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name   | Type                   | Description       |
|--------|------------------------|-------------------|
| _links | <a href="#">_links</a> |                   |
| name   | string                 | Job schedule name |
| uuid   | string                 | Job schedule UUID |

snapshot\_policy

This is a reference to the Snapshot copy policy.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description       |
|-----------|--|-------------------|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments |
| code      | string                                   | Error code        |

| Name    | Type   | Description                                 |
|---------|--------|---|
| message | string | Error message                               |
| target  | string | The target parameter that caused the error. |

## Update a Snapshot copy policy schedule

PATCH /storage/snapshot-policies/{snapshot\_policy.uuid}/schedules/{schedule.uuid}

**Introduced In:** 9.8

Updates a Snapshot copy policy schedule

### Related ONTAP commands

- `snapshot policy modify-schedule`

### Learn more

- [DOC /storage/snapshot-policies/{snapshot\\_policy.uuid}/schedules](#)

### Parameters

| Name                 | Type   | In   | Required | Description                        |
|----------------------|--------|------|----------|------------------------------------|
| snapshot_policy.uuid | string | path | True     | Snapshot copy policy UUID          |
| schedule.uuid        | string | path | True     | Snapshot copy policy schedule UUID |

### Request Body

| Name     | Type                     | Description  |
|----------|--------------------------|--|
| _links   | <a href="#">_links</a>   |  |
| count    | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix   | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule | <a href="#">schedule</a> |  |

| Name             | Type                            | Description                                      |
|------------------|---------------------------------|--|
| snapmirror_label | string                          | Label for SnapMirror operations                  |
| snapshot_policy  | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy. |

### Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "prefix": "string",
  "schedule": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "weekly",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "snapshot_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

### Response

Status: 200, Ok

### Error

Status: Default

## ONTAP Error Response Code

| Error Code | Description  |
|------------|--|
| 1638451    | This operation would result in total Snapshot copy count for the policy to exceed maximum supported count. |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

schedule

| Name   | Type                   | Description       |
|--------|------------------------|-------------------|
| _links | <a href="#">_links</a> |                   |
| name   | string                 | Job schedule name |
| uuid   | string                 | Job schedule UUID |

snapshot\_policy

This is a reference to the Snapshot copy policy.

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

snapshot\_policy\_schedule

The Snapshot copy policy schedule object is associated with a Snapshot copy policy and it defines the interval at which Snapshot copies are created and deleted.

| Name     | Type                     | Description  |
|----------|--------------------------|--|
| _links   | <a href="#">_links</a>   |  |
| count    | integer                  | The number of Snapshot copies to maintain for this schedule.           |
| prefix   | string                   | The prefix to use while creating Snapshot copies at regular intervals. |
| schedule | <a href="#">schedule</a> |  |

| Name             | Type                            | Description                                      |
|------------------|---------------------------------|--|
| snapmirror_label | string                          | Label for SnapMirror operations                  |
| snapshot_policy  | <a href="#">snapshot_policy</a> | This is a reference to the Snapshot copy policy. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage storage switches

### Storage switches endpoint overview

#### Retrieving storage switch information

The storage switch GET API retrieves all of the switches in the cluster.

#### Examples

1) Retrieves a list of storage switches from the cluster

The following example shows the response with a list of storage switches in the cluster:

```
# The API:
```



```
/api/storage/switches
```

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/switches" -H "accept: application/hal+json"
```

```
# The response:
```

```
{  
  "records": [  
    {  
      "name": "Brocade_10.226.57.206",  
      "_links": {  
        "self": {  
          "href": "/api/storage/switches/Brocade_10.226.57.206"  
        }  
      }  
    },  
    {  
      "name": "Brocade_10.226.57.207",  
      "_links": {  
        "self": {  
          "href": "/api/storage/switches/Brocade_10.226.57.207"  
        }  
      }  
    },  
    {  
      "name": "Brocade_10.226.57.208",  
      "_links": {  
        "self": {  
          "href": "/api/storage/switches/Brocade_10.226.57.208"  
        }  
      }  
    },  
    {  
      "name": "Brocade_10.226.57.209",  
      "_links": {  
        "self": {  
          "href": "/api/storage/switches/Brocade_10.226.57.209"  
        }  
      }  
    }  
  ],  
  "num_records": 4,  
  "_links": {  
    "self": {  
      "href": "/api/storage/switches/"  
    }  
  }  
}
```

```
}  
}  
}
```

## 2) Retrieves a specific storage switch from the cluster

The following example shows the response of the requested storage switch. If there is no storage switch with the requested name, an error is returned.

```
# The API:  
/api/storage/switches/{name}  
  
# The call:  
curl -X GET "https://<mgmt-ip>/api/storage/switches/Brocade_10.226.57.206"  
-H "accept: application/hal+json"  
  
# The response:  
{  
  "name": "Brocade_10.226.57.206",  
  "domain_id": 5,  
  "switch_fabric_name": "100050eb1a238892",  
  "fw_version": "v7.2.1c1",  
  "ip_address": "10.226.57.206",  
  "is_director_class": false,  
  "local": false,  
  "monitoring_enabled": true,  
  "model": "Brocade6510",  
  "role": "subordinate",  
  "state": "ok",  
  "symbolic_name": "rtp-fc01-41kk11",  
  "vendor": "brocade",  
  "wwn": "100050eb1a1ef7d7",  
  "power_supply_units": [  
    {  
      "name": "Power Supply #1",  
      "state": "ok"  
    },  
    {  
      "name": "Power Supply #2",  
      "state": "ok"  
    }  
  ],  
  "temperature_sensors": [  

```

```

    {
      "name": "SLOT #0: TEMP #1",
      "reading": 52,
      "state": "ok"
    }
  ],
  "ports": [
    {
      "name": "FC port 0/0",
      "mode": "f_port",
      "wwn": "200050eb1a1ef7d7",
      "enabled": true,
      "state": "online",
      "speed": 16,
      "sfp": {
        "type": "small_form_factor",
        "transmitter_type": "short_wave_laser",
        "serial_number": "HAA2140310058E5"
      }
    },
    {
      "name": "FC port 0/1",
      "mode": "f_port",
      "wwn": "200050eb1a1ef2d7",
      "enabled": true,
      "state": "online",
      "speed": 16,
      "sfp": {
        "type": "small_form_factor",
        "transmitter_type": "short_wave_laser",
        "serial_number": "HAA2140310058E5"
      }
    },
    {
      "name": "FC port 0/2",
      "mode": "f_port",
      "wwn": "200050eb1a1ef7d0",
      "enabled": true,
      "state": "online",
      "speed": 16,
      "sfp": {
        "type": "small_form_factor",
        "transmitter_type": "short_wave_laser",
        "serial_number": "HAA2140310058E5"
      }
    }
  ],

```

```

{
  "name": "FC port 0/3",
  "mode": "f_port",
  "wwn": "200050eb1a1ef7d7",
  "enabled": true,
  "state": "online",
  "speed": 16,
  "sfp": {
    "type": "small_form_factor",
    "transmitter_type": "short_wave_laser",
    "serial_number": "HAA2140310058E5"
  }
},
{
  "name": "FC port 0/4",
  "mode": "f_port",
  "wwn": "200050eb1a1ef2d7",
  "enabled": true,
  "state": "online",
  "speed": 16,
  "sfp": {
    "type": "small_form_factor",
    "transmitter_type": "short_wave_laser",
    "serial_number": "HAA2140310058E5"
  }
},
{
  "name": "FC port 0/5",
  "mode": "f_port",
  "wwn": "200050eb1a1ef7d0",
  "enabled": true,
  "state": "online",
  "speed": 16,
  "sfp": {
    "type": "small_form_factor",
    "transmitter_type": "short_wave_laser",
    "serial_number": "HAA2140310058E5"
  }
}
],
"connections": [
  {
    "source_port": {
      "name": "FC port 0/0",
      "wwn": "200050eb1a236efd",
      "mode": "f_port"
    }
  }
]

```

```

    },
    "peer_port": {
      "wwn": "2100000e1e30ac5f",
      "connection": "sti8020mcc-htp-006:fcvi_device_1",
      "type": "fcvi_adapter",
      "unique_id": "38993dc0-4ea1-11eb-9331-00a0985bd455"
    }
  },
  {
    "source_port": {
      "name": "FC port 0/1",
      "wwn": "200150eb1a236efd",
      "mode": "f_port"
    },
    "peer_port": {
      "wwn": "21000024ff72c0c9",
      "connection": "sti8020mcc-htp-006:2b",
      "type": "fcp_adapter",
      "unique_id": "38993dc0-4ea1-11eb-9331-00a0985bd455"
    }
  },
  {
    "source_port": {
      "name": "FC port 0/2",
      "wwn": "200250eb1a236efd",
      "mode": "f_port"
    },
    "peer_port": {
      "wwn": "21000024ff72c0cb",
      "connection": "sti8020mcc-htp-006:2d",
      "type": "fcp_adapter",
      "unique_id": "38993dc0-4ea1-11eb-9331-00a0985bd455"
    }
  }
],
"fans": [
  {
    "name": "FAN #1",
    "speed": 7336,
    "state": "ok"
  },
  {
    "name": "FAN #2",
    "speed": 7336,
    "state": "ok"
  }
]

```

```

],
"paths": [
  {
    "adapter": {
      "name": "2a",
      "wwn": "21000024ff6c4bc0",
      "type": "fc_initiator"
    },
    "port": {
      "name": "FC port 0/4",
      "speed": 8
    },
    "node": {
      "name": "sti8020mcc-htp-005",
      "uuid": "382cb083-4416-11eb-ad1d-00a0985bd455",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/382cb083-4416-11eb-ad1d-00a0985bd455"
        }
      }
    },
    "_links": {
      "self": {
        "href": "/api/storage/ports/382cb083-4416-11eb-ad1d-00a0985bd455/2a"
      }
    }
  },
  {
    "adapter": {
      "name": "2c",
      "wwn": "21000024ff6c4bc2",
      "type": "fc_initiator"
    },
    "port": {
      "name": "FC port 0/5",
      "speed": 8
    },
    "node": {
      "name": "sti8020mcc-htp-005",
      "uuid": "382cb083-4416-11eb-ad1d-00a0985bd455",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/382cb083-4416-11eb-ad1d-00a0985bd455"
        }
      }
    }
  }
]

```

```

    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/ports/382cb083-4416-11eb-ad1d-00a0985bd455/2c"
    }
  }
},
{
  "adapter": {
    "name": "fcvi_device_0",
    "wwn": "2100000ele09d5d2",
    "type": "fc_vi"
  },
  "port": {
    "name": "FC port 0/3",
    "speed": 16
  },
  "node": {
    "name": "sti8020mcc-htp-005",
    "uuid": "382cb083-4416-11eb-ad1d-00a0985bd455",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/382cb083-4416-11eb-ad1d-00a0985bd455"
      }
    }
  }
},
{
  "adapter": {
    "name": "2a",
    "wwn": "21000024ff72c0c8",
    "type": "fcp_initiator"
  },
  "port": {
    "name": "FC port 0/1",
    "speed": 8
  },
  "node": {
    "name": "sti8020mcc-htp-006",
    "uuid": "364fbba8-4416-11eb-8e72-00a098431045",
    "_links": {
      "self": {

```

```

        "href": "/api/cluster/nodes/364fbba8-4416-11eb-8e72-
00a098431045"
      }
    },
    "_links": {
      "self": {
        "href": "/api/storage/ports/364fbba8-4416-11eb-8e72-
00a098431045/2a"
      }
    }
  },
  {
    "adapter": {
      "name": "2c",
      "wwn": "21000024ff72c0ca",
      "type": "fcp_initiator"
    },
    "port": {
      "name": "FC port 0/2",
      "speed": 8
    },
    "node": {
      "name": "sti8020mcc-htp-006",
      "uuid": "364fbba8-4416-11eb-8e72-00a098431045",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/364fbba8-4416-11eb-8e72-
00a098431045"
        }
      }
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/ports/364fbba8-4416-11eb-8e72-
00a098431045/2c"
    }
  }
},
"_links": {
  "self": {
    "href": "/api/storage/switches/Brocade_10.226.57.206"
  }
}
}
}

```



## Retrieve storage switches

GET /storage/switches

**Introduced In:** 9.9

Retrieves a collection of storage switches.

### Related ONTAP commands

- `storage switch show`

### Learn more

- [DOC /storage/switches](#)

### Parameters

| Name           | Type          | In    | Required | Description   |
|----------------|---------------|-------|----------|---|
| fields         | array[string] | query | False    | Specify the fields to return.   |
| max_records    | integer       | query | False    | Limit the number of records returned.   |
| return_records | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"><li>• Default value: 1</li></ul>  |
| return_timeout | integer       | query | False    | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"><li>• Default value: 1</li><li>• Max value: 120</li><li>• Min value: 0</li></ul> |

| Name     | Type          | In    | Required | Description   |
|----------|---------------|-------|----------|---|
| order_by | array[string] | query | False    | Order results by specified fields and optional [asc |

## Response

Status: 200, Ok

| Name        | Type                                    | Description       |
|-------------|---|-------------------|
| _links      | <a href="#">_links</a>                  |                   |
| num_records | integer                                 | Number of records |
| records     | array[ <a href="#">storage_switch</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "connections": {
      "peer_port": {
        "type": "unknown"
      }
    },
    "errors": {
      "reason": {
        "arguments": {
          "code": "string",
          "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      },
      "severity": "unknown",
      "type": "switch_unreachable"
    },
    "fans": {
      "state": "ok"
    },
    "monitored_blades": {
    },
    "paths": {
      "adapter": {
        "type": "unknown"
      },
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",

```

```

    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"ports": {
  "mode": "unknown",
  "sfp": {
    "transmitter_type": "unknown",
    "type": "unknown"
  },
  "state": "error"
},
"power_supply_units": {
  "state": "ok"
},
"role": "unknown",
"state": "ok",
"temperature_sensors": {
  "state": "error"
},
"vendor": "unknown",
"vsans": {
  "state": "ok"
},
"zones": {
}
}
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

peer\_port

| Name       | Type   | Description                              |
|------------|--------|--|
| connection | string | Storage switch peer port host and name   |
| type       | string | Storage switch peer type                 |
| unique_id  | string | Storage switch peer unique ID            |
| wwn        | string | Storage switch peer port world wide name |

source\_port

| Name | Type   | Description                              |
|------|--------|--|
| mode | string | Storage switch port operating mode       |
| name | string | Storage switch port name                 |
| wwn  | string | Storage switch peer port world wide name |

connections

| Name        | Type                        | Description |
|-------------|-----------------------------|-------------|
| peer_port   | <a href="#">peer_port</a>   |             |
| source_port | <a href="#">source_port</a> |             |

component

| Name | Type    | Description          |
|------|---------|----------------------|
| id   | integer | Error component ID   |
| name | string  | Error component name |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### errors

| Name      | Type                      | Description              |
|-----------|---------------------------|--------------------------|
| component | <a href="#">component</a> |                          |
| reason    | <a href="#">error</a>     |                          |
| severity  | string                    | Error component severity |
| type      | string                    | Error component type     |

#### fans

| Name  | Type    | Description              |
|-------|---------|--------------------------|
| name  | string  | Storage switch fan name  |
| speed | integer | Storage switch fan speed |
| state | string  | Storage switch fan state |

## adapter

| Name | Type   | Description                  |
|------|--------|------------------------------|
| name | string | Node adapter name            |
| type | string | Node adapter type            |
| wwn  | string | Node adapter world wide name |

## \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

## node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

## port

| Name  | Type    | Description                        |
|-------|---------|------------------------------------|
| name  | string  | Storage switch port name           |
| speed | integer | Storage switch port speed, in Gbps |

## paths

| Name    | Type                    | Description |
|---------|-------------------------|-------------|
| adapter | <a href="#">adapter</a> |             |
| node    | <a href="#">node</a>    |             |
| port    | <a href="#">port</a>    |             |

## sfp

| Name          | Type   | Description                           |
|---------------|--------|---------------------------------------|
| serial_number | string | Storage switch port SFP serial number |



| Name             | Type   | Description                              |
|------------------|--------|--|
| transmitter_type | string | Storage switch port SFP transmitter type |
| type             | string | Storage switch port SFP type             |

#### ports

| Name    | Type                | Description   |
|---------|---------------------|---|
| enabled | boolean             | Indicates whether the storage switch port is enabled. |
| mode    | string              | Storage switch port mode                              |
| name    | string              | Storage switch port name                              |
| sfp     | <a href="#">sfp</a> |   |
| speed   | integer             | Storage switch port speed, in Gbps                    |
| state   | string              | Storage switch port state                             |
| wwn     | string              | Storage switch port world wide name                   |

#### power\_supply\_units

| Name  | Type   | Description             |
|-------|--------|-------------------------|
| name  | string | Power supply unit name  |
| state | string | Power supply unit state |

#### temperature\_sensors

| Name    | Type    | Description                                     |
|---------|---------|---|
| name    | string  | Temperature sensor name                         |
| reading | integer | Temperature sensor reading, in degrees celsius. |
| state   | string  | Temperature sensor state                        |

#### vsans

| Name                 | Type    | Description  |
|----------------------|---------|--|
| id                   | integer | Storage switch VSAN ID                                 |
| iod                  | boolean | Indicates whether in-order delivery is set for a zone. |
| load_balancing_types | string  | Storage switch VSAN load balancing type                |
| name                 | string  | Storage switch VSAN name                               |
| state                | string  | Storage switch VSAN Port state                         |

#### port

| Name | Type   | Description                 |
|------|--------|-----------------------------|
| id   | string | Storage switch zone port ID |
| name | string | Storage switch zone port    |

#### zones

| Name | Type                 | Description                         |
|------|----------------------|-------------------------------------|
| id   | integer              | Storage switch zone ID              |
| name | string               | Storage switch zone name            |
| port | <a href="#">port</a> |                                     |
| wwn  | string               | Storage switch zone world wide name |

#### storage\_switch

The Storage switch object describes the storage switch properties, features and cabling.

| Name           | Type                                 | Description |
|----------------|--------------------------------------|-------------|
| connections    | array[ <a href="#">connections</a> ] |             |
| director_class | boolean                              |             |
| domain_id      | integer                              | Domain ID   |
| errors         | array[ <a href="#">errors</a> ]      |             |

| Name                | Type                       | Description  |
|---------------------|----------------------------|--|
| fabric_name         | string                     | Storage switch fabric name   |
| fans                | array[fans]                |  |
| firmware_version    | string                     | Storage switch firmware version  |
| ip_address          | string                     | IP Address   |
| local               | boolean                    | Indicates whether the storage switch is directly connected to the reporting cluster. |
| model               | string                     | Storage switch model.  |
| monitored_blades    | array[integer]             | Indicates the blades that are being monitored for a director-class switch.           |
| monitoring_enabled  | boolean                    | Indicates whether monitoring is enabled for the storage switch.                      |
| name                | string                     | Storage switch name  |
| paths               | array[paths]               |  |
| ports               | array[ports]               |  |
| power_supply_units  | array[power_supply_units]  |  |
| role                | string                     | Storage switch role in fabric.   |
| state               | string                     | Storage switch state   |
| symbolic_name       | string                     | Storage switch symbolic name   |
| temperature_sensors | array[temperature_sensors] |  |
| vendor              | string                     | Storage switch vendor  |
| vsans               | array[vsans]               |  |
| wwn                 | string                     | Storage switch world wide name   |
| zones               | array[zones]               |  |

## Retrieve a specific storage switch

GET /storage/switches/{name}

## Introduced In: 9.9

Retrieves a specific storage switch.

### Related ONTAP commands

- `storage switch show`

### Learn more

- [DOC /storage/switches](#)

### Parameters

| Name   | Type          | In    | Required | Description                   |
|--------|---------------|-------|----------|-------------------------------|
| name   | string        | path  | True     |                               |
| fields | array[string] | query | False    | Specify the fields to return. |

### Response

```
Status: 200, Ok
```

| Name             | Type                                 | Description  |
|------------------|--------------------------------------|--|
| connections      | array[ <a href="#">connections</a> ] |  |
| director_class   | boolean                              |  |
| domain_id        | integer                              | Domain ID  |
| errors           | array[ <a href="#">errors</a> ]      |  |
| fabric_name      | string                               | Storage switch fabric name   |
| fans             | array[ <a href="#">fans</a> ]        |  |
| firmware_version | string                               | Storage switch firmware version  |
| ip_address       | string                               | IP Address   |
| local            | boolean                              | Indicates whether the storage switch is directly connected to the reporting cluster. |
| model            | string                               | Storage switch model.  |

| Name                | Type                       | Description  |
|---------------------|----------------------------|--|
| monitored_blades    | array[integer]             | Indicates the blades that are being monitored for a director-class switch. |
| monitoring_enabled  | boolean                    | Indicates whether monitoring is enabled for the storage switch.            |
| name                | string                     | Storage switch name  |
| paths               | array[paths]               |  |
| ports               | array[ports]               |  |
| power_supply_units  | array[power_supply_units]  |  |
| role                | string                     | Storage switch role in fabric.   |
| state               | string                     | Storage switch state   |
| symbolic_name       | string                     | Storage switch symbolic name   |
| temperature_sensors | array[temperature_sensors] |  |
| vendor              | string                     | Storage switch vendor  |
| vsans               | array[vsans]               |  |
| wwn                 | string                     | Storage switch world wide name   |
| zones               | array[zones]               |  |

## Example response

```
{
  "connections": {
    "peer_port": {
      "type": "unknown"
    }
  },
  "errors": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    },
    "severity": "unknown",
    "type": "switch_unreachable"
  },
  "fans": {
    "state": "ok"
  },
  "monitored_blades": {
  },
  "paths": {
    "adapter": {
      "type": "unknown"
    },
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "ports": {
    "mode": "unknown",
    "sfp": {
      "transmitter_type": "unknown",
      "type": "unknown"
    }
  },
}
```

```

    "state": "error"
  },
  "power_supply_units": {
    "state": "ok"
  },
  "role": "unknown",
  "state": "ok",
  "temperature_sensors": {
    "state": "error"
  },
  "vendor": "unknown",
  "vsans": {
    "state": "ok"
  },
  "zones": {
  }
}

```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

## Definitions



## See Definitions

### peer\_port

| Name       | Type   | Description                              |
|------------|--------|--|
| connection | string | Storage switch peer port host and name   |
| type       | string | Storage switch peer type                 |
| unique_id  | string | Storage switch peer unique ID            |
| wwn        | string | Storage switch peer port world wide name |

### source\_port

| Name | Type   | Description                              |
|------|--------|--|
| mode | string | Storage switch port operating mode       |
| name | string | Storage switch port name                 |
| wwn  | string | Storage switch peer port world wide name |

### connections

| Name        | Type                        | Description |
|-------------|-----------------------------|-------------|
| peer_port   | <a href="#">peer_port</a>   |             |
| source_port | <a href="#">source_port</a> |             |

### component

| Name | Type    | Description          |
|------|---------|----------------------|
| id   | integer | Error component ID   |
| name | string  | Error component name |

### error\_arguments

| Name | Type   | Description   |
|------|--------|---------------|
| code | string | Argument code |

| Name    | Type   | Description      |
|---------|--------|------------------|
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

#### errors

| Name      | Type                      | Description              |
|-----------|---------------------------|--------------------------|
| component | <a href="#">component</a> |                          |
| reason    | <a href="#">error</a>     |                          |
| severity  | string                    | Error component severity |
| type      | string                    | Error component type     |

#### fans

| Name  | Type    | Description              |
|-------|---------|--------------------------|
| name  | string  | Storage switch fan name  |
| speed | integer | Storage switch fan speed |
| state | string  | Storage switch fan state |

#### adapter

| Name | Type   | Description                  |
|------|--------|------------------------------|
| name | string | Node adapter name            |
| type | string | Node adapter type            |
| wwn  | string | Node adapter world wide name |

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |
| name   | string                 |             |
| uuid   | string                 |             |

port

| Name  | Type    | Description                        |
|-------|---------|------------------------------------|
| name  | string  | Storage switch port name           |
| speed | integer | Storage switch port speed, in Gbps |

paths

| Name    | Type                    | Description |
|---------|-------------------------|-------------|
| adapter | <a href="#">adapter</a> |             |
| node    | <a href="#">node</a>    |             |
| port    | <a href="#">port</a>    |             |

sfp

| Name             | Type   | Description                              |
|------------------|--------|--|
| serial_number    | string | Storage switch port SFP serial number    |
| transmitter_type | string | Storage switch port SFP transmitter type |
| type             | string | Storage switch port SFP type             |

## ports

| Name    | Type                | Description   |
|---------|---------------------|---|
| enabled | boolean             | Indicates whether the storage switch port is enabled. |
| mode    | string              | Storage switch port mode                              |
| name    | string              | Storage switch port name                              |
| sfp     | <a href="#">sfp</a> |   |
| speed   | integer             | Storage switch port speed, in Gbps                    |
| state   | string              | Storage switch port state                             |
| wwn     | string              | Storage switch port world wide name                   |

## power\_supply\_units

| Name  | Type   | Description             |
|-------|--------|-------------------------|
| name  | string | Power supply unit name  |
| state | string | Power supply unit state |

## temperature\_sensors

| Name    | Type    | Description                                     |
|---------|---------|---|
| name    | string  | Temperature sensor name                         |
| reading | integer | Temperature sensor reading, in degrees celsius. |
| state   | string  | Temperature sensor state                        |

## vsans

| Name | Type    | Description  |
|------|---------|--|
| id   | integer | Storage switch VSAN ID                                 |
| iod  | boolean | Indicates whether in-order delivery is set for a zone. |

| Name                 | Type   | Description                             |
|----------------------|--------|---|
| load_balancing_types | string | Storage switch VSAN load balancing type |
| name                 | string | Storage switch VSAN name                |
| state                | string | Storage switch VSAN Port state          |

port

| Name | Type   | Description                 |
|------|--------|-----------------------------|
| id   | string | Storage switch zone port ID |
| name | string | Storage switch zone port    |

zones

| Name | Type                 | Description                         |
|------|----------------------|-------------------------------------|
| id   | integer              | Storage switch zone ID              |
| name | string               | Storage switch zone name            |
| port | <a href="#">port</a> |                                     |
| wwn  | string               | Storage switch zone world wide name |

## Manage storage tape devices

### Storage tape-devices endpoint overview

#### Retrieving storage tape information

The storage tape GET API retrieves all of the tapes in the cluster.

#### Examples

##### 1) Retrieving a list of tapes from the cluster

The following example returns the list of tapes in the cluster:

```

# The API:
/api/storage/tape-devices

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/tape-devices" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "node": {
        "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
        "name": "st-8020-1-01",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-
00a0985ebbe7"
          }
        }
      },
      "device_id": "2d.0",
      "_links": {
        "self": {
          "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-
00a0985ebbe7/2d.0"
        }
      }
    },
    {
      "node": {
        "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
        "name": "st-8020-1-01",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-
00a0985ebbe7"
          }
        }
      },
      "device_id": "2d.0L1",
      "_links": {
        "self": {
          "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-
00a0985ebbe7/2d.0L1"
        }
      }
    }
  ]
}

```

```

    }
  },
  {
    "node": {
      "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
      "name": "st-8020-1-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
        }
      }
    },
    "device_id": "qeg-tape-brocade2-8g:0.126",
    "_links": {
      "self": {
        "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/qeg-tape-brocade2-8g%3A0.126"
      }
    }
  },
  {
    "node": {
      "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
      "name": "st-8020-1-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
        }
      }
    },
    "device_id": "stsw-broc6510-01:11.126",
    "_links": {
      "self": {
        "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/stsw-broc6510-01%3A11.126"
      }
    }
  },
  {
    "node": {
      "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
      "name": "st-8020-1-01",
      "_links": {
        "self": {

```

```

        "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
      }
    },
    "device_id": "stsw-broc6510-01:15.126",
    "_links": {
      "self": {
        "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/stsw-broc6510-01%3A15.126"
      }
    }
  },
  {
    "node": {
      "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
      "name": "st-8020-1-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
        }
      }
    },
    "device_id": "stsw-broc6510-01:15.126L1",
    "_links": {
      "self": {
        "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/stsw-broc6510-01%3A15.126L1"
      }
    }
  },
  {
    "node": {
      "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
      "name": "st-8020-1-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
        }
      }
    },
    "device_id": "stsw-broc6510-01:22.126",
    "_links": {
      "self": {

```



```

    "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/stsw-broc6510-01%3A22.126"
  }
}
},
{
  "node": {
    "uuid": "4083be52-5315-11eb-a839-00a0985ebbe7",
    "name": "st-8020-1-01",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/4083be52-5315-11eb-a839-00a0985ebbe7"
      }
    }
  },
  "device_id": "stsw-broc6510-01:23.126",
  "_links": {
    "self": {
      "href": "/api/storage/tape-devices/4083be52-5315-11eb-a839-00a0985ebbe7/stsw-broc6510-01%3A23.126"
    }
  }
},
],
"num_records": 7,
"_links": {
  "self": {
    "href": "/api/storage/tape-devices"
  }
}
}
}

```

## 2) Retrieving a specific tape device from the cluster

The following example returns the requested tape device. If there is no tape with the requested UID, an error is returned.

```

# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-

```

```
11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json"

# The response:
{
  "node": {
    "uuid": "5f5275eb-5315-11eb-8ac4-00a0985e0dcf",
    "name": "st-8020-1-02",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/5f5275eb-5315-11eb-8ac4-00a0985e0dcf"
      }
    }
  },
  "device_id": "2d.0",
  "type": "tape",
  "description": "IBM LTO-6 ULT3580",
  "alias": {
    "name": "st7",
    "mapping": "SN[1068000245]"
  },
  "aliases": [
    {
      "name": "st7",
      "mapping": "SN[1068000245]"
    }
  ],
  "wwnn": "5001697722ee0010",
  "wwpn": "5001697722ee0011",
  "serial_number": "1068000245",
  "interface": "sas",
  "device_state": "offline",
  "formats": [
    "LTO-4/5 Native Density",
    "LTO-4/5 Compressed",
    "LTO-6 2.5TB",
    "LTO-6 6.25TB Compressed"
  ],
  "storage_port": {
    "name": "2d"
  },
  "file_number": -1,
  "block_number": -1,
  "residual_count": 0,
  "density": "low",
  "device_names": [
    {
```

```
"rewind_device": "rst0l",
"no_rewind_device": "nrst0l",
"unload_reload_device": "urst0l"
},
{
"rewind_device": "rst0m",
"no_rewind_device": "nrst0m",
"unload_reload_device": "urst0m"
},
{
"rewind_device": "rst0h",
"no_rewind_device": "nrst0h",
"unload_reload_device": "urst0h"
},
{
"rewind_device": "rst0a",
"no_rewind_device": "nrst0a",
"unload_reload_device": "urst0a"
}
],
"reservation_type": "off",
"_links": {
"self": {
"href": "/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-
00a0985e0dcf/2d.0"
}
}
}
```

---

## Updating a tape device

The tape PATCH API allows the tape device to be set online or offline, positioned, and given an alias.

---

## Examples

### 1) Taking a tape device offline

The following example takes a tape device offline:

---

```
# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"online": "false"}'

# The response:
{
  "job": {
    "uuid": "9e544626-306e-11ec-8c2e-00a098b81daa",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/9e544626-306e-11ec-8c2e-00a098b81daa"
      }
    }
  }
}
```

---

## 2) Bringing a tape device online

The following example brings a tape device online:

---

```
# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"online": "true"}'

# The response:
{
  "job": {
    "uuid": "9e544626-306e-11ec-8c2e-00a098b81daa",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/9e544626-306e-11ec-8c2e-00a098b81daa"
      }
    }
  }
}
```

### 3) Giving a tape device an alias

The following example assigns an alias to a tape device:

```
# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"aliases": [{"name": "st0"}]}'

# The response:
{
}
```

### 4) Removing a tape device's aliases

The following example clears any aliases previously assigned to a tape device:

```
# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"aliases": []}'

# The response:
{
}
```

---

### 5) Rewinding a tape device

The following example rewinds a tape device:

```
# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"position": {"operation": "rewind"}}'

# The response:
{
  "job": {
    "uuid": "9e544626-306e-11ec-8c2e-00a098b81daa",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/9e544626-306e-11ec-8c2e-00a098b81daa"
      }
    }
  }
}
```

---

### 6) Forwarding the tape five files

The following example moves the tape forward five file records:

```

# The API:
/api/storage/tape-devices/{node.uuid}/{device_id}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/tape-devices/5f5275eb-5315-11eb-8ac4-00a0985e0dcf/2d.0" -H "accept: application/hal+json" -H "Content-Type: application/hal_json" -d '{"position": {"operation": "fsf", "count": 5}}'

# The response:
{
  "job": {
    "uuid": "954c20d5-306e-11ec-8c2e-00a098b81daa",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/954c20d5-306e-11ec-8c2e-00a098b81daa"
      }
    }
  }
}

```

## Retrieve tape devices

GET /storage/tape-devices

**Introduced In:** 9.9

Retrieves a collection of tape devices.

### Related ONTAP commands

- `storage tape show`

### Learn more

- [DOC /storage/tape-devices](#)

### Parameters

| Name      | Type   | In    | Required | Description         |
|-----------|--------|-------|----------|---------------------|
| formats   | string | query | False    | Filter by formats   |
| interface | string | query | False    | Filter by interface |

| Name                              | Type    | In    | Required | Description                                    |
|-----------------------------------|---------|-------|----------|--|
| online                            | boolean | query | False    | Filter by online<br><br>• Introduced in: 9.11  |
| density                           | string  | query | False    | Filter by density<br><br>• Introduced in: 9.11 |
| file_number                       | integer | query | False    | Filter by file_number                          |
| block_number                      | integer | query | False    | Filter by block_number                         |
| storage_port.name                 | string  | query | False    | Filter by storage_port.name                    |
| serial_number                     | string  | query | False    | Filter by serial_number                        |
| wwnn                              | string  | query | False    | Filter by wwnn                                 |
| device_id                         | string  | query | False    | Filter by device_id                            |
| type                              | string  | query | False    | Filter by type                                 |
| device_state                      | string  | query | False    | Filter by device_state                         |
| residual_count                    | integer | query | False    | Filter by residual_count                       |
| alias.mapping                     | string  | query | False    | Filter by alias.mapping                        |
| alias.name                        | string  | query | False    | Filter by alias.name                           |
| device_names.unload_reload_device | string  | query | False    | Filter by device_names.unload_reload_device    |
| device_names.no_rewind_device     | string  | query | False    | Filter by device_names.no_rewind_device        |



| Name                       | Type          | In    | Required | Description  |
|----------------------------|---------------|-------|----------|--|
| device_names.rewind_device | string        | query | False    | Filter by device_names.rewind_device   |
| node.uuid                  | string        | query | False    | Filter by node.uuid  |
| node.name                  | string        | query | False    | Filter by node.name  |
| wwpn                       | string        | query | False    | Filter by wwpn   |
| aliases.mapping            | string        | query | False    | Filter by aliases.mapping <ul style="list-style-type: none"> <li>• Introduced in: 9.11</li> </ul>  |
| aliases.name               | string        | query | False    | Filter by aliases.name <ul style="list-style-type: none"> <li>• Introduced in: 9.11</li> </ul>   |
| description                | string        | query | False    | Filter by description  |
| reservation_type           | string        | query | False    | Filter by reservation_type   |
| fields                     | array[string] | query | False    | Specify the fields to return.  |
| max_records                | integer       | query | False    | Limit the number of records returned.  |
| return_records             | boolean       | query | False    | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul> |

| Name           | Type          | In    | Required | Description  |
|----------------|---------------|-------|----------|--|
| return_timeout | integer       | query | False    | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |
| order_by       | array[string] | query | False    | Order results by specified fields and optional [asc  |

## Response

Status: 200, Ok

| Name        | Type                                 | Description       |
|-------------|--------------------------------------|-------------------|
| _links      | <a href="#">_links</a>               |                   |
| num_records | integer                              | Number of records |
| records     | array[ <a href="#">tape_device</a> ] |                   |

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "alias": {
      "mapping": "SN[10WT000933]",
      "name": "st6"
    },
    "aliases": {
      "mapping": "SN[10WT000933]",
      "name": "st6"
    },
    "block_number": 0,
    "density": "low",
    "description": "QUANTUM LTO-8 ULTRIUM",
    "device_id": "1a.0",
    "device_names": {
      "no_rewind_device": "nrst6l",
      "rewind_device": "rst6l",
      "unload_reload_device": "urst6l"
    },
    "device_state": "read_write_enabled",
    "file_number": 0,
    "formats": [
      "LTO-7 6TB",
      "LTO-7 15TB Compressed",
      "LTO-8 12TB",
      "LTO-8 30TB Compressed"
    ],
    "interface": "sas",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  }
}
```

```
    },
    "position": {
      "count": 5,
      "operation": "rewind"
    },
    "reservation_type": "off",
    "residual_count": 0,
    "serial_number": "10WT00093",
    "storage_port": {
      "name": "2b"
    },
    "type": "tape",
    "wwnn": "500507631295741c",
    "wwpn": "500507631295741c"
  }
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| next | <a href="#">href</a> |             |
| self | <a href="#">href</a> |             |

alias

| Name    | Type   | Description   |
|---------|--------|---|
| mapping | string | This field will no longer be supported in a future release. Use <code>aliases.mapping</code> instead. |
| name    | string | This field will no longer be supported in a future release. Use <code>aliases.name</code> instead.    |

aliases

| Name    | Type   | Description    |
|---------|--------|----------------|
| mapping | string | Alias mapping. |
| name    | string | Alias name.    |

device\_names

| Name                 | Type   | Description                                  |
|----------------------|--------|--|
| no_rewind_device     | string | Device name for no rewind.                   |
| rewind_device        | string | Device name for rewind.                      |
| unload_reload_device | string | Device name for unload or reload operations. |

\_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

node

| Name                   | Type                   | Description |
|------------------------|------------------------|-------------|
| <a href="#">_links</a> | <a href="#">_links</a> |             |
| name                   | string                 |             |
| uuid                   | string                 |             |

position

| Name      | Type    | Description                                |
|-----------|---------|--|
| count     | integer | Number of times to run position operation. |
| operation | string  | Position operation.                        |

storage\_port

| Name | Type   | Description     |
|------|--------|-----------------|
| name | string | Initiator port. |

tape\_device

| Name         | Type                                  | Description                      |
|--------------|---------------------------------------|----------------------------------|
| alias        | <a href="#">alias</a>                 |                                  |
| aliases      | array[ <a href="#">aliases</a> ]      |                                  |
| block_number | integer                               | Block number.                    |
| density      | string                                | Density.                         |
| description  | string                                |                                  |
| device_id    | string                                |                                  |
| device_names | array[ <a href="#">device_names</a> ] |                                  |
| device_state | string                                | Operational state of the device. |
| file_number  | integer                               | File number.                     |
| formats      | array[string]                         | Tape cartridge format.           |

| Name             | Type                         | Description                               |
|------------------|------------------------------|---|
| interface        | string                       | Device interface type.                    |
| node             | <a href="#">node</a>         |   |
| online           | boolean                      |   |
| position         | <a href="#">position</a>     |   |
| reservation_type | string                       |   |
| residual_count   | integer                      | Residual count of the last I/O operation. |
| serial_number    | string                       |   |
| storage_port     | <a href="#">storage_port</a> |   |
| type             | string                       | Device type.                              |
| wwnn             | string                       | World Wide Node Name.                     |
| wwpn             | string                       | World Wide Port Name.                     |

#### error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

#### error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Retrieve a tape device

GET /storage/tape-devices/{node.uuid}/{device\_id}

## Introduced In: 9.9

Retrieves a specific tape device.

### Related ONTAP commands

- `storage tape show`

### Learn more

- [DOC /storage/tape-devices](#)

### Parameters

| Name      | Type          | In    | Required | Description                   |
|-----------|---------------|-------|----------|-------------------------------|
| node.uuid | string        | path  | True     | Node UUID                     |
| device_id | string        | path  | True     | Device ID                     |
| fields    | array[string] | query | False    | Specify the fields to return. |

### Response

Status: 200, Ok

| Name         | Type                                  | Description                      |
|--------------|---------------------------------------|----------------------------------|
| alias        | <a href="#">alias</a>                 |                                  |
| aliases      | array[ <a href="#">aliases</a> ]      |                                  |
| block_number | integer                               | Block number.                    |
| density      | string                                | Density.                         |
| description  | string                                |                                  |
| device_id    | string                                |                                  |
| device_names | array[ <a href="#">device_names</a> ] |                                  |
| device_state | string                                | Operational state of the device. |
| file_number  | integer                               | File number.                     |
| formats      | array[string]                         | Tape cartridge format.           |
| interface    | string                                | Device interface type.           |



| Name             | Type         | Description                               |
|------------------|--------------|---|
| node             | node         |   |
| online           | boolean      |   |
| position         | position     |   |
| reservation_type | string       |   |
| residual_count   | integer      | Residual count of the last I/O operation. |
| serial_number    | string       |   |
| storage_port     | storage_port |   |
| type             | string       | Device type.                              |
| wwnn             | string       | World Wide Node Name.                     |
| wwpn             | string       | World Wide Port Name.                     |

## Example response

```
{
  "alias": {
    "mapping": "SN[10WT000933]",
    "name": "st6"
  },
  "aliases": {
    "mapping": "SN[10WT000933]",
    "name": "st6"
  },
  "block_number": 0,
  "density": "low",
  "description": "QUANTUM LTO-8 ULTRIUM",
  "device_id": "1a.0",
  "device_names": {
    "no_rewind_device": "nrst6l",
    "rewind_device": "rst6l",
    "unload_reload_device": "urst6l"
  },
  "device_state": "read_write_enabled",
  "file_number": 0,
  "formats": [
    "LTO-7 6TB",
    "LTO-7 15TB Compressed",
    "LTO-8 12TB",
    "LTO-8 30TB Compressed"
  ],
  "interface": "sas",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "position": {
    "count": 5,
    "operation": "rewind"
  },
  "reservation_type": "off",
  "residual_count": 0,
  "serial_number": "10WT00093",
  "storage_port": {
```

```
  "name": "2b"
},
"type": "tape",
"wwnn": "500507631295741c",
"wwpn": "500507631295741c"
}
```

## Error

Status: Default, Error

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

### alias

| Name    | Type   | Description   |
|---------|--------|---|
| mapping | string | This field will no longer be supported in a future release. Use <code>aliases.mapping</code> instead. |
| name    | string | This field will no longer be supported in a future release. Use <code>aliases.name</code> instead.    |

### aliases

| Name    | Type   | Description    |
|---------|--------|----------------|
| mapping | string | Alias mapping. |
| name    | string | Alias name.    |

### device\_names

| Name                 | Type   | Description                                  |
|----------------------|--------|--|
| no_rewind_device     | string | Device name for no rewind.                   |
| rewind_device        | string | Device name for rewind.                      |
| unload_reload_device | string | Device name for unload or reload operations. |

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

position

| Name      | Type    | Description                                |
|-----------|---------|--|
| count     | integer | Number of times to run position operation. |
| operation | string  | Position operation.                        |

storage\_port

| Name | Type   | Description     |
|------|--------|-----------------|
| name | string | Initiator port. |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Update a tape device

PATCH /storage/tape-devices/{node.uuid}/{device\_id}

Introduced In: 9.11

Updates a specific tape device.

### Related ONTAP commands

- `storage tape alias-set`
- `storage tape alias-clear`
- `storage tape online`
- `storage tape offline`
- `storage tape position`

### Learn more

- [DOC /storage/tape-devices](#)

### Parameters

| Name      | Type   | In   | Required | Description |
|-----------|--------|------|----------|-------------|
| node.uuid | string | path | True     | Node UUID   |
| device_id | string | path | True     | Device ID   |

| Name           | Type    | In    | Required | Description  |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False    | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul> |

### Request Body

| Name         | Type                                  | Description   |
|--------------|---------------------------------------|---------------|
| alias        | <a href="#">alias</a>                 |               |
| aliases      | array[ <a href="#">aliases</a> ]      |               |
| block_number | integer                               | Block number. |
| density      | string                                | Density.      |
| description  | string                                |               |
| device_id    | string                                |               |
| device_names | array[ <a href="#">device_names</a> ] |               |

| <b>Name</b>      | <b>Type</b>                  | <b>Description</b>                        |
|------------------|------------------------------|---|
| device_state     | string                       | Operational state of the device.          |
| file_number      | integer                      | File number.                              |
| formats          | array[string]                | Tape cartridge format.                    |
| interface        | string                       | Device interface type.                    |
| node             | <a href="#">node</a>         |   |
| online           | boolean                      |   |
| position         | <a href="#">position</a>     |   |
| reservation_type | string                       |   |
| residual_count   | integer                      | Residual count of the last I/O operation. |
| serial_number    | string                       |   |
| storage_port     | <a href="#">storage_port</a> |   |
| type             | string                       | Device type.                              |
| wwnn             | string                       | World Wide Node Name.                     |
| wwpn             | string                       | World Wide Port Name.                     |



## Example request

```
{
  "alias": {
    "mapping": "SN[10WT000933]",
    "name": "st6"
  },
  "aliases": {
    "mapping": "SN[10WT000933]",
    "name": "st6"
  },
  "block_number": 0,
  "density": "low",
  "description": "QUANTUM LTO-8 ULTRIUM",
  "device_id": "1a.0",
  "device_names": {
    "no_rewind_device": "nrst6l",
    "rewind_device": "rst6l",
    "unload_reload_device": "urst6l"
  },
  "device_state": "read_write_enabled",
  "file_number": 0,
  "formats": [
    "LTO-7 6TB",
    "LTO-7 15TB Compressed",
    "LTO-8 12TB",
    "LTO-8 30TB Compressed"
  ],
  "interface": "sas",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "position": {
    "count": 5,
    "operation": "rewind"
  },
  "reservation_type": "off",
  "residual_count": 0,
  "serial_number": "10WT00093",
  "storage_port": {
```

```

    "name": "2b"
  },
  "type": "tape",
  "wwnn": "500507631295741c",
  "wwpn": "500507631295741c"
}

```

## Response

Status: 200, Ok

## Response

Status: 202, Accepted

## Error

Status: Default

## ONTAP Error Response Codes

| Error Code | Description  |
|------------|--|
| 11403264   | Tape operation "<operation>" failed on tape device \"<device_id>\". This may indicate tape reached end of data, a hardware error, an illegal request, an invalid name format, or an aborted command.</device_id></operation> |
| 11403265   | Tape operation "<operation>" failed because it encountered an unexpected file mark on tape device \"<device_id>\".</device_id></operation>   |
| 11403266   | Internal error. Unknown tape parameter for tape device "<device_id>\".</device_id>   |
| 11403267   | Tape device "<device_id>" is busy.</device_id>   |
| 11403268   | No tape loaded for "<operation>" operation on tape drive \"<device_id>\".</device_id></operation>  |
| 11403269   | Tape device "<device_id>" unknown.</device_id>   |
| 11403270   | Tape alias name "<alias>" already exists.</alias>  |
| 11403271   | The format of the tape alias name "<alias>" is invalid. Use \"st\" or \"mcl\" followed by one or more digits.</alias>  |

| Error Code | Description   |
|------------|---|
| 11403273   | Internal error. Tape alias name "<alias>" not saved.</alias>  |
| 11403274   | Internal error. Tape alias operation "<operation>" for alias name "<alias>" failed.</alias></operation> |
| 11403275   | Tape alias name "<alias>" not found.</alias>  |
| 11403277   | Tape device "<device_id>" is reserved by another host.</device_id>                                      |
| 11403278   | Invalid count value specified with operation "<operation>". Valid values are from 0 to {1}.</operation> |

| Name  | Type  | Description |
|-------|-------|-------------|
| error | error |             |

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

### Definitions

## See Definitions

### alias

| Name    | Type   | Description  |
|---------|--------|--|
| mapping | string | This field will no longer be supported in a future release. Use aliases.mapping instead. |
| name    | string | This field will no longer be supported in a future release. Use aliases.name instead.    |

### aliases

| Name    | Type   | Description    |
|---------|--------|----------------|
| mapping | string | Alias mapping. |
| name    | string | Alias name.    |

### device\_names

| Name                 | Type   | Description                                  |
|----------------------|--------|--|
| no_rewind_device     | string | Device name for no rewind.                   |
| rewind_device        | string | Device name for rewind.                      |
| unload_reload_device | string | Device name for unload or reload operations. |

### href

| Name | Type   | Description |
|------|--------|-------------|
| href | string |             |

### \_links

| Name | Type                 | Description |
|------|----------------------|-------------|
| self | <a href="#">href</a> |             |

### node

| Name   | Type                   | Description |
|--------|------------------------|-------------|
| _links | <a href="#">_links</a> |             |

| Name | Type   | Description |
|------|--------|-------------|
| name | string |             |
| uuid | string |             |

#### position

| Name      | Type    | Description                                |
|-----------|---------|--|
| count     | integer | Number of times to run position operation. |
| operation | string  | Position operation.                        |

#### storage\_port

| Name | Type   | Description     |
|------|--------|-----------------|
| name | string | Initiator port. |

#### tape\_device

| Name         | Type                                  | Description                      |
|--------------|---------------------------------------|----------------------------------|
| alias        | <a href="#">alias</a>                 |                                  |
| aliases      | array[ <a href="#">aliases</a> ]      |                                  |
| block_number | integer                               | Block number.                    |
| density      | string                                | Density.                         |
| description  | string                                |                                  |
| device_id    | string                                |                                  |
| device_names | array[ <a href="#">device_names</a> ] |                                  |
| device_state | string                                | Operational state of the device. |
| file_number  | integer                               | File number.                     |
| formats      | array[string]                         | Tape cartridge format.           |
| interface    | string                                | Device interface type.           |
| node         | <a href="#">node</a>                  |                                  |
| online       | boolean                               |                                  |
| position     | <a href="#">position</a>              |                                  |

| Name             | Type                         | Description                               |
|------------------|------------------------------|---|
| reservation_type | string                       |   |
| residual_count   | integer                      | Residual count of the last I/O operation. |
| serial_number    | string                       |   |
| storage_port     | <a href="#">storage_port</a> |   |
| type             | string                       | Device type.                              |
| wwnn             | string                       | World Wide Node Name.                     |
| wwpn             | string                       | World Wide Port Name.                     |

error\_arguments

| Name    | Type   | Description      |
|---------|--------|------------------|
| code    | string | Argument code    |
| message | string | Message argument |

error

| Name      | Type                                     | Description                                 |
|-----------|--|---|
| arguments | array[ <a href="#">error_arguments</a> ] | Message arguments                           |
| code      | string                                   | Error code                                  |
| message   | string                                   | Error message                               |
| target    | string                                   | The target parameter that caused the error. |

## Manage volume efficiency policies

### Storage volume-efficiency-policies endpoint overview

#### Overview

Volume efficiency policies specify information about efficiency policies that are applied to the volume.

## Volume efficiency policy APIs

The following APIs are used to perform operations related to volume efficiency policy information:

&ndash; POST /api/storage/volume-efficiency-policies

&ndash; GET /api/storage/volume-efficiency-policies

&ndash; GET /api/storage/volume-efficiency-policies/{uuid}

&ndash; PATCH /api/storage/volume-efficiency-policies/{uuid}

&ndash; DELETE /api/storage/volume-efficiency-policies/{uuid}

## Examples

### Creating a volume efficiency policy

The POST operation is used to create a volume efficiency policy with the specified attributes.


```
# The API:
/api/storage/volume-efficiency-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/volume-efficiency-policies"
-H "accept: application/hal+json" -d '{"name": "new_policy", "type":
"scheduled", "schedule": { "name": "daily" }, "duration": "2",
"qos_policy": "best_effort", "enabled": "true", "comment": "schedule-
policy", "svm": { "name": "vs1"}}'
```

```
# The response:
HTTP/1.1 201 Created
Date: Tue, 12 Mar 2019 21:20:24 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Location: /api/storage/volume-efficiency-policies/a69d8173-450c-11e9-aa44-
005056bbc848
Content-Length: 369
Content-Type: application/json
{
  "num_records": 1,
  "records": [
    {
      "uuid": "a69d8173-450c-11e9-aa44-005056bbc848",
      "svm": {
        "name": "vs1"
      },
      "name": "new_policy",
      "type": "scheduled",
      "schedule":{
        "name": "daily"
      },
      "duration": "2",
      "qos_policy": "best_effort",
      "enabled": "true",
      "comment": "schedule-policy"
    }
  ]
}
```

### Retrieving volume efficiency policy attributes

The GET operation is used to retrieve volume efficiency policy attributes.





```
# The API:
/api/storage/volume-efficiency-policies

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/volume-efficiency-policies" -H
"accept: application/hal+json"

# The response:
HTTP/1.1 200 OK
Date: Tue, 12 Mar 2019 21:17:17 GMT
Server: libzapid-http
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 686
Content-Type: application/json
{
  "records": [
    {
      "uuid": "3c112527-2fe8-11e9-b55e-005056bbf1c8",
      "name": "default",
      "_links": {
        "self": {
          "href": "/api/storage/volume-efficiency-policies/3c112527-2fe8-
11e9-b55e-005056bbf1c8"
        }
      }
    },
    {
      "uuid": "3c1c1656-2fe8-11e9-b55e-005056bbf1c8",
      "name": "default-1weekly",
      "_links": {
        "self": {
          "href": "/api/storage/volume-efficiency-policies/3c1c1656-2fe8-
11e9-b55e-005056bbf1c8"
        }
      }
    },
    {
      "uuid": "3c228b82-2fe8-11e9-b55e-005056bbf1c8",
      "name": "none",
      "_links": {
        "self": {
          "href": "/api/storage/volume-efficiency-policies/3c228b82-2fe8-
11e9-b55e-005056bbf1c8"
        }
      }
    }
  ]
}
```

```

    }
  ],
  "num_records": 3,
  "_links": {
    "self": {
      "href": "/api/storage/volume-efficiency-policies/"
    }
  }
}
}

```

### Retrieving the attributes of a specific volume efficiency policy

The GET operation is used to retrieve the attributes of a specific volume efficiency policy.

### The API:

/api/storage/volume-efficiency-policies/{uuid}

### The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volume-efficiency-policies/3c112527-2fe8-11e9-b55e-005056bbf1c8" -H "accept: application/hal+json"</mgmt-ip>
```

### The response:

```
HTTP/1.1 200 OK Date: Tue, 12 Mar 2019 21:24:48 GMT Server: libzapid-httpd X-Content-Type-Options: nosniff Cache-Control: no-cache,no-store,must-revalidate Content-Length: 381 Content-Type: application/json {
  "uuid": "3c112527-2fe8-11e9-b55e-005056bbf1c8", "name": "new_policy", "type": "scheduled", "schedule": {
    "name": "daily" } "duration": "2", "qos_policy": "best_effort", "enabled": "true", "comment": "schedule-policy",
  "svm": { "name": "vs1" } "_links": { "self": { "href": "/api/storage/volume-efficiency-policies/3c112527-2fe8-11e9-b55e-005056bbf1c8" } } }
```

```
### Updating a volume efficiency policy
```

The PATCH operation is used to update the specific attributes of a volume efficiency policy.

### The API:

/api/storage/volume-efficiency-policies/{uuid}

### The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volume-efficiency-policies/ae9e65c4-4506-11e9-aa44-005056bbc848" -d '{"duration": "3"}' -H "accept: application/hal+json"</mgmt-ip>
```

### The response:

```
HTTP/1.1 200 OK Date: Tue, 12 Mar 2019 21:27:04 GMT Server: libzapid-httpd X-Content-Type-Options: nosniff Cache-Control: no-cache,no-store,must-revalidate Content-Length: 3 Content-Type: application/json
```

```
### Deleting a volume efficiency policy
The DELETE operation is used to delete a volume efficiency policy.
```

## The API:

```
/api/storage/volume-efficiency-policies/{uuid}
```

## The call:

```
curl -X DELETE "https://<mgmt-ip>/api/storage/volume-efficiency-policies/ ae9e65c4-4506-11e9-aa44-005056bbc848" -H "accept: application/hal+json"</mgmt-ip>
```

## The response:

```
HTTP/1.1 200 OK Date: Tue, 12 Mar 2019 21:19:04 GMT Server: libzapid-httpd X-Content-Type-Options: nosniff Cache-Control: no-cache,no-store,must-revalidate Content-Length: 3 Content-Type: application/json
```

```
[[IDaaad58a7becc80d3de260083f349291f]]
= Retrieve volume efficiency policies

[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volume-efficiency-policies`#

*Introduced In:* 9.8

Retrieves a collection of volume efficiency policies.

== Related ONTAP commands

* `volume efficiency policy show`

== Learn more

* xref:{relative_path}storage_volume-efficiency-policies_endpoint_overview.html[DOC /storage/volume-efficiency-policies]

== Parameters

[cols=5*,options=header]
|===
|Name
|Type
|In
|Required
```

```
|Description

|svm.uuid
|string
|query
|False
a|Filter by svm.uuid

|svm.name
|string
|query
|False
a|Filter by svm.name

|qos_policy
|string
|query
|False
a|Filter by qos_policy

|enabled
|boolean
|query
|False
a|Filter by enabled

|name
|string
|query
|False
a|Filter by name

|comment
|string
|query
|False
a|Filter by comment

|type
|string
|query
```

```
|False
a|Filter by type

|uuid
|string
|query
|False
a|Filter by uuid

|duration
|integer
|query
|False
a|Filter by duration

|start_threshold_percent
|integer
|query
|False
a|Filter by start_threshold_percent

|schedule.name
|string
|query
|False
a|Filter by schedule.name

|fields
|array[string]
|query
|False
a|Specify the fields to return.

|max_records
|integer
|query
|False
a|Limit the number of records returned.

|return_records
```

```
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
of records is returned.

* Default value: 1

|return_timeout
|integer
|query
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.

* Default value: 1
* Max value: 120
* Min value: 0

|order_by
|array[string]
|query
|False
a|Order results by specified fields and optional [asc|desc] direction.
Default direction is 'asc' for ascending.

|===

== Response
```

Status: 200, Ok

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|
```

```
|num_records
|integer
a|Number of records

|records
|array[link:#volume_efficiency_policy[volume_efficiency_policy]]
a|

|===
```

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "comment": "string",
    "duration": 5,
    "enabled": 1,
    "name": "default",
    "qos_policy": "background",
    "schedule": {
      "name": "daily"
    },
    "start_threshold_percent": 30,
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      }
    }
  },
}
```

```

    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "type": "threshold",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
}
====
== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]

```



```

.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|next
|link:#href[href]
a|

|self
|link:#href[href]
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#schedule]
[.api-collapsible-fifth-title]
schedule

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|Schedule at which volume efficiency policies are captured on the SVM.
Some common schedules already defined in the system are hourly, daily,
weekly, at 5 minute intervals, and at 8 hour intervals. Volume efficiency
policies with custom schedules can be referenced.

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#volume_efficiency_policy]
[.api-collapsible-fifth-title]
volume_efficiency_policy
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|comment
|string
a|A comment associated with the volume efficiency policy.
```

```
|duration
|integer
a|This field is used with the policy type "scheduled" to indicate the
allowed duration for a session, in hours. Possible value is a number
between 0 and 999 inclusive. Default is unlimited indicated by value 0.
```

```
|enabled
|boolean
a|Is the volume efficiency policy enabled?
```

```
|name
|string
a|Name of the volume efficiency policy.
```

|qos\_policy  
|string  
a|QoS policy for the sis operation. Possible values are background and best\_effort. In background, sis operation will run in background with minimal or no impact on data serving client operations. In best\_effort, sis operations may have some impact on data serving client operations.

|schedule  
|link:#schedule[schedule]  
a|

|start\_threshold\_percent  
|integer  
a|This field is used with the policy type "threshold" to indicate the threshold percentage for triggering the volume efficiency policy. It is mutually exclusive of the schedule.

|svm  
|link:#svm[svm]  
a|

|type  
|string  
a|Type of volume efficiency policy.

|uuid  
|string  
a|Unique identifier of volume efficiency policy.

|===

[#error\_arguments]  
[.api-collapsible-fifth-title]  
error\_arguments

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

```
|code
|string
a|Argument code
```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
```

```
====
```

```
[[IDdedd6623500741ecefcl0a62405abef5]]
```

```
= Create a volume efficiency policy
```

```
[.api-doc-operation .api-doc-operation-post]#POST# [.api-doc-code-block]#`/storage/volume-efficiency-policies`#
```

```
*Introduced In:* 9.8
```

```
Creates a volume efficiency policy.
```

```
== Required properties
```

```
* `svm.uuid` or `svm.name` - Existing SVM in which to create the volume efficiency policy.
```

```
* `name` - Name for the volume efficiency policy.
```

```
== Recommended optional properties
```

```
* `type` - Type of volume policy.
```

```
* `schedule` - Schedule the volume efficiency defined in minutes, hourly, daily and weekly.
```

```
* `duration` - Indicates the allowed duration for a session for policy type "scheduled".
```

```
* `start_threshold_percent` - Indicates the start threshold percentage for the policy type "threshold". It is mutually exclusive of the schedule.
```

```
* `qos_policy` - QoS policy for the sis operation.
```

```
* `comment` - A comment associated with the volume efficiency policy.
```

```
* `enabled` - Is the volume efficiency policy enabled?
```

```
== Default property values
```

```
If not specified in POST, the following default property values are assigned:
```

```
* `type` - scheduled
```

```
* `enabled` - true
```

```
* `qos_policy` - best_effort
```

```
== Related ONTAP commands
```

```
* `volume efficiency policy create`
```

== Learn more

\* xref:{relative\_path}storage\_volume-efficiency-policies\_endpoint\_overview.html[DOC /storage/volume-efficiency-policies]

== Parameters

[cols=5\*,options=header]

|===

|Name

|Type

|In

|Required

|Description

|return\_records

|boolean

|query

|False

a|The default is false. If set to true, the records are returned.

\* Default value:

|===

== Request Body

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|comment

|string

a|A comment associated with the volume efficiency policy.

|duration

```
|integer
a|This field is used with the policy type "scheduled" to indicate the
allowed duration for a session, in hours. Possible value is a number
between 0 and 999 inclusive. Default is unlimited indicated by value 0.

|enabled
|boolean
a|Is the volume efficiency policy enabled?

|name
|string
a|Name of the volume efficiency policy.

|qos_policy
|string
a|QoS policy for the sis operation. Possible values are background and
best_effort. In background, sis operation will run in background with
minimal or no impact on data serving client operations. In best_effort,
sis operations may have some impact on data serving client operations.

|schedule
|link:#schedule[schedule]
a|

|start_threshold_percent
|integer
a|This field is used with the policy type "threshold" to indicate the
threshold percentage for triggering the volume efficiency policy. It is
mutually exclusive of the schedule.

|svm
|link:#svm[svm]
a|

|type
|string
a|Type of volume efficiency policy.

|uuid
|string
a|Unique identifier of volume efficiency policy.
```



```
|===
```

```
.Example request
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{  
  "_links": {  
    "self": {  
      "href": "/api/resourcelink"  
    }  
  },  
  "comment": "string",  
  "duration": 5,  
  "enabled": 1,  
  "name": "default",  
  "qos_policy": "background",  
  "schedule": {  
    "name": "daily"  
  },  
  "start_threshold_percent": 30,  
  "svm": {  
    "_links": {  
      "self": {  
        "href": "/api/resourcelink"  
      }  
    },  
    "name": "svm1",  
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"  
  },  
  "type": "threshold",  
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"  
}
```

```
====
```

```
== Response
```

Status: 201, Created

```
== Error
```

Status: Default

## ONTAP Error Response Codes

|===

| Error Code | Description

| 6881341

| Specified schedule not found.

| 6881344

| Failed to queue specified job.

| 6881345

| This operation is not permitted on a node SVM.

| 6881349

| Policy name is not valid.

| 6881362

| Threshold percentage cannot be less than 1 percent.

| 6881433

| For "{\{0\}}" type policy, attribute "{\{1\}}" is not supported.

| 6881435

| Only a policy of type "threshold" can set the "start-threshold-percent" attribute.

| 6881436

| For a policy of type "scheduled", a valid "schedule" is a required attribute.

| 6881454

| An efficiency policy of type "threshold" requires an effective cluster version of ONTAP 8.3 or later.

| 6881474

| Duration cannot be null.

| 6881475

| Duration is not valid.

| 6881476

| Duration cannot be less than 1 hour.

| 6881477

| Duration cannot be more than 999 hours.

```

|===

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
=====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
=====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===

```

```
|Name
|Type
|Description
```

```
|href
|string
a|
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|self
|link:href[href]
a|
```

```
|===
```

```
[#schedule]
[.api-collapsible-fifth-title]
schedule
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|name
|string
a|Schedule at which volume efficiency policies are captured on the SVM.
Some common schedules already defined in the system are hourly, daily,
weekly, at 5 minute intervals, and at 8 hour intervals. Volume efficiency
policies with custom schedules can be referenced.
```

```
|===
```

```
[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#volume_efficiency_policy]
[.api-collapsible-fifth-title]
volume_efficiency_policy
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|comment
|string
a|A comment associated with the volume efficiency policy.
```

|duration  
|integer  
a|This field is used with the policy type "scheduled" to indicate the allowed duration for a session, in hours. Possible value is a number between 0 and 999 inclusive. Default is unlimited indicated by value 0.

|enabled  
|boolean  
a|Is the volume efficiency policy enabled?

|name  
|string  
a|Name of the volume efficiency policy.

|qos\_policy  
|string  
a|QoS policy for the sis operation. Possible values are background and best\_effort. In background, sis operation will run in background with minimal or no impact on data serving client operations. In best\_effort, sis operations may have some impact on data serving client operations.

|schedule  
|link:#schedule[schedule]  
a|

|start\_threshold\_percent  
|integer  
a|This field is used with the policy type "threshold" to indicate the threshold percentage for triggering the volume efficiency policy. It is mutually exclusive of the schedule.

|svm  
|link:#svm[svm]  
a|

|type  
|string  
a|Type of volume efficiency policy.

|uuid

```
|string  
a|Unique identifier of volume efficiency policy.
```

```
|===
```

```
[#error_arguments]  
[.api-collapsible-fifth-title]  
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|code  
|string  
a|Argument code
```

```
|message  
|string  
a|Message argument
```

```
|===
```

```
[#error]  
[.api-collapsible-fifth-title]  
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|arguments  
|array[link:#error_arguments[error_arguments]]  
a|Message arguments
```

```
|code  
|string
```

```

a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

[[IDeaa9ae144ad000a668f169bb7c95a51f]]
= Delete a volume efficiency policy

[.api-doc-operation .api-doc-operation-delete]#DELETE# [.api-doc-code-
block]#`/storage/volume-efficiency-policies/{uuid}`#

*Introduced In:* 9.8

Deletes a volume efficiency policy.

== Related ONTAP commands

* `volume efficiency policy modify`

== Learn more

* xref:{relative_path}storage_volume-efficiency-
policies_endpoint_overview.html[DOC /storage/volume-efficiency-policies]

== Parameters

[cols=5*,options=header]
|===

|Name

```



```

|Type
|In
|Required
|Description

|uuid
|string
|path
|True
a|Volume efficiency policy UUID

|===

== Response

```

Status: 200, Ok

```

== Error

```

Status: Default

ONTAP Error Response Code

```

|===
| Error Code | Description

| 6881346
| The policy was not deleted because the policy is in use by at least one
volume.

| 6881347
| This operation cannot be performed because the specified policy is owned
by the cluster admin.

| 6881431
| The specified policy is a predefined policy and cannot be deleted.
|===

```

```

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

```

```
|error
|link:#error[error]
a|
```

```
|===
```

```
.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
```

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

```
====
```

```
== Definitions
```

```
[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
```

```
====
```

```
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Argument code
```

```
|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
=====
```

```
[[ID01fb37a833a18f3a350b9aeb743b84dd]]
```

= Retrieve volume efficiency policy details

[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volume-efficiency-policies/{uuid}`#

\*Introduced In:\* 9.8

Retrieves the details of the specified volume efficiency policy.

== Related ONTAP commands

\* `volume efficiency policy show`

== Learn more

\* xref:{relative\_path}storage\_volume-efficiency-policies\_endpoint\_overview.html[DOC /storage/volume-efficiency-policies]

== Parameters

[cols=5\*,options=header]

|===

|Name

|Type

|In

|Required

|Description

|uuid

|string

|path

|True

a|Volume efficiency policy UUID

|fields

|array[string]

|query

|False

a|Specify the fields to return.

|===

== Response

Status: 200, Ok

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|comment
|string
a|A comment associated with the volume efficiency policy.

|duration
|integer
a|This field is used with the policy type "scheduled" to indicate the
allowed duration for a session, in hours. Possible value is a number
between 0 and 999 inclusive. Default is unlimited indicated by value 0.

|enabled
|boolean
a|Is the volume efficiency policy enabled?

|name
|string
a|Name of the volume efficiency policy.

|qos_policy
|string
a|QoS policy for the sis operation. Possible values are background and
best_effort. In background, sis operation will run in background with
minimal or no impact on data serving client operations. In best_effort,
sis operations may have some impact on data serving client operations.

|schedule
|link:#schedule[schedule]
a|
```

```
|start_threshold_percent
|integer
a|This field is used with the policy type "threshold" to indicate the
threshold percentage for triggering the volume efficiency policy. It is
mutually exclusive of the schedule.
```

```
|svm
|link:#svm[svm]
a|

|type
|string
a|Type of volume efficiency policy.
```

```
|uuid
|string
a|Unique identifier of volume efficiency policy.
```

```
|===
```

.Example response

```
[%collapsible%closed]
```

```
=====
```

```
[source,json,subs=+macros]
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "duration": 5,
  "enabled": 1,
  "name": "default",
  "qos_policy": "background",
  "schedule": {
    "name": "daily"
  },
  "start_threshold_percent": 30,
  "svm": {
    "_links": {
      "self": {
```

```

        "href": "/api/resourcelink"
    }
},
"name": "svm1",
"uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"type": "threshold",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
====
== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

```

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#schedule]
[.api-collapsible-fifth-title]
schedule

[cols=3*,options=header]
|===
|Name

```



```

|Type
|Description

|name
|string
a|Schedule at which volume efficiency policies are captured on the SVM.
Some common schedules already defined in the system are hourly, daily,
weekly, at 5 minute intervals, and at 8 hour intervals. Volume efficiency
policies with custom schedules can be referenced.

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===

```

```
|Name
|Type
|Description

|code
|string
a|Argument code
```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```

|===

//end collapsible .Definitions block
=====

[[IDd56da3f32ca4160d98ea9687b28e8eda]]
= Update a volume efficiency policy

[.api-doc-operation .api-doc-operation-patch]#PATCH# [.api-doc-code-
block]#`/storage/volume-efficiency-policies/{uuid}`#

*Introduced In:* 9.8

Updates a volume efficiency policy.

== Related ONTAP commands

* `volume efficiency policy modify`

== Learn more

* xref:{relative_path}storage_volume-efficiency-
policies_endpoint_overview.html[DOC /storage/volume-efficiency-policies]

== Parameters

[cols=5*,options=header]
|===

|Name
|Type
|In
|Required
|Description

|uuid
|string
|path
|True
a|Volume efficiency policy UUID

|===

```

## == Request Body

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|comment

|string

a|A comment associated with the volume efficiency policy.

|duration

|integer

a|This field is used with the policy type "scheduled" to indicate the allowed duration for a session, in hours. Possible value is a number between 0 and 999 inclusive. Default is unlimited indicated by value 0.

|enabled

|boolean

a|Is the volume efficiency policy enabled?

|name

|string

a|Name of the volume efficiency policy.

|qos\_policy

|string

a|QoS policy for the sis operation. Possible values are background and best\_effort. In background, sis operation will run in background with minimal or no impact on data serving client operations. In best\_effort, sis operations may have some impact on data serving client operations.

|schedule

|link:#schedule[schedule]

a|

```
|start_threshold_percent
|integer
a|This field is used with the policy type "threshold" to indicate the
threshold percentage for triggering the volume efficiency policy. It is
mutually exclusive of the schedule.
```

```
|svm
|link:#svm[svm]
a|
```

```
|type
|string
a|Type of volume efficiency policy.
```

```
|uuid
|string
a|Unique identifier of volume efficiency policy.
```

```
|===
```

```
.Example request
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "duration": 5,
  "enabled": 1,
  "name": "default",
  "qos_policy": "background",
  "schedule": {
    "name": "daily"
  },
  "start_threshold_percent": 30,
  "svm": {
    "_links": {
```

```
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"type": "threshold",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
====
== Response
```

Status: 200, Ok

```
== Error
```

Status: Default

ONTAP Error Response Code

|===

| Error Code | Description

| 6881341

| Specified schedule not found.

| 6881344

| Failed to queue specified job.

| 6881348

| This operation cannot be performed because the specified policy is owned by the cluster admin.

| 6881349

| Policy name is not valid.

| 6881362

| Threshold percentage cannot be less than 1 percent.

| 6881433

| For "{\{0\}}" type policy, "{\{1\}}" duration is not supported.

| 6881435

| Only a policy of type "threshold" can set the "start-threshold-percent" attribute.

| 6881436

| For a policy of type "scheduled", a valid "schedule" is a required attribute.

| 6881438

| For "{\{0\}}" policy, modification of attributes is not allowed.

| 6881474

| Duration cannot be null.

| 6881475

| Duration is not valid.

| 6881476

| Duration cannot be less than 1 hour.

| 6881477

| Duration cannot be more than 999 hours.

|===

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|error

|link:#error[error]

a|

|===

.Example error

[%collapsible%closed]

====

[source,json,subs=+macros]

{

  "error": {

    "arguments": {

      "code": "string",

      "message": "string"

```

    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

```

== Definitions

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====

```

```

[#href]
[.api-collapsible-fifth-title]
href

```

```

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

```

```

|href
|string
a|

```

```

|===

```

```

[#_links]
[.api-collapsible-fifth-title]
_links

```

```

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

```

```

|self
|link:#href[href]
a|

```

```

|===

```



```

[#schedule]
[.api-collapsible-fifth-title]
schedule

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|Schedule at which volume efficiency policies are captured on the SVM.
Some common schedules already defined in the system are hourly, daily,
weekly, at 5 minute intervals, and at 8 hour intervals. Volume efficiency
policies with custom schedules can be referenced.

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

```

```

|===

[#volume_efficiency_policy]
[.api-collapsible-fifth-title]
volume_efficiency_policy

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|comment
|string
a|A comment associated with the volume efficiency policy.

|duration
|integer
a|This field is used with the policy type "scheduled" to indicate the
allowed duration for a session, in hours. Possible value is a number
between 0 and 999 inclusive. Default is unlimited indicated by value 0.

|enabled
|boolean
a|Is the volume efficiency policy enabled?

|name
|string
a|Name of the volume efficiency policy.

|qos_policy
|string
a|QoS policy for the sis operation. Possible values are background and
best_effort. In background, sis operation will run in background with
minimal or no impact on data serving client operations. In best_effort,
sis operations may have some impact on data serving client operations.

```

```

|schedule
|link:#schedule[schedule]
a|

|start_threshold_percent
|integer
a|This field is used with the policy type "threshold" to indicate the
threshold percentage for triggering the volume efficiency policy. It is
mutually exclusive of the schedule.

|svm
|link:#svm[svm]
a|

|type
|string
a|Type of volume efficiency policy.

|uuid
|string
a|Unique identifier of volume efficiency policy.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument

```

```

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

:leveloffset: -1

= Manage storage volumes

```

```
:leveloffset: +1
```

```
[[IDb208e35ae6c382f63cd587aa7d2e0f82]]  
= Storage volumes endpoint overview
```

```
== Overview
```

FlexVol volumes are logical containers used by ONTAP to serve data to clients. They contain file systems in a NAS environment and LUNs in a SAN environment.

A FlexGroup volume is a scale-out NAS container that provides high performance along with automatic load distribution and scalability. A FlexGroup volume contains several constituents that automatically and transparently share the traffic.

FlexClone volumes are writable, point-in-time copies of a FlexVol volume. At this time, FlexClones of FlexGroups are not supported.

Volumes with SnapLock type Compliance or Enterprise, are referred to as SnapLock volumes. Volumes with SnapLock type cannot be of FlexGroup style. Once a SnapLock aggregate is created, by default, volumes created inside the aggregate inherit the "snaplock" property from the aggregate. It is possible to create a SnapLock volume by specifying SnapLock parameters. SnapLock parameters are only available at the "advanced" privilege level.

ONTAP storage APIs allow you to create, modify, and monitor volumes and aggregates.

```
== Storage efficiency
```

Storage efficiency is used to remove duplicate blocks in the data and to compress the data. Efficiency has deduplication, compression, cross volume deduplication, compaction, policy-name, enabled, application\_io\_size, compression\_type and storage\_efficiency\_mode options. On All Flash systems, all efficiencies are enabled by default, on volume creation. Options such as "background/inline/both" are treated as both, which means both background and inline are enabled for any efficiency option. The option "none" disables both background and inline efficiency. Application-io-size and compression-type decides type of compression behavior in the system. Storage efficiency mode decides if the system is to run in default/efficient mode. Detailed information about each field is available under efficiency object for storage efficiency fields.

To enable any efficiency option on all-flash or FAS systems, background deduplication is always enabled.

#### == Quotas

Quotas provide a way to restrict or track the files and space usage by a user, group, or qtree. Quotas are enabled for a specific FlexVol or a FlexGroup volume.

The following APIs can be used to enable or disable and obtain quota state for a FlexVol or a FlexGroup volume:

&ndash; PATCH /api/storage/volumes/{uuid} -d '{"quota.enabled":"true"}'

&ndash; PATCH /api/storage/volumes/{uuid} -d '{"quota.enabled":"false"}'

&ndash; GET /api/storage/volumes/{uuid}/?fields=quota.state

#### == File System Analytics

File system analytics provide a quick method for obtaining information summarizing properties of all files within any directory tree of a volume. For more information on file system analytics, see [xref:{relative\\_path}storage\\_volumes\\_volume.uuid\\_files\\_path\\_endpoint\\_overview.html\[DOC /storage/volumes{volume.uuid}/files/{path}\]](#) . Analytics can be enabled or disabled on individual volumes.

The following APIs can be used to enable or disable and obtain analytics state for a FlexVol volume or a FlexGroup volume:

&ndash; PATCH /api/storage/volumes/{uuid} -d '{"analytics.state":"on"}'

&ndash; PATCH /api/storage/volumes/{uuid} -d '{"analytics.state":"off"}'

&ndash; GET /api/storage/volumes/{uuid}/?fields=analytics

#### == QoS

QoS policy and settings enforce Service Level Objectives (SLO) on a volume. SLO can be set by specifying `qos.max_throughput_iops` and/or `qos.max_throughput_mbps` or `qos.min_throughput_iops` and/or `qos.min_throughput_mbps`. Specifying `min_throughput_iops` or `min_throughput_mbps` is only supported on volumes hosted on a node that is flash optimized. A pre-created QoS policy can also be used by specifying `qos.name` or `qos.uuid` property.

#### == Performance monitoring

Performance of a volume can be monitored by the ``metric.+*+`` and ``statistics.+*+`` fields. These show the performance of the volume in terms of IOPS, latency and throughput. The ``metric.+*+`` fields denote an average whereas ``statistics.+*+`` fields denote a real-time monotonically increasing value aggregated across all nodes.

## == Volume APIs

The following APIs are used to perform operations related with FlexVol volumes and FlexGroup volumes:

```
&ndash; POST      /api/storage/volumes
&ndash; GET      /api/storage/volumes
&ndash; GET      /api/storage/volumes/{uuid}
&ndash; PATCH    /api/storage/volumes/{uuid}
&ndash; DELETE   /api/storage/volumes/{uuid}
```

## == Examples

### === Creating a volume

The POST request is used to create a new volume and to specify its properties.

----

# The API:

```
/api/storage/volumes
```

# The call:

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes" -H "accept:
application/hal+json" -d '{"name": "vol1",
"aggregates":[{"name":"aggr1"}], "svm":{"name" : "vs1"}'}
```

# The response:

```
{
"job": {
  "uuid": "b89bc5dd-94a3-11e8-a7a3-0050568edf84",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/b89bc5dd-94a3-11e8-a7a3-0050568edf84"
    }
  }
}
```

```
    }  
  }  
}  
-----
```

=== Creating a SnapLock volume and specifying its properties using POST

-----

# The API:

/api/storage/volumes

# The call:

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes" -H "accept:  
application/hal+json" -d '{"name": "vol1", "aggregates":[{"name":  
"aggr1"}], "svm":{"name" : "vs1"}, "snaplock":{"retention":{"default":  
"P20Y"}, "type": "compliance"}}'
```

# The response:

```
{  
"job": {  
  "uuid": "e45b123b-c228-11e8-aa20-0050568e36bb",  
  "_links": {  
    "self": {  
      "href": "/api/cluster/jobs/e45b123b-c228-11e8-aa20-0050568e36bb"  
    }  
  }  
}  
}  
}
```

-----

=== Creating a FlexGroup volume and specifying its properties using POST

-----

# The API:

/api/storage/volumes

# The call:

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes" -H "accept:  
application/hal+json" -d '{"name" : "vol1", "state" : "online", "type" :  
"RW", "aggregates" : [{"name" : "aggr1"}, {"name" : "aggr2"},  
{"name":"aggr3"}], "constituents_per_aggregate" : "1", "svm" : {"name" :  
"vs1"}, "size" : "240MB", "encryption" : {"enabled" : "False"},  
"efficiency" : {"compression" : "both"}, "autosize" : {"maximum" :  
"500MB", "minimum" : "240MB"}}'
```



```

# The response:
{
"job": {
  "uuid": "3cfa38bd-3a78-11e9-ae39-0050568ed7dd",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/3cfa38bd-3a78-11e9-ae39-0050568ed7dd"
    }
  }
}
}
-----

=== Creating a FlexClone and specifying its properties using POST

-----

# The API:
/api/storage/volumes

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/volumes" -H "accept:
application/hal+json" -d '{"name":"voll_clone", "clone": {"parent_volume":
{"name": "voll1"}, "is_flexclone": "true"}, "svm":{"name": "vs0"}}'

# The response:
HTTP/1.1 202 Accepted
Date: Tue, 26 Feb 2019 09:06:22 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Location: /api/storage/volumes/?name=voll_clone
Content-Length: 189
Content-Type: application/hal+json
{
"job": {
  "uuid": "c9ee0040-39a5-11e9-9b24-00a098439a83",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/c9ee0040-39a5-11e9-9b24-00a098439a83"
    }
  }
}
}
}
-----

```

```
== Volumes reported in the GET REST API
```

```
=== The following types of volumes are reported:
```

```
&ndash; RW, DP and LS volumes
```

```
&ndash; FlexGroup volume
```

```
&ndash; FlexCache volume
```

```
&ndash; FlexClone volume
```

```
&ndash; FlexGroup constituent
```

```
=== The following volumes are not reported:
```

```
&ndash; DEL and TMP type volume
```

```
&ndash; Node Root volume
```

```
&ndash; System Vserver volume
```

```
&ndash; FlexCache constituent
```

```
== Examples
```

```
=== Retrieving the list of volumes
```

```
----
```

```
# The API:
```

```
/api/storage/volumes
```

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes" -H "accept: application/hal+json"
```

```
# The response:
```

```
{  
  "records": [  
    {  
      "uuid": "2d1167cc-c3f2-495a-a23f-8f50b071b9b8",  
      "name": "vsdata_root",  
      "_links": {  
        "self": {  
          "href": "/api/storage/volumes/2d1167cc-c3f2-495a-a23f-  
8f50b071b9b8"        }  
      }  
    }  
  ]  
}
```

```

    }
  },
  {
    "uuid": "3969be7e-78b4-4b4c-82a4-fa86331f03df",
    "name": "vsfg_root",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/3969be7e-78b4-4b4c-82a4-
fa86331f03df"
      }
    }
  },
  {
    "uuid": "59c03ac5-e708-4ce8-a676-278dc249fda2",
    "name": "svm_root",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/59c03ac5-e708-4ce8-a676-
278dc249fda2"
      }
    }
  },
  {
    "uuid": "6802635b-8036-11e8-aae5-0050569503ac",
    "name": "fgvol",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/6802635b-8036-11e8-aae5-
0050569503ac"
      }
    }
  },
  {
    "uuid": "d0c3359c-5448-4a9b-a077-e3295a7e9057",
    "name": "datavol",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/d0c3359c-5448-4a9b-a077-
e3295a7e9057"
      }
    }
  }
],
"num_records": 5,
"_links": {

```

```
"self": {
  "href": "/api/storage/volumes"
}
}
}
-----
```

=== Retrieving the attributes of a volume

The GET request is used to retrieve the attributes of a volume.

-----

# The API:

```
/api/storage/volumes/{uuid}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-a077-e3295a7e9057" -H "accept: application/hal+json"
```

# The response:

```
{
  "uuid": "d0c3359c-5448-4a9b-a077-e3295a7e9057",
  "comment": "This is a data volume",
  "create_time": "2018-07-05T14:56:44+05:30",
  "language": "en_us",
  "name": "datavol",
  "size": 20971520,
  "state": "online",
  "style": "flexvol",
  "tiering_policy": "auto",
  "type": "rw",
  "aggregates": [
    {
      "name": "data",
      "uuid": "aa742322-36bc-4d98-bbc4-0a827534c035",
      "_links": {
        "self": {
          "href": "/api/cluster/aggregates/data"
        }
      }
    }
  ],
  "encryption": {
    "enabled": false,
    "state": "none",
```

```
"key_id": "",
"type" : "none"
},
"error_state": {
  "has_bad_blocks": false,
  "is_inconsistent": false
},
"files": {
  "maximum": 566,
  "used": 96
},
"nas": {
  "gid": 2468,
  "security_style": "unix",
  "uid": 1357,
  "unix_permissions": 4755,
  "export_policy": {
    "name": "default",
    "id": 8589934593
  },
  "junction_parent": {
    "name": "voll",
    "uuid": "a2564f80-25fb-41e8-9b49-44de2600991f",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/a2564f80-25fb-41e8-9b49-44de2600991f"
      }
    }
  }
},
"metric": {
  "timestamp": "2019-04-09T05:50:15Z",
  "status": "ok",
  "duration": "PT15S",
  "latency": {
    "other": 0,
    "total": 0,
    "read": 0,
    "write": 0
  },
  "iops": {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  }
}
```

```
},
"throughput": {
  "read": 0,
  "write": 0,
  "other": 0,
  "total": 0
},
"cloud": {
  "timestamp": "2019-04-09T05:50:15Z",
  "status": "ok",
  "duration": "PT15S",
  "iops" : {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  },
  "latency": {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  }
},
"flexcache": {
  "timestamp": "2019-04-09T05:50:15Z",
  "status": "ok",
  "duration": "PT1D",
  "cache_miss_percent": 0,
  "bandwidth_savings": 0
}
},
"statistics": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
  "latency_raw": {
    "other": 38298,
    "total": 38298,
    "read": 0,
    "write": 0
  },
  "iops_raw": {
    "read": 0,
    "write": 0,
    "other": 3,
    "total": 3
  }
}
```

```
},
"throughput_raw": {
  "read": 0,
  "write": 0,
  "other": 0,
  "total": 0
},
"cloud": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
  "iops_raw" : {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  },
  "latency_raw": {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  }
},
"flexcache_raw": {
  "timestamp": "2019-04-09T05:50:15Z",
  "status": "ok",
  "cache_miss_blocks": 0,
  "client_requested_blocks": 0
}
},
"qos": {
  "policy": {
    "min_throughput_iops": 0,
    "min_throughput_mbps": 0,
    "max_throughput_iops": 1000,
    "max_throughput_mbps": 0,
    "uuid": "228454af-5a8b-11e9-bd5b-005056ac6f1f",
    "name": "pg1"
  }
},
"snaplock": {
  "append_mode_enabled": false,
  "autocommit_period": "none",
  "compliance_clock_time": "2019-05-24T10:59:00+05:30",
  "expiry_time": "2038-01-19T08:44:28+05:30",
  "is_audit_log": false,
```

```

    "litigation_count": 0,
    "privileged_delete": "disabled",
    "type": "enterprise",
    "retention": {
      "default": "P0Y",
      "minimum": "P0Y",
      "maximum": "P30Y"
    }
  },
  "snapshot_policy": {
    "name": "default"
  },
  "svm": {
    "name": "vsdata",
    "uuid": "d61b69f5-7458-11e8-ad3f-0050569503ac"
  },
  "anti_ransomware_state": "disabled",
  "_links": {
    "self": {
      "href": "/api/storage/volumes/d0c3359c-5448-4a9b-a077-e3295a7e9057"
    }
  }
}
}
}
-----

```

=== Retrieving the quota state of a FlexVol or a FlexGroup volume

-----

# The API:

```
/api/storage/volumes/{uuid}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717/?fields=quota.state" -H "accept: application/hal+json"
```

# The response:

```

{
  "uuid": "cb20da45-4f6b-11e9-9a71-005056a7f717",
  "name": "fv",
  "quota": {
    "state": "on"
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/cb20da45-4f6b-11e9-9a71-005056a7f717/"
    }
  }
}

```



```

}
}
}
----

=== Retrieving the constituents of a FlexGroup volume

----

# The API:
/api/storage/volumes/{uuid}

# The call:
curl -X GET "https://<mgmt-
ip>/api/storage/volumes?flexgroup.uuid=fd87d06f-8876-11ec-94a3-
005056a7484f&is_constituent=true" -H "accept: application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "fd877f7c-8876-11ec-94a3-005056a7484f",
    "name": "fg__0001",
    "flexgroup": {
      "uuid": "fd87d06f-8876-11ec-94a3-005056a7484f"
    },
    "_links": {
      "self": {
        "href": "/api/storage/volumes/fd877f7c-8876-11ec-94a3-
005056a7484f?is_constituent=true"
      }
    }
  },
  {
    "uuid": "fea631d6-8876-11ec-94a3-005056a7484f",
    "name": "fg__0002",
    "flexgroup": {
      "uuid": "fd87d06f-8876-11ec-94a3-005056a7484f"
    },
    "_links": {
      "self": {
        "href": "/api/storage/volumes/fea631d6-8876-11ec-94a3-
005056a7484f?is_constituent=true"
      }
    }
  },
}

```

```

{
  "uuid": "ff38a34e-8876-11ec-94a3-005056a7484f",
  "name": "fg__0003",
  "flexgroup": {
    "uuid": "fd87d06f-8876-11ec-94a3-005056a7484f"
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/ff38a34e-8876-11ec-94a3-005056a7484f?is_constituent=true"
    }
  }
},
{
  "uuid": "ffdbbd1f-8876-11ec-94a3-005056a7484f",
  "name": "fg__0004",
  "flexgroup": {
    "uuid": "fd87d06f-8876-11ec-94a3-005056a7484f"
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/ffdbbd1f-8876-11ec-94a3-005056a7484f?is_constituent=true"
    }
  }
}
],
"num_records": 4,
"_links": {
  "self": {
    "href": "/api/storage/volumes?flexgroup.uuid=fd87d06f-8876-11ec-94a3-005056a7484f&is_constituent=true"
  }
}
}
}
-----

```

=== Retrieving the efficiency attributes of volume

-----

# The API:

/api/storage/volumes/{uuid}

# The call:

curl -X GET "https://<mgmt-ip>/api/storage/volumes/5f098ebc-32c8-11eb-

```
8dde-005056ace228/?fields=efficiency" -H "accept: application/hal+json"
```

```
# The response:
```

```
{
"uuid": "5f098ebc-32c8-11eb-8dde-005056ace228",
"name": "vol1",
"efficiency": {
  "compression": "both",
  "dedupe": "background",
  "cross_volume_dedupe": "none",
  "compaction": "none",
  "schedule": "sun-sat@0",
  "svm": "vs0",
  "state": "enabled",
  "status": "idle",
  "type": "regular",
  "progress": "Idle for 00:10:37",
  "last_op_begin_timestamp": "Mon Nov 30 00:00:02 2020",
  "last_op_end_timestamp": "Mon Nov 30 00:00:03 2020",
  "last_op_state": "Success",
  "last_op_size": 0,
  "addr": "/vol/vol1",
  "policy": {
    "name": "-"
  }
},
"_links": {
  "self": {
    "href": "/api/storage/volumes/5f098ebc-32c8-11eb-8dde-005056ace228"
  }
}
}
```

```
----
```

```
== Updating the attributes of a volume
```

```
== Examples
```

```
=== Updating the attributes of a volume
```

```
The PATCH request is used to update the attributes of a volume.
```

```
----
```

```
# The API:
```

```
/api/storage/volumes/{uuid}
```

```
# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{ "size": 26214400, "nas": {"security_style":
"mixed"}, "comment": "This is a data volume" }' -H "accept:
application/hal+json"
```

```
# The response:
HTTP/1.1 202 Accepted
Date: Tue, 31 Jul 2018 09:36:43 GMT
Server: libzapid-httpd
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/hal+json
```

```
{
  "job": {
    "uuid": "3c5be5a6-94a5-11e8-8ca3-00505695c11b",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/3c5be5a6-94a5-11e8-8ca3-00505695c11b"
      }
    }
  }
}
}
}
-----
```

```
=== Updating the attributes of a FlexClone using PATCH
```

```
-----
```

```
# The API:
/api/storage/volumes/{uuid}
```

```
# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{"clone":{"split_initiated":"true"}}' -H "accept:
application/hal+json"
```

```
# The response:
HTTP/1.1 202 Accepted
Date: Mon, 25 Feb 2019 10:10:19 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/hal+json
{
```

```
"job": {
  "uuid": "8e01747f-38e5-11e9-8a3a-00a09843994b",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/8e01747f-38e5-11e9-8a3a-00a09843994b"
    }
  }
}
}
}
-----
```

=== Stopping a volume clone split operation on a FlexClone using PATCH.

-----

# The API:

/api/storage/volumes/{uuid}

# The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{"clone":{"split_initiated":"false"}}' -H "accept:
application/hal+json"
```

# The response:

HTTP/1.1 202 Accepted

Date: Wed, 03 Nov 2021 15:10:04 GMT

Server: libzapid-httpd

X-Content-Type-Options: nosniff

Cache-Control: no-cache,no-store,must-revalidate

Content-Length: 189

Content-Type: application/hal+json

```
{
"job": {
  "uuid": "1f8b3673-3cb8-11ec-b89e-005056bb2cb5",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/1f8b3673-3cb8-11ec-b89e-005056bb2cb5"
    }
  }
}
}
}
-----
```

=== Enabling quotas for a FlexVol or a FlexGroup volume using PATCH

-----

```
# The API:
/api/storage/volumes/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{"quota":{"enabled":"true"}}' -H "accept:
application/hal+json"

# The response:
HTTP/1.1 202 Accepted
Date: Mon, 25 Feb 2019 10:10:19 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/hal+json
{
  "job": {
    "uuid": "d2fe7299-57d0-11e9-a2dc-005056a7f717",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/d2fe7299-57d0-11e9-a2dc-005056a7f717"
      }
    }
  }
}
}
}
-----

=== Disabling quotas for a FlexVol or a FlexGroup volume using PATCH

-----

# The API:
/api/storage/volumes/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{"quota":{"enabled":"false"}}' -H "accept:
application/hal+json"

# The response:
HTTP/1.1 202 Accepted
Date: Mon, 25 Feb 2019 10:10:19 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
```

```
Content-Length: 189
Content-Type: application/hal+json
{
  "job": {
    "uuid": "0c8f6bea-57d1-11e9-a2dc-005056a7f717",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/0c8f6bea-57d1-11e9-a2dc-005056a7f717"
      }
    }
  }
}
}
-----
```

== Add tiering object tags for a FlexVol volume

The following example shows how to use a PATCH request to add tiering object tags for a FlexVol volume:

```
-----

# The API:
/api/storage/volumes/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-a077-e3295a7e9057" -d '{"tiering.object_tags": [ "key1=val1", "key2=val2" ]}' -H "accept: application/hal+json"

# The response:
HTTP/1.1 202 Accepted
Date: Tue, 11 Feb 2020 19:29:25 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/hal+json
{
  "job": {
    "uuid": "d05012de-4d04-11ea-836b-005056bb6f9d",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/d05012de-4d04-11ea-836b-005056bb6f9d"
      }
    }
  }
}
}
```

```

}
----

=== Remove tiering object tags for a FlexVol using PATCH

----

# The API:
/api/storage/volumes/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/d0c3359c-5448-4a9b-
a077-e3295a7e9057" -d '{"tiering.object_tags": []}' -H "accept:
application/hal+json"

# The response:
HTTP/1.1 202 Accepted
Date: Fri, 24 Jan 2020 22:28:04 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/hal+json
{
"job": {
  "uuid": "ca234df1-3ef8-11ea-9a56-005056bb69a1",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/ca234df1-3ef8-11ea-9a56-005056bb69a1"
    }
  }
}
}
}
----

== Deleting a volume

== Example

=== Deleting a volume

The DELETE request is used to delete a volume.

----

# The API:
/api/storage/volumes

```



```
# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/{uuid} " -H
"accept: application/hal+json"

# The response:
HTTP/1.1 202 Accepted
cache-control: no-cache,no-store,must-revalidate
connection: Keep-Alive
content-length: 189
content-type: application/json
date: Wed, 01 Aug 2018 09:40:36 GMT
keep-alive: timeout=5, max=100
server: libzapid-httpd
{
"job": {
  "uuid": "f1aa3eb8-956e-11e8-86bf-0050568e2249",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f1aa3eb8-956e-11e8-86bf-0050568e2249"
    }
  }
}
}
}
-----
```

```
[[ID8885ae2fb3907a0788554dcc5374df1f]]
= Retrieve volumes
```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-
block]#`/storage/volumes`#
```

\*Introduced In:\* 9.6

Retrieves volumes.

== Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [xref:{relative\\_path}getting\\_started\\_with\\_the\\_ontap\\_rest\\_api.html#Requestin](#) [g\\_specific\\_fields\[Requesting specific fields\]](#) to learn more.

```
* `is_svm_root`
* `analytics.+++`
* `anti_ransomware.+++`
* `application.+++`
* `encryption.+++`
* `queue_for_encryption`
* `convert_unicode`
* `clone.parent_snapshot.name`
* `clone.parent_snapshot.uuid`
* `clone.parent_svm.name`
* `clone.parent_svm.uuid`
* `clone.parent_volume.name`
* `clone.parent_volume.uuid`
* `clone.split_complete_percent`
* `clone.split_estimate`
* `clone.split_initiated`
* `efficiency.+++`
* `error_state.+++`
* `files.+++`
* `max_dir_size`
* `nas.export_policy.id`
* `nas.gid`
* `nas.path`
* `nas.security_style`
* `nas.uid`
* `nas.unix_permissions`
* `nas.junction_parent.name`
* `nas.junction_parent.uuid`
* `snaplock.+++`
* `restore_to.+++`
* `snapshot_policy.uuid`
* `quota.+++`
* `qos.+++`
* `flexcache_endpoint_type`
* `space.block_storage_inactive_user_data`
* `space.capacity_tier_footprint`
* `space.performance_tier_footprint`
* `space.local_tier_footprint`
* `space.footprint`
* `space.over_provisioned`
* `space.metadata`
* `space.total_footprint`
* `space.dedupe_metafiles_footprint`
* `space.dedupe_metafiles_temporary_footprint`
* `space.delayed_free_footprint`
```

```
* `space.file_operation_metadata`
* `space.snapmirror_destination_footprint`
* `space.volume_guarantee_footprint`
* `space.cross_volume_dedupe_metafiles_footprint`
* `space.cross_volume_dedupe_metafiles_temporary_footprint`
* `space.snapshot_reserve_unusable`
* `space.snapshot_spill`
* `space.user_data`
* `space.logical_space.+++`
* `space.snapshot.+++`
* `space.used_by_afs`
* `space.afs_total`
* `space.available_percent`
* `space.full_threshold_percent`
* `space.nearly_full_threshold_percent`
* `space.overwrite_reserve`
* `space.overwrite_reserve_used`
* `space.size_available_for_snapshots`
* `space.percent_used`
* `space.fractional_reserve`
* `space.block_storage_inactive_user_data_percent`
* `space.physical_used`
* `space.physical_used_percent`
* `space.expected_available`
* `space.filesystem_size`
* `space.filesystem_size_fixed`
* `guarantee.+++`
* `autosize.+++`
* `movement.+++`
* `statistics.+++`
* `constituents.name`
* `constituents.space.size`
* `constituents.space.available`
* `constituents.space.used`
* `constituents.space.available_percent`
* `constituents.space.used_percent`
* `constituents.space.block_storage_inactive_user_data`
* `constituents.space.capacity_tier_footprint`
* `constituents.space.performance_tier_footprint`
* `constituents.space.local_tier_footprint`
* `constituents.space.footprint`
* `constituents.space.over_provisioned`
* `constituents.space.metadata`
* `constituents.space.total_footprint`
* `constituents.space.logical_space.reporting`
* `constituents.space.logical_space.enforcement`
```

```
* `constituents.space.logical_space.used_by_afs`  
* `constituents.space.logical_space.available`  
* `constituents.space.snapshot.used`  
* `constituents.space.snapshot.reserve_percent`  
* `constituents.space.snapshot.autodelete_enabled`  
* `constituents.aggregates.name`  
* `constituents.aggregates.uuid`  
* `constituents.movement.destination_aggregate.name`  
* `constituents.movement.destination_aggregate.uuid`  
* `constituents.movement.state`  
* `constituents.movement.percent_complete`  
* `constituents.movement.cutover_window`  
* `constituents.movement.tiering_policy`  
* `asynchronous_directory_delete.+++`
```

== Related ONTAP commands

```
* `volume show`  
* `volume clone show`  
* `volume efficiency show`  
* `volume encryption show`  
* `volume flexcache show`  
* `volume flexgroup show`  
* `volume move show`  
* `volume quota show`  
* `volume show-space`  
* `volume snaplock show`  
* `security anti-ransomware volume show`  
* `security anti-ransomware volume space show`  
* `volume file async-delete client show`
```

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|is_constituent
```

```
|boolean
```

```
|query
```

```
|False
a|When set to false, only FlexVol and FlexGroup volumes are returned.
When set to true, only FlexGroup constituent volumes are returned. Default
for GET calls is false.

* Default value:
* Introduced in: 9.10

|name
|string
|query
|False
a|Filter by name

* maxLength: 203
* minLength: 1

|comment
|string
|query
|False
a|Filter by comment

* maxLength: 1023
* minLength: 0

|clone.parent_snapshot.name
|string
|query
|False
a|Filter by clone.parent_snapshot.name

|clone.parent_snapshot.uuid
|string
|query
|False
a|Filter by clone.parent_snapshot.uuid

|clone.split_estimate
|integer
|query
|False
```

```
a|Filter by clone.split_estimate
```

```
|clone.is_flexclone
```

```
|boolean
```

```
|query
```

```
|False
```

```
a|Filter by clone.is_flexclone
```

```
|clone.parent_svm.uuid
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by clone.parent_svm.uuid
```

```
|clone.parent_svm.name
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by clone.parent_svm.name
```

```
|clone.split_complete_percent
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by clone.split_complete_percent
```

```
|clone.parent_volume.name
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by clone.parent_volume.name
```

```
|clone.parent_volume.uuid
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by clone.parent_volume.uuid
```

```
|clone.split_initiated
```

```
|boolean
```

```
|query
|False
a|Filter by clone.split_initiated
```

```
|max_dir_size
|integer
|query
|False
a|Filter by max_dir_size
```

\* Introduced in: 9.10

```
|aggregates.uuid
|string
|query
|False
a|Filter by aggregates.uuid
```

```
|aggregates.name
|string
|query
|False
a|Filter by aggregates.name
```

```
|svm.uuid
|string
|query
|False
a|Filter by svm.uuid
```

```
|svm.name
|string
|query
|False
a|Filter by svm.name
```

```
|granular_data
|boolean
|query
|False
a|Filter by granular_data
```

\* Introduced in: 9.11

|analytics.supported  
|boolean  
|query  
|False  
a|Filter by analytics.supported

\* Introduced in: 9.8

|analytics.unsupported\_reason.code  
|string  
|query  
|False  
a|Filter by analytics.unsupported\_reason.code

\* Introduced in: 9.8

|analytics.unsupported\_reason.message  
|string  
|query  
|False  
a|Filter by analytics.unsupported\_reason.message

\* Introduced in: 9.8

|analytics.state  
|string  
|query  
|False  
a|Filter by analytics.state

\* Introduced in: 9.8

|analytics.scan\_progress  
|integer  
|query  
|False  
a|Filter by analytics.scan\_progress

\* Introduced in: 9.8



```
|language
|string
|query
|False
a|Filter by language
```

```
|flexgroup.name
|string
|query
|False
a|Filter by flexgroup.name
```

```
* Introduced in: 9.10
* maxLength: 203
* minLength: 1
```

```
|flexgroup.uuid
|string
|query
|False
a|Filter by flexgroup.uuid
```

```
* Introduced in: 9.10
```

```
|state
|string
|query
|False
a|Filter by state
```

```
|is_object_store
|boolean
|query
|False
a|Filter by is_object_store
```

```
* Introduced in: 9.8
```

```
|snapmirror.destinations.is_cloud
|boolean
```

```
|query
|False
a|Filter by snapmirror.destinations.is_cloud
```

\* Introduced in: 9.9

```
|snapmirror.destinations.is_ontap
|boolean
|query
|False
a|Filter by snapmirror.destinations.is_ontap
```

\* Introduced in: 9.9

```
|snapmirror.is_protected
|boolean
|query
|False
a|Filter by snapmirror.is_protected
```

\* Introduced in: 9.7

```
|style
|string
|query
|False
a|Filter by style
```

```
|access_time_enabled
|boolean
|query
|False
a|Filter by access_time_enabled
```

\* Introduced in: 9.8

```
|snaplock.retention.minimum
|string
|query
|False
a|Filter by snaplock.retention.minimum
```

```
|snaplock.retention.maximum
|string
|query
|False
a|Filter by snaplock.retention.maximum
```

```
|snaplock.retention.default
|string
|query
|False
a|Filter by snaplock.retention.default
```

```
|snaplock.unspecified_retention_file_count
|integer
|query
|False
a|Filter by snaplock.unspecified_retention_file_count
```

\* Introduced in: 9.8

```
|snaplock.is_audit_log
|boolean
|query
|False
a|Filter by snaplock.is_audit_log
```

```
|snaplock.expiry_time
|string
|query
|False
a|Filter by snaplock.expiry_time
```

```
|snaplock.litigation_count
|integer
|query
|False
a|Filter by snaplock.litigation_count
```

```
|snaplock.privileged_delete
|string
```

```
|query
|False
a|Filter by snaplock.privileged_delete

|snaplock.append_mode_enabled
|boolean
|query
|False
a|Filter by snaplock.append_mode_enabled

|snaplock.type
|string
|query
|False
a|Filter by snaplock.type

|snaplock.autocommit_period
|string
|query
|False
a|Filter by snaplock.autocommit_period

|snaplock.compliance_clock_time
|string
|query
|False
a|Filter by snaplock.compliance_clock_time

|autosize.mode
|string
|query
|False
a|Filter by autosize.mode

|autosize.shrink_threshold
|integer
|query
|False
a|Filter by autosize.shrink_threshold
```

```
|autosize.maximum  
|integer  
|query  
|False  
a|Filter by autosize.maximum
```

```
|autosize.grow_threshold  
|integer  
|query  
|False  
a|Filter by autosize.grow_threshold
```

```
|autosize.minimum  
|integer  
|query  
|False  
a|Filter by autosize.minimum
```

```
|metric.duration  
|string  
|query  
|False  
a|Filter by metric.duration
```

```
|metric.throughput.other  
|integer  
|query  
|False  
a|Filter by metric.throughput.other
```

```
|metric.throughput.read  
|integer  
|query  
|False  
a|Filter by metric.throughput.read
```

```
|metric.throughput.write  
|integer  
|query  
|False  
a|Filter by metric.throughput.write
```

```
|metric.throughput.total
|integer
|query
|False
a|Filter by metric.throughput.total
```

```
|metric.timestamp
|string
|query
|False
a|Filter by metric.timestamp
```

```
|metric.cloud.duration
|string
|query
|False
a|Filter by metric.cloud.duration
```

\* Introduced in: 9.7

```
|metric.cloud.status
|string
|query
|False
a|Filter by metric.cloud.status
```

\* Introduced in: 9.7

```
|metric.cloud.iops.other
|integer
|query
|False
a|Filter by metric.cloud.iops.other
```

\* Introduced in: 9.7

```
|metric.cloud.iops.read
|integer
|query
|False
```

a|Filter by metric.cloud.iops.read

\* Introduced in: 9.7

|metric.cloud.iops.write

|integer

|query

|False

a|Filter by metric.cloud.iops.write

\* Introduced in: 9.7

|metric.cloud.iops.total

|integer

|query

|False

a|Filter by metric.cloud.iops.total

\* Introduced in: 9.7

|metric.cloud.latency.other

|integer

|query

|False

a|Filter by metric.cloud.latency.other

\* Introduced in: 9.7

|metric.cloud.latency.read

|integer

|query

|False

a|Filter by metric.cloud.latency.read

\* Introduced in: 9.7

|metric.cloud.latency.write

|integer

|query

|False

a|Filter by metric.cloud.latency.write

\* Introduced in: 9.7

```
|metric.cloud.latency.total  
|integer  
|query  
|False  
a|Filter by metric.cloud.latency.total
```

\* Introduced in: 9.7

```
|metric.cloud.timestamp  
|string  
|query  
|False  
a|Filter by metric.cloud.timestamp
```

\* Introduced in: 9.7

```
|metric.flexcache.timestamp  
|string  
|query  
|False  
a|Filter by metric.flexcache.timestamp
```

\* Introduced in: 9.8

```
|metric.flexcache.duration  
|string  
|query  
|False  
a|Filter by metric.flexcache.duration
```

\* Introduced in: 9.8

```
|metric.flexcache.bandwidth_savings  
|integer  
|query  
|False  
a|Filter by metric.flexcache.bandwidth_savings
```

\* Introduced in: 9.9



```
|metric.flexcache.status  
|string  
|query  
|False  
a|Filter by metric.flexcache.status
```

\* Introduced in: 9.8

```
|metric.flexcache.cache_miss_percent  
|integer  
|query  
|False  
a|Filter by metric.flexcache.cache_miss_percent
```

\* Introduced in: 9.8

```
|metric.status  
|string  
|query  
|False  
a|Filter by metric.status
```

```
|metric.iops.other  
|integer  
|query  
|False  
a|Filter by metric.iops.other
```

```
|metric.iops.read  
|integer  
|query  
|False  
a|Filter by metric.iops.read
```

```
|metric.iops.write  
|integer  
|query  
|False  
a|Filter by metric.iops.write
```

```
|metric.iops.total
|integer
|query
|False
a|Filter by metric.iops.total
```

```
|metric.latency.other
|integer
|query
|False
a|Filter by metric.latency.other
```

```
|metric.latency.read
|integer
|query
|False
a|Filter by metric.latency.read
```

```
|metric.latency.write
|integer
|query
|False
a|Filter by metric.latency.write
```

```
|metric.latency.total
|integer
|query
|False
a|Filter by metric.latency.total
```

```
|flash_pool.cache_eligibility
|string
|query
|False
a|Filter by flash_pool.cache_eligibility
```

\* Introduced in: 9.10

```
|flash_pool.cache_retention_priority
|string
|query
```

```
|False
a|Filter by flash_pool.cache_retention_priority

* Introduced in: 9.10

|flash_pool.caching_policy
|string
|query
|False
a|Filter by flash_pool.caching_policy

* Introduced in: 9.10

|activity_tracking.state
|string
|query
|False
a|Filter by activity_tracking.state

* Introduced in: 9.10

|activity_tracking.supported
|boolean
|query
|False
a|Filter by activity_tracking.supported

* Introduced in: 9.10

|activity_tracking.unsupported_reason.message
|string
|query
|False
a|Filter by activity_tracking.unsupported_reason.message

* Introduced in: 9.10

|activity_tracking.unsupported_reason.code
|string
|query
|False
a|Filter by activity_tracking.unsupported_reason.code
```

\* Introduced in: 9.10

|msid  
|integer  
|query  
|False  
a|Filter by msid

\* Introduced in: 9.11

|tiering.policy  
|string  
|query  
|False  
a|Filter by tiering.policy

|tiering.min\_cooling\_days  
|integer  
|query  
|False  
a|Filter by tiering.min\_cooling\_days

\* Introduced in: 9.8

\* Max value: 183

\* Min value: 2

|tiering.object\_tags  
|string  
|query  
|False  
a|Filter by tiering.object\_tags

\* Introduced in: 9.8

\* maxLength: 257

|files.maximum  
|integer  
|query  
|False  
a|Filter by files.maximum

```
|files.used
|integer
|query
|False
a|Filter by files.used
```

```
|status
|string
|query
|False
a|Filter by status
```

\* Introduced in: 9.9

```
|application.uuid
|string
|query
|False
a|Filter by application.uuid
```

```
|application.name
|string
|query
|False
a|Filter by application.name
```

```
|asynchronous_directory_delete.trash_bin
|string
|query
|False
a|Filter by asynchronous_directory_delete.trash_bin
```

\* Introduced in: 9.11

```
|asynchronous_directory_delete.enabled
|boolean
|query
|False
a|Filter by asynchronous_directory_delete.enabled
```

\* Introduced in: 9.11

```
|is_svm_root
|boolean
|query
|False
a|Filter by is_svm_root
```

\* Introduced in: 9.7

```
|scheduled_snapshot_naming_scheme
|string
|query
|False
a|Filter by scheduled_snapshot_naming_scheme
```

\* Introduced in: 9.10

```
|idcs_scanner.status
|string
|query
|False
a|Filter by idcs_scanner.status
```

\* Introduced in: 9.11

```
|idcs_scanner.mode
|string
|query
|False
a|Filter by idcs_scanner.mode
```

\* Introduced in: 9.11

```
|idcs_scanner.operation_state
|string
|query
|False
a|Filter by idcs_scanner.operation_state
```

\* Introduced in: 9.11

```
|idcs_scanner.threshold_inactive_time
|string
|query
|False
a|Filter by idcs_scanner.threshold_inactive_time
```

\* Introduced in: 9.11

```
|idcs_scanner.enabled
|boolean
|query
|False
a|Filter by idcs_scanner.enabled
```

\* Introduced in: 9.11

```
|create_time
|string
|query
|False
a|Filter by create_time
```

```
|snapshot_policy.name
|string
|query
|False
a|Filter by snapshot_policy.name
```

```
|snapshot_policy.uuid
|string
|query
|False
a|Filter by snapshot_policy.uuid
```

```
|statistics.nfs_ops_raw.open.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.open.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.open.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.open.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.lock.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.lock.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.lock.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.lock.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.read.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.read.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.read.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.read.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.read.volume_protocol_size_histogram_counts
```



```
|integer
|query
|False
a|Filter by
statistics.nfs_ops_raw.read.volume_protocol_size_histogram_counts

* Introduced in: 9.11

|statistics.nfs_ops_raw.read.volume_protocol_latency_histogram_labels
|string
|query
|False
a|Filter by
statistics.nfs_ops_raw.read.volume_protocol_latency_histogram_labels

* Introduced in: 9.11

|statistics.nfs_ops_raw.read.volume_protocol_size_histogram_labels
|string
|query
|False
a|Filter by
statistics.nfs_ops_raw.read.volume_protocol_size_histogram_labels

* Introduced in: 9.11

|statistics.nfs_ops_raw.read.volume_protocol_latency_histogram_counts
|integer
|query
|False
a|Filter by
statistics.nfs_ops_raw.read.volume_protocol_latency_histogram_counts

* Introduced in: 9.11

|statistics.nfs_ops_raw.readlink.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.readlink.total_time

* Introduced in: 9.11
```

```
|statistics.nfs_ops_raw.readlink.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.readlink.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.access.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.access.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.access.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.access.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.unlink.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.unlink.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.unlink.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.unlink.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.audit.total_time
```

```
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.audit.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.audit.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.audit.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.lookup.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.lookup.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.lookup.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.lookup.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.create.symlink.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.symlink.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.create.symlink.count
|integer
|query
```

```
|False
a|Filter by statistics.nfs_ops_raw.create.symlink.count

* Introduced in: 9.11

|statistics.nfs_ops_raw.create.file.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.file.total_time

* Introduced in: 9.11

|statistics.nfs_ops_raw.create.file.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.file.count

* Introduced in: 9.11

|statistics.nfs_ops_raw.create.dir.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.dir.total_time

* Introduced in: 9.11

|statistics.nfs_ops_raw.create.dir.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.dir.count

* Introduced in: 9.11

|statistics.nfs_ops_raw.create.other.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.other.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.create.other.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.create.other.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.rename.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.rename.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.rename.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.rename.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.getattr.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.getattr.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.getattr.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.getattr.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.link.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.link.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.link.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.link.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.watch.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.watch.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.watch.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.watch.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.setattr.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.setattr.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.setattr.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.setattr.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.readdir.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.readdir.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.readdir.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.readdir.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.write.total_time
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.write.total_time
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.write.count
|integer
|query
|False
a|Filter by statistics.nfs_ops_raw.write.count
```

\* Introduced in: 9.11

```
|statistics.nfs_ops_raw.write.volume_protocol_size_histogram_counts
|integer
```

```
|query
|False
a|Filter by
statistics.nfs_ops_raw.write.volume_protocol_size_histogram_counts

* Introduced in: 9.11

|statistics.nfs_ops_raw.write.volume_protocol_latency_histogram_labels
|string
|query
|False
a|Filter by
statistics.nfs_ops_raw.write.volume_protocol_latency_histogram_labels

* Introduced in: 9.11

|statistics.nfs_ops_raw.write.volume_protocol_size_histogram_labels
|string
|query
|False
a|Filter by
statistics.nfs_ops_raw.write.volume_protocol_size_histogram_labels

* Introduced in: 9.11

|statistics.nfs_ops_raw.write.volume_protocol_latency_histogram_counts
|integer
|query
|False
a|Filter by
statistics.nfs_ops_raw.write.volume_protocol_latency_histogram_counts

* Introduced in: 9.11

|statistics.status
|string
|query
|False
a|Filter by statistics.status

|statistics.iops_raw.other
|integer
```



```
|query
|False
a|Filter by statistics.iops_raw.other

|statistics.iops_raw.read
|integer
|query
|False
a|Filter by statistics.iops_raw.read

|statistics.iops_raw.write
|integer
|query
|False
a|Filter by statistics.iops_raw.write

|statistics.iops_raw.total
|integer
|query
|False
a|Filter by statistics.iops_raw.total

|statistics.cloud.timestamp
|string
|query
|False
a|Filter by statistics.cloud.timestamp

* Introduced in: 9.7

|statistics.cloud.iops_raw.other
|integer
|query
|False
a|Filter by statistics.cloud.iops_raw.other

* Introduced in: 9.7

|statistics.cloud.iops_raw.read
|integer
|query
```

```
|False
a|Filter by statistics.cloud.iops_raw.read

* Introduced in: 9.7

|statistics.cloud.iops_raw.write
|integer
|query
|False
a|Filter by statistics.cloud.iops_raw.write

* Introduced in: 9.7

|statistics.cloud.iops_raw.total
|integer
|query
|False
a|Filter by statistics.cloud.iops_raw.total

* Introduced in: 9.7

|statistics.cloud.status
|string
|query
|False
a|Filter by statistics.cloud.status

* Introduced in: 9.7

|statistics.cloud.latency_raw.other
|integer
|query
|False
a|Filter by statistics.cloud.latency_raw.other

* Introduced in: 9.7

|statistics.cloud.latency_raw.read
|integer
|query
|False
a|Filter by statistics.cloud.latency_raw.read
```

\* Introduced in: 9.7

```
|statistics.cloud.latency_raw.write  
|integer  
|query  
|False  
a|Filter by statistics.cloud.latency_raw.write
```

\* Introduced in: 9.7

```
|statistics.cloud.latency_raw.total  
|integer  
|query  
|False  
a|Filter by statistics.cloud.latency_raw.total
```

\* Introduced in: 9.7

```
|statistics.throughput_raw.other  
|integer  
|query  
|False  
a|Filter by statistics.throughput_raw.other
```

```
|statistics.throughput_raw.read  
|integer  
|query  
|False  
a|Filter by statistics.throughput_raw.read
```

```
|statistics.throughput_raw.write  
|integer  
|query  
|False  
a|Filter by statistics.throughput_raw.write
```

```
|statistics.throughput_raw.total  
|integer  
|query  
|False
```

```
a|Filter by statistics.throughput_raw.total
```

```
|statistics.timestamp
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by statistics.timestamp
```

```
|statistics.flexcache_raw.client_requested_blocks
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by statistics.flexcache_raw.client_requested_blocks
```

```
* Introduced in: 9.8
```

```
|statistics.flexcache_raw.status
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by statistics.flexcache_raw.status
```

```
* Introduced in: 9.8
```

```
|statistics.flexcache_raw.cache_miss_blocks
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by statistics.flexcache_raw.cache_miss_blocks
```

```
* Introduced in: 9.8
```

```
|statistics.flexcache_raw.timestamp
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by statistics.flexcache_raw.timestamp
```

```
* Introduced in: 9.8
```

```
|statistics.cifs_ops_raw.open.total_time
```

```
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.open.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.open.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.open.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.lock.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.lock.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.lock.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.lock.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.read.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.read.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.read.count
|integer
|query
```

```
|False
a|Filter by statistics.cifs_ops_raw.read.count

* Introduced in: 9.11

|statistics.cifs_ops_raw.read.volume_protocol_size_histogram_counts
|integer
|query
|False
a|Filter by
statistics.cifs_ops_raw.read.volume_protocol_size_histogram_counts

* Introduced in: 9.11

|statistics.cifs_ops_raw.read.volume_protocol_latency_histogram_labels
|string
|query
|False
a|Filter by
statistics.cifs_ops_raw.read.volume_protocol_latency_histogram_labels

* Introduced in: 9.11

|statistics.cifs_ops_raw.read.volume_protocol_size_histogram_labels
|string
|query
|False
a|Filter by
statistics.cifs_ops_raw.read.volume_protocol_size_histogram_labels

* Introduced in: 9.11

|statistics.cifs_ops_raw.read.volume_protocol_latency_histogram_counts
|integer
|query
|False
a|Filter by
statistics.cifs_ops_raw.read.volume_protocol_latency_histogram_counts

* Introduced in: 9.11

|statistics.cifs_ops_raw.readlink.total_time
```

```
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.readlink.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.readlink.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.readlink.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.access.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.access.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.access.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.access.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.unlink.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.unlink.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.unlink.count
|integer
|query
```

```
|False  
a|Filter by statistics.cifs_ops_raw.unlink.count
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.audit.total_time  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.audit.total_time
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.audit.count  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.audit.count
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.lookup.total_time  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.lookup.total_time
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.lookup.count  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.lookup.count
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.create.symlink.total_time  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.create.symlink.total_time
```



\* Introduced in: 9.11

|statistics.cifs\_ops\_raw.create.symlink.count

|integer

|query

|False

a|Filter by statistics.cifs\_ops\_raw.create.symlink.count

\* Introduced in: 9.11

|statistics.cifs\_ops\_raw.create.file.total\_time

|integer

|query

|False

a|Filter by statistics.cifs\_ops\_raw.create.file.total\_time

\* Introduced in: 9.11

|statistics.cifs\_ops\_raw.create.file.count

|integer

|query

|False

a|Filter by statistics.cifs\_ops\_raw.create.file.count

\* Introduced in: 9.11

|statistics.cifs\_ops\_raw.create.dir.total\_time

|integer

|query

|False

a|Filter by statistics.cifs\_ops\_raw.create.dir.total\_time

\* Introduced in: 9.11

|statistics.cifs\_ops\_raw.create.dir.count

|integer

|query

|False

a|Filter by statistics.cifs\_ops\_raw.create.dir.count

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.create.other.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.create.other.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.create.other.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.create.other.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.rename.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.rename.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.rename.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.rename.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.getattr.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.getattr.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.getattr.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.getattr.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.link.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.link.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.link.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.link.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.watch.total_time
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.watch.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.watch.count
|integer
|query
|False
a|Filter by statistics.cifs_ops_raw.watch.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.setattr.total_time
|integer
```

```
|query  
|False  
a|Filter by statistics.cifs_ops_raw.setattr.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.setattr.count  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.setattr.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.readdir.total_time  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.readdir.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.readdir.count  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.readdir.count
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.write.total_time  
|integer  
|query  
|False  
a|Filter by statistics.cifs_ops_raw.write.total_time
```

\* Introduced in: 9.11

```
|statistics.cifs_ops_raw.write.count  
|integer  
|query  
|False
```

```
a|Filter by statistics.cifs_ops_raw.write.count
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.write.volume_protocol_size_histogram_counts
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by
```

```
statistics.cifs_ops_raw.write.volume_protocol_size_histogram_counts
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.write.volume_protocol_latency_histogram_labels
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by
```

```
statistics.cifs_ops_raw.write.volume_protocol_latency_histogram_labels
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.write.volume_protocol_size_histogram_labels
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by
```

```
statistics.cifs_ops_raw.write.volume_protocol_size_histogram_labels
```

```
* Introduced in: 9.11
```

```
|statistics.cifs_ops_raw.write.volume_protocol_latency_histogram_counts
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by
```

```
statistics.cifs_ops_raw.write.volume_protocol_latency_histogram_counts
```

```
* Introduced in: 9.11
```

```
|statistics.latency_raw.other
```

```
|integer
```

```
|query
|False
a|Filter by statistics.latency_raw.other
```

```
|statistics.latency_raw.read
|integer
|query
|False
a|Filter by statistics.latency_raw.read
```

```
|statistics.latency_raw.write
|integer
|query
|False
a|Filter by statistics.latency_raw.write
```

```
|statistics.latency_raw.total
|integer
|query
|False
a|Filter by statistics.latency_raw.total
```

```
|queue_for_encryption
|boolean
|query
|False
a|Filter by queue_for_encryption
```

\* Introduced in: 9.8

```
|constituents.movement.destination_aggregate.uuid
|string
|query
|False
a|Filter by constituents.movement.destination_aggregate.uuid
```

\* Introduced in: 9.9

```
|constituents.movement.destination_aggregate.name
|string
|query
```

```
|False  
a|Filter by constituents.movement.destination_aggregate.name
```

```
* Introduced in: 9.9
```

```
|constituents.movement.percent_complete  
|integer  
|query  
|False  
a|Filter by constituents.movement.percent_complete
```

```
* Introduced in: 9.9
```

```
|constituents.movement.state  
|string  
|query  
|False  
a|Filter by constituents.movement.state
```

```
* Introduced in: 9.9
```

```
|constituents.movement.cutover_window  
|integer  
|query  
|False  
a|Filter by constituents.movement.cutover_window
```

```
* Introduced in: 9.9
```

```
|constituents.aggregates.name  
|string  
|query  
|False  
a|Filter by constituents.aggregates.name
```

```
* Introduced in: 9.9
```

```
|constituents.aggregates.uuid  
|string  
|query  
|False  
a|Filter by constituents.aggregates.uuid
```

\* Introduced in: 9.9

```
|constituents.space.capacity_tier_footprint
|integer
|query
|False
a|Filter by constituents.space.capacity_tier_footprint
```

\* Introduced in: 9.9

```
|constituents.space.over_provisioned
|integer
|query
|False
a|Filter by constituents.space.over_provisioned
```

\* Introduced in: 9.9

```
|constituents.space.available_percent
|integer
|query
|False
a|Filter by constituents.space.available_percent
```

\* Introduced in: 9.9

```
|constituents.space.used_by_afs
|integer
|query
|False
a|Filter by constituents.space.used_by_afs
```

\* Introduced in: 9.9

```
|constituents.space.logical_space.reporting
|boolean
|query
|False
a|Filter by constituents.space.logical_space.reporting
```

\* Introduced in: 9.9



```
|constituents.space.logical_space.used_by_afs
|integer
|query
|False
a|Filter by constituents.space.logical_space.used_by_afs
```

\* Introduced in: 9.9

```
|constituents.space.logical_space.enforcement
|boolean
|query
|False
a|Filter by constituents.space.logical_space.enforcement
```

\* Introduced in: 9.9

```
|constituents.space.logical_space.available
|integer
|query
|False
a|Filter by constituents.space.logical_space.available
```

\* Introduced in: 9.9

```
|constituents.space.total_footprint
|integer
|query
|False
a|Filter by constituents.space.total_footprint
```

\* Introduced in: 9.9

```
|constituents.space.available
|integer
|query
|False
a|Filter by constituents.space.available
```

\* Introduced in: 9.9

```
|constituents.space.afs_total
|integer
|query
|False
a|Filter by constituents.space.afs_total
```

\* Introduced in: 9.9

```
|constituents.space.footprint
|integer
|query
|False
a|Filter by constituents.space.footprint
```

\* Introduced in: 9.9

```
|constituents.space.block_storage_inactive_user_data
|integer
|query
|False
a|Filter by constituents.space.block_storage_inactive_user_data
```

\* Introduced in: 9.9

```
|constituents.space.local_tier_footprint
|integer
|query
|False
a|Filter by constituents.space.local_tier_footprint
```

\* Introduced in: 9.9

```
|constituents.space.used_percent
|integer
|query
|False
a|Filter by constituents.space.used_percent
```

\* Introduced in: 9.10

```
|constituents.space.snapshot.reserve_percent
|integer
```

```
|query  
|False  
a|Filter by constituents.space.snapshot.reserve_percent
```

\* Introduced in: 9.9

```
|constituents.space.snapshot.used  
|integer  
|query  
|False  
a|Filter by constituents.space.snapshot.used
```

\* Introduced in: 9.9

```
|constituents.space.performance_tier_footprint  
|integer  
|query  
|False  
a|Filter by constituents.space.performance_tier_footprint
```

\* Introduced in: 9.9

```
|constituents.space.metadata  
|integer  
|query  
|False  
a|Filter by constituents.space.metadata
```

\* Introduced in: 9.9

```
|constituents.space.size  
|integer  
|query  
|False  
a|Filter by constituents.space.size
```

\* Introduced in: 9.9

```
|constituents.space.used  
|integer  
|query  
|False
```

```
a|Filter by constituents.space.used
```

```
* Introduced in: 9.9
```

```
|constituents.name
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by constituents.name
```

```
* Introduced in: 9.9
```

```
|error_state.is_inconsistent
```

```
|boolean
```

```
|query
```

```
|False
```

```
a|Filter by error_state.is_inconsistent
```

```
|error_state.has_bad_blocks
```

```
|boolean
```

```
|query
```

```
|False
```

```
a|Filter by error_state.has_bad_blocks
```

```
|size
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by size
```

```
|quota.state
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by quota.state
```

```
|rebalancing.start_time
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by rebalancing.start_time
```

\* Introduced in: 9.11

|rebalancing.exclude\_snapshots  
|boolean  
|query  
|False  
a|Filter by rebalancing.exclude\_snapshots

\* Introduced in: 9.11

|rebalancing.data\_moved  
|integer  
|query  
|False  
a|Filter by rebalancing.data\_moved

\* Introduced in: 9.11

|rebalancing.failure\_reason.code  
|string  
|query  
|False  
a|Filter by rebalancing.failure\_reason.code

\* Introduced in: 9.11

|rebalancing.failure\_reason.message  
|string  
|query  
|False  
a|Filter by rebalancing.failure\_reason.message

\* Introduced in: 9.11

|rebalancing.state  
|string  
|query  
|False  
a|Filter by rebalancing.state

\* Introduced in: 9.11

```
|rebalancing.min_file_size
|integer
|query
|False
a|Filter by rebalancing.min_file_size
```

\* Introduced in: 9.11

```
|rebalancing.max_threshold
|integer
|query
|False
a|Filter by rebalancing.max_threshold
```

\* Introduced in: 9.11

```
|rebalancing.target_used
|integer
|query
|False
a|Filter by rebalancing.target_used
```

\* Introduced in: 9.11

```
|rebalancing.max_constituent_imbalance_percent
|integer
|query
|False
a|Filter by rebalancing.max_constituent_imbalance_percent
```

\* Introduced in: 9.11

```
|rebalancing.min_threshold
|integer
|query
|False
a|Filter by rebalancing.min_threshold
```

\* Introduced in: 9.11

```
|rebalancing.max_file_moves
|integer
|query
|False
a|Filter by rebalancing.max_file_moves
```

\* Introduced in: 9.11

```
|rebalancing.stop_time
|string
|query
|False
a|Filter by rebalancing.stop_time
```

\* Introduced in: 9.11

```
|rebalancing.runtime
|string
|query
|False
a|Filter by rebalancing.runtime
```

\* Introduced in: 9.11

```
|rebalancing.imbalance_percent
|integer
|query
|False
a|Filter by rebalancing.imbalance_percent
```

\* Introduced in: 9.11

```
|rebalancing.imbalance_size
|integer
|query
|False
a|Filter by rebalancing.imbalance_size
```

\* Introduced in: 9.11

```
|rebalancing.max_runtime
|string
```

```
|query
|False
a|Filter by rebalancing.max_runtime
```

\* Introduced in: 9.11

```
|space.nearly_full_threshold_percent
|integer
|query
|False
a|Filter by space.nearly_full_threshold_percent
```

\* Introduced in: 9.9

```
|space.footprint
|integer
|query
|False
a|Filter by space.footprint
```

```
|space.afs_total
|integer
|query
|False
a|Filter by space.afs_total
```

\* Introduced in: 9.9

```
|space.filesystem_size
|integer
|query
|False
a|Filter by space.filesystem_size
```

\* Introduced in: 9.10

```
|space.total_footprint
|integer
|query
|False
a|Filter by space.total_footprint
```



\* Introduced in: 9.8

|space.expected\_available  
|integer  
|query  
|False  
a|Filter by space.expected\_available

\* Introduced in: 9.10

|space.logical\_space.reporting  
|boolean  
|query  
|False  
a|Filter by space.logical\_space.reporting

|space.logical\_space.used  
|integer  
|query  
|False  
a|Filter by space.logical\_space.used

\* Introduced in: 9.9

|space.logical\_space.used\_percent  
|integer  
|query  
|False  
a|Filter by space.logical\_space.used\_percent

\* Introduced in: 9.9

|space.logical\_space.used\_by\_snapshots  
|integer  
|query  
|False  
a|Filter by space.logical\_space.used\_by\_snapshots

\* Introduced in: 9.10

|space.logical\_space.enforcement

```
|boolean
|query
|False
a|Filter by space.logical_space.enforcement
```

```
|space.logical_space.available
|integer
|query
|False
a|Filter by space.logical_space.available
```

```
|space.logical_space.used_by_afs
|integer
|query
|False
a|Filter by space.logical_space.used_by_afs
```

```
|space.used_by_afs
|integer
|query
|False
a|Filter by space.used_by_afs
```

\* Introduced in: 9.9

```
|space.available_percent
|integer
|query
|False
a|Filter by space.available_percent
```

\* Introduced in: 9.9

```
|space.file_operation_metadata
|integer
|query
|False
a|Filter by space.file_operation_metadata
```

\* Introduced in: 9.10

```
|space.cross_volume_dedupe_metafiles_temporary_footprint
|integer
|query
|False
a|Filter by space.cross_volume_dedupe_metafiles_temporary_footprint
```

\* Introduced in: 9.10

```
|space.overwrite_reserve
|integer
|query
|False
a|Filter by space.overwrite_reserve
```

\* Introduced in: 9.9

```
|space.used
|integer
|query
|False
a|Filter by space.used
```

```
|space.effective_total_footprint
|integer
|query
|False
a|Filter by space.effective_total_footprint
```

\* Introduced in: 9.11

```
|space.volume_guarantee_footprint
|integer
|query
|False
a|Filter by space.volume_guarantee_footprint
```

\* Introduced in: 9.10

```
|space.size
|integer
|query
|False
```

a|Filter by space.size

|space.snapmirror\_destination\_footprint

|integer

|query

|False

a|Filter by space.snapmirror\_destination\_footprint

\* Introduced in: 9.10

|space.snapshot\_spill

|integer

|query

|False

a|Filter by space.snapshot\_spill

\* Introduced in: 9.10

|space.filesystem\_size\_fixed

|boolean

|query

|False

a|Filter by space.filesystem\_size\_fixed

\* Introduced in: 9.10

|space.snapshot.space\_used\_percent

|integer

|query

|False

a|Filter by space.snapshot.space\_used\_percent

\* Introduced in: 9.9

|space.snapshot.used

|integer

|query

|False

a|Filter by space.snapshot.used

|space.snapshot.autodelete\_trigger

```
|string
|query
|False
a|Filter by space.snapshot.autodelete_trigger
```

\* Introduced in: 9.10

```
|space.snapshot.reserve_size
|integer
|query
|False
a|Filter by space.snapshot.reserve_size
```

\* Introduced in: 9.9

```
|space.snapshot.reserve_available
|integer
|query
|False
a|Filter by space.snapshot.reserve_available
```

\* Introduced in: 9.10

```
|space.snapshot.reserve_percent
|integer
|query
|False
a|Filter by space.snapshot.reserve_percent
```

```
|space.snapshot_reserve_unusable
|integer
|query
|False
a|Filter by space.snapshot_reserve_unusable
```

\* Introduced in: 9.10

```
|space.physical_used
|integer
|query
|False
a|Filter by space.physical_used
```

\* Introduced in: 9.10

```
|space.delayed_free_footprint
|integer
|query
|False
a|Filter by space.delayed_free_footprint
```

\* Introduced in: 9.10

```
|space.percent_used
|integer
|query
|False
a|Filter by space.percent_used
```

\* Introduced in: 9.9

```
|space.size_available_for_snapshots
|integer
|query
|False
a|Filter by space.size_available_for_snapshots
```

\* Introduced in: 9.9

```
|space.local_tier_footprint
|integer
|query
|False
a|Filter by space.local_tier_footprint
```

\* Introduced in: 9.8

```
|space.block_storage_inactive_user_data
|integer
|query
|False
a|Filter by space.block_storage_inactive_user_data
```

```
|space.available  
|integer  
|query  
|False  
a|Filter by space.available
```

```
|space.physical_used_percent  
|integer  
|query  
|False  
a|Filter by space.physical_used_percent
```

\* Introduced in: 9.10

```
|space.over_provisioned  
|integer  
|query  
|False  
a|Filter by space.over_provisioned
```

```
|space.full_threshold_percent  
|integer  
|query  
|False  
a|Filter by space.full_threshold_percent
```

\* Introduced in: 9.9

```
|space.capacity_tier_footprint  
|integer  
|query  
|False  
a|Filter by space.capacity_tier_footprint
```

```
|space.auto_adaptive_compression_footprint_data_reduction  
|integer  
|query  
|False  
a|Filter by space.auto_adaptive_compression_footprint_data_reduction
```

\* Introduced in: 9.11

```
|space.user_data
|integer
|query
|False
a|Filter by space.user_data
```

\* Introduced in: 9.10

```
|space.fractional_reserve
|integer
|query
|False
a|Filter by space.fractional_reserve
```

\* Introduced in: 9.9

```
|space.cross_volume_dedupe_metafiles_footprint
|integer
|query
|False
a|Filter by space.cross_volume_dedupe_metafiles_footprint
```

\* Introduced in: 9.10

```
|space.dedupe_metafiles_temporary_footprint
|integer
|query
|False
a|Filter by space.dedupe_metafiles_temporary_footprint
```

\* Introduced in: 9.10

```
|space.block_storage_inactive_user_data_percent
|integer
|query
|False
a|Filter by space.block_storage_inactive_user_data_percent
```

\* Introduced in: 9.9

```
|space.dedupe_metafiles_footprint
```



```
|integer
|query
|False
a|Filter by space.dedupe_metafiles_footprint
```

\* Introduced in: 9.10

```
|space.overwrite_reserve_used
|integer
|query
|False
a|Filter by space.overwrite_reserve_used
```

\* Introduced in: 9.9

```
|space.metadata
|integer
|query
|False
a|Filter by space.metadata
```

```
|space.performance_tier_footprint
|integer
|query
|False
a|Filter by space.performance_tier_footprint
```

\* Introduced in: 9.8

```
|nas.path
|string
|query
|False
a|Filter by nas.path
```

```
|nas.security_style
|string
|query
|False
a|Filter by nas.security_style
```

```
|nas.junction_parent.name  
|string  
|query  
|False  
a|Filter by nas.junction_parent.name
```

\* Introduced in: 9.9

```
|nas.junction_parent.uuid  
|string  
|query  
|False  
a|Filter by nas.junction_parent.uuid
```

\* Introduced in: 9.9

```
|nas.unix_permissions  
|integer  
|query  
|False  
a|Filter by nas.unix_permissions
```

```
|nas.export_policy.id  
|integer  
|query  
|False  
a|Filter by nas.export_policy.id
```

```
|nas.export_policy.name  
|string  
|query  
|False  
a|Filter by nas.export_policy.name
```

```
|nas.gid  
|integer  
|query  
|False  
a|Filter by nas.gid
```

```
|nas.uid
```

```
|integer  
|query  
|False  
a|Filter by nas.uid
```

```
|qos.policy.uuid  
|string  
|query  
|False  
a|Filter by qos.policy.uuid
```

```
|qos.policy.min_throughput_mbps  
|integer  
|query  
|False  
a|Filter by qos.policy.min_throughput_mbps
```

\* Introduced in: 9.8

```
|qos.policy.name  
|string  
|query  
|False  
a|Filter by qos.policy.name
```

```
|qos.policy.max_throughput_mbps  
|integer  
|query  
|False  
a|Filter by qos.policy.max_throughput_mbps
```

```
|qos.policy.min_throughput_iops  
|integer  
|query  
|False  
a|Filter by qos.policy.min_throughput_iops
```

```
|qos.policy.max_throughput_iops  
|integer  
|query  
|False
```

a|Filter by qos.policy.max\_throughput\_iops

|snapshot\_count

|integer

|query

|False

a|Filter by snapshot\_count

\* Introduced in: 9.10

\* Max value: 1023

\* Min value: 0

|consistency\_group.uuid

|string

|query

|False

a|Filter by consistency\_group.uuid

\* Introduced in: 9.10

|consistency\_group.name

|string

|query

|False

a|Filter by consistency\_group.name

\* Introduced in: 9.7

|type

|string

|query

|False

a|Filter by type

|uuid

|string

|query

|False

a|Filter by uuid

|anti\_ransomware\_state

```
|string
|query
|False
a|Filter by anti_ransomware_state
```

```
* Introduced in: 9.10
```

```
|guarantee.honored
|boolean
|query
|False
a|Filter by guarantee.honored
```

```
|guarantee.type
|string
|query
|False
a|Filter by guarantee.type
```

```
|movement.percent_complete
|integer
|query
|False
a|Filter by movement.percent_complete
```

```
|movement.destination_aggregate.uuid
|string
|query
|False
a|Filter by movement.destination_aggregate.uuid
```

```
|movement.destination_aggregate.name
|string
|query
|False
a|Filter by movement.destination_aggregate.name
```

```
|movement.start_time
|string
|query
|False
```

a|Filter by movement.start\_time

\* Introduced in: 9.9

|movement.cutover\_window

|integer

|query

|False

a|Filter by movement.cutover\_window

|movement.state

|string

|query

|False

a|Filter by movement.state

|flexcache\_endpoint\_type

|string

|query

|False

a|Filter by flexcache\_endpoint\_type

|anti\_ransomware.attack\_reports.time

|string

|query

|False

a|Filter by anti\_ransomware.attack\_reports.time

\* Introduced in: 9.10

|anti\_ransomware.surge\_as\_normal

|boolean

|query

|False

a|Filter by anti\_ransomware.surge\_as\_normal

\* Introduced in: 9.11

|anti\_ransomware.suspect\_files.format

|string

|query

```
|False  
a|Filter by anti_ransomware.suspect_files.format
```

```
* Introduced in: 9.10
```

```
|anti_ransomware.suspect_files.entropy  
|string  
|query  
|False  
a|Filter by anti_ransomware.suspect_files.entropy
```

```
* Introduced in: 9.11
```

```
|anti_ransomware.suspect_files.count  
|integer  
|query  
|False  
a|Filter by anti_ransomware.suspect_files.count
```

```
* Introduced in: 9.10
```

```
|anti_ransomware.state  
|string  
|query  
|False  
a|Filter by anti_ransomware.state
```

```
* Introduced in: 9.10
```

```
|anti_ransomware.space.used_by_logs  
|integer  
|query  
|False  
a|Filter by anti_ransomware.space.used_by_logs
```

```
* Introduced in: 9.10
```

```
|anti_ransomware.space.used  
|integer  
|query  
|False  
a|Filter by anti_ransomware.space.used
```

\* Introduced in: 9.10

```
|anti_ransomware.space.snapshot_count
|integer
|query
|False
a|Filter by anti_ransomware.space.snapshot_count
```

\* Introduced in: 9.10

```
|anti_ransomware.space.used_by_snapshots
|integer
|query
|False
a|Filter by anti_ransomware.space.used_by_snapshots
```

\* Introduced in: 9.10

```
|anti_ransomware.attack_probability
|string
|query
|False
a|Filter by anti_ransomware.attack_probability
```

\* Introduced in: 9.10

```
|anti_ransomware.dry_run_start_time
|string
|query
|False
a|Filter by anti_ransomware.dry_run_start_time
```

\* Introduced in: 9.10

```
|convert_unicode
|boolean
|query
|False
a|Filter by convert_unicode
```

\* Introduced in: 9.10



```
|cloud_retrieval_policy
|string
|query
|False
a|Filter by cloud_retrieval_policy
```

\* Introduced in: 9.8

```
|encryption.enabled
|boolean
|query
|False
a|Filter by encryption.enabled
```

```
|encryption.type
|string
|query
|False
a|Filter by encryption.type
```

```
|encryption.rekey
|boolean
|query
|False
a|Filter by encryption.rekey
```

```
|encryption.state
|string
|query
|False
a|Filter by encryption.state
```

```
|encryption.key_id
|string
|query
|False
a|Filter by encryption.key_id
```

```
|encryption.status.code
```

```
|string
|query
|False
a|Filter by encryption.status.code
```

```
|encryption.status.message
|string
|query
|False
a|Filter by encryption.status.message
```

```
|encryption.key_create_time
|string
|query
|False
a|Filter by encryption.key_create_time
```

\* Introduced in: 9.11

```
|efficiency.last_op_size
|integer
|query
|False
a|Filter by efficiency.last_op_size
```

\* Introduced in: 9.9

```
|efficiency.cross_volume_dedupe
|string
|query
|False
a|Filter by efficiency.cross_volume_dedupe
```

```
|efficiency.storage_efficiency_mode
|string
|query
|False
a|Filter by efficiency.storage_efficiency_mode
```

\* Introduced in: 9.10

```
|efficiency.op_state
|string
|query
|False
a|Filter by efficiency.op_state
```

\* Introduced in: 9.9

```
|efficiency.path
|string
|query
|False
a|Filter by efficiency.path
```

\* Introduced in: 9.9

```
|efficiency.has_savings
|boolean
|query
|False
a|Filter by efficiency.has_savings
```

\* Introduced in: 9.11

```
|efficiency.last_op_end
|string
|query
|False
a|Filter by efficiency.last_op_end
```

\* Introduced in: 9.9

```
|efficiency.application_io_size
|string
|query
|False
a|Filter by efficiency.application_io_size
```

\* Introduced in: 9.8

```
|efficiency.last_op_err
|string
```

```
|query
|False
a|Filter by efficiency.last_op_err
```

\* Introduced in: 9.9

```
|efficiency.space_savings.dedupe_percent
|integer
|query
|False
a|Filter by efficiency.space_savings.dedupe_percent
```

\* Introduced in: 9.11

```
|efficiency.space_savings.compression_percent
|integer
|query
|False
a|Filter by efficiency.space_savings.compression_percent
```

\* Introduced in: 9.11

```
|efficiency.space_savings.compression
|integer
|query
|False
a|Filter by efficiency.space_savings.compression
```

\* Introduced in: 9.11

```
|efficiency.space_savings.total
|integer
|query
|False
a|Filter by efficiency.space_savings.total
```

\* Introduced in: 9.11

```
|efficiency.space_savings.dedupe_sharing
|integer
|query
|False
```

a|Filter by efficiency.space\_savings.dedupe\_sharing

\* Introduced in: 9.11

|efficiency.space\_savings.total\_percent

|integer

|query

|False

a|Filter by efficiency.space\_savings.total\_percent

\* Introduced in: 9.11

|efficiency.space\_savings.dedupe

|integer

|query

|False

a|Filter by efficiency.space\_savings.dedupe

\* Introduced in: 9.11

|efficiency.state

|string

|query

|False

a|Filter by efficiency.state

\* Introduced in: 9.9

|efficiency.progress

|string

|query

|False

a|Filter by efficiency.progress

\* Introduced in: 9.9

|efficiency.policy.name

|string

|query

|False

a|Filter by efficiency.policy.name

\* Introduced in: 9.7

```
|efficiency.last_op_state  
|string  
|query  
|False  
a|Filter by efficiency.last_op_state
```

\* Introduced in: 9.9

```
|efficiency.dedupe  
|string  
|query  
|False  
a|Filter by efficiency.dedupe
```

```
|efficiency.type  
|string  
|query  
|False  
a|Filter by efficiency.type
```

\* Introduced in: 9.9

```
|efficiency.scanner.compression  
|boolean  
|query  
|False  
a|Filter by efficiency.scanner.compression
```

\* Introduced in: 9.11

```
|efficiency.scanner.dedupe  
|boolean  
|query  
|False  
a|Filter by efficiency.scanner.dedupe
```

\* Introduced in: 9.11

```
|efficiency.scanner.scan_old_data
```

```
|boolean  
|query  
|False  
a|Filter by efficiency.scanner.scan_old_data
```

\* Introduced in: 9.11

```
|efficiency.scanner.state  
|string  
|query  
|False  
a|Filter by efficiency.scanner.state
```

\* Introduced in: 9.11

```
|efficiency.compression  
|string  
|query  
|False  
a|Filter by efficiency.compression
```

```
|efficiency.schedule  
|string  
|query  
|False  
a|Filter by efficiency.schedule
```

\* Introduced in: 9.8

```
|efficiency.logging_enabled  
|boolean  
|query  
|False  
a|Filter by efficiency.logging_enabled
```

\* Introduced in: 9.11

```
|efficiency.last_op_begin  
|string  
|query  
|False  
a|Filter by efficiency.last_op_begin
```

\* Introduced in: 9.9

```
|efficiency.compression_type
|string
|query
|False
a|Filter by efficiency.compression_type
```

\* Introduced in: 9.11

```
|efficiency.compaction
|string
|query
|False
a|Filter by efficiency.compaction
```

```
|fields
|array[string]
|query
|False
a|Specify the fields to return.
```

```
|max_records
|integer
|query
|False
a|Limit the number of records returned.
```

```
|return_records
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
of records is returned.
```

\* Default value: 1

```
|return_timeout
|integer
|query
```



```
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.
```

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|order_by
|array[string]
|query
|False
a|Order results by specified fields and optional [asc|desc] direction.
Default direction is 'asc' for ascending.
```

```
|===
```

```
== Response
```

Status: 200, Ok

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|num_records
```

```
|integer
```

```
a|Number of records
```

```
|records
```

```
|array[link:#volume[volume]]
```

```
a|
```

```
|===
```

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "activity_tracking": {
      "state": "off",
      "unsupported_reason": {
        "code": "124518405",
        "message": "Volume activity tracking cannot be enabled on volumes
that contain LUNs."
      }
    },
    "aggregates": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "analytics": {
      "scan_progress": 17,
      "state": "unknown",
      "unsupported_reason": {
        "code": "111411207",
        "message": "File system analytics cannot be enabled on volumes
that contain LUNs."
      }
    },
    "anti_ransomware": {
```

```
"attack_probability": "none",
"attack_reports": {
  "_links": {
    "suspects": {
      "href": "/api/resourcelink"
    }
  },
  "time": "2021-06-01T20:36:41+05:30"
},
"dry_run_start_time": "string",
"space": {
  "snapshot_count": 0,
  "used": 0,
  "used_by_logs": 0,
  "used_by_snapshots": 0
},
"state": "disabled",
"suspect_files": {
  "count": 0,
  "entropy": "string",
  "format": "string"
}
},
"anti_ransomware_state": "disabled",
"application": {
  "name": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"autosize": {
  "mode": "grow"
},
"clone": {
  "parent_snapshot": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    }
  },
  "name": "this_snapshot",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"parent_svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
}
```

```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "parent_volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "split_complete_percent": 0,
  "split_estimate": 0
},
"cloud_retrieval_policy": "default",
"comment": "string",
"consistency_group": {
  "name": "consistency_group_1",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"constituents": {
  "aggregates": {
    "name": "string",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "movement": {
    "cutover_window": 30,
    "destination_aggregate": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "percent_complete": 0,
    "state": "replicating",
    "tiering_policy": "all"
  },
  "name": "string",
  "space": {
    "available": 0,
    "block_storage_inactive_user_data": 0,

```

```
"capacity_tier_footprint": 0,
"footprint": 0,
"local_tier_footprint": 0,
"logical_space": {
  "available": 0,
  "used_by_afs": 0
},
"metadata": 0,
"over_provisioned": 0,
"performance_tier_footprint": 0,
"snapshot": {
  "used": 0
},
"total_footprint": 0,
"used": 0
}
},
"create_time": "2018-06-04T19:00:00Z",
"efficiency": {
  "application_io_size": "8k",
  "compaction": "inline",
  "compression": "inline",
  "compression_type": "none",
  "cross_volume_dedupe": "inline",
  "dedupe": "inline",
  "last_op_begin": "string",
  "last_op_end": "string",
  "last_op_err": "string",
  "last_op_size": 0,
  "last_op_state": "string",
  "op_state": "idle",
  "path": "string",
  "progress": "string",
  "scanner": {
    "state": "idle"
  },
  "schedule": "string",
  "space_savings": {
    "compression": 0,
    "compression_percent": 0,
    "dedupe": 0,
    "dedupe_percent": 0,
    "dedupe_sharing": 0,
    "total": 0,
    "total_percent": 0
  },
},
```

```
    "state": "disabled",
    "storage_efficiency_mode": "default",
    "type": "regular"
  },
  "encryption": {
    "key_create_time": "2022-01-01T19:00:00Z",
    "key_id": "string",
    "key_manager_attribute": "CRN=v1:bluemix:public:containers-
kubernetes:us-south:a/asdfghjkl1234:asdfghjkl1234:worker:kubernetes-
asdfghjkl-worker1",
    "state": "encrypted",
    "status": {
      "code": "string",
      "message": "string"
    },
    "type": "none"
  },
  "files": {
    "used": 0
  },
  "flash_pool": {
    "cache_eligibility": "read",
    "cache_retention_priority": "normal",
    "caching_policy": "none"
  },
  "flexcache_endpoint_type": "none",
  "flexgroup": {
    "name": "my_flexgroup",
    "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
  },
  "guarantee": {
    "type": "volume"
  },
  "idcs_scanner": {
    "mode": "default",
    "operation_state": "idle",
    "status": "success"
  },
  "language": "ar",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "cloud": {
```

```
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "duration": "PT15S",
  "flexcache": {
    "bandwidth_savings": 4096,
    "cache_miss_percent": 20,
    "duration": "PT1D",
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"movement": {
  "cutover_window": 30,
  "destination_aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
```

```

    }
  },
  "name": "aggr1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"percent_complete": 0,
"start_time": "2020-12-07T03:45:12-05:00",
"state": "replicating",
"tiering_policy": "all"
},
"name": "vol_cs_dept",
"nas": {
  "export_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 100,
    "name": "default"
  },
  "junction_parent": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "vs1_root",
    "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
  },
  "path": "/user/my_volume",
  "security_style": "mixed",
  "unix_permissions": 755
},
"qos": {
  "policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "max_throughput_iops": 10000,
    "max_throughput_mbps": 500,
    "min_throughput_iops": 2000,
    "min_throughput_mbps": 500,
    "name": "performance",

```



```

    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},
"quota": {
  "state": "corrupt"
},
"rebalancing": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "data_moved": 0,
  "failure_reason": {
    "code": "string",
    "message": "string"
  },
  "imbalance_percent": 0,
  "imbalance_size": 0,
  "max_constituent_imbalance_percent": 0,
  "runtime": "string",
  "start_time": "string",
  "state": "rebalancing",
  "stop_time": "string",
  "target_used": 0
},
"scheduled_snapshot_naming_scheme": "create_time",
"snaplock": {
  "append_mode_enabled": "",
  "autocommit_period": "P30M",
  "compliance_clock_time": "2018-06-04T19:00:00Z",
  "expiry_time": "Wed Sep 5 11:02:42 GMT 2018",
  "is_audit_log": 1,
  "litigation_count": 10,
  "privileged_delete": "enabled",
  "retention": {
    "default": "P30Y",
    "maximum": "P30Y",
    "minimum": "P30Y"
  },
  "type": "enterprise",
  "unspecified_retention_file_count": 10
},
"snapshot_count": 0,
"snapshot_policy": {
  "_links": {

```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "default",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"space": {
  "auto_adaptive_compression_footprint_data_reduction": 0,
  "available": 0,
  "block_storage_inactive_user_data": 0,
  "block_storage_inactive_user_data_percent": 0,
  "capacity_tier_footprint": 0,
  "cross_volume_dedupe_metafiles_footprint": 0,
  "cross_volume_dedupe_metafiles_temporary_footprint": 0,
  "dedupe_metafiles_footprint": 0,
  "dedupe_metafiles_temporary_footprint": 0,
  "delayed_free_footprint": 0,
  "effective_total_footprint": 0,
  "file_operation_metadata": 0,
  "filesystem_size": 0,
  "footprint": 0,
  "local_tier_footprint": 0,
  "logical_space": {
    "available": 0,
    "used": 0,
    "used_by_afs": 0,
    "used_by_snapshots": 0,
    "used_percent": 0
  },
  "metadata": 0,
  "over_provisioned": 0,
  "overwrite_reserve": 0,
  "overwrite_reserve_used": 0,
  "percent_used": 0,
  "performance_tier_footprint": 0,
  "size_available_for_snapshots": 0,
  "snapmirror_destination_footprint": 0,
  "snapshot": {
    "autodelete_trigger": "volume",
    "reserve_available": 0,
    "reserve_size": 0,
    "space_used_percent": 0,
    "used": 0
  },
  "snapshot_reserve_unusable": 0,

```

```
"snapshot_spill": 0,
"total_footprint": 0,
"used": 0,
"user_data": 0,
"volume_guarantee_footprint": 0
},
"state": "error",
"statistics": {
  "cifs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
      "file": {
        "count": 1000,
        "total_time": 200
      },
      "other": {
        "count": 1000,
        "total_time": 200
      },
      "symlink": {
        "count": 1000,
        "total_time": 200
      }
    },
    "getattr": {
      "count": 1000,
      "total_time": 200
    },
    "link": {
      "count": 1000,
      "total_time": 200
    },
    "lock": {
      "count": 1000,
      "total_time": 200
    }
  }
}
```



```
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
],  
"volume_protocol_latency_histogram_labels": [  
  "<2us",  
  "<6us",  
  "<10us",  
  "<14us",  
  "<20us",  
  "<40us",  
  "<60us",  
  "<80us",  
  "<100us",  
  "<200us",  
  "<400us",  
  "<600us",  
  "<800us",  
  "<1ms",  
  "<2ms",  
  "<4ms",  
  "<6ms",  
  "<8ms",  
  "<10ms",  
  "<12ms",  
  "<14ms",  
  "<16ms",  
  "<18ms",  
  "<20ms",  
  "<40ms",  
  "<60ms",  
  "<80ms",  
  "<100ms",  
  "<200ms",  
  "<400ms",  
  "<600ms",  
  "<800ms",  
  "<1s",  
  "<2s",  
  "<4s",  
  "<6s",  
  "<8s",
```

```

    "<10s",
    "<20s",
    ">20s"
  ],
  "volume_protocol_size_histogram_counts": [
    2400,
    1055,
    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
}

```

```
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,
    35,
    100,
    200,
    200,
    300,
    500,
    500,
    500,
    1000,
    1000,
    800,
    500,
    500,
    300,
    200,
    50,
    40,
    15,
    0,
```





```
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
"volume_protocol_size_histogram_labels": [
  "< 4KB",
  "= 4KB",
  "< 8KB",
  "= 8KB",
  "< 16KB",
  "= 16KB",
  "< 32KB",
  "= 32KB",
  "< 64KB",
  "= 64KB",
  "< 256KB",
  "= 256KB",
  "< 1024KB",
  "= 1024KB",
  "> 1024KB"
]
```

```

    }
  },
  "cloud": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "flexcache_raw": {
    "cache_miss_blocks": 10,
    "client_requested_blocks": 500,
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "nfs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
    },
  },

```

```
"file": {
  "count": 1000,
  "total_time": 200
},
"other": {
  "count": 1000,
  "total_time": 200
},
"symlink": {
  "count": 1000,
  "total_time": 200
}
},
"getattr": {
  "count": 1000,
  "total_time": 200
},
"link": {
  "count": 1000,
  "total_time": 200
},
"lock": {
  "count": 1000,
  "total_time": 200
},
"lookup": {
  "count": 1000,
  "total_time": 200
},
"open": {
  "count": 1000,
  "total_time": 200
},
"read": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,
    35,
    100,
    200,
```



```
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
"volume_protocol_size_histogram_labels": [
```

```

    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,

```



```
"<40us",
"<60us",
"<80us",
"<100us",
"<200us",
"<400us",
"<600us",
"<800us",
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
```



```

        50,
        50,
        75,
        25,
        0,
        0
    ],
    "volume_protocol_size_histogram_labels": [
        "< 4KB",
        "= 4KB",
        "< 8KB",
        "= 8KB",
        "< 16KB",
        "= 16KB",
        "< 32KB",
        "= 32KB",
        "< 64KB",
        "= 64KB",
        "< 256KB",
        "= 256KB",
        "< 1024KB",
        "= 1024KB",
        "> 1024KB"
    ]
}
},
"status": "ok",
"throughput_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},
"status": {
},
"style": "flexvol",
"svm": {
    "_links": {
        "self": {
            "href": "/api/resourcelink"
        }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
},

```

```

    "tiering": {
      "object_tags": {
      },
      "policy": "all"
    },
    "type": "rw",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

```

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|next
|link:#href[href]
a|

|self
|link:#href[href]
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If volume activity tracking is not supported on the volume, this field
provides an appropriate error code.

|message
|string
a|If volume activity tracking is not supported on the volume, this field
provides an error message detailing why this is the case.

|===

[#activity_tracking]
[.api-collapsible-fifth-title]
activity_tracking

[cols=3*,options=header]
|===
|Name
|Type

```

```

|Description

|state
|string
a|Activity tracking state of the volume. If this value is "on", ONTAP
collects top metrics information for the volume in real time. There is a
slight impact to I/O performance in order to collect this information. If
this value is "off", no activity tracking information is collected or
available to view.

* enum: ["off", "on"]
* Introduced in: 9.10

|supported
|boolean
a|This field indicates whether or not volume activity tracking is
supported on the volume. If volume activity tracking is not supported, the
reason why is provided in the "activity_tracking.unsupported_reason"
field.

|unsupported_reason
|link:#unsupported_reason[unsupported_reason]
a|

|===

[#aggregates]
[.api-collapsible-fifth-title]
aggregates

Aggregate

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name

```

```

|string
a|

|uuid
|string
a|

|===

[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If file system analytics is not supported on the volume, this field
provides the error code explaining why.

|message
|string
a|If file system analytics is not supported on the volume, this field
provides the error message explaining why.

|===

[#analytics]
[.api-collapsible-fifth-title]
analytics

[cols=3*,options=header]
|===
|Name
|Type
|Description

|scan_progress
|integer

```

a|Percentage of files in the volume that the file system analytics initialization scan has processed. Only returned when the state is `initializing`.

|state

|string

a|File system analytics state of the volume. If this value is "on", ONTAP collects extra file system analytics information for all directories on the volume. There will be a slight impact to I/O performance to collect this information. If this value is "off", file system analytics information is not collected and not available to be viewed. If this value is "initializing", that means file system analytics was recently turned on, and the initialization scan to gather information all all existing files and directories is currently running. If this value is 'unknown' that means there was an internal error when determining the file system analytics state for the volume.

\* enum: ["unknown", "initializing", "off", "on"]

\* Introduced in: 9.8

|supported

|boolean

a|This field indicates whether or not file system analytics is supported on the volume. If file system analytics is not supported, the reason will be specified in the "analytics.unsupported\_reason" field.

|unsupported\_reason

|link:#unsupported\_reason[unsupported\_reason]

a|

|===

[#\_links]

[.api-collapsible-fifth-title]

\_links

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|suspects

```

|link:#href[href]
a|

|===

[#anti_ransomware_attack_report]
[.api-collapsible-fifth-title]
anti_ransomware_attack_report

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|time
|string
a|Timestamp at which ransomware attack is observed.

|===

[#space]
[.api-collapsible-fifth-title]
space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|snapshot_count
|integer
a|Total number of Anti-ransomware backup Snapshot copies.

|used
|integer
a|Total space in bytes used by the Anti-ransomware feature.

```



```
|used_by_logs
|integer
a|Space in bytes used by the Anti-ransomware analytics logs.
```

```
|used_by_snapshots
|integer
a|Space in bytes used by the Anti-ransomware backup Snapshot copies.
```

```
|===
```

```
[#suspect_files]
[.api-collapsible-fifth-title]
suspect_files
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
a|Total number of `suspect_files.format` files observed by the Anti-ransomware analytics engine on the volume.
```

```
|entropy
|string
a|Indicates the entropy level of this file type.
```

```
|format
|string
a|File formats observed by the Anti-ransomware analytics engine on the volume.
```

```
|===
```

```
[#anti_ransomware]
[.api-collapsible-fifth-title]
anti_ransomware
```

Anti-ransomware related information of the volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|attack_probability
```

```
|string
```

```
a|Probability of a ransomware attack.
```

```
`none` No files are suspected of ransomware activity.
```

```
`low` A number of files are suspected of ransomware activity.
```

```
`moderate` A moderate number of files are suspected of ransomware activity.
```

```
`high` A large number of files are suspected of ransomware activity.
```

```
|attack_reports
```

```
|array[link:#anti_ransomware_attack_report[anti_ransomware_attack_report]]
```

```
a|
```

```
|dry_run_start_time
```

```
|string
```

```
a|Time when Anti-ransomware monitoring `state` is set to dry-run value for starting evaluation mode.
```

```
|space
```

```
|link:#space[space]
```

```
a|
```

```
|state
```

```
|string
```

```
a|Anti-ransomware state.
```

```
`disabled` Anti-ransomware monitoring is disabled on the volume. This is the default state in a POST operation.
```

```
`disable_in_progress` Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. Valid in GET operation.
```

```
`dry_run` Anti-ransomware monitoring is enabled in the evaluation mode.
```

```
`enabled` Anti-ransomware monitoring is active on the volume.
```

```
`paused` Anti-ransomware monitoring is paused on the volume.
```

```
`enable_paused` Anti-ransomware monitoring is paused on the volume from its earlier enabled state. Valid in GET operation.
```

``dry_run_paused`` Anti-ransomware monitoring is paused on the volume from its earlier `dry_run` state. Valid in GET operation. For POST, the valid Anti-ransomware states are only ``disabled``, ``enabled`` and ``dry_run``, whereas for PATCH, ``paused`` is also valid along with the three valid states for POST.

|surge\_as\_normal

|boolean

a|Indicates whether or not to set the surge values as historical values.

|suspect\_files

|array[link:#suspect\_files[suspect\_files]]

a|

|===

[#application]

[.api-collapsible-fifth-title]

application

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name

|string

a|Name of the application to which the volume belongs. Available only when the volume is part of an application.

|uuid

|string

a|UUID of the application to which the volume belongs. Available only when the volume is part of an application.

|===

[#asynchronous\_directory\_delete]

[.api-collapsible-fifth-title]

asynchronous\_directory\_delete

Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|enabled
```

```
|boolean
```

```
a|Specifies whether asynchronous directory delete from the client is enabled on the volume.
```

```
|trash_bin
```

```
|string
```

```
a|Name of the trash bin directory. If no "trash_bin" property is specified when enabling, the default trash bin name, "._ontaptrashbin", is used.
```

```
|===
```

```
[#autosize]
```

```
[.api-collapsible-fifth-title]
```

```
autosize
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|grow_threshold
```

```
|integer
```

```
a|Used space threshold size, in percentage, for the automatic growth of the volume. When the amount of used space in the volume becomes greater than this threshold, the volume automatically grows unless it has reached the maximum size. The volume grows when 'space.used' is greater than this percent of 'space.size'. The 'grow_threshold' size cannot be less than or equal to the 'shrink_threshold' size..
```

```
|maximum
```

|integer

a|Maximum size in bytes up to which a volume grows automatically. This size cannot be less than the current volume size, or less than or equal to the minimum size of volume.

|minimum

|integer

a|Minimum size in bytes up to which the volume shrinks automatically. This size cannot be greater than or equal to the maximum size of volume.

|mode

|string

a|Autosize mode for the volume.

grow &dash; Volume automatically grows when the amount of used space is above the 'grow\_threshold' value.

grow\_shrink &dash; Volume grows or shrinks in response to the amount of space used.

off &dash; Autosizing of the volume is disabled.

|shrink\_threshold

|integer

a|Used space threshold size, in percentage, for the automatic shrinkage of the volume. When the amount of used space in the volume drops below this threshold, the volume automatically shrinks unless it has reached the minimum size. The volume shrinks when the 'space.used' is less than the 'shrink\_threshold' percent of 'space.size'. The 'shrink\_threshold' size cannot be greater than or equal to the 'grow\_threshold' size.

|===

[#snapshot\_reference]

[.api-collapsible-fifth-title]

snapshot\_reference

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

```

a|

|name
|string
a|

|uuid
|string
a|

|===

[#parent_svm]
[.api-collapsible-fifth-title]
parent_svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#parent_volume]
[.api-collapsible-fifth-title]
parent_volume

[cols=3*,options=header]
|===
|Name

```

```

|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

|===

[#clone]
[.api-collapsible-fifth-title]
clone

[cols=3*,options=header]
|===
|Name
|Type
|Description

|is_flexclone
|boolean
a|Specifies if this volume is a normal FlexVol or FlexClone. This field
needs to be set when creating a FlexClone. Valid in POST.

|parent_snapshot
|link:#snapshot_reference[snapshot_reference]
a|

|parent_svm
|link:#parent_svm[parent_svm]

```

a|

|parent\_volume  
|link:#parent\_volume[parent\_volume]

a|

|split\_complete\_percent  
|integer  
a|Percentage of FlexClone blocks split from its parent volume.

|split\_estimate  
|integer  
a|Space required by the containing-aggregate to split the FlexClone volume.

|split\_initiated  
|boolean  
a|This field is set when split is executed on any FlexClone, that is when the FlexClone volume is split from its parent FlexVol. This field needs to be set for splitting a FlexClone form FlexVol. Valid in PATCH.

|===

[#consistency\_group]  
[.api-collapsible-fifth-title]  
consistency\_group

Consistency group the volume is part of.

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|name  
|string

a|The name of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.



```
|uuid
|string
a|The UUID of the consistency group to which the volume belongs. Available
only when the volume is part of a consistency group. If this volume
belongs to a child consistency group, then this will be the UUID of the
parent consistency group.
```

```
|===
```

```
[#aggregates]
[.api-collapsible-fifth-title]
aggregates
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|name
|string
a|Name of the aggregate hosting the FlexGroup Constituent.
```

```
|uuid
|string
a|Unique identifier for the aggregate.
```

```
|===
```

```
[#destination_aggregate]
[.api-collapsible-fifth-title]
destination_aggregate
```

Aggregate

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|cutover_window
|integer
```

```
a|Time window in seconds for cutover. The allowed range is between 30 to 300 seconds.
```

```
|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate
```

```
|percent_complete
|integer
a|Completion percentage
```

```
|state
|string
a|State of volume move operation. PATCH the state to "aborted" to abort
the move operation. PATCH the state to "cutover" to trigger cutover. PATCH
the state to "paused" to pause the volume move operation in progress.
PATCH the state to "replicating" to resume the paused volume move
operation. PATCH the state to "cutover_wait" to go into cutover manually.
When volume move operation is waiting to go into "cutover" state, this is
indicated by the "cutover_pending" state. A change of state is only
supported if volume movement is in progress.
```

```
|tiering_policy
|string
a|Tiering policy for FabricPool
```

```
|===
```

```
[#logical_space]
[.api-collapsible-fifth-title]
logical_space
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|available
|integer
a|The amount of space available in this volume with storage efficiency
space considered used, in bytes.
```

```
|enforcement
|boolean
a|Specifies whether space accounting for operations on the volume is done
along with storage efficiency.
```

```
|reporting
|boolean
a|Specifies whether space reporting on the volume is done along with
storage efficiency.
```

```
|used_by_afs
|integer
a|The virtual space used by AFS alone (includes volume reserves) and along
with storage efficiency, in bytes.
```

```
|===
```

```
[#snapshot]
[.api-collapsible-fifth-title]
snapshot
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|autodelete_enabled
|boolean
a|Specifies whether Snapshot copy autodelete is currently enabled on this
volume.
```

```
|reserve_percent
|integer
a|The space that has been set aside as a reserve for Snapshot copy usage,
in percent.
```

```
|used
|integer
a|The total space used by Snapshot copies in the volume, in bytes.
```

```
|===
```

```
[#space]
[.api-collapsible-fifth-title]
space
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|afs_total
|integer
a|Total size of AFS, excluding snap-reserve, in bytes.

|available
|integer
a|The available space, in bytes.

|available_percent
|integer
a|The space available, as a percent.

|block_storage_inactive_user_data
|integer
a|The size that is physically used in the block storage of the volume and
has a cold temperature. In bytes. This parameter is only supported if the
volume is in an aggregate that is either attached to a cloud store or
could be attached to a cloud store.

|capacity_tier_footprint
|integer
a|Space used by capacity tier for this volume in the FabricPool aggregate,
in bytes.

|footprint
|integer
a|Data used for this volume in the aggregate, in bytes.

|local_tier_footprint
|integer
a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical_space
|link:#logical_space[logical_space]
a|

|metadata

```

```
|integer
a|Space used by the volume metadata in the aggregate, in bytes.

|over_provisioned
|integer
a|The amount of space not available for this volume in the aggregate, in
bytes.

|performance_tier_footprint
|integer
a|Space used by the performance tier for this volume in the FabricPool
aggregate, in bytes.

|size
|integer
a|Total provisioned size. The default size is equal to the minimum size of
20MB, in bytes.

|snapshot
|link:#snapshot[snapshot]
a|

|total_footprint
|integer
a|Data and metadata used for this volume in the aggregate, in bytes.

|used
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.

|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.

|used_percent
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, as a percent.
```

```
|===
```

```
[#constituents]  
[.api-collapsible-fifth-title]  
constituents
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|aggregates  
|link:#aggregates[aggregates]  
a|
```

```
|movement  
|link:#movement[movement]  
a|Volume movement. All attributes are modify, that is, not writable  
through POST. Set PATCH state to destination_aggregate to initiate a  
volume move operation. Volume movement on FlexGroup constituents are not  
supported.
```

```
|name  
|string  
a|FlexGroup Constituents name.
```

```
|space  
|link:#space[space]  
a|
```

```
|===
```

```
[#policy]  
[.api-collapsible-fifth-title]  
policy
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|name
|string
a|Specifies the name of the efficiency policy.
```

```
|===
```

```
[#scanner]
[.api-collapsible-fifth-title]
scanner
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|compression
|boolean
a|Start compression if scanning old data. Valid for PATCH and GET.
```

```
|dedupe
|boolean
a|Start deduplication if scanning old data. Valid for PATCH and GET.
```

```
|scan_old_data
|boolean
a|Indicates whether or not to scan old data. Valid for PATCH and GET.
```

```
|state
|string
a|State of the volume efficiency scanner. Valid for PATCH and GET. Valid options for PATCH are "idle" and "active".
```

```
|===
```

```
[#space_savings]
[.api-collapsible-fifth-title]
space_savings
```



```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|compression
```

```
|integer
```

```
a|Total disk space that is saved by compressing blocks on the referenced file system, in bytes.
```

```
|compression_percent
```

```
|integer
```

```
a|Percentage of total disk space that is saved by compressing blocks on the referenced file system.
```

```
|dedupe
```

```
|integer
```

```
a|Total disk space that is saved by deduplication and file cloning, in bytes.
```

```
|dedupe_percent
```

```
|integer
```

```
a|Percentage of total disk space that is saved by deduplication and file cloning.
```

```
|dedupe_sharing
```

```
|integer
```

```
a|Total disk space that is shared due to deduplication and file cloning.
```

```
|total
```

```
|integer
```

```
a|Total disk space saved in the volume due to deduplication, compression and file cloning, in bytes.
```

```
|total_percent
```

```
|integer
```

```
a|Percentage of total disk space saved in the volume due to deduplication, compression and file cloning.
```

```
|===
```

```
[#efficiency]  
[.api-collapsible-fifth-title]  
efficiency
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|application_io_size  
|string  
a|Block size to use by compression.
```

```
|compaction  
|string  
a|The system can be enabled/disabled compaction.  
inline &dash; Data will be compacted first and written to the volume.  
none &dash; None  
mixed &dash; Read only field for FlexGroups, where some of the constituent  
volumes are compaction enabled and some are disabled.
```

```
|compression  
|string  
a|The system can be enabled/disabled compression.  
inline &dash; Data will be compressed first and written to the volume.  
background &dash; Data will be written to the volume and compressed later.  
both &dash; Inline compression compresses the data and write to the  
volume, background compression compresses only the blocks on which inline  
compression is not run.  
none &dash; None  
mixed &dash; Read only field for FlexGroups, where some of the constituent  
volumes are compression enabled and some are disabled.
```

NOTE: that On volumes with container compression enabled, background compression refers to inactive data compression scan enabled on the volume.

```
|compression_type  
|string  
a|Compression type to use by compression. Valid for PATCH and GET.
```

|cross\_volume\_dedupe  
|string  
a|The system can be enabled/disabled cross volume dedupe. it can be enabled only when dedupe is enabled.  
inline &dash; Data will be cross volume deduped first and written to the volume.  
background &dash; Data will be written to the volume and cross volume deduped later.  
both &dash; Inline cross volume dedupe dedupes the data and write to the volume, background cross volume dedupe dedupes only the blocks on which inline dedupe is not run.  
none &dash; None  
mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are cross volume dedupe enabled and some are disabled.

|dedupe  
|string  
a|The system can be enabled/disabled dedupe.  
inline &dash; Data will be deduped first and written to the volume.  
background &dash; Data will be written to the volume and deduped later.  
both &dash; Inline dedupe dedupes the data and write to the volume, background dedupe dedupes only the blocks on which inline dedupe is not run.  
none &dash; None  
mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are dedupe enabled and some are disabled.

|has\_savings  
|boolean  
a|When true, indicates that the volume contains shared(deduplication, file clones) or compressed data.

|last\_op\_begin  
|string  
a|Last sis operation begin timestamp.

|last\_op\_end  
|string  
a|Last sis operation end timestamp.

```
|last_op_err
|string
a|Last sis operation error text.
```

```
|last_op_size
|integer
a|Last sis operation size.
```

```
|last_op_state
|string
a|Last sis operation state.
```

```
|logging_enabled
|boolean
a|When true, indicates that space savings for any newly-written data are
being logged.
```

```
|op_state
|string
a|Sis status of the volume.
```

```
|path
|string
a|Absolute volume path of the volume.
```

```
|policy
|link:#policy[policy]
a|
```

```
|progress
|string
a|Sis progress of the volume.
```

```
|scanner
|link:#scanner[scanner]
a|
```

```
|schedule
|string
a|Schedule associated with volume.
```

```
|space_savings
|link:#space_savings[space_savings]
a|
```

```
|state
|string
```

a|Storage efficiency state of the volume. Currently, this field supports POST/PATCH only for RW (Read-Write) volumes on FSx for ONTAP and Cloud Volumes ONTAP.

disabled &dash; All storage efficiency features are disabled.

mixed &dash; Read-only field for FlexGroup volumes, storage efficiency is enabled on certain constituents and disabled on others.

On FSx for ONTAP and Cloud Volumes ONTAP &dash;

  &emsp; enabled &dash; All supported storage efficiency features for the volume are enabled.

  &emsp; custom &dash; Read-only field currently only supported for the FSx for ONTAP and Cloud Volumes ONTAP, user-defined storage efficiency features are enabled.

For other platforms &dash;

  &emsp; enabled &dash; At least one storage efficiency feature for the volume is enabled.

\* enum: ["disabled", "enabled", "mixed", "custom"]

\* Introduced in: 9.9

```
|storage_efficiency_mode
|string
```

a|Storage efficiency mode used by volume. This parameter is supported only on AFF platform.

```
|type
|string
```

a|Sis Type of the volume.

```
|===
```

```
[#status]
[.api-collapsible-fifth-title]
status
```

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description

|code
|string
a|Encryption progress message code.
```

```
|message
|string
a|Encryption progress message.
```

```
|===
```

```
[#encryption]
[.api-collapsible-fifth-title]
encryption
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|enabled
|boolean
```

```
a|Creates an encrypted or an unencrypted volume. For POST, when set to 'true', a new key is generated and used to encrypt the given volume. In that case, the underlying SVM must be configured with the key manager. When set to 'false', the volume created will be unencrypted. For PATCH, when set to 'true', it encrypts an unencrypted volume. Specifying the parameter as 'false' in a PATCH operation for an encrypted volume is only supported when moving the volume to another aggregate.
```

```
|key_create_time
|string
a|Encryption key creation time of the volume.
```

```
|key_id
|string
a|The key ID used for creating encrypted volume. A new key-id is generated
```

for creating an encrypted volume. This key-id is associated with the generated key.

|key\_manager\_attribute

|string

a|Specifies an additional key manager attribute that is an identifier-value pair, separated by '='. For example, CRN=unique-value. This parameter is required when using the POST method and an IBM Key Lore key manager is configured on the SVM.

|rekey

|boolean

a|If set to 'true', re-encrypts the volume with a new key. Valid in PATCH.

|state

|string

a|Volume encryption state.

encrypted &dash; The volume is completely encrypted.

encrypting &dash; Encryption operation is in progress.

partial &dash; Some constituents are encrypted and some are not.

Applicable only for FlexGroup volume.

rekeying. Encryption of volume with a new key is in progress.

unencrypted &dash; The volume is a plain-text one.

|status

|link:#status[status]

a|

|type

|string

a|Volume encryption type.

none &dash; The volume is a plain-text one.

volume &dash; The volume is encrypted with NVE (NetApp Volume Encryption).

aggregate &dash; The volume is encrypted with NAE (NetApp Aggregate Encryption).

|===

[#error\_state]

[.api-collapsible-fifth-title]

error\_state

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|has_bad_blocks
```

```
|boolean
```

```
a|Indicates whether the volume has any corrupt data blocks. If the damaged data block is accessed, an IO error, such as EIO for NFS or STATUS_FILE_CORRUPT for CIFS, is returned.
```

```
|is_inconsistent
```

```
|boolean
```

```
a|Indicates whether the file system has any inconsistencies.  
true &dash; File system is inconsistent.  
false &dash; File system in not inconsistent.
```

```
|===
```

```
[#files]
```

```
[.api-collapsible-fifth-title]
```

```
files
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|maximum
```

```
|integer
```

```
a|The maximum number of files (inodes) for user-visible data allowed on the volume. This value can be increased or decreased. Increasing the maximum number of files does not immediately cause additional disk space to be used to track files. Instead, as more files are created on the volume, the system dynamically increases the number of disk blocks that are used to track files. The space assigned to track files is never freed, and this value cannot be decreased below the current number of files that can be tracked within the assigned space for the volume. Valid in PATCH.
```

```
|used
```



```
|integer
```

```
a|Number of files (inodes) used for user-visible data permitted on the volume. This field is valid only when the volume is online.
```

```
|===
```

```
[#flash_pool]
```

```
[.api-collapsible-fifth-title]
```

```
flash_pool
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cache_eligibility
```

```
|string
```

```
a|If this parameter is specified, the command displays information only about the volume or volumes with the specified Flash Pool caching attributes.
```

```
|cache_retention_priority
```

```
|string
```

```
a|If this parameter is specified, the command displays the volumes that match the specified cache retention priority policy. A cache retention priority defines how long the blocks of a volume will be cached in the Flash Pool once they become cold.
```

```
|caching_policy
```

```
|string
```

```
a|This optionally specifies the caching policy to apply to the volume. A caching policy defines how the system caches a volume's data in Flash Cache modules. If a caching policy is not assigned to a volume, the system uses the caching policy that is assigned to the containing SVM. If a caching policy is not assigned to the containing SVM, the system uses the default cluster-wide policy.
```

```
|===
```

```
[#flexgroup]
```

```
[.api-collapsible-fifth-title]
```

```
flexgroup
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

```
a|Name of the FlexGroup volume that the constituent is part of.
```

```
|uuid
```

```
|string
```

```
a|Unique identifier for the FlexGroup volume that the constituent is part of.
```

```
|===
```

```
[#guarantee]
```

```
[.api-collapsible-fifth-title]
```

```
guarantee
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|honored
```

```
|boolean
```

```
a|Is the space guarantee of this volume honored in the aggregate?
```

```
|type
```

```
|string
```

```
a|The type of space guarantee of this volume in the aggregate.
```

```
|===
```

```
[#idcs_scanner]
```

```
[.api-collapsible-fifth-title]
```

```
idcs_scanner
```

Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, except for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|enabled
```

```
|boolean
```

a|Specifies the administrative state of the inactive data compression scanner.

```
|mode
```

```
|string
```

a|Specifies the mode of inactive data compression scanner. Valid for PATCH and GET.

```
|operation_state
```

```
|string
```

a|Specifies the operational state of the inactive data compression scanner. VALID for PATCH and GET. Valid options for PATCH are "idle" and "active".

```
|status
```

```
|string
```

a|Status of last inactive data compression scan on the volume.

```
|threshold_inactive_time
```

```
|string
```

a|Time interval after which inactive data compression will be triggered automatically. The value is in days and is represented in the ISO-8601 format as "P+++<num>+++D" , for example "P3D" represents a duration of 3 days.+++</num>+++

|===

[#iops]

[.api-collapsible-fifth-title]

iops

The rate of I/O operations observed at the storage object.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|other

|integer

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

|read

|integer

a|Performance metric for read I/O operations.

|total

|integer

a|Performance metric aggregated over all types of I/O operations.

|write

|integer

a|Performance metric for write I/O operations.

|===

[#latency]

[.api-collapsible-fifth-title]

latency

The round trip latency in microseconds observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
```

```
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]
```

```
[.api-collapsible-fifth-title]
```

```
cloud
```

Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|duration
```

```
|string
```

a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

|iops

|link:#iops[iops]

a|The rate of I/O operations observed at the storage object.

|latency

|link:#latency[latency]

a|The round trip latency in microseconds observed at the storage object.

|status

|string

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|timestamp

|string

a|The timestamp of the performance data.

|===

[#flexcache]

[.api-collapsible-fifth-title]

flexcache

Performance number for FlexCache used to measure cache effectiveness.

[cols=3\*,options=header]

|===

```

|Name
|Type
|Description

|bandwidth_savings
|integer
a|Bandwidth savings denoting the amount of data served locally by the
cache, in bytes.

|cache_miss_percent
|integer
a|Cache miss percentage.

|duration
|string
a|The duration over which this sample is calculated. The time durations
are represented in the ISO-8601 standard format. Samples can be calculated
over the following durations:

|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.

|timestamp
|string
a|The timestamp of the performance data.

|===

[#throughput]
[.api-collapsible-fifth-title]

```

throughput

The rate of throughput bytes per second observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
```

```
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#metric]
```

```
[.api-collapsible-fifth-title]
```

```
metric
```

Performance numbers, such as IOPS, latency and throughput.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```



```
|_links
|link:#_links[_links]
a|
```

```
|cloud
|link:#cloud[cloud]
a|Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
```

```
|flexcache
|link:#flexcache[flexcache]
a|Performance number for FlexCache used to measure cache effectiveness.
```

```
|iops
|link:#iops[iops]
a|The rate of I/O operations observed at the storage object.
```

```
|latency
|link:#latency[latency]
a|The round trip latency in microseconds observed at the storage object.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
```

```
|throughput
|link:#throughput[throughput]
a|The rate of throughput bytes per second observed at the storage object.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|cutover_window
|integer
a|Time window in seconds for cutover. The allowed range is between 30 to 300 seconds.
```

```
|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate
```

```
|percent_complete
|integer
a|Completion percentage
```

```
|start_time
|string
```

```
a|Start time of volume move.
```

```
|state
```

```
|string
```

```
a|State of volume move operation. PATCH the state to "aborted" to abort the move operation. PATCH the state to "cutover" to trigger cutover. PATCH the state to "paused" to pause the volume move operation in progress. PATCH the state to "replicating" to resume the paused volume move operation. PATCH the state to "cutover_wait" to go into cutover manually. When volume move operation is waiting to go into "cutover" state, this is indicated by the "cutover_pending" state. A change of state is only supported if volume movement is in progress.
```

```
|tiering_policy
```

```
|string
```

```
a|Tiering policy for FabricPool
```

```
|===
```

```
[#export_policy]
```

```
[.api-collapsible-fifth-title]
```

```
export_policy
```

```
Export Policy
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|id
```

```
|integer
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|===
```

```
[#junction_parent]  
[.api-collapsible-fifth-title]  
junction_parent
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
 |_links  
|link:#_links[_links]  
a|
```

```
|name  
|string  
a|The name of the parent volume that contains the junction inode of this  
volume. The junction parent volume must belong to the same SVM that owns  
this volume.
```

```
|uuid  
|string  
a|Unique identifier for the parent volume.
```

```
|===
```

```
[#nas]  
[.api-collapsible-fifth-title]  
nas
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
 |export_policy  
|link:#export_policy[export_policy]  
a|Export Policy
```

|gid  
|integer  
a|The UNIX group ID of the volume. Valid in POST or PATCH.

|junction\_parent  
|link:#junction\_parent[junction\_parent]  
a|

|path  
|string  
a|The fully-qualified path in the owning SVM's namespace at which the volume is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one volume can be mounted at any given junction path. An empty path in POST creates an unmounted volume. An empty path in PATCH deactivates and unmounts the volume. Taking a volume offline or restricted state removes its junction path. This attribute is reported in GET only when the volume is mounted.

|security\_style  
|string  
a|Security style associated with the volume. Valid in POST or PATCH.  
mixed &dash; Mixed-style security  
ntfs &dash; NTFS/Windows-style security  
unified &dash; Unified-style security, unified UNIX, NFS and CIFS  
permissions  
unix &dash; Unix-style security.

|uid  
|integer  
a|The UNIX user ID of the volume. Valid in POST or PATCH.

|unix\_permissions  
|integer  
a|UNIX permissions to be viewed as an octal number. It consists of 4 digits derived by adding up bits 4 (read), 2 (write) and 1 (execute). First digit selects the set user ID(4), set group ID (2) and sticky (1) attributes. The second digit selects permission for the owner of the file; the third selects permissions for other users in the same group; the fourth for other users not in the group. Valid in POST or PATCH. For security style "mixed" or "unix", the default setting is 0755 in octal

(493 in decimal) and for security style "ntfs", the default setting is 0000. In cases where only owner, group and other permissions are given (as in 755, representing the second, third and fourth digit), first digit is assumed to be zero.

|===

```
[#policy]
[.api-collapsible-fifth-title]
policy
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

a|

```
|max_throughput_iops
```

```
|integer
```

a|Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

```
|max_throughput_mbps
```

```
|integer
```

a|Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

```
|min_throughput_iops
```

```
|integer
```

a|Specifies the minimum throughput in IOPS, 0 means none. Setting "min\_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH.

```
|min_throughput_mbps
```

```
|integer
```

a|Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

```
|name
|string
a|The QoS policy group name. This is mutually exclusive with UUID and
other QoS attributes during POST and PATCH.
```

```
|uuid
|string
a|The QoS policy group UUID. This is mutually exclusive with name and
other QoS attributes during POST and PATCH.
```

```
|===
```

```
[#qos]
[.api-collapsible-fifth-title]
qos
```

QoS information

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|policy
|link:#policy[policy]
a|
```

```
|===
```

```
[#quota]
[.api-collapsible-fifth-title]
quota
```

Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```

|Name
|Type
|Description

|enabled
|boolean
a|This option is used to enable or disable the quota for the volume. This
option is valid only in PATCH. Quotas are enabled for FlexVols or
FlexGroup volumes when the quota state is "on". Quotas are disabled for
FlexVols or FlexGroup volumes when the quota state is "off".

|state
|string
a|Quota state of the volume

|===

[#failure_reason]
[.api-collapsible-fifth-title]
failure_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Error code of volume capacity rebalancing operation.

|message
|string
a|Details why the volume capacity rebalancing operation failed.

|===

[#rebalancing]
[.api-collapsible-fifth-title]
rebalancing

```



Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|data_moved
```

```
|integer
```

```
a|The amount of data that has been moved in or out of a constituent. A positive value represents data moving into the constituent while a negative value is data moving out of the constituent.
```

```
|exclude_snapshots
```

```
|boolean
```

```
a|Specifies whether or not to exclude files that are stuck in Snapshot copies during rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "exclude_snapshots" value. Once the operation is started, any changes to the "exclude_snapshots" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "exclude_snapshots" value.
```

```
|failure_reason
```

```
|link:#failure_reason[failure_reason]
```

```
a|
```

```
|imbalance_percent
```

```
|integer
```

```
a|Represents the percentage the volume is out of balance.
```

```
|imbalance_size
```

```
|integer
```

```
a|Represents how much the volume is out of balance, in bytes.
```

```
|max_constituent_imbalance_percent
```

|integer

a|Absolute percentage of the constituent that is most out of balance.

|max\_file\_moves

|integer

a|Specifies the maximum number of file moves in a volume capacity rebalancing operation on a constituent of the FlexGroup volume. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_file\_moves" value. Once the operation is started, any changes to the "max\_file\_moves" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_file\_moves" value.

|max\_runtime

|string

a|This optional field specifies the maximum time a capacity rebalancing operation runs for. Once the maximum runtime has passed, the capacity rebalancing operation stops. If it is not set, the default value is 6 hours. This value cannot be updated while a capacity rebalancing operation is running. The maximum runtime can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P3D" represents a duration of 3 days. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

|max\_threshold

|integer

a|Specifies the maximum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is larger than this value, files are moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_threshold" value. Once the operation is started, any changes to the "max\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_threshold" value.

|min\_file\_size

|integer

a|Specifies the minimum file size to consider for a volume capacity rebalancing operation. When a new capacity rebalancing operation is

started on a FlexGroup volume, it uses the current "min\_file\_size" value. Once the operation is started, any changes to the "min\_file\_size" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_file\_size" value. The value must be a multiple of 4KB. If it is not set, the default value will be 4KB.

|min\_threshold

|integer

a|Specifies the minimum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is smaller than this value, files are not moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it will use the current "min\_threshold" value. Once the operation is started, any changes to the "min\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_threshold" value.

|runtime

|string

a|Duration the capacity rebalancing operation has been running.

|start\_time

|string

a|Time when the current capacity rebalancing operation started.

|state

|string

a|State of volume capacity rebalancing operation. PATCH the state to "starting" to trigger the capacity rebalance operation. PATCH the state to "stopping" to stop the capacity rebalance operation.

|stop\_time

|string

a|Time when the capacity rebalancing operation stopped.

|target\_used

|integer

a|Represents the ideal used size of each constituent. Calculated by dividing the total FlexGroup volume used size by the number of constituents.

```
|===
```

```
[#retention]  
[.api-collapsible-fifth-title]  
retention
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|default
```

```
|string
```

a|Specifies the default retention period that is applied to files while committing them to the WORM state without an associated retention period. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period and the string "unspecified" to set an unspecified retention period.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

```
|maximum
```

```
|string
```

a|Specifies the maximum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element

that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|minimum

|string

a|Specifies the minimum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, month,s and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|===

[#snaplock]

[.api-collapsible-fifth-title]

snaplock

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|append\_mode\_enabled

|boolean

a|Specifies if the volume append mode is enabled or disabled. When it is enabled, all the files created with write permissions on the volume are, by default, WORM appendable files. The user can append the data to a WORM appendable file but cannot modify the existing contents of the file nor

delete the file until it expires.

|autocommit\_period

|string

a|Specifies the autocommit period for SnapLock volume. All files which are not modified for a period greater than the autocommit period of the volume are committed to the WORM state. The autocommit period value represents a duration and must be specified in the ISO-8601 duration format. The autocommit period can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The period string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the autocommit field also accepts the string "none".+++</num>++++</num>++++</num>++++</num>++++</num>+++

|compliance\_clock\_time

|string

a|This is the volume compliance clock time which is used to manage the SnapLock objects in the volume.

|expiry\_time

|string

a|Expiry time of the volume.

|is\_audit\_log

|boolean

a|Indicates if this volume has been configured as SnapLock audit log volume for the SVM .

|litigation\_count

|integer

a|Litigation count indicates the number of active legal-holds on the volume.

|privileged\_delete

|string

a|Specifies the privileged-delete attribute of a SnapLock volume. On a SnapLock Enterprise (SLE) volume, a designated privileged user can selectively delete files irrespective of the retention time of the file. SLE volumes can have privileged delete as disabled, enabled or permanently\_disabled and for SnapLock Compliance (SLC) volumes it is always permanently\_disabled.

|retention

|link:#retention[retention]

a|

|type

|string

a|The SnapLock type of the volume.

compliance &dash; A SnapLock Compliance (SLC) volume provides the highest level of WORM protection and an administrator cannot destroy a SLC volume if it contains unexpired WORM files.

enterprise &dash; An administrator can delete a SnapLock Enterprise (SLE) volume.

non\_snaplock &dash; Indicates the volume is non-snaplock.

|unspecified\_retention\_file\_count

|integer

a|Indicates the number of files with an unspecified retention time in the volume.

|===

[#destinations]

[.api-collapsible-fifth-title]

destinations

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|is\_cloud

|boolean

a|Specifies whether a volume is a SnapMirror source volume, using SnapMirror to protect its data to a cloud destination.

```
|is_ontap
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data to an ONTAP destination.
```

```
* readOnly: 1
* Introduced in: 9.9
```

```
|===
```

```
[#snapmirror]
[.api-collapsible-fifth-title]
snapmirror
```

Specifies attributes for SnapMirror protection.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|destinations
|link:#destinations[destinations]
a|
```

```
|is_protected
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data.
```

```
|===
```

```
[#snapshot_policy]
[.api-collapsible-fifth-title]
snapshot_policy
```

This is a reference to the Snapshot copy policy.

```
[cols=3*,options=header]
```



```

|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|

|uuid
|string
a|

|===

[#logical_space]
[.api-collapsible-fifth-title]
logical_space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|available
|integer
a|The amount of space available in this volume with storage efficiency
space considered used, in bytes.

|enforcement
|boolean
a|Specifies whether space accounting for operations on the volume is done
along with storage efficiency.

|reporting
|boolean
a|Specifies whether space reporting on the volume is done along with
storage efficiency.

```

|used  
|integer  
a|SUM of (physical-used, shared\_refs, compression\_saved\_in\_plane0, vbn\_zero, future\_blk\_cnt), in bytes.

|used\_by\_afs  
|integer  
a|The virtual space used by AFS alone (includes volume reserves) and along with storage efficiency, in bytes.

|used\_by\_snapshots  
|integer  
a|Size that is logically used across all Snapshot copies in the volume, in bytes.

|used\_percent  
|integer  
a|SUM of (physical-used, shared\_refs, compression\_saved\_in\_plane0, vbn\_zero, future\_blk\_cnt), as a percentage.

|===

[#snapshot]  
[.api-collapsible-fifth-title]  
snapshot

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|autodelete\_enabled

|boolean

a|Specifies whether Snapshot copy autodelete is currently enabled on this volume.

|autodelete\_trigger

|string

a|Specifies when the system should trigger an autodelete of Snapshot

copies. When set to `_volume_`, `autodelete` is triggered based on volume fullness. When set to `_snap_reserve_`, `autodelete` is triggered based on Snapshot reserve fullness. The default value is `_volume_`.

|`reserve_available`

|integer

a|Size available for Snapshot copies within the Snapshot copy reserve, in bytes.

|`reserve_percent`

|integer

a|The space that has been set aside as a reserve for Snapshot copy usage, in percent.

|`reserve_size`

|integer

a|Size in the volume that has been set aside as a reserve for Snapshot copy usage, in bytes.

|`space_used_percent`

|integer

a|Percentage of snapshot reserve size that has been used.

|`used`

|integer

a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|`afs_total`

```
|integer
a|Total size of AFS, excluding snap-reserve, in bytes.

|auto_adaptive_compression_footprint_data_reduction
|integer
a|Savings achieved due to Auto Adaptive Compression, in bytes.

|available
|integer
a|The available space, in bytes.

|available_percent
|integer
a|The space available, as a percent.

|block_storage_inactive_user_data
|integer
a|The size that is physically used in the block storage of the volume and
has a cold temperature. In bytes. This parameter is only supported if the
volume is in an aggregate that is either attached to a cloud store or
could be attached to a cloud store.

|block_storage_inactive_user_data_percent
|integer
a|Percentage of size that is physically used in the performance tier of
the volume.

|capacity_tier_footprint
|integer
a|Space used by capacity tier for this volume in the FabricPool aggregate,
in bytes.

|cross_volume_dedupe_metafiles_footprint
|integer
a|Cross volume deduplication metadata footprint, in bytes.

|cross_volume_dedupe_metafiles_temporary_footprint
|integer
a|Cross volume temporary deduplication metadata footprint, in bytes.
```

|dedupe\_metafiles\_footprint  
|integer  
a|Deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_temporary\_footprint  
|integer  
a|Temporary deduplication metadata footprint, in bytes.

|delayed\_free\_footprint  
|integer  
a|Delayed free blocks footprint, in bytes.

|effective\_total\_footprint  
|integer  
a|Volume footprint after efficiency savings, in bytes.

|expected\_available  
|integer  
a|Size that should be available for the volume, irrespective of available size in the aggregate, in bytes.

|file\_operation\_metadata  
|integer  
a|File operation metadata footprint, in bytes.

|filesystem\_size  
|integer  
a|Total usable size of the volume, in bytes.

|filesystem\_size\_fixed  
|boolean  
a|Specifies whether the file system is to remain of the same size when set to true or to grow when set to false. This option is automatically set to true when a volume becomes SnapMirrored.

|footprint  
|integer

a|Data used for this volume in the aggregate, in bytes.

|fractional\_reserve

|integer

a|Used to change the amount of space reserved for overwrites of reserved objects in a volume.

|full\_threshold\_percent

|integer

a|Volume full threshold percentage at which EMS warnings can be sent.

|local\_tier\_footprint

|integer

a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical\_space

|link:#logical\_space[logical\_space]

a|

|metadata

|integer

a|Space used by the volume metadata in the aggregate, in bytes.

|nearly\_full\_threshold\_percent

|integer

a|Volume nearly full threshold percentage at which EMS warnings can be sent.

|over\_provisioned

|integer

a|The amount of space not available for this volume in the aggregate, in bytes.

|overwrite\_reserve

|integer

a|Reserved space for overwrites, in bytes.

|overwrite\_reserve\_used

|integer

a|Overwrite logical reserve space used, in bytes.

|percent\_used

|integer

a|Percentage of the volume size that is used.

|performance\_tier\_footprint

|integer

a|Space used by the performance tier for this volume in the FabricPool aggregate, in bytes.

|physical\_used

|integer

a|Size that is physically used in the volume, in bytes.

|physical\_used\_percent

|integer

a|Size that is physically used in the volume, as a percentage.

|size

|integer

a|Total provisioned size. The default size is equal to the minimum size of 20MB, in bytes.

|size\_available\_for\_snapshots

|integer

a|Available space for Snapshot copies from snap-reserve, in bytes.

|snapmirror\_destination\_footprint

|integer

a|SnapMirror destination footprint, in bytes.

|snapshot

|link:#snapshot[snapshot]

a|

|snapshot\_reserve\_unusable

|integer

a|Snapshot reserve that is not available for Snapshot copy creation, in

bytes.

|snapshot\_spill

|integer

a|Space used by the snapshot copies beyond the snap-reserve, in bytes.

|total\_footprint

|integer

a|Data and metadata used for this volume in the aggregate, in bytes.

|used

|integer

a|The virtual space used (includes volume reserves) before storage efficiency, in bytes.

|used\_by\_afs

|integer

a|The space used by Active Filesystem, in bytes.

|user\_data

|integer

a|User data, in bytes.

|volume\_guarantee\_footprint

|integer

a|Space reserved for future writes in the volume, in bytes.

|===

[#access]

[.api-collapsible-fifth-title]

access

Raw count and latency data for access operations.

[cols=3\*,options=header]

|===

|Name



```

|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```

[#audit]
[.api-collapsible-fifth-title]
audit

```

Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```
[#dir]
```

```
[.api-collapsible-fifth-title]
```

```
dir
```

Raw count and latency data for directory-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#file]
```

```
[.api-collapsible-fifth-title]
```

```
file
```

Raw count and latency data for file-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#other]
[.api-collapsible-fifth-title]
other
```

Raw count and latency data for create operations on objects other than files, directories and symlinks.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#symlink]
[.api-collapsible-fifth-title]
symlink
```

Raw count and latency data for symlink-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#create]
```

```
[.api-collapsible-fifth-title]
```

```
create
```

Raw count and latency data for create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|dir
```

```
|link:#dir[dir]
```

```
a|Raw count and latency data for directory-create operations.
```

```
|file
|link:#file[file]
a|Raw count and latency data for file-create operations.
```

```
|other
|link:#other[other]
a|Raw count and latency data for create operations on objects other than
files, directories and symlinks.
```

```
|symlink
|link:#symlink[symlink]
a|Raw count and latency data for symlink-create operations.
```

```
|===
```

```
[#getattr]
[.api-collapsible-fifth-title]
getattr
```

Raw count and latency data for getattr operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#link]  
[.api-collapsible-fifth-title]  
link
```

Raw count and latency data for link operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#lock]  
[.api-collapsible-fifth-title]  
lock
```

Raw count and latency data for lock operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#lookup]
[.api-collapsible-fifth-title]
lookup
```

Raw count and latency data for lookup operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#open]
```

```
[.api-collapsible-fifth-title]
```

```
open
```

Raw count and latency data for open operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#read]
```

```
[.api-collapsible-fifth-title]
```

```
read
```

Raw count and latency data for read operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.



```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* readOnly: 1
* x-ntap-advanced: true
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
|array[integer]
a|
```

```
|volume_protocol_latency_histogram_labels
|array[string]
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
|array[integer]
a|
```

```
|volume_protocol_size_histogram_labels
|array[string]
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#readdir]
[.api-collapsible-fifth-title]
readdir
```

Raw count and latency data for readdir operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#readlink]
[.api-collapsible-fifth-title]
readlink
```

Raw count and latency data for readlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#rename]
[.api-collapsible-fifth-title]
rename
```

Raw count and latency data for rename operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#setattr]
[.api-collapsible-fifth-title]
setattr
```

Raw count and latency data for setattr operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#unlink]
[.api-collapsible-fifth-title]
unlink
```

Raw count and latency data for unlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#watch]
[.api-collapsible-fifth-title]
watch
```

Raw count and latency data for watch operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#write]
```

```
[.api-collapsible-fifth-title]
```

```
write
```

Raw count and latency data for write operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* readOnly: 1
* x-ntap-advanced: true
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
|array[integer]
a|
```

```
|volume_protocol_latency_histogram_labels
|array[string]
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
|array[integer]
a|
```

```
|volume_protocol_size_histogram_labels
|array[string]
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#cifs_ops_raw]
[.api-collapsible-fifth-title]
cifs_ops_raw
```

Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|access
|link:#access[access]
a|Raw count and latency data for access operations.

|audit
|link:#audit[audit]
a|Raw count and latency data for audit operations. These statistics are
only applicable for CIFS protocol operations.

|create
|link:#create[create]
a|Raw count and latency data for create operations.

|getattr
|link:#getattr[getattr]
a|Raw count and latency data for getattr operations.

|link
|link:#link[link]
a|Raw count and latency data for link operations.

|lock
|link:#lock[lock]
a|Raw count and latency data for lock operations.

|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.

|open
|link:#open[open]
a|Raw count and latency data for open operations.

|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#iops_raw]
[.api-collapsible-fifth-title]
iops_raw
```

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.



```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
```

```
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#latency_raw]
```

```
[.api-collapsible-fifth-title]
```

```
latency_raw
```

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.
```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]
[.api-collapsible-fifth-title]
cloud
```

These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|iops_raw
|link:#iops_raw[iops_raw]
a|The number of I/O operations observed at the storage object. This can be
used along with delta time to calculate the rate of I/O operations per
unit of time.
```

```
|latency_raw
|link:#latency_raw[latency_raw]
a|The raw latency in microseconds observed at the storage object. This can
be divided by the raw IOPS value to calculate the average latency per I/O
operation.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#flexcache_raw]
[.api-collapsible-fifth-title]
flexcache_raw
```

Performance numbers for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|cache_miss_blocks
|integer
```

a|Blocks retrieved from origin in case of a cache miss. This can be
divided by the raw `client_requested_blocks` and multiplied by 100 to

calculate the cache miss percentage.

```
|client_requested_blocks  
|integer  
a|Total blocks requested by the client.
```

```
|status  
|string  
a|Errors associated with the sample. For example, if the aggregation of  
data over multiple nodes fails, then any partial errors might return "ok"  
on success or "error" on an internal uncategorized failure. Whenever a  
sample collection is missed but done at a later time, it is back filled to  
the previous 15 second timestamp and tagged with "backfilled_data".  
"Inconsistent_delta_time" is encountered when the time between two  
collections is not the same for all nodes. Therefore, the aggregated value  
might be over or under inflated. "Negative_delta" is returned when an  
expected monotonically increasing value has decreased in value.  
"Inconsistent_old_data" is returned when one or more nodes do not have the  
latest data.
```

```
|timestamp  
|string  
a|The timestamp of the performance data.
```

```
|===
```

```
[#nfs_ops_raw]  
[.api-collapsible-fifth-title]  
nfs_ops_raw
```

Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]  
|===  
|Name  
|Type  
|Description
```

```
|access
|link:#access[access]
a|Raw count and latency data for access operations.

|audit
|link:#audit[audit]
a|Raw count and latency data for audit operations. These statistics are
only applicable for CIFS protocol operations.

|create
|link:#create[create]
a|Raw count and latency data for create operations.

|getattr
|link:#getattr[getattr]
a|Raw count and latency data for getattr operations.

|link
|link:#link[link]
a|Raw count and latency data for link operations.

|lock
|link:#lock[lock]
a|Raw count and latency data for lock operations.

|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.

|open
|link:#open[open]
a|Raw count and latency data for open operations.

|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms categorizing operations by size and latency.
```

```
|===
```

```
[#throughput_raw]
[.api-collapsible-fifth-title]
throughput_raw
```

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
```

```
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#statistics]
```

```
[.api-collapsible-fifth-title]
```

```
statistics
```

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

|cifs\_ops\_raw

|link:#cifs\_ops\_raw[cifs\_ops\_raw]

a|Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

|cloud

|link:#cloud[cloud]

a|These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

|flexcache\_raw

|link:#flexcache\_raw[flexcache\_raw]

a|Performance numbers for FlexCache used to measure cache effectiveness.

|iops\_raw

|link:#iops\_raw[iops\_raw]

a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

|latency\_raw

|link:#latency\_raw[latency\_raw]

a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

|nfs\_ops\_raw

|link:#nfs\_ops\_raw[nfs\_ops\_raw]

a|Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

|status

|string

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok"



on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|throughput_raw
|link:#throughput_raw[throughput_raw]
a|Throughput bytes observed at the storage object. This can be used along
with delta time to calculate the rate of throughput bytes per unit of
time.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#svm]
[.api-collapsible-fifth-title]
svm
```

SVM containing the volume. Required on POST.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#tiering]
[.api-collapsible-fifth-title]
tiering
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|min_cooling_days
```

```
|integer
```

a|This parameter specifies the minimum number of days that user data blocks of the volume must be cooled before they can be considered cold and tiered out to the cloud tier. Note that this parameter is only used for tiering purposes and does not affect the reporting of inactive data. The value specified should be greater than the frequency with which applications in the volume shift between different sets of data. This parameter cannot be set when volume tiering policy is either "none" or "all". The default value of this parameter depends on the volume's tiering policy. See the tiering policy section of this documentation for corresponding default values. If the tiering policy on the volume gets changed, then this parameter will be reset to the default value corresponding to the new tiering policy.

```
|object_tags
```

```
|array[string]
```

a|This parameter specifies tags of a volume for objects stored on a FabricPool-enabled aggregate. Each tag is a key,value pair and should be in the format "key=value".

```
|policy
```

```
|string
```

a|Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold. FabricPool combines flash (performance tier) with a cloud store into a

single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH. all &dash; This policy allows tiering of both Snapshot copies and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.

auto &dash; This policy allows tiering of both snapshot and active file system user data to the cloud store

none &dash; Volume blocks will not be tiered to the cloud store.

snapshot\_only &dash; This policy allows tiering of only the volume Snapshot copies not associated with the active file system. The default tiering policy is "snapshot-only" for a FlexVol and "none" for a FlexGroup. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy is 31 days.

|supported

|boolean

a|This parameter specifies whether or not FabricPools are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only FabricPool aggregates are used if this parameter is set to true and only non FabricPool aggregates are used if this parameter is set to false. Tiering support for a FlexGroup can be changed by moving all of the constituents to the required aggregates. Note that in order to tier data, not only does the volume need to support tiering by using FabricPools, the tiering "policy" must not be 'none'. A volume that uses FabricPools but has a tiering "policy" of 'none' supports tiering, but will not tier any data.

|===

[#volume]

[.api-collapsible-fifth-title]

volume

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|access\_time\_enabled

```
|boolean
a|Indicates whether or not access time updates are enabled on the volume.
```

```
|activity_tracking
|link:#activity_tracking[activity_tracking]
a|
```

```
|aggregates
|array[link:#aggregates[aggregates]]
a|Aggregate hosting the volume. Required on POST.
```

```
|analytics
|link:#analytics[analytics]
a|
```

```
|anti_ransomware
|link:#anti_ransomware[anti_ransomware]
a|Anti-ransomware related information of the volume.
```

```
|anti_ransomware_state
|string
a|The Anti-ransomware state of the volume. If no "anti_ransomware_state" property is specified, the volume inherits the value from its parent SVM's "anti_ransomware_default_volume_state" property. If this value is "disabled", Anti-ransomware is disabled on the volume. If this value is "enabled", Anti-ransomware is enabled on the volume and alerts are raised if any suspect is detected for those volumes. If this value is "dry_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable_in_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry_run_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.
```

```
|application
|link:#application[application]
```

```
a|

|asynchronous_directory_delete
|link:#asynchronous_directory_delete[asynchronous_directory_delete]
a|Configuration for asynchronous directory delete from the client. This is
only supported on Flexible volumes and FlexGroup volumes.

|autosize
|link:#autosize[autosize]
a|

|clone
|link:#clone[clone]
a|

|cloud_retrieval_policy
|string
a|This parameter specifies the cloud retrieval policy for the volume. This
policy determines which tiered out blocks to retrieve from the capacity
tier to the performance tier. The available cloud retrieval policies are
"default" policy retrieves tiered data based on the underlying tiering
policy. If the tiering policy is 'auto', tiered data is retrieved only for
random client driven data reads. If the tiering policy is 'none' or
'snapshot_only', tiered data is retrieved for random and sequential client
driven data reads. If the tiering policy is 'all', tiered data is not
retrieved.
"on_read" policy retrieves tiered data for all client driven data reads.
"never" policy never retrieves tiered data.
"promote" policy retrieves all eligible tiered data automatically during
the next scheduled scan. It is only supported when the tiering policy is
'none' or 'snapshot_only'. If the tiering policy is 'snapshot_only', the
only data brought back is the data in the AFS. Data that is only in a
snapshot copy stays in the cloud and if tiering policy is 'none' then all
data is retrieved.

|comment
|string
a|A comment for the volume. Valid in POST or PATCH.

|consistency_group
|link:#consistency_group[consistency_group]
a|Consistency group the volume is part of.
```

```
|constituents
|array[link:#constituents[constituents]]
a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more
efficiently by specifying "is_constituent=true" or
"is_constituent=true&flexgroup.uuid=+++<flexgroup.uuid>+++>+++</flexgroup.uuid>+++>
as query parameters.
```

```
|constituents_per_aggregate
|integer
a|Specifies the number of times to iterate over the aggregates listed with
the "aggregates.name" or "aggregates.uuid" when creating or expanding a
FlexGroup volume. If a volume is being created on a single aggregate, the
system creates a flexible volume if the "constituents_per_aggregate" field
is not specified, or a FlexGroup volume if it is specified. If a volume is
being created on multiple aggregates, the system always creates a
FlexGroup volume. The root constituent of a FlexGroup volume is always
placed on the first aggregate in the list.
```

```
|convert_unicode
|boolean
a|Specifies whether directory Unicode format conversion is enabled when
directories are accessed by NFS clients.
```

```
|create_time
|string
a|Creation time of the volume. This field is generated when the volume is
created.
```

```
|efficiency
|link:#efficiency[efficiency]
a|
```

```
|encryption
|link:#encryption[encryption]
a|
```

```
|error_state
|link:#error_state[error_state]
a|
```

```
|files
|link:#files[files]
a|
```

```
|flash_pool
|link:#flash_pool[flash_pool]
a|
```

```
|flexcache_endpoint_type
|string
a|FlexCache endpoint type.
none &dash; The volume is neither a FlexCache nor origin of any FlexCache.
cache &dash; The volume is a FlexCache volume.
origin &dash; The volume is origin of a FlexCache volume.
```

```
|flexgroup
|link:#flexgroup[flexgroup]
a|
```

```
|granular_data
|boolean
a|State of granular data on the volume. This setting is true by default
when creating a new FlexGroup volume, but can be specified as false at the
time of creation via a POST request. On FlexVol volumes, the setting is
always false, as only FlexGroup volumes and FlexGroup constituents support
this feature. Once enabled, this setting can only be disabled by restoring
a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible
with this feature. Therefore, reverting to an earlier version of ONTAP is
not possible unless this volume is deleted or restored to a Snapshot copy
that was taken before the setting was enabled.
```

\* Introduced in: 9.11

```
|guarantee
|link:#guarantee[guarantee]
a|
```

```
|idcs_scanner
|link:#idcs_scanner[idcs_scanner]
a|Inactive data compression scan looks and picks up blocks that have not
been read for a certain amount of time(threshold_inactive_days). These
blocks are then compressed in 32K chunks. All attributes are valid for GET
only, expect for 'op_state' that is valid for PATCH and GET, and is used
to start/stop the scanner.
```

```
|is_object_store
|boolean
```

a|Specifies whether the volume is provisioned for an object store server.

|is\_svm\_root

|boolean

a|Specifies whether the volume is a root volume of the SVM it belongs to.

|language

|string

a|Language encoding setting for volume. If no language is specified, the volume inherits its SVM language encoding setting.

|max\_dir\_size

|integer

a|Maximum directory size. This value sets maximum size, in bytes, to which a directory can grow. The default maximum directory size for FlexVol volumes is model-dependent, and optimized for the size of system memory. Before increasing the maximum directory size, involve technical support.

|metric

|link:#metric[metric]

a|Performance numbers, such as IOPS, latency and throughput.

|movement

|link:#movement[movement]

a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|msid

|integer

a|The volume's Mirror Set ID.

|name

|string

a|Volume name. The name of volume must start with an alphabetic character (a to z or A to Z) or an underscore (\_). The name must be 197 or fewer characters in length for FlexGroups, and 203 or fewer characters in length for all other types of volumes. Volume names must be unique within an SVM. Required on POST.



|nas  
|link:#nas[nas]  
a|

|qos  
|link:#qos[qos]  
a|QoS information

|queue\_for\_encryption  
|boolean  
a|Specifies whether the volume is queued for encryption.

|quota  
|link:#quota[quota]  
a|Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

|rebalancing  
|link:#rebalancing[rebalancing]  
a|Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

|scheduled\_snapshot\_naming\_scheme  
|string  
a|Naming Scheme for automatic Snapshot copies:

\* create\_time - Automatic Snapshot copies are saved as per the start of their current date and time.

\* ordinal - Latest automatic snapshot copy is saved as +++<scheduled\_frequency>+++0 and subsequent copies will follow the create\_time naming convention.+++</scheduled\_frequency>+++

|size  
|integer  
a|Physical size of the volume, in bytes. The minimum size for a FlexVol volume is 20MB and the minimum size for a FlexGroup volume is 200MB per constituent. The recommended size for a FlexGroup volume is a minimum of 100GB per constituent. For all volumes, the default size is equal to the minimum size.

```
|snaplock
|link:#snaplock[snaplock]
a|
```

```
|snapmirror
|link:#snapmirror[snapmirror]
a|Specifies attributes for SnapMirror protection.
```

```
|snapshot_count
|integer
a|Number of Snapshot copies in the volume.
```

```
|snapshot_policy
|link:#snapshot_policy[snapshot_policy]
a|This is a reference to the Snapshot copy policy.
```

```
|space
|link:#space[space]
a|
```

```
|state
|string
a|Volume state. Client access is supported only when volume is online and junctioned. Taking volume to offline or restricted state removes its junction path and blocks client access. When volume is in restricted state some operations like parity reconstruction and iron on commit are allowed. The 'mixed' state applies to FlexGroup volumes only and cannot be specified as a target state. An 'error' state implies that the volume is not in a state to serve data.
```

```
|statistics
|link:#statistics[statistics]
a|These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
```

```
|status
|array[string]
a|Describes the current status of a volume.
```

|style  
|string  
a|The style of the volume. If "style" is not specified, the volume type is determined based on the specified aggregates. Specifying a single aggregate, without "constituents\_per\_aggregate", creates a flexible volume. Specifying multiple aggregates, or a single aggregate with "constituents\_per\_aggregate", creates a FlexGroup. Specifying a volume "style" creates a volume of that type. For example, if the style is "flexvol" you must specify a single aggregate. If the style is "flexgroup", the system either uses the specified aggregates or automatically provisions aggregates if there are no specified aggregates. The style "flexgroup\_constituent" is not supported when creating a volume.  
flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm  
|link:#svm[svm]  
a|SVM containing the volume. Required on POST.

|tiering  
|link:#tiering[tiering]  
a|

|type  
|string  
a|Type of the volume.  
rw &dash; read-write volume.  
dp &dash; data-protection volume.  
ls &dash; load-sharing `dp` volume. Valid in GET.

|use\_mirrored\_aggregates  
|boolean  
a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.

```
|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* readOnly: 1
* Introduced in: 9.6
```

```
|===
```

```
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Argument code
```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
=====
```

```
[[ID58809ad1d53d5454436698bfeed42877]]
= Create a volume on an SVM and storage aggregates
```

```
[.api-doc-operation .api-doc-operation-post]#POST# [.api-doc-code-
block]#`/storage/volumes`#
```

```
*Introduced In:* 9.6
```

Creates a volume on a specified SVM and storage aggregates.

```
== Required properties
```

\* `svm.uuid` or `svm.name` - Existing SVM in which to create the volume.

\* `name` - Name of the volume.

\* `aggregates.name` or `aggregates.uuid` - Existing aggregates in which to create the volume.

```
== Default property values
```

```
* `state` - _online_
* `size` - _20MB_
* `style` - _flexvol_
* `type` - _rw_
* `encryption.enabled` - _false_
* `snapshot_policy.name` - _default_
* `guarantee.type` - _volume_
* `anti_ransomware.state` - _default_
```

== Related ONTAP commands

```
* `volume create`
* `volume clone create`
```

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
|Type
|In
|Required
|Description
```

```
|return_timeout
|integer
|query
|False
```

a|The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|return_records
|boolean
|query
|False
```

a|The default is false. If set to true, the records are returned.

\* Default value:

|===

== Request Body

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|access\_time\_enabled

|boolean

a|Indicates whether or not access time updates are enabled on the volume.

|activity\_tracking

|link:#activity\_tracking[activity\_tracking]

a|

|aggregates

|array[link:#aggregates[aggregates]]

a|Aggregate hosting the volume. Required on POST.

|analytics

|link:#analytics[analytics]

a|

|anti\_ransomware

|link:#anti\_ransomware[anti\_ransomware]

a|Anti-ransomware related information of the volume.

|anti\_ransomware\_state

|string

a|The Anti-ransomware state of the volume. If no "anti\_ransomware\_state" property is specified, the volume inherits the value from its parent SVM's

"anti\_ransomware\_default\_volume\_state" property. If this value is "disabled", Anti-ransomware is disabled on the volume. If this value is "enabled", Anti-ransomware is enabled on the volume and alerts are raised if any suspect is detected for those volumes. If this value is "dry\_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry\_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable\_in\_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable\_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry\_run\_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry\_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry\_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.

|application

|link:#application[application]

a|

|asynchronous\_directory\_delete

|link:#asynchronous\_directory\_delete[asynchronous\_directory\_delete]

a|Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.

|autosize

|link:#autosize[autosize]

a|

|clone

|link:#clone[clone]

a|

|cloud\_retrieval\_policy

|string

a|This parameter specifies the cloud retrieval policy for the volume. This policy determines which tiered out blocks to retrieve from the capacity tier to the performance tier. The available cloud retrieval policies are "default" policy retrieves tiered data based on the underlying tiering policy. If the tiering policy is 'auto', tiered data is retrieved only for random client driven data reads. If the tiering policy is 'none' or 'snapshot\_only', tiered data is retrieved for random and sequential client



driven data reads. If the tiering policy is 'all', tiered data is not retrieved.

"on\_read" policy retrieves tiered data for all client driven data reads.

"never" policy never retrieves tiered data.

"promote" policy retrieves all eligible tiered data automatically during the next scheduled scan. It is only supported when the tiering policy is 'none' or 'snapshot\_only'. If the tiering policy is 'snapshot\_only', the only data brought back is the data in the AFS. Data that is only in a snapshot copy stays in the cloud and if tiering policy is 'none' then all data is retrieved.

|comment

|string

a|A comment for the volume. Valid in POST or PATCH.

|consistency\_group

|link:#consistency\_group[consistency\_group]

a|Consistency group the volume is part of.

|constituents

|array[link:#constituents[constituents]]

a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more efficiently by specifying "is\_constituent=true" or "is\_constituent=true&flexgroup.uuid=+++<flexgroup.uuid>+++" as query parameters.+++</flexgroup.uuid>+++

|constituents\_per\_aggregate

|integer

a|Specifies the number of times to iterate over the aggregates listed with the "aggregates.name" or "aggregates.uuid" when creating or expanding a FlexGroup volume. If a volume is being created on a single aggregate, the system creates a flexible volume if the "constituents\_per\_aggregate" field is not specified, or a FlexGroup volume if it is specified. If a volume is being created on multiple aggregates, the system always creates a FlexGroup volume. The root constituent of a FlexGroup volume is always placed on the first aggregate in the list.

|convert\_unicode

|boolean

a|Specifies whether directory Unicode format conversion is enabled when directories are accessed by NFS clients.

```
|create_time
|string
a|Creation time of the volume. This field is generated when the volume is
created.
```

```
|efficiency
|link:#efficiency[efficiency]
a|
```

```
|encryption
|link:#encryption[encryption]
a|
```

```
|error_state
|link:#error_state[error_state]
a|
```

```
|files
|link:#files[files]
a|
```

```
|flash_pool
|link:#flash_pool[flash_pool]
a|
```

```
|flexcache_endpoint_type
|string
a|FlexCache endpoint type.
none &dash; The volume is neither a FlexCache nor origin of any FlexCache.
cache &dash; The volume is a FlexCache volume.
origin &dash; The volume is origin of a FlexCache volume.
```

```
|flexgroup
|link:#flexgroup[flexgroup]
a|
```

```
|granular_data
|boolean
a|State of granular data on the volume. This setting is true by default
when creating a new FlexGroup volume, but can be specified as false at the
time of creation via a POST request. On FlexVol volumes, the setting is
always false, as only FlexGroup volumes and FlexGroup constituents support
this feature. Once enabled, this setting can only be disabled by restoring
a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible
```

with this feature. Therefore, reverting to an earlier version of ONTAP is not possible unless this volume is deleted or restored to a Snapshot copy that was taken before the setting was enabled.

\* Introduced in: 9.11

|guarantee  
|link:#guarantee[guarantee]  
a|

|idcs\_scanner  
|link:#idcs\_scanner[idcs\_scanner]  
a|Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

|is\_object\_store  
|boolean  
a|Specifies whether the volume is provisioned for an object store server.

|is\_svm\_root  
|boolean  
a|Specifies whether the volume is a root volume of the SVM it belongs to.

|language  
|string  
a|Language encoding setting for volume. If no language is specified, the volume inherits its SVM language encoding setting.

|max\_dir\_size  
|integer  
a|Maximum directory size. This value sets maximum size, in bytes, to which a directory can grow. The default maximum directory size for FlexVol volumes is model-dependent, and optimized for the size of system memory. Before increasing the maximum directory size, involve technical support.

|metric  
|link:#metric[metric]  
a|Performance numbers, such as IOPS, latency and throughput.

|movement  
|link:#movement[movement]  
a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|msid  
|integer  
a|The volume's Mirror Set ID.

|name  
|string  
a|Volume name. The name of volume must start with an alphabetic character (a to z or A to Z) or an underscore (\_). The name must be 197 or fewer characters in length for FlexGroups, and 203 or fewer characters in length for all other types of volumes. Volume names must be unique within an SVM. Required on POST.

|nas  
|link:#nas[nas]  
a|

|qos  
|link:#qos[qos]  
a|QoS information

|queue\_for\_encryption  
|boolean  
a|Specifies whether the volume is queued for encryption.

|quota  
|link:#quota[quota]  
a|Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

|rebalancing  
|link:#rebalancing[rebalancing]  
a|Configurations and settings involving non-disruptive volume capacity

rebalancing for a FlexGroup volume.

|scheduled\_snapshot\_naming\_scheme

|string

a|Naming Scheme for automatic Snapshot copies:

\* create\_time - Automatic Snapshot copies are saved as per the start of their current date and time.

\* ordinal - Latest automatic snapshot copy is saved as

+++<scheduled\_frequency>+++0 and subsequent copies will follow the create\_time naming convention.+++</scheduled\_frequency>+++

|size

|integer

a|Physical size of the volume, in bytes. The minimum size for a FlexVol volume is 20MB and the minimum size for a FlexGroup volume is 200MB per constituent. The recommended size for a FlexGroup volume is a minimum of 100GB per constituent. For all volumes, the default size is equal to the minimum size.

|snaplock

|link:#snaplock[snaplock]

a|

|snapmirror

|link:#snapmirror[snapmirror]

a|Specifies attributes for SnapMirror protection.

|snapshot\_count

|integer

a|Number of Snapshot copies in the volume.

|snapshot\_policy

|link:#snapshot\_policy[snapshot\_policy]

a|This is a reference to the Snapshot copy policy.

|space

|link:#space[space]

a|

|state

|string  
a|Volume state. Client access is supported only when volume is online and junctioned. Taking volume to offline or restricted state removes its junction path and blocks client access. When volume is in restricted state some operations like parity reconstruction and iron on commit are allowed. The 'mixed' state applies to FlexGroup volumes only and cannot be specified as a target state. An 'error' state implies that the volume is not in a state to serve data.

|statistics  
|link:#statistics[statistics]  
a|These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

|status  
|array[string]  
a|Describes the current status of a volume.

|style  
|string  
a|The style of the volume. If "style" is not specified, the volume type is determined based on the specified aggregates. Specifying a single aggregate, without "constituents\_per\_aggregate", creates a flexible volume. Specifying multiple aggregates, or a single aggregate with "constituents\_per\_aggregate", creates a FlexGroup. Specifying a volume "style" creates a volume of that type. For example, if the style is "flexvol" you must specify a single aggregate. If the style is "flexgroup", the system either uses the specified aggregates or automatically provisions aggregates if there are no specified aggregates. The style "flexgroup\_constituent" is not supported when creating a volume.  
flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm  
|link:#svm[svm]  
a|SVM containing the volume. Required on POST.

|tiering  
|link:#tiering[tiering]  
a|

```
|type
|string
a|Type of the volume.
rw &dash; read-write volume.
dp &dash; data-protection volume.
ls &dash; load-sharing `dp` volume. Valid in GET.
```

```
|use_mirrored_aggregates
|boolean
a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.
```

```
|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* readOnly: 1
* Introduced in: 9.6
```

```
|===
```

```
.Example request
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "activity_tracking": {
```

```
    "state": "off",
    "unsupported_reason": {
      "code": "124518405",
      "message": "Volume activity tracking cannot be enabled on volumes
that contain LUNs."
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "analytics": {
    "scan_progress": 17,
    "state": "unknown",
    "unsupported_reason": {
      "code": "111411207",
      "message": "File system analytics cannot be enabled on volumes that
contain LUNs."
    }
  },
  "anti_ransomware": {
    "attack_probability": "none",
    "attack_reports": {
      "_links": {
        "suspects": {
          "href": "/api/resourcelink"
        }
      }
    },
    "time": "2021-06-01T20:36:41+05:30"
  },
  "dry_run_start_time": "string",
  "space": {
    "snapshot_count": 0,
    "used": 0,
    "used_by_logs": 0,
    "used_by_snapshots": 0
  },
  "state": "disabled",
  "suspect_files": {
    "count": 0,
    "entropy": "string",
```



```
    "format": "string"
  }
},
"anti_ransomware_state": "disabled",
"application": {
  "name": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"autosize": {
  "mode": "grow"
},
"clone": {
  "parent_snapshot": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "this_snapshot",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "parent_svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "parent_volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "split_complete_percent": 0,
  "split_estimate": 0
},
"cloud_retrieval_policy": "default",
"comment": "string",
"consistency_group": {
  "name": "consistency_group_1",
```

```

    "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
  },
  "constituents": {
    "aggregates": {
      "name": "string",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    },
    "movement": {
      "cutover_window": 30,
      "destination_aggregate": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "aggr1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "percent_complete": 0,
      "state": "replicating",
      "tiering_policy": "all"
    },
    "name": "string",
    "space": {
      "available": 0,
      "block_storage_inactive_user_data": 0,
      "capacity_tier_footprint": 0,
      "footprint": 0,
      "local_tier_footprint": 0,
      "logical_space": {
        "available": 0,
        "used_by_afs": 0
      },
      "metadata": 0,
      "over_provisioned": 0,
      "performance_tier_footprint": 0,
      "snapshot": {
        "used": 0
      },
      "total_footprint": 0,
      "used": 0
    }
  },
  "create_time": "2018-06-04T19:00:00Z",
  "efficiency": {
    "application_io_size": "8k",

```

```
"compaction": "inline",
"compression": "inline",
"compression_type": "none",
"cross_volume_dedupe": "inline",
"dedupe": "inline",
"last_op_begin": "string",
"last_op_end": "string",
"last_op_err": "string",
"last_op_size": 0,
"last_op_state": "string",
"op_state": "idle",
"path": "string",
"progress": "string",
"scanner": {
  "state": "idle"
},
"schedule": "string",
"space_savings": {
  "compression": 0,
  "compression_percent": 0,
  "dedupe": 0,
  "dedupe_percent": 0,
  "dedupe_sharing": 0,
  "total": 0,
  "total_percent": 0
},
"state": "disabled",
"storage_efficiency_mode": "default",
"type": "regular"
},
"encryption": {
  "key_create_time": "2022-01-01T19:00:00Z",
  "key_id": "string",
  "key_manager_attribute": "CRN=v1:bluemix:public:containers-
kubernetes:us-south:a/asdfghjkl1234:asdfghjkl1234:worker:kubernetes-
asdfghjkl-worker1",
  "state": "encrypted",
  "status": {
    "code": "string",
    "message": "string"
  },
  "type": "none"
},
"files": {
  "used": 0
},
```

```
"flash_pool": {
  "cache_eligibility": "read",
  "cache_retention_priority": "normal",
  "caching_policy": "none"
},
"flexcache_endpoint_type": "none",
"flexgroup": {
  "name": "my_flexgroup",
  "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
},
"guarantee": {
  "type": "volume"
},
"idcs_scanner": {
  "mode": "default",
  "operation_state": "idle",
  "status": "success"
},
"language": "ar",
"metric": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"cloud": {
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "timestamp": "2017-01-25T11:20:13Z"
},
"duration": "PT15S",
"flexcache": {
  "bandwidth_savings": 4096,
  "cache_miss_percent": 20,
  "duration": "PT1D",
  "status": "ok",
```

```

    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"movement": {
  "cutover_window": 30,
  "destination_aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "percent_complete": 0,
  "start_time": "2020-12-07T03:45:12-05:00",
  "state": "replicating",
  "tiering_policy": "all"
},
"name": "vol_cs_dept",
"nas": {
  "export_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": 100,
    "name": "default"
  }
}

```

```

    },
    "junction_parent": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "vsl_root",
      "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
    },
    "path": "/user/my_volume",
    "security_style": "mixed",
    "unix_permissions": 755
  },
  "qos": {
    "policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "max_throughput_iops": 10000,
      "max_throughput_mbps": 500,
      "min_throughput_iops": 2000,
      "min_throughput_mbps": 500,
      "name": "performance",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "quota": {
    "state": "corrupt"
  },
  "rebalancing": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "data_moved": 0,
    "failure_reason": {
      "code": "string",
      "message": "string"
    },
    "imbalance_percent": 0,
    "imbalance_size": 0,
    "max_constituent_imbalance_percent": 0,

```

```

    "runtime": "string",
    "start_time": "string",
    "state": "rebalancing",
    "stop_time": "string",
    "target_used": 0
  },
  "scheduled_snapshot_naming_scheme": "create_time",
  "snaplock": {
    "append_mode_enabled": "",
    "autocommit_period": "P30M",
    "compliance_clock_time": "2018-06-04T19:00:00Z",
    "expiry_time": "Wed Sep 5 11:02:42 GMT 2018",
    "is_audit_log": 1,
    "litigation_count": 10,
    "privileged_delete": "enabled",
    "retention": {
      "default": "P30Y",
      "maximum": "P30Y",
      "minimum": "P30Y"
    },
    "type": "enterprise",
    "unspecified_retention_file_count": 10
  },
  "snapshot_count": 0,
  "snapshot_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "space": {
    "auto_adaptive_compression_footprint_data_reduction": 0,
    "available": 0,
    "block_storage_inactive_user_data": 0,
    "block_storage_inactive_user_data_percent": 0,
    "capacity_tier_footprint": 0,
    "cross_volume_dedupe_metafiles_footprint": 0,
    "cross_volume_dedupe_metafiles_temporary_footprint": 0,
    "dedupe_metafiles_footprint": 0,
    "dedupe_metafiles_temporary_footprint": 0,
    "delayed_free_footprint": 0,
    "effective_total_footprint": 0,
    "file_operation_metadata": 0,

```

```

"filesystem_size": 0,
"footprint": 0,
"local_tier_footprint": 0,
"logical_space": {
  "available": 0,
  "used": 0,
  "used_by_afs": 0,
  "used_by_snapshots": 0,
  "used_percent": 0
},
"metadata": 0,
"over_provisioned": 0,
"overwrite_reserve": 0,
"overwrite_reserve_used": 0,
"percent_used": 0,
"performance_tier_footprint": 0,
"size_available_for_snapshots": 0,
"snapmirror_destination_footprint": 0,
"snapshot": {
  "autodelete_trigger": "volume",
  "reserve_available": 0,
  "reserve_size": 0,
  "space_used_percent": 0,
  "used": 0
},
"snapshot_reserve_unusable": 0,
"snapshot_spill": 0,
"total_footprint": 0,
"used": 0,
"user_data": 0,
"volume_guarantee_footprint": 0
},
"state": "error",
"statistics": {
  "cifs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,

```



```
    "total_time": 200
  },
  "file": {
    "count": 1000,
    "total_time": 200
  },
  "other": {
    "count": 1000,
    "total_time": 200
  },
  "symlink": {
    "count": 1000,
    "total_time": 200
  }
},
"getattr": {
  "count": 1000,
  "total_time": 200
},
"link": {
  "count": 1000,
  "total_time": 200
},
"lock": {
  "count": 1000,
  "total_time": 200
},
"lookup": {
  "count": 1000,
  "total_time": 200
},
"open": {
  "count": 1000,
  "total_time": 200
},
"read": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,
    35,
```



```
"<600us",
"<800us",
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
```

```
],
"volume_protocol_size_histogram_labels": [
  "< 4KB",
  "= 4KB",
  "< 8KB",
  "= 8KB",
  "< 16KB",
  "= 16KB",
  "< 32KB",
  "= 32KB",
  "< 64KB",
  "= 64KB",
  "< 256KB",
  "= 256KB",
  "< 1024KB",
  "= 1024KB",
  "> 1024KB"
]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
```



```
"<14us",
"<20us",
"<40us",
"<60us",
"<80us",
"<100us",
"<200us",
"<400us",
"<600us",
"<800us",
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
```

```
    100,  
    100,  
    50,  
    50,  
    75,  
    25,  
    0,  
    0  
  ],  
  "volume_protocol_size_histogram_labels": [  
    "< 4KB",  
    "= 4KB",  
    "< 8KB",  
    "= 8KB",  
    "< 16KB",  
    "= 16KB",  
    "< 32KB",  
    "= 32KB",  
    "< 64KB",  
    "= 64KB",  
    "< 256KB",  
    "= 256KB",  
    "< 1024KB",  
    "= 1024KB",  
    "> 1024KB"  
  ]  
}  
},  
"cloud": {  
  "iops_raw": {  
    "read": 200,  
    "total": 1000,  
    "write": 100  
  },  
  "latency_raw": {  
    "read": 200,  
    "total": 1000,  
    "write": 100  
  },  
  "status": "ok",  
  "timestamp": "2017-01-25T11:20:13Z"  
},  
"flexcache_raw": {  
  "cache_miss_blocks": 10,  
  "client_requested_blocks": 500,  
  "status": "ok",
```

```
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "nfs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
      "file": {
        "count": 1000,
        "total_time": 200
      },
      "other": {
        "count": 1000,
        "total_time": 200
      },
      "symlink": {
        "count": 1000,
        "total_time": 200
      }
    },
    "getattr": {
      "count": 1000,
      "total_time": 200
    },
    "link": {
      "count": 1000,
      "total_time": 200
    }
  }
}
```







```

    "<2s",
    "<4s",
    "<6s",
    "<8s",
    "<10s",
    "<20s",
    ">20s"
  ],
  "volume_protocol_size_histogram_counts": [
    2400,
    1055,
    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
}

```

```
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,
    35,
    100,
    200,
    200,
    300,
    500,
    500,
    500,
    1000,
    1000,
    800,
    500,
    500,
    300,
    200,
```



```
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
"volume_protocol_size_histogram_labels": [
  "< 4KB",
  "= 4KB",
  "< 8KB",
  "= 8KB",
  "< 16KB",
  "= 16KB",
  "< 32KB",
  "= 32KB",
  "< 64KB",
  "= 64KB",
  "< 256KB",
  "= 256KB",
```

```
        "< 1024KB",
        "= 1024KB",
        "> 1024KB"
    ]
}
},
"status": "ok",
"throughput_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},
"status": {
},
"style": "flexvol",
"svm": {
    "_links": {
        "self": {
            "href": "/api/resourcelink"
        }
    },
},
"name": "svm1",
"uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"tiering": {
    "object_tags": {
    },
    "policy": "all"
},
"type": "rw",
"uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
====

== Response
```

Status: 202, Accepted

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===

.Example response
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
====

== Error

```

## Status: Default

### ONTAP Error Response Codes

```

|===
| Error Code | Description

| 787140
| One of "aggregates.uuid", "aggregates.name", or "style" must be
provided.

| 787141
| The specified "aggregates.name" and "aggregates.uuid" refer to different
aggregates.

```



| 917526  
| The volume name specified is a duplicate.

| 917829  
| Volume autosize grow threshold must be larger than autosize shrink threshold.

| 917831  
| Volume minimum autosize must be smaller than the maximum autosize.

| 917835  
| Maximum allowed snapshot.reserve\_percent value during a volume creation is 90. Use PATCH to set it to a higher value after the volume has been created.

| 918191  
| Flexvol tiering min cooling days requires an effective cluster version of ONTAP 9.4 or later.

| 918194  
| Tiering min cooling days not supported for SVMDR.

| 918195  
| Tiering min cooling days not supported for non data volumes.

| 918196  
| Tiering min cooling days not allowed for the provided tiering policy.

| 918215  
| FlexGroup tiering min cooling days requires an effective cluster version of ONTAP 9.5 or later.

| 918233  
| The target field cannot be specified for this operation.

| 918236  
| The specified "parent\_volume.uuid" and "parent\_volume.name" do not refer to the same volume.

| 918240  
| The target style is an invalid volume style.

| 918241  
| The target style is an unsupported volume style for volume creation.

| 918242

| When creating a flexible volume, exactly one aggregate must be specified via either "aggregates.name" or "aggregates.uuid".

| 918243

| The specified Snapshot copy UUID is not correct for the specified Snapshot copy name.

| 918244

| Invalid "volume.type" for clone volume.

| 918246

| "volume.clone.parent\_volume.name" or "volume.clone.parent\_volume.uuid" must be provided.

| 918247

| Specifying a value is not valid for a volume FlexClone creation.

| 918252

| "nas.path" is invalid.

| 918290

| cloud retrieval policy requires an effective cluster version of 9.8 or later.

| 918291

| Invalid volume cloud retrieval policy for the provided tiering policy.

| 918292

| cloud retrieval policy not supported for non data volume.

| 918521

| The volume maximum autosize must be smaller than or equal to the maximum volume size.

| 918524

| Volume minimum autosize must be less than or equal to the current volume size.

| 2621706

| The specified "svm.uuid" and "svm.name" do not refer to the same SVM.

| 2621707

| No SVM was specified. Either "svm.name" or "svm.uuid" must be supplied.

| 111411205

| File system analytics requires an effective cluster version of 9.8 or later.

```
| 111411206
| The specified "analytics.state" is invalid.

| 111411207
| File system analytics cannot be enabled on volumes that contain LUNs.
|===
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|error
```

```
|link:#error[error]
```

```
a|
```

```
|===
```

```
.Example error
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

```
====
```

```
== Definitions
```

```
[.api-def-first-level]
```

```
.See Definitions
```

```
[%collapsible%closed]
```

```
//Start collapsible Definitions block
```

```
====
```

```

[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If volume activity tracking is not supported on the volume, this field

```

provides an appropriate error code.

|message

|string

a|If volume activity tracking is not supported on the volume, this field provides an error message detailing why this is the case.

|===

[#activity\_tracking]

[.api-collapsible-fifth-title]

activity\_tracking

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|state

|string

a|Activity tracking state of the volume. If this value is "on", ONTAP collects top metrics information for the volume in real time. There is a slight impact to I/O performance in order to collect this information. If this value is "off", no activity tracking information is collected or available to view.

\* enum: ["off", "on"]

\* Introduced in: 9.10

|supported

|boolean

a|This field indicates whether or not volume activity tracking is supported on the volume. If volume activity tracking is not supported, the reason why is provided in the "activity\_tracking.unsupported\_reason" field.

|unsupported\_reason

|link:#unsupported\_reason[unsupported\_reason]

a|

|===

```
[#aggregates]
[.api-collapsible-fifth-title]
aggregates
```

Aggregate

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|uuid
```

```
|string
```

```
a|
```

```
|===
```

```
[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|If file system analytics is not supported on the volume, this field provides the error code explaining why.
```

```
|message
```

```
|string
a|If file system analytics is not supported on the volume, this field
provides the error message explaining why.
```

```
|===
```

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|scan_progress
```

```
|integer
```

```
a|Percentage of files in the volume that the file system analytics
initialization scan has processed. Only returned when the state is
`initializing`.
```

```
|state
```

```
|string
```

```
a|File system analytics state of the volume. If this value is "on", ONTAP
collects extra file system analytics information for all directories on
the volume. There will be a slight impact to I/O performance to collect
this information. If this value is "off", file system analytics
information is not collected and not available to be viewed. If this value
is "initializing", that means file system analytics was recently turned
on, and the initialization scan to gather information all all existing
files and directories is currently running. If this value is 'unknown'
that means there was an internal error when determining the file system
analytics state for the volume.
```

```
* enum: ["unknown", "initializing", "off", "on"]
```

```
* Introduced in: 9.8
```

```
|supported
```

```
|boolean
```

```
a|This field indicates whether or not file system analytics is supported
on the volume. If file system analytics is not supported, the reason will
be specified in the "analytics.unsupported_reason" field.
```

```

|unsupported_reason
|link:#unsupported_reason[unsupported_reason]
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|suspects
|link:#href[href]
a|

|===

[#anti_ransomware_attack_report]
[.api-collapsible-fifth-title]
anti_ransomware_attack_report

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|time
|string
a|Timestamp at which ransomware attack is observed.

|===

```



```

[#space]
[.api-collapsible-fifth-title]
space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|snapshot_count
|integer
a|Total number of Anti-ransomware backup Snapshot copies.

|used
|integer
a|Total space in bytes used by the Anti-ransomware feature.

|used_by_logs
|integer
a|Space in bytes used by the Anti-ransomware analytics logs.

|used_by_snapshots
|integer
a|Space in bytes used by the Anti-ransomware backup Snapshot copies.

|===

[#suspect_files]
[.api-collapsible-fifth-title]
suspect_files

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Total number of `suspect_files.format` files observed by the Anti-

```

ransomware analytics engine on the volume.

|entropy

|string

a|Indicates the entropy level of this file type.

|format

|string

a|File formats observed by the Anti-ransomware analytics engine on the volume.

|===

[#anti\_ransomware]

[.api-collapsible-fifth-title]

anti\_ransomware

Anti-ransomware related information of the volume.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|attack\_probability

|string

a|Probability of a ransomware attack.

`none` No files are suspected of ransomware activity.

`low` A number of files are suspected of ransomware activity.

`moderate` A moderate number of files are suspected of ransomware activity.

`high` A large number of files are suspected of ransomware activity.

|attack\_reports

|array[link:#anti\_ransomware\_attack\_report[anti\_ransomware\_attack\_report]]

a|

|dry\_run\_start\_time

|string

a|Time when Anti-ransomware monitoring `state` is set to dry-run value for

starting evaluation mode.

|space

|link:#space[space]

a|

|state

|string

a|Anti-ransomware state.

`disabled` Anti-ransomware monitoring is disabled on the volume. This is the default state in a POST operation.

`disable\_in\_progress` Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. Valid in GET operation.

`dry\_run` Anti-ransomware monitoring is enabled in the evaluation mode.

`enabled` Anti-ransomware monitoring is active on the volume.

`paused` Anti-ransomware monitoring is paused on the volume.

`enable\_paused` Anti-ransomware monitoring is paused on the volume from its earlier enabled state. Valid in GET operation.

`dry\_run\_paused` Anti-ransomware monitoring is paused on the volume from its earlier dry\_run state. Valid in GET operation.

For POST, the valid Anti-ransomware states are only `disabled`, `enabled` and `dry\_run`, whereas for PATCH, `paused` is also valid along with the three valid states for POST.

|surge\_as\_normal

|boolean

a|Indicates whether or not to set the surge values as historical values.

|suspect\_files

|array[link:#suspect\_files[suspect\_files]]

a|

|===

[#application]

[.api-collapsible-fifth-title]

application

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name  
|string  
a|Name of the application to which the volume belongs. Available only when the volume is part of an application.

|uuid  
|string  
a|UUID of the application to which the volume belongs. Available only when the volume is part of an application.

|===

[#asynchronous\_directory\_delete]  
[.api-collapsible-fifth-title]  
asynchronous\_directory\_delete

Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|enabled  
|boolean  
a|Specifies whether asynchronous directory delete from the client is enabled on the volume.

|trash\_bin  
|string  
a|Name of the trash bin directory. If no "trash\_bin" property is specified when enabling, the default trash bin name, "\_ontaptrashbin", is used.

|===

[#autosize]  
[.api-collapsible-fifth-title]

autosize

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|grow_threshold
```

```
|integer
```

a|Used space threshold size, in percentage, for the automatic growth of the volume. When the amount of used space in the volume becomes greater than this threshold, the volume automatically grows unless it has reached the maximum size. The volume grows when 'space.used' is greater than this percent of 'space.size'. The 'grow\_threshold' size cannot be less than or equal to the 'shrink\_threshold' size..

```
|maximum
```

```
|integer
```

a|Maximum size in bytes up to which a volume grows automatically. This size cannot be less than the current volume size, or less than or equal to the minimum size of volume.

```
|minimum
```

```
|integer
```

a|Minimum size in bytes up to which the volume shrinks automatically. This size cannot be greater than or equal to the maximum size of volume.

```
|mode
```

```
|string
```

a|Autosize mode for the volume.

grow &dash; Volume automatically grows when the amount of used space is above the 'grow\_threshold' value.

grow\_shrink &dash; Volume grows or shrinks in response to the amount of space used.

off &dash; Autosizing of the volume is disabled.

```
|shrink_threshold
```

```
|integer
```

a|Used space threshold size, in percentage, for the automatic shrinkage of the volume. When the amount of used space in the volume drops below this threshold, the volume automatically shrinks unless it has reached the minimum size. The volume shrinks when the 'space.used' is less than the

'shrink\_threshold' percent of 'space.size'. The 'shrink\_threshold' size cannot be greater than or equal to the 'grow\_threshold' size.

|===

```
[#snapshot_reference]
[.api-collapsible-fifth-title]
snapshot_reference
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

|===

```
[#parent_svm]
[.api-collapsible-fifth-title]
parent_svm
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
a|
```

```
|name
```

```

|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#parent_volume]
[.api-collapsible-fifth-title]
parent_volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

|===

[#clone]
[.api-collapsible-fifth-title]
clone

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|is_flexclone
|boolean
a|Specifies if this volume is a normal FlexVol or FlexClone. This field
needs to be set when creating a FlexClone. Valid in POST.

|parent_snapshot
|link:#snapshot_reference[snapshot_reference]
a|

|parent_svm
|link:#parent_svm[parent_svm]
a|

|parent_volume
|link:#parent_volume[parent_volume]
a|

|split_complete_percent
|integer
a|Percentage of FlexClone blocks split from its parent volume.

|split_estimate
|integer
a|Space required by the containing-aggregate to split the FlexClone
volume.

|split_initiated
|boolean
a|This field is set when split is executed on any FlexClone, that is when
the FlexClone volume is split from its parent FlexVol. This field needs to
be set for splitting a FlexClone form FlexVol. Valid in PATCH.

|===

[#consistency_group]

```



```
[.api-collapsible-fifth-title]
```

```
consistency_group
```

Consistency group the volume is part of.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

a|The name of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

```
|uuid
```

```
|string
```

a|The UUID of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

```
|===
```

```
[#aggregates]
```

```
[.api-collapsible-fifth-title]
```

```
aggregates
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

a|Name of the aggregate hosting the FlexGroup Constituent.

```
|uuid
```

```
|string
a|Unique identifier for the aggregate.
```

```
|===
```

```
[#destination_aggregate]
[.api-collapsible-fifth-title]
destination_aggregate
```

Aggregate

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|cutover_window
|integer
a|Time window in seconds for cutover. The allowed range is between 30 to
300 seconds.

|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate

|percent_complete
|integer
a|Completion percentage

|state
|string
a|State of volume move operation. PATCH the state to "aborted" to abort
the move operation. PATCH the state to "cutover" to trigger cutover. PATCH
the state to "paused" to pause the volume move operation in progress.
PATCH the state to "replicating" to resume the paused volume move
operation. PATCH the state to "cutover_wait" to go into cutover manually.
When volume move operation is waiting to go into "cutover" state, this is
indicated by the "cutover_pending" state. A change of state is only
supported if volume movement is in progress.

|tiering_policy
|string
a|Tiering policy for FabricPool

|===

[#logical_space]
[.api-collapsible-fifth-title]
logical_space

[cols=3*,options=header]
|===
|Name
|Type

```

|Description

|available

|integer

a|The amount of space available in this volume with storage efficiency space considered used, in bytes.

|enforcement

|boolean

a|Specifies whether space accounting for operations on the volume is done along with storage efficiency.

|reporting

|boolean

a|Specifies whether space reporting on the volume is done along with storage efficiency.

|used\_by\_afs

|integer

a|The virtual space used by AFS alone (includes volume reserves) and along with storage efficiency, in bytes.

|===

[#snapshot]

[.api-collapsible-fifth-title]

snapshot

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|autodelete\_enabled

|boolean

a|Specifies whether Snapshot copy autodelete is currently enabled on this volume.

|reserve\_percent

|integer

a|The space that has been set aside as a reserve for Snapshot copy usage, in percent.

|used

|integer

a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|afs\_total

|integer

a|Total size of AFS, excluding snap-reserve, in bytes.

|available

|integer

a|The available space, in bytes.

|available\_percent

|integer

a|The space available, as a percent.

|block\_storage\_inactive\_user\_data

|integer

a|The size that is physically used in the block storage of the volume and has a cold temperature. In bytes. This parameter is only supported if the volume is in an aggregate that is either attached to a cloud store or could be attached to a cloud store.

|capacity\_tier\_footprint

|integer

a|Space used by capacity tier for this volume in the FabricPool aggregate, in bytes.

|footprint

|integer

a|Data used for this volume in the aggregate, in bytes.

|local\_tier\_footprint

|integer

a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical\_space

|link:#logical\_space[logical\_space]

a|

|metadata

|integer

a|Space used by the volume metadata in the aggregate, in bytes.

|over\_provisioned

|integer

a|The amount of space not available for this volume in the aggregate, in bytes.

|performance\_tier\_footprint

|integer

a|Space used by the performance tier for this volume in the FabricPool aggregate, in bytes.

|size

|integer

a|Total provisioned size. The default size is equal to the minimum size of 20MB, in bytes.

|snapshot

|link:#snapshot[snapshot]

a|

|total\_footprint

|integer

a|Data and metadata used for this volume in the aggregate, in bytes.

|used

|integer

a|The virtual space used (includes volume reserves) before storage efficiency, in bytes.

|used\_by\_afs

|integer

a|The space used by Active Filesystem, in bytes.

|used\_percent

|integer

a|The virtual space used (includes volume reserves) before storage efficiency, as a percent.

|===

[#constituents]

[.api-collapsible-fifth-title]

constituents

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|aggregates

|link:#aggregates[aggregates]

a|

|movement

|link:#movement[movement]

a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|name

|string

a|FlexGroup Constituents name.

|space

|link:#space[space]

a|

|===

[#policy]

[.api-collapsible-fifth-title]

policy

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name

|string

a|Specifies the name of the efficiency policy.

|===

[#scanner]

[.api-collapsible-fifth-title]

scanner

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|compression

|boolean

a|Start compression if scanning old data. Valid for PATCH and GET.

|dedupe

|boolean

a|Start deduplication if scanning old data. Valid for PATCH and GET.



```
|scan_old_data
|boolean
a|Indicates whether or not to scan old data. Valid for PATCH and GET.
```

```
|state
|string
a|State of the volume efficiency scanner. Valid for PATCH and GET. Valid
options for PATCH are "idle" and "active".
```

```
|===
```

```
[#space_savings]
[.api-collapsible-fifth-title]
space_savings
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|compression
|integer
a|Total disk space that is saved by compressing blocks on the referenced
file system, in bytes.
```

```
|compression_percent
|integer
a|Percentage of total disk space that is saved by compressing blocks on
the referenced file system.
```

```
|dedupe
|integer
a|Total disk space that is saved by deduplication and file cloning, in
bytes.
```

```
|dedupe_percent
|integer
a|Percentage of total disk space that is saved by deduplication and file
cloning.
```

```
|dedupe_sharing
|integer
a|Total disk space that is shared due to deduplication and file cloning.
```

```
|total
|integer
a|Total disk space saved in the volume due to deduplication, compression
and file cloning, in bytes.
```

```
|total_percent
|integer
a|Percentage of total disk space saved in the volume due to deduplication,
compression and file cloning.
```

```
|===
```

```
[#efficiency]
[.api-collapsible-fifth-title]
efficiency
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|application_io_size
|string
a|Block size to use by compression.
```

```
|compaction
|string
a|The system can be enabled/disabled compaction.
inline &dash; Data will be compacted first and written to the volume.
none &dash; None
mixed &dash; Read only field for FlexGroups, where some of the constituent
volumes are compaction enabled and some are disabled.
```

```
|compression
```

|string

a|The system can be enabled/disabled compression.

inline &dash; Data will be compressed first and written to the volume.

background &dash; Data will be written to the volume and compressed later.

both &dash; Inline compression compresses the data and write to the volume, background compression compresses only the blocks on which inline compression is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are compression enabled and some are disabled.

NOTE: that On volumes with container compression enabled, background compression refers to inactive data compression scan enabled on the volume.

|compression\_type

|string

a|Compression type to use by compression. Valid for PATCH and GET.

|cross\_volume\_dedupe

|string

a|The system can be enabled/disabled cross volume dedupe. it can be enabled only when dedupe is enabled.

inline &dash; Data will be cross volume deduped first and written to the volume.

background &dash; Data will be written to the volume and cross volume deduped later.

both &dash; Inline cross volume dedupe dedupes the data and write to the volume, background cross volume dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are cross volume dedupe enabled and some are disabled.

|dedupe

|string

a|The system can be enabled/disabled dedupe.

inline &dash; Data will be deduped first and written to the volume.

background &dash; Data will be written to the volume and deduped later.

both &dash; Inline dedupe dedupes the data and write to the volume, background dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are dedupe enabled and some are disabled.

|has\_savings

|boolean

a|When true, indicates that the volume contains shared(deduplication, file clones) or compressed data.

|last\_op\_begin

|string

a|Last sis operation begin timestamp.

|last\_op\_end

|string

a|Last sis operation end timestamp.

|last\_op\_err

|string

a|Last sis operation error text.

|last\_op\_size

|integer

a|Last sis operation size.

|last\_op\_state

|string

a|Last sis operation state.

|logging\_enabled

|boolean

a|When true, indicates that space savings for any newly-written data are being logged.

|op\_state

|string

a|Sis status of the volume.

|path

```

|string
a|Absolute volume path of the volume.

|policy
|link:#policy[policy]
a|

|progress
|string
a|Sis progress of the volume.

|scanner
|link:#scanner[scanner]
a|

|schedule
|string
a|Schedule associated with volume.

|space_savings
|link:#space_savings[space_savings]
a|

|state
|string
a|Storage efficiency state of the volume. Currently, this field supports
POST/PATCH only for RW (Read-Write) volumes on FSx for ONTAP and Cloud
Volumes ONTAP.
disabled &dash; All storage efficiency features are disabled.
mixed &dash; Read-only field for FlexGroup volumes, storage efficiency is
enabled on certain constituents and disabled on others.
On FSx for ONTAP and Cloud Volumes ONTAP &dash;
    &emsp; enabled &dash; All supported storage efficiency features for the
volume are enabled.
    &emsp; custom &dash; Read-only field currently only supported for the FSx
for ONTAP and Cloud Volumes ONTAP, user-defined storage efficiency
features are enabled.
For other platforms &dash;
    &emsp; enabled &dash; At least one storage efficiency feature for the
volume is enabled.

* enum: ["disabled", "enabled", "mixed", "custom"]
* Introduced in: 9.9

```

```
|storage_efficiency_mode
|string
a|Storage efficiency mode used by volume. This parameter is supported only
on AFF platform.
```

```
|type
|string
a|Sis Type of the volume.
```

```
|===
```

```
[#status]
[.api-collapsible-fifth-title]
status
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Encryption progress message code.
```

```
|message
|string
a|Encryption progress message.
```

```
|===
```

```
[#encryption]
[.api-collapsible-fifth-title]
encryption
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

|enabled  
|boolean  
a|Creates an encrypted or an unencrypted volume. For POST, when set to 'true', a new key is generated and used to encrypt the given volume. In that case, the underlying SVM must be configured with the key manager. When set to 'false', the volume created will be unencrypted. For PATCH, when set to 'true', it encrypts an unencrypted volume. Specifying the parameter as 'false' in a PATCH operation for an encrypted volume is only supported when moving the volume to another aggregate.

|key\_create\_time  
|string  
a|Encryption key creation time of the volume.

|key\_id  
|string  
a|The key ID used for creating encrypted volume. A new key-id is generated for creating an encrypted volume. This key-id is associated with the generated key.

|key\_manager\_attribute  
|string  
a|Specifies an additional key manager attribute that is an identifier-value pair, separated by '='. For example, CRN=unique-value. This parameter is required when using the POST method and an IBM Key Lore key manager is configured on the SVM.

|rekey  
|boolean  
a|If set to 'true', re-encrypts the volume with a new key. Valid in PATCH.

|state  
|string  
a|Volume encryption state.  
encrypted &dash; The volume is completely encrypted.  
encrypting &dash; Encryption operation is in progress.  
partial &dash; Some constituents are encrypted and some are not.  
Applicable only for FlexGroup volume.  
rekeying. Encryption of volume with a new key is in progress.  
unencrypted &dash; The volume is a plain-text one.

```
|status
|link:#status[status]
a|
```

```
|type
|string
a|Volume encryption type.
none &dash; The volume is a plain-text one.
volume &dash; The volume is encrypted with NVE (NetApp Volume Encryption).
aggregate &dash; The volume is encrypted with NAE (NetApp Aggregate Encryption).
```

```
|===
```

```
[#error_state]
[.api-collapsible-fifth-title]
error_state
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|has_bad_blocks
|boolean
a|Indicates whether the volume has any corrupt data blocks. If the damaged data block is accessed, an IO error, such as EIO for NFS or STATUS_FILE_CORRUPT for CIFS, is returned.
```

```
|is_inconsistent
|boolean
a|Indicates whether the file system has any inconsistencies.
true &dash; File system is inconsistent.
false &dash; File system in not inconsistent.
```

```
|===
```

```
[#files]
[.api-collapsible-fifth-title]
files
```



```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|maximum
```

```
|integer
```

a|The maximum number of files (inodes) for user-visible data allowed on the volume. This value can be increased or decreased. Increasing the maximum number of files does not immediately cause additional disk space to be used to track files. Instead, as more files are created on the volume, the system dynamically increases the number of disk blocks that are used to track files. The space assigned to track files is never freed, and this value cannot be decreased below the current number of files that can be tracked within the assigned space for the volume. Valid in PATCH.

```
|used
```

```
|integer
```

a|Number of files (inodes) used for user-visible data permitted on the volume. This field is valid only when the volume is online.

```
|===
```

```
[#flash_pool]
```

```
[.api-collapsible-fifth-title]
```

```
flash_pool
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cache_eligibility
```

```
|string
```

a|If this parameter is specified, the command displays information only about the volume or volumes with the specified Flash Pool caching attributes.

```
|cache_retention_priority
```

```
|string
```

a|If this parameter is specified, the command displays the volumes that match the specified cache retention priority policy. A cache retention priority defines how long the blocks of a volume will be cached in the Flash Pool once they become cold.

|caching\_policy

|string

a|This optionally specifies the caching policy to apply to the volume. A caching policy defines how the system caches a volume's data in Flash Cache modules. If a caching policy is not assigned to a volume, the system uses the caching policy that is assigned to the containing SVM. If a caching policy is not assigned to the containing SVM, the system uses the default cluster-wide policy.

|===

[#flexgroup]

[.api-collapsible-fifth-title]

flexgroup

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name

|string

a|Name of the FlexGroup volume that the constituent is part of.

|uuid

|string

a|Unique identifier for the FlexGroup volume that the constituent is part of.

|===

[#guarantee]

[.api-collapsible-fifth-title]

guarantee

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|honored
```

```
|boolean
```

```
a|Is the space guarantee of this volume honored in the aggregate?
```

```
|type
```

```
|string
```

```
a|The type of space guarantee of this volume in the aggregate.
```

```
|===
```

```
[#idcs_scanner]
```

```
[.api-collapsible-fifth-title]
```

```
idcs_scanner
```

Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|enabled
```

```
|boolean
```

```
a|Specifies the administrative state of the inactive data compression scanner.
```

```
|mode
```

```
|string
```

```
a|Specifies the mode of inactive data compression scanner. Valid for PATCH and GET.
```

|operation\_state  
|string  
a|Specifies the operational state of the inactive data compression scanner. VALID for PATCH and GET. Valid options for PATCH are "idle" and "active".

|status  
|string  
a|Status of last inactive data compression scan on the volume.

|threshold\_inactive\_time  
|string  
a|Time interval after which inactive data compression will be triggered automatically. The value is in days and is represented in the ISO-8601 format as "P+++<num>+++D" , for example "P3D" represents a duration of 3 days.+++</num>+++

|===

[#iops]  
[.api-collapsible-fifth-title]  
iops

The rate of I/O operations observed at the storage object.

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|other

|integer

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

|read

|integer

a|Performance metric for read I/O operations.

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#latency]
[.api-collapsible-fifth-title]
latency
```

The round trip latency in microseconds observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.
```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]
```

```
[.api-collapsible-fifth-title]
```

```
cloud
```

Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|duration
```

```
|string
```

a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

```
|iops
```

```
|link:#iops[iops]
```

a|The rate of I/O operations observed at the storage object.

```
|latency
```

```
|link:#latency[latency]
```

a|The round trip latency in microseconds observed at the storage object.

```
|status
```

```
|string
```

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the

latest data.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#flexcache]
[.api-collapsible-fifth-title]
flexcache
```

Performance number for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|bandwidth_savings
|integer
```

a|Bandwidth savings denoting the amount of data served locally by the cache, in bytes.

```
|cache_miss_percent
|integer
```

a|Cache miss percentage.

```
|duration
|string
```

a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

```
|status
|string
```

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a

sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#throughput]
[.api-collapsible-fifth-title]
throughput
```

The rate of throughput bytes per second observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```



```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#metric]
[.api-collapsible-fifth-title]
metric
```

Performance numbers, such as IOPS, latency and throughput.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|cloud
|link:#cloud[cloud]
a|Performance numbers (IOPS and latency) for cloud store. These numbers
are relevant only for volumes hosted on FabricPools.
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations
are represented in the ISO-8601 standard format. Samples can be calculated
over the following durations:
```

```
|flexcache
|link:#flexcache[flexcache]
a|Performance number for FlexCache used to measure cache effectiveness.
```

```
|iops
|link:#iops[iops]
a|The rate of I/O operations observed at the storage object.
```

```
|latency
|link:#latency[latency]
a|The round trip latency in microseconds observed at the storage object.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
```

```
|throughput
|link:#throughput[throughput]
a|The rate of throughput bytes per second observed at the storage object.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
```

```
|Description

|cutover_window
|integer
a|Time window in seconds for cutover. The allowed range is between 30 to
300 seconds.

|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate

|percent_complete
|integer
a|Completion percentage

|start_time
|string
a|Start time of volume move.

|state
|string
a|State of volume move operation. PATCH the state to "aborted" to abort
the move operation. PATCH the state to "cutover" to trigger cutover. PATCH
the state to "paused" to pause the volume move operation in progress.
PATCH the state to "replicating" to resume the paused volume move
operation. PATCH the state to "cutover_wait" to go into cutover manually.
When volume move operation is waiting to go into "cutover" state, this is
indicated by the "cutover_pending" state. A change of state is only
supported if volume movement is in progress.

|tiering_policy
|string
a|Tiering policy for FabricPool

|===

[#export_policy]
[.api-collapsible-fifth-title]
export_policy
```

## Export Policy

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|id
```

```
|integer
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|===
```

```
[#junction_parent]
```

```
[.api-collapsible-fifth-title]
```

```
junction_parent
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|The name of the parent volume that contains the junction inode of this volume. The junction parent volume must belong to the same SVM that owns this volume.
```

```
|uuid
```

```
|string
```

a|Unique identifier for the parent volume.

|===

[#nas]

[.api-collapsible-fifth-title]

nas

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|export\_policy

|link:#export\_policy[export\_policy]

a|Export Policy

|gid

|integer

a|The UNIX group ID of the volume. Valid in POST or PATCH.

|junction\_parent

|link:#junction\_parent[junction\_parent]

a|

|path

|string

a|The fully-qualified path in the owning SVM's namespace at which the volume is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one volume can be mounted at any given junction path. An empty path in POST creates an unmounted volume. An empty path in PATCH deactivates and unmounts the volume. Taking a volume offline or restricted state removes its junction path. This attribute is reported in GET only when the volume is mounted.

|security\_style

|string

a|Security style associated with the volume. Valid in POST or PATCH.

mixed &dash; Mixed-style security

ntfs &dash; NTFS/Windows-style security

unified &dash; Unified-style security, unified UNIX, NFS and CIFS permissions  
unix &dash; Unix-style security.

|uid

|integer

a|The UNIX user ID of the volume. Valid in POST or PATCH.

|unix\_permissions

|integer

a|UNIX permissions to be viewed as an octal number. It consists of 4 digits derived by adding up bits 4 (read), 2 (write) and 1 (execute). First digit selects the set user ID(4), set group ID (2) and sticky (1) attributes. The second digit selects permission for the owner of the file; the third selects permissions for other users in the same group; the fourth for other users not in the group. Valid in POST or PATCH. For security style "mixed" or "unix", the default setting is 0755 in octal (493 in decimal) and for security style "ntfs", the default setting is 0000. In cases where only owner, group and other permissions are given (as in 755, representing the second, third and fourth digit), first digit is assumed to be zero.

|===

[#policy]

[.api-collapsible-fifth-title]

policy

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|max\_throughput\_iops

|integer

a|Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

|max\_throughput\_mbps  
|integer  
a|Specifies the maximum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

|min\_throughput\_iops  
|integer  
a|Specifies the minimum throughput in IOPS, 0 means none. Setting "min\_throughput" is supported on AFF platforms only, unless FabricPool tiering policies are set. This is mutually exclusive with name and UUID during POST and PATCH.

|min\_throughput\_mbps  
|integer  
a|Specifies the minimum throughput in Megabytes per sec, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

|name  
|string  
a|The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH.

|uuid  
|string  
a|The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH.

|===

[#qos]  
[.api-collapsible-fifth-title]  
qos

QoS information

[cols=3\*,options=header]

|===

|Name

|Type

```
|Description
```

```
|policy
```

```
|link:#policy[policy]
```

```
a|
```

```
|===
```

```
[#quota]
```

```
[.api-collapsible-fifth-title]
```

```
quota
```

Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|enabled
```

```
|boolean
```

a|This option is used to enable or disable the quota for the volume. This option is valid only in PATCH. Quotas are enabled for FlexVols or FlexGroup volumes when the quota state is "on". Quotas are disabled for FlexVols or FlexGroup volumes when the quota state is "off".

```
|state
```

```
|string
```

a|Quota state of the volume

```
|===
```

```
[#failure_reason]
```

```
[.api-collapsible-fifth-title]
```

```
failure_reason
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```



|Description

|code

|string

a|Error code of volume capacity rebalancing operation.

|message

|string

a|Details why the volume capacity rebalancing operation failed.

|===

[#rebalancing]

[.api-collapsible-fifth-title]

rebalancing

Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|data\_moved

|integer

a|The amount of data that has been moved in or out of a constituent. A positive value represents data moving into the constituent while a negative value is data moving out of the constituent.

|exclude\_snapshots

|boolean

a|Specifies whether or not to exclude files that are stuck in Snapshot copies during rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "exclude\_snapshots" value. Once the operation is started, any changes to the "exclude\_snapshots" value do not affect the currently running capacity

rebalancing operation. Only future capacity rebalancing operations will use the new "exclude\_snapshots" value.

|failure\_reason  
|link:#failure\_reason[failure\_reason]  
a|

|imbalance\_percent  
|integer  
a|Represents the percentage the volume is out of balance.

|imbalance\_size  
|integer  
a|Represents how much the volume is out of balance, in bytes.

|max\_constituent\_imbalance\_percent  
|integer  
a|Absolute percentage of the constituent that is most out of balance.

|max\_file\_moves  
|integer  
a|Specifies the maximum number of file moves in a volume capacity rebalancing operation on a constituent of the FlexGroup volume. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_file\_moves" value. Once the operation is started, any changes to the "max\_file\_moves" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_file\_moves" value.

|max\_runtime  
|string  
a|This optional field specifies the maximum time a capacity rebalancing operation runs for. Once the maximum runtime has passed, the capacity rebalancing operation stops. If it is not set, the default value is 6 hours. This value cannot be updated while a capacity rebalancing operation is running. The maximum runtime can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P3D" represents a duration of 3 days. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

|max\_threshold

|integer

a|Specifies the maximum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is larger than this value, files are moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_threshold" value. Once the operation is started, any changes to the "max\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_threshold" value.

|min\_file\_size

|integer

a|Specifies the minimum file size to consider for a volume capacity rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "min\_file\_size" value. Once the operation is started, any changes to the "min\_file\_size" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_file\_size" value. The value must be a multiple of 4KB. If it is not set, the default value will be 4KB.

|min\_threshold

|integer

a|Specifies the minimum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is smaller than this value, files are not moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it will use the current "min\_threshold" value. Once the operation is started, any changes to the "min\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_threshold" value.

|runtime

|string

a|Duration the capacity rebalancing operation has been running.

|start\_time

|string

a|Time when the current capacity rebalancing operation started.

```
|state
|string
a|State of volume capacity rebalancing operation. PATCH the state to
"starting" to trigger the capacity rebalance operation. PATCH the state to
"stopping" to stop the capacity rebalance operation.
```

```
|stop_time
|string
a|Time when the capacity rebalancing operation stopped.
```

```
|target_used
|integer
a|Represents the ideal used size of each constituent. Calculated by
dividing the total FlexGroup volume used size by the number of
constituents.
```

```
|===
```

```
[#retention]
[.api-collapsible-fifth-title]
retention
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|default
```

```
|string
```

```
a|Specifies the default retention period that is applied to files while
committing them to the WORM state without an associated retention period.
The retention value represents a duration and must be specified in the
ISO-8601 duration format. The retention period can be in years, months,
days, hours, and minutes. A duration specified for years, months, and days
is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M",
"P+++<num>+++D" respectively, for example "P10Y" represents a duration of
10 years. A duration in hours and minutes is represented by
"PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string
must contain only a single time element that is, either years, months,
days, hours, or minutes. A duration which combines different periods is
not supported, for example "P1Y10M" is not supported. Apart from the
```

duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period and the string "unspecified" to set an unspecified retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|maximum

|string

a|Specifies the maximum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|minimum

|string

a|Specifies the minimum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, month,s and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|===

```
[#snaplock]
```

```
[.api-collapsible-fifth-title]
```

```
snaplock
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|append_mode_enabled
```

```
|boolean
```

a|Specifies if the volume append mode is enabled or disabled. When it is enabled, all the files created with write permissions on the volume are, by default, WORM appendable files. The user can append the data to a WORM appendable file but cannot modify the existing contents of the file nor delete the file until it expires.

```
|autocommit_period
```

```
|string
```

a|Specifies the autocommit period for SnapLock volume. All files which are not modified for a period greater than the autocommit period of the volume are committed to the WORM state. The autocommit period value represents a duration and must be specified in the ISO-8601 duration format. The autocommit period can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The period string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the autocommit field also accepts the string "none".+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

```
|compliance_clock_time
```

```
|string
```

a|This is the volume compliance clock time which is used to manage the SnapLock objects in the volume.

```
|expiry_time
```

```
|string
```

a|Expiry time of the volume.

|is\_audit\_log

|boolean

a|Indicates if this volume has been configured as SnapLock audit log volume for the SVM .

|litigation\_count

|integer

a|Litigation count indicates the number of active legal-holds on the volume.

|privileged\_delete

|string

a|Specifies the privileged-delete attribute of a SnapLock volume. On a SnapLock Enterprise (SLE) volume, a designated privileged user can selectively delete files irrespective of the retention time of the file. SLE volumes can have privileged delete as disabled, enabled or permanently\_disabled and for SnapLock Compliance (SLC) volumes it is always permanently\_disabled.

|retention

|link:#retention[retention]

a|

|type

|string

a|The SnapLock type of the volume.

compliance &dash; A SnapLock Compliance(SLC) volume provides the highest level of WORM protection and an administrator cannot destroy a SLC volume if it contains unexpired WORM files.

enterprise &dash; An administrator can delete a SnapLock Enterprise(SLE) volume.

non\_snaplock &dash; Indicates the volume is non-snaplock.

|unspecified\_retention\_file\_count

|integer

a|Indicates the number of files with an unspecified retention time in the volume.

|===

```

[#destinations]
[.api-collapsible-fifth-title]
destinations

[cols=3*,options=header]
|===
|Name
|Type
|Description

|is_cloud
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data to a cloud destination.

|is_ontap
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data to an ONTAP destination.

* readOnly: 1
* Introduced in: 9.9

|===

[#snapmirror]
[.api-collapsible-fifth-title]
snapmirror

Specifies attributes for SnapMirror protection.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|destinations
|link:#destinations[destinations]
a|

```



```
|is_protected
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data.
```

```
|===
```

```
[#snapshot_policy]
[.api-collapsible-fifth-title]
snapshot_policy
```

This is a reference to the Snapshot copy policy.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

```
|===
```

```
[#logical_space]
[.api-collapsible-fifth-title]
logical_space
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|available
|integer
a|The amount of space available in this volume with storage efficiency
space considered used, in bytes.

|enforcement
|boolean
a|Specifies whether space accounting for operations on the volume is done
along with storage efficiency.

|reporting
|boolean
a|Specifies whether space reporting on the volume is done along with
storage efficiency.

|used
|integer
a|SUM of (physical-used, shared_refs, compression_saved_in_plane0,
vbn_zero, future_blk_cnt), in bytes.

|used_by_afs
|integer
a|The virtual space used by AFS alone (includes volume reserves) and along
with storage efficiency, in bytes.

|used_by_snapshots
|integer
a|Size that is logically used across all Snapshot copies in the volume, in
bytes.

|used_percent
|integer
a|SUM of (physical-used, shared_refs, compression_saved_in_plane0,
vbn_zero, future_blk_cnt), as a percentage.

|===

[#snapshot]
[.api-collapsible-fifth-title]
```

## snapshot

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|autodelete\_enabled

|boolean

a|Specifies whether Snapshot copy autodelete is currently enabled on this volume.

|autodelete\_trigger

|string

a|Specifies when the system should trigger an autodelete of Snapshot copies. When set to `_volume_`, autodelete is triggered based on volume fullness. When set to `_snap_reserve_`, autodelete is triggered based on Snapshot reserve fullness. The default value is `_volume_`.

|reserve\_available

|integer

a|Size available for Snapshot copies within the Snapshot copy reserve, in bytes.

|reserve\_percent

|integer

a|The space that has been set aside as a reserve for Snapshot copy usage, in percent.

|reserve\_size

|integer

a|Size in the volume that has been set aside as a reserve for Snapshot copy usage, in bytes.

|space\_used\_percent

|integer

a|Percentage of snapshot reserve size that has been used.

|used

|integer

a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|afs\_total

|integer

a|Total size of AFS, excluding snap-reserve, in bytes.

|auto\_adaptive\_compression\_footprint\_data\_reduction

|integer

a|Savings achieved due to Auto Adaptive Compression, in bytes.

|available

|integer

a|The available space, in bytes.

|available\_percent

|integer

a|The space available, as a percent.

|block\_storage\_inactive\_user\_data

|integer

a|The size that is physically used in the block storage of the volume and has a cold temperature. In bytes. This parameter is only supported if the volume is in an aggregate that is either attached to a cloud store or could be attached to a cloud store.

|block\_storage\_inactive\_user\_data\_percent

|integer

a|Percentage of size that is physically used in the performance tier of

the volume.

|capacity\_tier\_footprint

|integer

a|Space used by capacity tier for this volume in the FabricPool aggregate, in bytes.

|cross\_volume\_dedupe\_metafiles\_footprint

|integer

a|Cross volume deduplication metadata footprint, in bytes.

|cross\_volume\_dedupe\_metafiles\_temporary\_footprint

|integer

a|Cross volume temporary deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_footprint

|integer

a|Deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_temporary\_footprint

|integer

a|Temporary deduplication metadata footprint, in bytes.

|delayed\_free\_footprint

|integer

a|Delayed free blocks footprint, in bytes.

|effective\_total\_footprint

|integer

a|Volume footprint after efficiency savings, in bytes.

|expected\_available

|integer

a|Size that should be available for the volume, irrespective of available size in the aggregate, in bytes.

|file\_operation\_metadata

|integer

a|File operation metadata footprint, in bytes.

|filesystem\_size

|integer

a|Total usable size of the volume, in bytes.

|filesystem\_size\_fixed

|boolean

a|Specifies whether the file system is to remain of the same size when set to true or to grow when set to false. This option is automatically set to true when a volume becomes SnapMirrored.

|footprint

|integer

a|Data used for this volume in the aggregate, in bytes.

|fractional\_reserve

|integer

a|Used to change the amount of space reserved for overwrites of reserved objects in a volume.

|full\_threshold\_percent

|integer

a|Volume full threshold percentage at which EMS warnings can be sent.

|local\_tier\_footprint

|integer

a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical\_space

|link:#logical\_space[logical\_space]

a|

|metadata

|integer

a|Space used by the volume metadata in the aggregate, in bytes.

|nearly\_full\_threshold\_percent

|integer

a|Volume nearly full threshold percentage at which EMS warnings can be sent.

|over\_provisioned

|integer

a|The amount of space not available for this volume in the aggregate, in bytes.

|overwrite\_reserve

|integer

a|Reserved space for overwrites, in bytes.

|overwrite\_reserve\_used

|integer

a|Overwrite logical reserve space used, in bytes.

|percent\_used

|integer

a|Percentage of the volume size that is used.

|performance\_tier\_footprint

|integer

a|Space used by the performance tier for this volume in the FabricPool aggregate, in bytes.

|physical\_used

|integer

a|Size that is physically used in the volume, in bytes.

|physical\_used\_percent

|integer

a|Size that is physically used in the volume, as a percentage.

|size

|integer

a|Total provisioned size. The default size is equal to the minimum size of 20MB, in bytes.

```
|size_available_for_snapshots
|integer
a|Available space for Snapshot copies from snap-reserve, in bytes.

|snapmirror_destination_footprint
|integer
a|SnapMirror destination footprint, in bytes.

|snapshot
|link:#snapshot[snapshot]
a|

|snapshot_reserve_unusable
|integer
a|Snapshot reserve that is not available for Snapshot copy creation, in
bytes.

|snapshot_spill
|integer
a|Space used by the snapshot copies beyond the snap-reserve, in bytes.

|total_footprint
|integer
a|Data and metadata used for this volume in the aggregate, in bytes.

|used
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.

|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.

|user_data
|integer
a|User data, in bytes.

|volume_guarantee_footprint
```



```
|integer
a|Space reserved for future writes in the volume, in bytes.
```

```
|===
```

```
[#access]
[.api-collapsible-fifth-title]
access
```

Raw count and latency data for access operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#audit]
[.api-collapsible-fifth-title]
audit
```

Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#dir]
[.api-collapsible-fifth-title]
dir
```

Raw count and latency data for directory-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#file]  
[.api-collapsible-fifth-title]  
file
```

Raw count and latency data for file-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#other]  
[.api-collapsible-fifth-title]  
other
```

Raw count and latency data for create operations on objects other than files, directories and symlinks.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#symlink]
[.api-collapsible-fifth-title]
symlink
```

Raw count and latency data for symlink-create operations.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#create]
[.api-collapsible-fifth-title]
create
```

Raw count and latency data for create operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|dir
|link:#dir[dir]
a|Raw count and latency data for directory-create operations.
```

```
|file
|link:#file[file]
a|Raw count and latency data for file-create operations.
```

```
|other
|link:#other[other]
a|Raw count and latency data for create operations on objects other than
files, directories and symlinks.
```

```
|symlink
|link:#symlink[symlink]
a|Raw count and latency data for symlink-create operations.
```

```
|===
```

```
[#getattr]
[.api-collapsible-fifth-title]
getattr
```

Raw count and latency data for getattr operations.

```
[cols=3*,options=header]
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#link]
[.api-collapsible-fifth-title]
link
```

Raw count and latency data for link operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#lock]  
[.api-collapsible-fifth-title]  
lock
```

Raw count and latency data for lock operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#lookup]  
[.api-collapsible-fifth-title]  
lookup
```

Raw count and latency data for lookup operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#open]
[.api-collapsible-fifth-title]
open
```

Raw count and latency data for open operations.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```



```
[#read]
```

```
[.api-collapsible-fifth-title]
```

```
read
```

Raw count and latency data for read operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* readOnly: 1
```

```
* x-ntap-advanced: true
```

```
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
```

```
|array[string]
```

```
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_size_histogram_labels
```

```
|array[string]
```

```
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#readdir]  
[.api-collapsible-fifth-title]  
readdir
```

Raw count and latency data for readdir operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#readlink]  
[.api-collapsible-fifth-title]  
readlink
```

Raw count and latency data for readlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#rename]
[.api-collapsible-fifth-title]
rename
```

Raw count and latency data for rename operations.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#setattr]
[.api-collapsible-fifth-title]
setattr
```

Raw count and latency data for setattr operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#unlink]
[.api-collapsible-fifth-title]
unlink
```

Raw count and latency data for unlink operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#watch]
[.api-collapsible-fifth-title]
watch
```

Raw count and latency data for watch operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#write]
[.api-collapsible-fifth-title]
write
```

Raw count and latency data for write operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* readOnly: 1
```

```
* x-ntap-advanced: true
```

```
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
```

```
|array[string]
```

```
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_size_histogram_labels
```

```
|array[string]
```

```
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#cifs_ops_raw]
[.api-collapsible-fifth-title]
cifs_ops_raw
```

Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|access
```

```
|link:#access[access]
```

```
a|Raw count and latency data for access operations.
```

```
|audit
```

```
|link:#audit[audit]
```

```
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
```

```
|link:#create[create]
```

```
a|Raw count and latency data for create operations.
```

```
|getattr
```

```
|link:#getattr[getattr]
```

```
a|Raw count and latency data for getattr operations.
```

```
|link
```

```
|link:#link[link]
```

```
a|Raw count and latency data for link operations.
```

```
|lock
```

```
|link:#lock[lock]
```

```
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```



```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#iops_raw]
[.api-collapsible-fifth-title]
iops_raw
```

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
|integer
```

a|Performance metric for read I/O operations.

```
|total
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#latency_raw]
[.api-collapsible-fifth-title]
latency_raw
```

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#cloud]
```

```
[.api-collapsible-fifth-title]
```

```
cloud
```

These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase

with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|iops_raw
```

```
|link:#iops_raw[iops_raw]
```

a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
|latency_raw
```

```
|link:#latency_raw[latency_raw]
```

a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
|status
```

```
|string
```

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
```

```
|string
```

a|The timestamp of the performance data.

```
|===
```

```
[#flexcache_raw]
[.api-collapsible-fifth-title]
flexcache_raw
```

Performance numbers for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|cache_miss_blocks
|integer
a|Blocks retrieved from origin in case of a cache miss. This can be
divided by the raw client_requested_blocks and multiplied by 100 to
calculate the cache miss percentage.
```

```
|client_requested_blocks
|integer
a|Total blocks requested by the client.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#nfs_ops_raw]
[.api-collapsible-fifth-title]
nfs_ops_raw
```

Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|access
|link:#access[access]
a|Raw count and latency data for access operations.
```

```
|audit
|link:#audit[audit]
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
|link:#create[create]
a|Raw count and latency data for create operations.
```

```
|getattr
|link:#getattr[getattr]
a|Raw count and latency data for getattr operations.
```

```
|link
|link:#link[link]
a|Raw count and latency data for link operations.
```

```
|lock
|link:#lock[lock]
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#throughput_raw]
[.api-collapsible-fifth-title]
throughput_raw
```

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#statistics]
[.api-collapsible-fifth-title]
statistics
```

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cifs_ops_raw
```

```
|link:#cifs_ops_raw[cifs_ops_raw]
```

a|Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
|cloud
```

```
|link:#cloud[cloud]
```

a|These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
|flexcache_raw
```

```
|link:#flexcache_raw[flexcache_raw]
```

a|Performance numbers for FlexCache used to measure cache effectiveness.

```
|iops_raw
```

```
|link:#iops_raw[iops_raw]
```

a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
|latency_raw
```

```
|link:#latency_raw[latency_raw]
```



a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

|nfs\_ops\_raw

|link:#nfs\_ops\_raw[nfs\_ops\_raw]

a|Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

|status

|string

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|throughput\_raw

|link:#throughput\_raw[throughput\_raw]

a|Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

|timestamp

|string

a|The timestamp of the performance data.

|===

[#svm]

[.api-collapsible-fifth-title]

svm

SVM containing the volume. Required on POST.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|The name of the SVM.
```

```
|uuid
```

```
|string
```

```
a|The unique identifier of the SVM.
```

```
|===
```

```
[#tiering]
```

```
[.api-collapsible-fifth-title]
```

```
tiering
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|min_cooling_days
```

```
|integer
```

```
a|This parameter specifies the minimum number of days that user data blocks of the volume must be cooled before they can be considered cold and tiered out to the cloud tier. Note that this parameter is only used for tiering purposes and does not affect the reporting of inactive data. The value specified should be greater than the frequency with which applications in the volume shift between different sets of data. This parameter cannot be set when volume tiering policy is either "none" or "all". The default value of this parameter depends on the volume's tiering policy. See the tiering policy section of this documentation for
```

corresponding default values. If the tiering policy on the volume gets changed, then this parameter will be reset to the default value corresponding to the new tiering policy.

|object\_tags

|array[string]

a|This parameter specifies tags of a volume for objects stored on a FabricPool-enabled aggregate. Each tag is a key,value pair and should be in the format "key=value".

|policy

|string

a|Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold. FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH. all &dash; This policy allows tiering of both Snapshot copies and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.

auto &dash; This policy allows tiering of both snapshot and active file system user data to the cloud store

none &dash; Volume blocks will not be tiered to the cloud store.

snapshot\_only &dash; This policy allows tiering of only the volume Snapshot copies not associated with the active file system. The default tiering policy is "snapshot-only" for a FlexVol and "none" for a FlexGroup. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy is 31 days.

|supported

|boolean

a|This parameter specifies whether or not FabricPools are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only FabricPool aggregates are used if this parameter is set to true and only non FabricPool aggregates are used if this parameter is set to false. Tiering support for a FlexGroup can be changed by moving all of the constituents to the required aggregates. Note that in order to tier data, not only does the volume need to support tiering by using FabricPools, the tiering "policy" must not be 'none'. A volume that uses FabricPools but has a tiering "policy" of 'none' supports tiering, but will not tier any data.

```

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|access_time_enabled
|boolean
a|Indicates whether or not access time updates are enabled on the volume.

|activity_tracking
|link:#activity_tracking[activity_tracking]
a|

|aggregates
|array[link:#aggregates[aggregates]]
a|Aggregate hosting the volume. Required on POST.

|analytics
|link:#analytics[analytics]
a|

|anti_ransomware
|link:#anti_ransomware[anti_ransomware]
a|Anti-ransomware related information of the volume.

|anti_ransomware_state
|string
a|The Anti-ransomware state of the volume. If no "anti_ransomware_state"
property is specified, the volume inherits the value from its parent SVM's
"anti_ransomware_default_volume_state" property. If this value is
"disabled", Anti-ransomware is disabled on the volume. If this value is
"enabled", Anti-ransomware is enabled on the volume and alerts are raised

```

if any suspect is detected for those volumes. If this value is "dry\_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry\_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable\_in\_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable\_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry\_run\_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry\_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry\_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.

```
|application
|link:#application[application]
a|
```

```
|asynchronous_directory_delete
|link:#asynchronous_directory_delete[asynchronous_directory_delete]
a|Configuration for asynchronous directory delete from the client. This is
only supported on Flexible volumes and FlexGroup volumes.
```

```
|autosize
|link:#autosize[autosize]
a|
```

```
|clone
|link:#clone[clone]
a|
```

```
|cloud_retrieval_policy
|string
a|This parameter specifies the cloud retrieval policy for the volume. This
policy determines which tiered out blocks to retrieve from the capacity
tier to the performance tier. The available cloud retrieval policies are
"default" policy retrieves tiered data based on the underlying tiering
policy. If the tiering policy is 'auto', tiered data is retrieved only for
random client driven data reads. If the tiering policy is 'none' or
'snapshot_only', tiered data is retrieved for random and sequential client
driven data reads. If the tiering policy is 'all', tiered data is not
retrieved.
"on_read" policy retrieves tiered data for all client driven data reads.
```

"never" policy never retrieves tiered data.

"promote" policy retrieves all eligible tiered data automatically during the next scheduled scan. It is only supported when the tiering policy is 'none' or 'snapshot\_only'. If the tiering policy is 'snapshot\_only', the only data brought back is the data in the AFS. Data that is only in a snapshot copy stays in the cloud and if tiering policy is 'none' then all data is retrieved.

|comment

|string

a|A comment for the volume. Valid in POST or PATCH.

|consistency\_group

|link:#consistency\_group[consistency\_group]

a|Consistency group the volume is part of.

|constituents

|array[link:#constituents[constituents]]

a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more efficiently by specifying "is\_constituent=true" or "is\_constituent=true&flexgroup.uuid=+++<flexgroup.uuid>+++" as query parameters.+++</flexgroup.uuid>+++

|constituents\_per\_aggregate

|integer

a|Specifies the number of times to iterate over the aggregates listed with the "aggregates.name" or "aggregates.uuid" when creating or expanding a FlexGroup volume. If a volume is being created on a single aggregate, the system creates a flexible volume if the "constituents\_per\_aggregate" field is not specified, or a FlexGroup volume if it is specified. If a volume is being created on multiple aggregates, the system always creates a FlexGroup volume. The root constituent of a FlexGroup volume is always placed on the first aggregate in the list.

|convert\_unicode

|boolean

a|Specifies whether directory Unicode format conversion is enabled when directories are accessed by NFS clients.

|create\_time

|string

a|Creation time of the volume. This field is generated when the volume is created.

|efficiency  
|link:#efficiency[efficiency]  
a|

|encryption  
|link:#encryption[encryption]  
a|

|error\_state  
|link:#error\_state[error\_state]  
a|

|files  
|link:#files[files]  
a|

|flash\_pool  
|link:#flash\_pool[flash\_pool]  
a|

|flexcache\_endpoint\_type  
|string  
a|FlexCache endpoint type.  
none &dash; The volume is neither a FlexCache nor origin of any FlexCache.  
cache &dash; The volume is a FlexCache volume.  
origin &dash; The volume is origin of a FlexCache volume.

|flexgroup  
|link:#flexgroup[flexgroup]  
a|

|granular\_data  
|boolean  
a|State of granular data on the volume. This setting is true by default when creating a new FlexGroup volume, but can be specified as false at the time of creation via a POST request. On FlexVol volumes, the setting is always false, as only FlexGroup volumes and FlexGroup constituents support this feature. Once enabled, this setting can only be disabled by restoring a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible with this feature. Therefore, reverting to an earlier version of ONTAP is not possible unless this volume is deleted or restored to a Snapshot copy that was taken before the setting was enabled.

\* Introduced in: 9.11

|guarantee

|link:#guarantee[guarantee]

a|

|idcs\_scanner

|link:#idcs\_scanner[idcs\_scanner]

a|Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

|is\_object\_store

|boolean

a|Specifies whether the volume is provisioned for an object store server.

|is\_svm\_root

|boolean

a|Specifies whether the volume is a root volume of the SVM it belongs to.

|language

|string

a|Language encoding setting for volume. If no language is specified, the volume inherits its SVM language encoding setting.

|max\_dir\_size

|integer

a|Maximum directory size. This value sets maximum size, in bytes, to which a directory can grow. The default maximum directory size for FlexVol volumes is model-dependent, and optimized for the size of system memory. Before increasing the maximum directory size, involve technical support.

|metric

|link:#metric[metric]

a|Performance numbers, such as IOPS, latency and throughput.

|movement



|link:#movement[movement]

a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|msid

|integer

a|The volume's Mirror Set ID.

|name

|string

a|Volume name. The name of volume must start with an alphabetic character (a to z or A to Z) or an underscore (\_). The name must be 197 or fewer characters in length for FlexGroups, and 203 or fewer characters in length for all other types of volumes. Volume names must be unique within an SVM. Required on POST.

|nas

|link:#nas[nas]

a|

|qos

|link:#qos[qos]

a|QoS information

|queue\_for\_encryption

|boolean

a|Specifies whether the volume is queued for encryption.

|quota

|link:#quota[quota]

a|Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

|rebalancing

|link:#rebalancing[rebalancing]

a|Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

```

|scheduled_snapshot_naming_scheme
|string
a|Naming Scheme for automatic Snapshot copies:

* create_time - Automatic Snapshot copies are saved as per the start of
their current date and time.
* ordinal - Latest automatic snapshot copy is saved as
+++<scheduled_frequency>+++0 and subsequent copies will follow the
create_time naming convention.+++</scheduled_frequency>+++

|size
|integer
a|Physical size of the volume, in bytes. The minimum size for a FlexVol
volume is 20MB and the minimum size for a FlexGroup volume is 200MB per
constituent. The recommended size for a FlexGroup volume is a minimum of
100GB per constituent. For all volumes, the default size is equal to the
minimum size.

|snaplock
|link:#snaplock[snaplock]
a|

|snapmirror
|link:#snapmirror[snapmirror]
a|Specifies attributes for SnapMirror protection.

|snapshot_count
|integer
a|Number of Snapshot copies in the volume.

|snapshot_policy
|link:#snapshot_policy[snapshot_policy]
a|This is a reference to the Snapshot copy policy.

|space
|link:#space[space]
a|

|state
|string
a|Volume state. Client access is supported only when volume is online and
junctioned. Taking volume to offline or restricted state removes its

```

junction path and blocks client access. When volume is in restricted state some operations like parity reconstruction and iron on commit are allowed. The 'mixed' state applies to FlexGroup volumes only and cannot be specified as a target state. An 'error' state implies that the volume is not in a state to serve data.

|statistics

|link:#statistics[statistics]

a|These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

|status

|array[string]

a|Describes the current status of a volume.

|style

|string

a|The style of the volume. If "style" is not specified, the volume type is determined based on the specified aggregates. Specifying a single aggregate, without "constituents\_per\_aggregate", creates a flexible volume. Specifying multiple aggregates, or a single aggregate with "constituents\_per\_aggregate", creates a FlexGroup. Specifying a volume "style" creates a volume of that type. For example, if the style is "flexvol" you must specify a single aggregate. If the style is "flexgroup", the system either uses the specified aggregates or automatically provisions aggregates if there are no specified aggregates. The style "flexgroup\_constituent" is not supported when creating a volume.  
flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm

|link:#svm[svm]

a|SVM containing the volume. Required on POST.

|tiering

|link:#tiering[tiering]

a|

|type

|string

a|Type of the volume.  
rw &dash; read-write volume.  
dp &dash; data-protection volume.  
ls &dash; load-sharing `dp` volume. Valid in GET.

|use\_mirrored\_aggregates

|boolean

a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.

|uuid

|string

a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7

\* readOnly: 1

\* Introduced in: 9.6

|===

[#job\_link]

[.api-collapsible-fifth-title]

job\_link

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|uuid

```

|string
a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or
DELETE operation.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code

```

```

|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

[[ID7ae8732ccaf9c12ca32ef293ffed00a2]]
= Delete a volume

[.api-doc-operation .api-doc-operation-delete]#DELETE# [.api-doc-code-
block]#`/storage/volumes/{uuid}`#

*Introduced In:* 9.6

Deletes a volume. If the UUID belongs to a volume, all of its blocks are
freed and returned to its containing aggregate. If a volume is online, it
is offlined before deletion. If a volume is mounted, unmount the volume by
specifying the nas.path as empty before deleting it using the DELETE
operation.

== Related ONTAP commands

* `volume delete`
* `volume clone delete`

== Parameters

[cols=5*,options=header]
|===

```

```
|Name
|Type
|In
|Required
|Description
```

```
|uuid
|string
|path
|True
a|Unique identifier of the volume.
```

```
|return_timeout
|integer
|query
|False
```

a|The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|===
```

```
== Response
```

Status: 202, Accepted

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===

.Example response
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
=====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

```



```
.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====
```

== Definitions

```
[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
```

```
[#href]
[.api-collapsible-fifth-title]
href
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|href
|string
a|
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#job_link]
[.api-collapsible-fifth-title]
job_link

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|uuid
|string
a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or
DELETE operation.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code

```

```

|string
a|Argument code

|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
=====

```

```
[[ID39df7eb03aa65ddca22492676520263e]]
```

```
= Retrieve a volume
```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volumes/{uuid}`#
```

```
*Introduced In:* 9.6
```

Retrieves a volume. The GET API can be used to retrieve the quota state for a FlexVol or a FlexGroup volume.

```
== Expensive properties
```

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [xref:{relative\\_path}getting\\_started\\_with\\_the\\_ontap\\_rest\\_api.html#Requesting\\_specific\\_fields\[Requesting specific fields\]](#) to learn more.

```
* `is_svm_root`  
* `analytics.+++`  
* `anti_ransomware.+++`  
* `application.+++`  
* `encryption.+++`  
* `convert_unicode`  
* `clone.parent_snapshot.name`  
* `clone.parent_snapshot.uuid`  
* `clone.parent_svm.name`  
* `clone.parent_svm.uuid`  
* `clone.parent_volume.name`  
* `clone.parent_volume.uuid`  
* `clone.split_complete_percent`  
* `clone.split_estimate`  
* `clone.split_initiated`  
* `efficiency.+++`  
* `error_state.+++`  
* `files.+++`  
* `max_dir_size`  
* `nas.export_policy.id`  
* `nas.gid`  
* `nas.path`  
* `nas.security_style`  
* `nas.uid`
```

```
* `nas.unix_permissions`
* `nas.junction_parent.name`
* `nas.junction_parent.uuid`
* `snaplock.+++`
* `restore_to.+++`
* `snapshot_policy.uuid`
* `quota.+++`
* `qos.+++`
* `flexcache_endpoint_type`
* `space.block_storage_inactive_user_data`
* `space.capacity_tier_footprint`
* `space.performance_tier_footprint`
* `space.local_tier_footprint`
* `space.footprint`
* `space.over_provisioned`
* `space.metadata`
* `space.total_footprint`
* `space.dedupe_metafiles_footprint`
* `space.dedupe_metafiles_temporary_footprint`
* `space.delayed_free_footprint`
* `space.file_operation_metadata`
* `space.snapmirror_destination_footprint`
* `space.volume_guarantee_footprint`
* `space.cross_volume_dedupe_metafiles_footprint`
* `space.cross_volume_dedupe_metafiles_temporary_footprint`
* `space.auto_adaptive_compression_footprint_data_reduction`
* `space.effective_total_footprint`
* `space.snapshot_reserve_unusable`
* `space.snapshot_spill`
* `space.user_data`
* `space.logical_space.+++`
* `space.snapshot.+++`
* `space.used_by_afs`
* `space.afs_total`
* `space.available_percent`
* `space.full_threshold_percent`
* `space.nearly_full_threshold_percent`
* `space.overwrite_reserve`
* `space.overwrite_reserve_used`
* `space.size_available_for_snapshots`
* `space.percent_used`
* `space.fractional_reserve`
* `space.block_storage_inactive_user_data_percent`
* `space.physical_used`
* `space.physical_used_percent`
* `space.expected_available`
```

```
* `space.filesystem_size`  
* `space.filesystem_size_fixed`  
* `guarantee.+++`  
* `autosize.+++`  
* `movement.+++`  
* `statistics.+++`  
* `asynchronous_directory_delete.+++`
```

== Related ONTAP commands

```
* `volume show`  
* `volume clone show`  
* `volume efficiency show`  
* `volume encryption show`  
* `volume flexcache show`  
* `volume flexgroup show`  
* `volume move show`  
* `volume quota show`  
* `volume show-space`  
* `volume snaplock show`  
* `security anti-ransomware volume show`  
* `security anti-ransomware volume attack generate-report`  
* `security anti-ransomware volume space show`  
* `volume file async-delete client show`
```

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Unique identifier of the volume.
```

```
|is_constituent
```

```
|boolean
```

```
|query
|False
a|When set to false, only FlexVol and FlexGroup volumes are returned.
When set to true, only FlexGroup constituent volumes are returned. Default
for GET calls is false.

* Introduced in: 9.10
* Default value:

|fields
|array[string]
|query
|False
a|Specify the fields to return.

|===
```

== Response

Status: 200, Ok

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|access_time_enabled
|boolean
a|Indicates whether or not access time updates are enabled on the volume.

|activity_tracking
|link:#activity_tracking[activity_tracking]
a|

|aggregates
|array[link:#aggregates[aggregates]]
a|Aggregate hosting the volume. Required on POST.
```

```
|analytics
|link:#analytics[analytics]
a|
```

```
|anti_ransomware
|link:#anti_ransomware[anti_ransomware]
a|Anti-ransomware related information of the volume.
```

```
|anti_ransomware_state
|string
a|The Anti-ransomware state of the volume. If no "anti_ransomware_state" property is specified, the volume inherits the value from its parent SVM's "anti_ransomware_default_volume_state" property. If this value is "disabled", Anti-ransomware is disabled on the volume. If this value is "enabled", Anti-ransomware is enabled on the volume and alerts are raised if any suspect is detected for those volumes. If this value is "dry_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable_in_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry_run_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.
```

```
|application
|link:#application[application]
a|
```

```
|asynchronous_directory_delete
|link:#asynchronous_directory_delete[asynchronous_directory_delete]
a|Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.
```

```
|autosize
|link:#autosize[autosize]
a|
```



```
|clone
|link:#clone[clone]
a|

|cloud_retrieval_policy
|string
a|This parameter specifies the cloud retrieval policy for the volume. This
policy determines which tiered out blocks to retrieve from the capacity
tier to the performance tier. The available cloud retrieval policies are
"default" policy retrieves tiered data based on the underlying tiering
policy. If the tiering policy is 'auto', tiered data is retrieved only for
random client driven data reads. If the tiering policy is 'none' or
'snapshot_only', tiered data is retrieved for random and sequential client
driven data reads. If the tiering policy is 'all', tiered data is not
retrieved.
"on_read" policy retrieves tiered data for all client driven data reads.
"never" policy never retrieves tiered data.
"promote" policy retrieves all eligible tiered data automatically during
the next scheduled scan. It is only supported when the tiering policy is
'none' or 'snapshot_only'. If the tiering policy is 'snapshot_only', the
only data brought back is the data in the AFS. Data that is only in a
snapshot copy stays in the cloud and if tiering policy is 'none' then all
data is retrieved.

|comment
|string
a|A comment for the volume. Valid in POST or PATCH.

|consistency_group
|link:#consistency_group[consistency_group]
a|Consistency group the volume is part of.

|constituents
|array[link:#constituents[constituents]]
a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more
efficiently by specifying "is_constituent=true" or
"is_constituent=true&flexgroup.uid=+++<flexgroup.uid>+++> as query
parameters.+++</flexgroup.uid>+++

|constituents_per_aggregate
|integer
a|Specifies the number of times to iterate over the aggregates listed with
```

the "aggregates.name" or "aggregates.uuid" when creating or expanding a FlexGroup volume. If a volume is being created on a single aggregate, the system creates a flexible volume if the "constituents\_per\_aggregate" field is not specified, or a FlexGroup volume if it is specified. If a volume is being created on multiple aggregates, the system always creates a FlexGroup volume. The root constituent of a FlexGroup volume is always placed on the first aggregate in the list.

|convert\_unicode

|boolean

a|Specifies whether directory Unicode format conversion is enabled when directories are accessed by NFS clients.

|create\_time

|string

a|Creation time of the volume. This field is generated when the volume is created.

|efficiency

|link:#efficiency[efficiency]

a|

|encryption

|link:#encryption[encryption]

a|

|error\_state

|link:#error\_state[error\_state]

a|

|files

|link:#files[files]

a|

|flash\_pool

|link:#flash\_pool[flash\_pool]

a|

|flexcache\_endpoint\_type

|string

a|FlexCache endpoint type.

none &dash; The volume is neither a FlexCache nor origin of any FlexCache.  
cache &dash; The volume is a FlexCache volume.

origin &dash; The volume is origin of a FlexCache volume.

```
|flexgroup
|link:#flexgroup[flexgroup]
a|
```

```
|granular_data
|boolean
a|State of granular data on the volume. This setting is true by default when creating a new FlexGroup volume, but can be specified as false at the time of creation via a POST request. On FlexVol volumes, the setting is always false, as only FlexGroup volumes and FlexGroup constituents support this feature. Once enabled, this setting can only be disabled by restoring a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible with this feature. Therefore, reverting to an earlier version of ONTAP is not possible unless this volume is deleted or restored to a Snapshot copy that was taken before the setting was enabled.
```

\* Introduced in: 9.11

```
|guarantee
|link:#guarantee[guarantee]
a|
```

```
|idcs_scanner
|link:#idcs_scanner[idcs_scanner]
a|Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(threshold_inactive_days). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op_state' that is valid for PATCH and GET, and is used to start/stop the scanner.
```

```
|is_object_store
|boolean
a|Specifies whether the volume is provisioned for an object store server.
```

```
|is_svm_root
|boolean
a|Specifies whether the volume is a root volume of the SVM it belongs to.
```

```
|language
|string
a|Language encoding setting for volume. If no language is specified, the
```

volume inherits its SVM language encoding setting.

|max\_dir\_size

|integer

a|Maximum directory size. This value sets maximum size, in bytes, to which a directory can grow. The default maximum directory size for FlexVol volumes is model-dependent, and optimized for the size of system memory. Before increasing the maximum directory size, involve technical support.

|metric

|link:#metric[metric]

a|Performance numbers, such as IOPS, latency and throughput.

|movement

|link:#movement[movement]

a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|msid

|integer

a|The volume's Mirror Set ID.

|name

|string

a|Volume name. The name of volume must start with an alphabetic character (a to z or A to Z) or an underscore (\_). The name must be 197 or fewer characters in length for FlexGroups, and 203 or fewer characters in length for all other types of volumes. Volume names must be unique within an SVM. Required on POST.

|nas

|link:#nas[nas]

a|

|qos

|link:#qos[qos]

a|QoS information

|queue\_for\_encryption  
|boolean  
a|Specifies whether the volume is queued for encryption.

|quota  
|link:#quota[quota]  
a|Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

|rebalancing  
|link:#rebalancing[rebalancing]  
a|Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

|scheduled\_snapshot\_naming\_scheme  
|string  
a|Naming Scheme for automatic Snapshot copies:

- \* create\_time - Automatic Snapshot copies are saved as per the start of their current date and time.
- \* ordinal - Latest automatic snapshot copy is saved as +++<scheduled\_frequency>+++0 and subsequent copies will follow the create\_time naming convention.+++</scheduled\_frequency>+++

|size  
|integer  
a|Physical size of the volume, in bytes. The minimum size for a FlexVol volume is 20MB and the minimum size for a FlexGroup volume is 200MB per constituent. The recommended size for a FlexGroup volume is a minimum of 100GB per constituent. For all volumes, the default size is equal to the minimum size.

|snaplock  
|link:#snaplock[snaplock]  
a|

|snapmirror  
|link:#snapmirror[snapmirror]  
a|Specifies attributes for SnapMirror protection.

|snapshot\_count

```
|integer
a|Number of Snapshot copies in the volume.

|snapshot_policy
|link:#snapshot_policy[snapshot_policy]
a|This is a reference to the Snapshot copy policy.

|space
|link:#space[space]
a|

|state
|string
a|Volume state. Client access is supported only when volume is online and
junctioned. Taking volume to offline or restricted state removes its
junction path and blocks client access. When volume is in restricted state
some operations like parity reconstruction and iron on commit are allowed.
The 'mixed' state applies to FlexGroup volumes only and cannot be
specified as a target state. An 'error' state implies that the volume is
not in a state to serve data.

|statistics
|link:#statistics[statistics]
a|These are raw performance numbers, such as IOPS latency and throughput.
These numbers are aggregated across all nodes in the cluster and increase
with the uptime of the cluster.

|status
|array[string]
a|Describes the current status of a volume.

|style
|string
a|The style of the volume. If "style" is not specified, the volume type is
determined based on the specified aggregates. Specifying a single
aggregate, without "constituents_per_aggregate", creates a flexible
volume. Specifying multiple aggregates, or a single aggregate with
"constituents_per_aggregate", creates a FlexGroup. Specifying a volume
"style" creates a volume of that type. For example, if the style is
"flexvol" you must specify a single aggregate. If the style is
"flexgroup", the system either uses the specified aggregates or
automatically provisions aggregates if there are no specified aggregates.
```

The style "flexgroup\_constituent" is not supported when creating a volume.  
flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm  
|link:#svm[svm]  
a|SVM containing the volume. Required on POST.

|tiering  
|link:#tiering[tiering]  
a|

|type  
|string  
a|Type of the volume.  
rw &dash; read-write volume.  
dp &dash; data-protection volume.  
ls &dash; load-sharing `dp` volume. Valid in GET.

|use\_mirrored\_aggregates  
|boolean  
a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.

|uuid  
|string  
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7  
\* readOnly: 1  
\* Introduced in: 9.6

|===

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "activity_tracking": {
    "state": "off",
    "unsupported_reason": {
      "code": "124518405",
      "message": "Volume activity tracking cannot be enabled on volumes
that contain LUNs."
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "analytics": {
    "scan_progress": 17,
    "state": "unknown",
    "unsupported_reason": {
      "code": "111411207",
      "message": "File system analytics cannot be enabled on volumes that
contain LUNs."
    }
  },
  "anti_ransomware": {
    "attack_probability": "none",
    "attack_reports": {
      "_links": {
        "suspects": {
          "href": "/api/resourcelink"
        }
      }
    }
  },
}
```



```
    "time": "2021-06-01T20:36:41+05:30"
  },
  "dry_run_start_time": "string",
  "space": {
    "snapshot_count": 0,
    "used": 0,
    "used_by_logs": 0,
    "used_by_snapshots": 0
  },
  "state": "disabled",
  "suspect_files": {
    "count": 0,
    "entropy": "string",
    "format": "string"
  }
},
"anti_ransomware_state": "disabled",
"application": {
  "name": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"autosize": {
  "mode": "grow"
},
"clone": {
  "parent_snapshot": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "this_snapshot",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "parent_svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "parent_volume": {
    "_links": {
      "self": {
```

```

        "href": "/api/resourcelink"
    }
},
"name": "volume1",
"uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
},
"split_complete_percent": 0,
"split_estimate": 0
},
"cloud_retrieval_policy": "default",
"comment": "string",
"consistency_group": {
    "name": "consistency_group_1",
    "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"constituents": {
    "aggregates": {
        "name": "string",
        "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    },
    "movement": {
        "cutover_window": 30,
        "destination_aggregate": {
            "_links": {
                "self": {
                    "href": "/api/resourcelink"
                }
            },
            "name": "aggr1",
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "percent_complete": 0,
        "state": "replicating",
        "tiering_policy": "all"
    },
    "name": "string",
    "space": {
        "available": 0,
        "block_storage_inactive_user_data": 0,
        "capacity_tier_footprint": 0,
        "footprint": 0,
        "local_tier_footprint": 0,
        "logical_space": {
            "available": 0,
            "used_by_afs": 0
        }
    },

```

```
    "metadata": 0,
    "over_provisioned": 0,
    "performance_tier_footprint": 0,
    "snapshot": {
      "used": 0
    },
    "total_footprint": 0,
    "used": 0
  }
},
"create_time": "2018-06-04T19:00:00Z",
"efficiency": {
  "application_io_size": "8k",
  "compaction": "inline",
  "compression": "inline",
  "compression_type": "none",
  "cross_volume_dedupe": "inline",
  "dedupe": "inline",
  "last_op_begin": "string",
  "last_op_end": "string",
  "last_op_err": "string",
  "last_op_size": 0,
  "last_op_state": "string",
  "op_state": "idle",
  "path": "string",
  "progress": "string",
  "scanner": {
    "state": "idle"
  },
  "schedule": "string",
  "space_savings": {
    "compression": 0,
    "compression_percent": 0,
    "dedupe": 0,
    "dedupe_percent": 0,
    "dedupe_sharing": 0,
    "total": 0,
    "total_percent": 0
  },
  "state": "disabled",
  "storage_efficiency_mode": "default",
  "type": "regular"
},
"encryption": {
  "key_create_time": "2022-01-01T19:00:00Z",
  "key_id": "string",
```

```
  "key_manager_attribute": "CRN=v1:bluemix:public:containers-
kubernetes:us-south:a/asdfghjkl1234:asdfghjkl1234:worker:kubernetes-
asdfghjkl-worker1",
  "state": "encrypted",
  "status": {
    "code": "string",
    "message": "string"
  },
  "type": "none"
},
"files": {
  "used": 0
},
"flash_pool": {
  "cache_eligibility": "read",
  "cache_retention_priority": "normal",
  "caching_policy": "none"
},
"flexcache_endpoint_type": "none",
"flexgroup": {
  "name": "my_flexgroup",
  "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
},
"guarantee": {
  "type": "volume"
},
"idcs_scanner": {
  "mode": "default",
  "operation_state": "idle",
  "status": "success"
},
"language": "ar",
"metric": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"cloud": {
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
```

```
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "timestamp": "2017-01-25T11:20:13Z"
},
"duration": "PT15S",
"flexcache": {
  "bandwidth_savings": 4096,
  "cache_miss_percent": 20,
  "duration": "PT1D",
  "status": "ok",
  "timestamp": "2017-01-25T11:20:13Z"
},
"iops": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"latency": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"status": "ok",
"throughput": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},
"movement": {
  "cutover_window": 30,
  "destination_aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "percent_complete": 0,
  "start_time": "2020-12-07T03:45:12-05:00",
```

```

    "state": "replicating",
    "tiering_policy": "all"
  },
  "name": "vol_cs_dept",
  "nas": {
    "export_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 100,
      "name": "default"
    },
    "junction_parent": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "vsl_root",
      "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
    },
    "path": "/user/my_volume",
    "security_style": "mixed",
    "unix_permissions": 755
  },
  "qos": {
    "policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "max_throughput_iops": 10000,
      "max_throughput_mbps": 500,
      "min_throughput_iops": 2000,
      "min_throughput_mbps": 500,
      "name": "performance",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "quota": {
    "state": "corrupt"
  },
  "rebalancing": {

```

```

    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "data_moved": 0,
    "failure_reason": {
      "code": "string",
      "message": "string"
    },
    "imbalance_percent": 0,
    "imbalance_size": 0,
    "max_constituent_imbalance_percent": 0,
    "runtime": "string",
    "start_time": "string",
    "state": "rebalancing",
    "stop_time": "string",
    "target_used": 0
  },
  "scheduled_snapshot_naming_scheme": "create_time",
  "snaplock": {
    "append_mode_enabled": "",
    "autocommit_period": "P30M",
    "compliance_clock_time": "2018-06-04T19:00:00Z",
    "expiry_time": "Wed Sep 5 11:02:42 GMT 2018",
    "is_audit_log": 1,
    "litigation_count": 10,
    "privileged_delete": "enabled",
    "retention": {
      "default": "P30Y",
      "maximum": "P30Y",
      "minimum": "P30Y"
    },
    "type": "enterprise",
    "unspecified_retention_file_count": 10
  },
  "snapshot_count": 0,
  "snapshot_policy": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },

```

```

"space": {
  "auto_adaptive_compression_footprint_data_reduction": 0,
  "available": 0,
  "block_storage_inactive_user_data": 0,
  "block_storage_inactive_user_data_percent": 0,
  "capacity_tier_footprint": 0,
  "cross_volume_dedupe_metafiles_footprint": 0,
  "cross_volume_dedupe_metafiles_temporary_footprint": 0,
  "dedupe_metafiles_footprint": 0,
  "dedupe_metafiles_temporary_footprint": 0,
  "delayed_free_footprint": 0,
  "effective_total_footprint": 0,
  "file_operation_metadata": 0,
  "filesystem_size": 0,
  "footprint": 0,
  "local_tier_footprint": 0,
  "logical_space": {
    "available": 0,
    "used": 0,
    "used_by_afs": 0,
    "used_by_snapshots": 0,
    "used_percent": 0
  },
  "metadata": 0,
  "over_provisioned": 0,
  "overwrite_reserve": 0,
  "overwrite_reserve_used": 0,
  "percent_used": 0,
  "performance_tier_footprint": 0,
  "size_available_for_snapshots": 0,
  "snapmirror_destination_footprint": 0,
  "snapshot": {
    "autodelete_trigger": "volume",
    "reserve_available": 0,
    "reserve_size": 0,
    "space_used_percent": 0,
    "used": 0
  },
  "snapshot_reserve_unusable": 0,
  "snapshot_spill": 0,
  "total_footprint": 0,
  "used": 0,
  "user_data": 0,
  "volume_guarantee_footprint": 0
},
"state": "error",

```



```
"statistics": {
  "cifs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
      "file": {
        "count": 1000,
        "total_time": 200
      },
      "other": {
        "count": 1000,
        "total_time": 200
      },
      "symlink": {
        "count": 1000,
        "total_time": 200
      }
    },
    "getattr": {
      "count": 1000,
      "total_time": 200
    },
    "link": {
      "count": 1000,
      "total_time": 200
    },
    "lock": {
      "count": 1000,
      "total_time": 200
    },
    "lookup": {
      "count": 1000,
      "total_time": 200
    },
    "open": {
      "count": 1000,
```



```
],
"volume_protocol_latency_histogram_labels": [
  "<2us",
  "<6us",
  "<10us",
  "<14us",
  "<20us",
  "<40us",
  "<60us",
  "<80us",
  "<100us",
  "<200us",
  "<400us",
  "<600us",
  "<800us",
  "<1ms",
  "<2ms",
  "<4ms",
  "<6ms",
  "<8ms",
  "<10ms",
  "<12ms",
  "<14ms",
  "<16ms",
  "<18ms",
  "<20ms",
  "<40ms",
  "<60ms",
  "<80ms",
  "<100ms",
  "<200ms",
  "<400ms",
  "<600ms",
  "<800ms",
  "<1s",
  "<2s",
  "<4s",
  "<6s",
  "<8s",
  "<10s",
  "<20s",
  ">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
```

```

    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,

```



```
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0  
],  
"volume_protocol_latency_histogram_labels": [  
  "<2us",  
  "<6us",  
  "<10us",  
  "<14us",  
  "<20us",  
  "<40us",  
  "<60us",  
  "<80us",  
  "<100us",  
  "<200us",  
  "<400us",  
  "<600us",  
  "<800us",  
  "<1ms",  
  "<2ms",  
  "<4ms",  
  "<6ms",  
  "<8ms",  
  "<10ms",  
  "<12ms",  
  "<14ms",  
  "<16ms",  
  "<18ms",  
  "<20ms",  
  "<40ms",  
  "<60ms",  
  "<80ms",  
  "<100ms",  
  "<200ms",  
  "<400ms",  
  "<600ms",  
  "<800ms",  
  "<1s",  
  "<2s",  
  "<4s",  
  "<6s",
```

```

    "<8s",
    "<10s",
    "<20s",
    ">20s"
  ],
  "volume_protocol_size_histogram_counts": [
    2400,
    1055,
    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
}
},
"cloud": {
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  }
}

```

```

    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "flexcache_raw": {
    "cache_miss_blocks": 10,
    "client_requested_blocks": 500,
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "nfs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
      "file": {
        "count": 1000,
        "total_time": 200
      },
      "other": {
        "count": 1000,
        "total_time": 200
      }
    }
  }
}

```



```
    },
    "symlink": {
      "count": 1000,
      "total_time": 200
    }
  },
  "getattr": {
    "count": 1000,
    "total_time": 200
  },
  "link": {
    "count": 1000,
    "total_time": 200
  },
  "lock": {
    "count": 1000,
    "total_time": 200
  },
  "lookup": {
    "count": 1000,
    "total_time": 200
  },
  "open": {
    "count": 1000,
    "total_time": 200
  },
  "read": {
    "count": 1000,
    "total_time": 200,
    "volume_protocol_latency_histogram_counts": [
      0,
      0,
      0,
      0,
      0,
      15,
      35,
      100,
      200,
      200,
      300,
      500,
      500,
      500,
      1000,
      1000,
```



```
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
"volume_protocol_size_histogram_labels": [
  "< 4KB",
  "= 4KB",
  "< 8KB",
  "= 8KB",
  "< 16KB",
  "= 16KB",
  "< 32KB",
```

```

    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,
    35,
    100,

```



```
"<800us",
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
```

```

    "volume_protocol_size_histogram_labels": [
      "< 4KB",
      "= 4KB",
      "< 8KB",
      "= 8KB",
      "< 16KB",
      "= 16KB",
      "< 32KB",
      "= 32KB",
      "< 64KB",
      "= 64KB",
      "< 256KB",
      "= 256KB",
      "< 1024KB",
      "= 1024KB",
      "> 1024KB"
    ]
  },
  "status": "ok",
  "throughput_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"status": {
},
"style": "flexvol",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"tiering": {
  "object_tags": {
  },
  "policy": "all"
},
"type": "rw",
"uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"

```

```
}  
====  
  
== Error
```

Status: Default, Error

```
[cols=3*,options=header]  
|===  
|Name  
|Type  
|Description  
  
|error  
|link:#error[error]  
a|  
  
|===  
  
.Example error  
[%collapsible%closed]  
====  
[source,json,subs=+macros]  
{  
  "error": {  
    "arguments": {  
      "code": "string",  
      "message": "string"  
    },  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}  
====  
  
== Definitions  
  
[.api-def-first-level]  
.See Definitions  
[%collapsible%closed]  
//Start collapsible Definitions block  
====  
[#href]  
[.api-collapsible-fifth-title]
```



href

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|href
```

```
|string
```

```
a|
```

```
|===
```

```
[#_links]
```

```
[.api-collapsible-fifth-title]
```

```
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|self
```

```
|link:href[href]
```

```
a|
```

```
|===
```

```
[#unsupported_reason]
```

```
[.api-collapsible-fifth-title]
```

```
unsupported_reason
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|If volume activity tracking is not supported on the volume, this field provides an appropriate error code.
```

```

|message
|string
a|If volume activity tracking is not supported on the volume, this field
provides an error message detailing why this is the case.

|===

[#activity_tracking]
[.api-collapsible-fifth-title]
activity_tracking

[cols=3*,options=header]
|===
|Name
|Type
|Description

|state
|string
a|Activity tracking state of the volume. If this value is "on", ONTAP
collects top metrics information for the volume in real time. There is a
slight impact to I/O performance in order to collect this information. If
this value is "off", no activity tracking information is collected or
available to view.

* enum: ["off", "on"]
* Introduced in: 9.10

|supported
|boolean
a|This field indicates whether or not volume activity tracking is
supported on the volume. If volume activity tracking is not supported, the
reason why is provided in the "activity_tracking.unsupported_reason"
field.

|unsupported_reason
|link:#unsupported_reason[unsupported_reason]
a|

|===

```

```

[#aggregates]
[.api-collapsible-fifth-title]
aggregates

Aggregate

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|

|uuid
|string
a|

|===

[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If file system analytics is not supported on the volume, this field
provides the error code explaining why.

|message
|string
a|If file system analytics is not supported on the volume, this field

```

provides the error message explaining why.

|===

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|scan_progress
```

```
|integer
```

a|Percentage of files in the volume that the file system analytics initialization scan has processed. Only returned when the state is `initializing`.

```
|state
```

```
|string
```

a|File system analytics state of the volume. If this value is "on", ONTAP collects extra file system analytics information for all directories on the volume. There will be a slight impact to I/O performance to collect this information. If this value is "off", file system analytics information is not collected and not available to be viewed. If this value is "initializing", that means file system analytics was recently turned on, and the initialization scan to gather information all all existing files and directories is currently running. If this value is 'unknown' that means there was an internal error when determining the file system analytics state for the volume.

\* enum: ["unknown", "initializing", "off", "on"]

\* Introduced in: 9.8

```
|supported
```

```
|boolean
```

a|This field indicates whether or not file system analytics is supported on the volume. If file system analytics is not supported, the reason will be specified in the "analytics.unsupported\_reason" field.

```

|unsupported_reason
|link:#unsupported_reason[unsupported_reason]
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|suspects
|link:#href[href]
a|

|===

[#anti_ransomware_attack_report]
[.api-collapsible-fifth-title]
anti_ransomware_attack_report

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|time
|string
a|Timestamp at which ransomware attack is observed.

|===

[#space]

```

```

[.api-collapsible-fifth-title]
space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|snapshot_count
|integer
a|Total number of Anti-ransomware backup Snapshot copies.

|used
|integer
a|Total space in bytes used by the Anti-ransomware feature.

|used_by_logs
|integer
a|Space in bytes used by the Anti-ransomware analytics logs.

|used_by_snapshots
|integer
a|Space in bytes used by the Anti-ransomware backup Snapshot copies.

|===

[#suspect_files]
[.api-collapsible-fifth-title]
suspect_files

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Total number of `suspect_files.format` files observed by the Anti-
ransomware analytics engine on the volume.

```

```
|entropy
|string
a|Indicates the entropy level of this file type.
```

```
|format
|string
a|File formats observed by the Anti-ransomware analytics engine on the
volume.
```

```
|===
```

```
[#anti_ransomware]
[.api-collapsible-fifth-title]
anti_ransomware
```

Anti-ransomware related information of the volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|attack_probability
|string
a|Probability of a ransomware attack.
`none` No files are suspected of ransomware activity.
`low` A number of files are suspected of ransomware activity.
`moderate` A moderate number of files are suspected of ransomware
activity.
`high` A large number of files are suspected of ransomware activity.
```

```
|attack_reports
|array[link:#anti_ransomware_attack_report[anti_ransomware_attack_report]]
a|
```

```
|dry_run_start_time
|string
a|Time when Anti-ransomware monitoring `state` is set to dry-run value for
starting evaluation mode.
```

```

|space
|link:#space[space]
a|

|state
|string
a|Anti-ransomware state.
`disabled` Anti-ransomware monitoring is disabled on the volume. This is
the default state in a POST operation.
`disable_in_progress` Anti-ransomware monitoring is being disabled and a
cleanup operation is in effect. Valid in GET operation.
`dry_run` Anti-ransomware monitoring is enabled in the evaluation mode.
`enabled` Anti-ransomware monitoring is active on the volume.
`paused` Anti-ransomware monitoring is paused on the volume.
`enable_paused` Anti-ransomware monitoring is paused on the volume from
its earlier enabled state. Valid in GET operation.
`dry_run_paused` Anti-ransomware monitoring is paused on the volume from
its earlier dry_run state. Valid in GET operation.
For POST, the valid Anti-ransomware states are only `disabled`, `enabled`
and `dry_run`, whereas for PATCH, `paused` is also valid along with the
three valid states for POST.

|surge_as_normal
|boolean
a|Indicates whether or not to set the surge values as historical values.

|suspect_files
|array[link:#suspect_files[suspect_files]]
a|

|===

[#application]
[.api-collapsible-fifth-title]
application

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name

```



```
|string
a|Name of the application to which the volume belongs. Available only when
the volume is part of an application.
```

```
|uuid
|string
a|UUID of the application to which the volume belongs. Available only when
the volume is part of an application.
```

```
|===
```

```
[#asynchronous_directory_delete]
[.api-collapsible-fifth-title]
asynchronous_directory_delete
```

Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|enabled
|boolean
a|Specifies whether asynchronous directory delete from the client is
enabled on the volume.
```

```
|trash_bin
|string
a|Name of the trash bin directory. If no "trash_bin" property is specified
when enabling, the default trash bin name, "._ontaptrashbin", is used.
```

```
|===
```

```
[#autosize]
[.api-collapsible-fifth-title]
autosize
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|grow_threshold
```

```
|integer
```

a|Used space threshold size, in percentage, for the automatic growth of the volume. When the amount of used space in the volume becomes greater than this threshold, the volume automatically grows unless it has reached the maximum size. The volume grows when 'space.used' is greater than this percent of 'space.size'. The 'grow\_threshold' size cannot be less than or equal to the 'shrink\_threshold' size..

```
|maximum
```

```
|integer
```

a|Maximum size in bytes up to which a volume grows automatically. This size cannot be less than the current volume size, or less than or equal to the minimum size of volume.

```
|minimum
```

```
|integer
```

a|Minimum size in bytes up to which the volume shrinks automatically. This size cannot be greater than or equal to the maximum size of volume.

```
|mode
```

```
|string
```

a|Autosize mode for the volume.

grow &dash; Volume automatically grows when the amount of used space is above the 'grow\_threshold' value.

grow\_shrink &dash; Volume grows or shrinks in response to the amount of space used.

off &dash; Autosizing of the volume is disabled.

```
|shrink_threshold
```

```
|integer
```

a|Used space threshold size, in percentage, for the automatic shrinkage of the volume. When the amount of used space in the volume drops below this threshold, the volume automatically shrinks unless it has reached the minimum size. The volume shrinks when the 'space.used' is less than the 'shrink\_threshold' percent of 'space.size'. The 'shrink\_threshold' size

cannot be greater than or equal to the 'grow\_threshold' size.

|===

```
[#snapshot_reference]
[.api-collapsible-fifth-title]
snapshot_reference
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

a|

```
|name
```

```
|string
```

a|

```
|uuid
```

```
|string
```

a|

|===

```
[#parent_svm]
[.api-collapsible-fifth-title]
parent_svm
```

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

a|

```
|name
```

```
|string
```

```
a|The name of the SVM.
```

```
|uuid
```

```
|string
```

```
a|The unique identifier of the SVM.
```

```
|===
```

```
[#parent_volume]
```

```
[.api-collapsible-fifth-title]
```

```
parent_volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|The name of the volume.
```

```
|uuid
```

```
|string
```

```
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
```

```
* Introduced in: 9.6
```

```
|===
```

```
[#clone]
```

```
[.api-collapsible-fifth-title]
```

```
clone
```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|is_flexclone
|boolean
a|Specifies if this volume is a normal FlexVol or FlexClone. This field
needs to be set when creating a FlexClone. Valid in POST.

|parent_snapshot
|link:#snapshot_reference[snapshot_reference]
a|

|parent_svm
|link:#parent_svm[parent_svm]
a|

|parent_volume
|link:#parent_volume[parent_volume]
a|

|split_complete_percent
|integer
a|Percentage of FlexClone blocks split from its parent volume.

|split_estimate
|integer
a|Space required by the containing-aggregate to split the FlexClone
volume.

|split_initiated
|boolean
a|This field is set when split is executed on any FlexClone, that is when
the FlexClone volume is split from its parent FlexVol. This field needs to
be set for splitting a FlexClone form FlexVol. Valid in PATCH.

|===

[#consistency_group]
[.api-collapsible-fifth-title]

```

## consistency\_group

Consistency group the volume is part of.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

a|The name of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

```
|uuid
```

```
|string
```

a|The UUID of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

```
|===
```

```
[#aggregates]
```

```
[.api-collapsible-fifth-title]
```

aggregates

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

a|Name of the aggregate hosting the FlexGroup Constituent.

```
|uuid
```

```
|string
```

```
a|Unique identifier for the aggregate.
```

```
|===
```

```
[#destination_aggregate]  
[.api-collapsible-fifth-title]  
destination_aggregate
```

Aggregate

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name  
|string  
a|
```

```
|uuid  
|string  
a|
```

```
|===
```

```
[#movement]  
[.api-collapsible-fifth-title]  
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type
```

```

|Description

|cutover_window
|integer
a|Time window in seconds for cutover. The allowed range is between 30 to
300 seconds.

|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate

|percent_complete
|integer
a|Completion percentage

|state
|string
a|State of volume move operation. PATCH the state to "aborted" to abort
the move operation. PATCH the state to "cutover" to trigger cutover. PATCH
the state to "paused" to pause the volume move operation in progress.
PATCH the state to "replicating" to resume the paused volume move
operation. PATCH the state to "cutover_wait" to go into cutover manually.
When volume move operation is waiting to go into "cutover" state, this is
indicated by the "cutover_pending" state. A change of state is only
supported if volume movement is in progress.

|tiering_policy
|string
a|Tiering policy for FabricPool

|===

[#logical_space]
[.api-collapsible-fifth-title]
logical_space

[cols=3*,options=header]
|===
|Name
|Type
|Description

```



|available  
|integer  
a|The amount of space available in this volume with storage efficiency space considered used, in bytes.

|enforcement  
|boolean  
a|Specifies whether space accounting for operations on the volume is done along with storage efficiency.

|reporting  
|boolean  
a|Specifies whether space reporting on the volume is done along with storage efficiency.

|used\_by\_afs  
|integer  
a|The virtual space used by AFS alone (includes volume reserves) and along with storage efficiency, in bytes.

|===

[#snapshot]  
[.api-collapsible-fifth-title]  
snapshot

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|autodelete\_enabled  
|boolean  
a|Specifies whether Snapshot copy autodelete is currently enabled on this volume.

|reserve\_percent  
|integer  
a|The space that has been set aside as a reserve for Snapshot copy usage,

in percent.

|used

|integer

a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|afs\_total

|integer

a|Total size of AFS, excluding snap-reserve, in bytes.

|available

|integer

a|The available space, in bytes.

|available\_percent

|integer

a|The space available, as a percent.

|block\_storage\_inactive\_user\_data

|integer

a|The size that is physically used in the block storage of the volume and has a cold temperature. In bytes. This parameter is only supported if the volume is in an aggregate that is either attached to a cloud store or could be attached to a cloud store.

|capacity\_tier\_footprint

|integer

a|Space used by capacity tier for this volume in the FabricPool aggregate,

in bytes.

|footprint

|integer

a|Data used for this volume in the aggregate, in bytes.

|local\_tier\_footprint

|integer

a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical\_space

|link:#logical\_space[logical\_space]

a|

|metadata

|integer

a|Space used by the volume metadata in the aggregate, in bytes.

|over\_provisioned

|integer

a|The amount of space not available for this volume in the aggregate, in bytes.

|performance\_tier\_footprint

|integer

a|Space used by the performance tier for this volume in the FabricPool aggregate, in bytes.

|size

|integer

a|Total provisioned size. The default size is equal to the minimum size of 20MB, in bytes.

|snapshot

|link:#snapshot[snapshot]

a|

|total\_footprint

|integer

a|Data and metadata used for this volume in the aggregate, in bytes.

```
|used
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.
```

```
|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.
```

```
|used_percent
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, as a percent.
```

```
|===
```

```
[#constituents]
[.api-collapsible-fifth-title]
constituents
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|aggregates
|link:#aggregates[aggregates]
a|
```

```
|movement
|link:#movement[movement]
a|Volume movement. All attributes are modify, that is, not writable
through POST. Set PATCH state to destination_aggregate to initiate a
volume move operation. Volume movement on FlexGroup constituents are not
supported.
```

```
|name
|string
a|FlexGroup Constituents name.
```

```
| space
| link:#space[space]
a|
```

```
|===
```

```
[#policy]
[.api-collapsible-fifth-title]
policy
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|name
|string
a|Specifies the name of the efficiency policy.
```

```
|===
```

```
[#scanner]
[.api-collapsible-fifth-title]
scanner
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|compression
|boolean
a|Start compression if scanning old data. Valid for PATCH and GET.
```

```
|dedupe
|boolean
a|Start deduplication if scanning old data. Valid for PATCH and GET.
```

```

|scan_old_data
|boolean
a|Indicates whether or not to scan old data. Valid for PATCH and GET.

|state
|string
a|State of the volume efficiency scanner. Valid for PATCH and GET. Valid
options for PATCH are "idle" and "active".

|===

[#space_savings]
[.api-collapsible-fifth-title]
space_savings

[cols=3*,options=header]
|===
|Name
|Type
|Description

|compression
|integer
a|Total disk space that is saved by compressing blocks on the referenced
file system, in bytes.

|compression_percent
|integer
a|Percentage of total disk space that is saved by compressing blocks on
the referenced file system.

|dedupe
|integer
a|Total disk space that is saved by deduplication and file cloning, in
bytes.

|dedupe_percent
|integer
a|Percentage of total disk space that is saved by deduplication and file
cloning.

```

```
|dedupe_sharing
|integer
a|Total disk space that is shared due to deduplication and file cloning.
```

```
|total
|integer
a|Total disk space saved in the volume due to deduplication, compression
and file cloning, in bytes.
```

```
|total_percent
|integer
a|Percentage of total disk space saved in the volume due to deduplication,
compression and file cloning.
```

```
|===
```

```
[#efficiency]
[.api-collapsible-fifth-title]
efficiency
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|application_io_size
|string
a|Block size to use by compression.
```

```
|compaction
|string
a|The system can be enabled/disabled compaction.
inline &dash; Data will be compacted first and written to the volume.
none &dash; None
mixed &dash; Read only field for FlexGroups, where some of the constituent
volumes are compaction enabled and some are disabled.
```

```
|compression
|string
```

a|The system can be enabled/disabled compression.

inline &dash; Data will be compressed first and written to the volume.

background &dash; Data will be written to the volume and compressed later.

both &dash; Inline compression compresses the data and write to the volume, background compression compresses only the blocks on which inline compression is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are compression enabled and some are disabled.

NOTE: that On volumes with container compression enabled, background compression refers to inactive data compression scan enabled on the volume.

|compression\_type

|string

a|Compression type to use by compression. Valid for PATCH and GET.

|cross\_volume\_dedupe

|string

a|The system can be enabled/disabled cross volume dedupe. it can be enabled only when dedupe is enabled.

inline &dash; Data will be cross volume deduped first and written to the volume.

background &dash; Data will be written to the volume and cross volume deduped later.

both &dash; Inline cross volume dedupe dedupes the data and write to the volume, background cross volume dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are cross volume dedupe enabled and some are disabled.

|dedupe

|string

a|The system can be enabled/disabled dedupe.

inline &dash; Data will be deduped first and written to the volume.

background &dash; Data will be written to the volume and deduped later.

both &dash; Inline dedupe dedupes the data and write to the volume, background dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent



volumes are dedupe enabled and some are disabled.

|has\_savings

|boolean

a|When true, indicates that the volume contains shared(deduplication, file clones) or compressed data.

|last\_op\_begin

|string

a|Last sis operation begin timestamp.

|last\_op\_end

|string

a|Last sis operation end timestamp.

|last\_op\_err

|string

a|Last sis operation error text.

|last\_op\_size

|integer

a|Last sis operation size.

|last\_op\_state

|string

a|Last sis operation state.

|logging\_enabled

|boolean

a|When true, indicates that space savings for any newly-written data are being logged.

|op\_state

|string

a|Sis status of the volume.

|path

|string

a|Absolute volume path of the volume.

|policy

|link:#policy[policy]

a|

|progress

|string

a|Sis progress of the volume.

|scanner

|link:#scanner[scanner]

a|

|schedule

|string

a|Schedule associated with volume.

|space\_savings

|link:#space\_savings[space\_savings]

a|

|state

|string

a|Storage efficiency state of the volume. Currently, this field supports POST/PATCH only for RW (Read-Write) volumes on FSx for ONTAP and Cloud Volumes ONTAP.

disabled &dash; All storage efficiency features are disabled.

mixed &dash; Read-only field for FlexGroup volumes, storage efficiency is enabled on certain constituents and disabled on others.

On FSx for ONTAP and Cloud Volumes ONTAP &dash;

&nbsp;&nbsp;&nbsp;enabled &dash; All supported storage efficiency features for the volume are enabled.

&nbsp;&nbsp;&nbsp;custom &dash; Read-only field currently only supported for the FSx for ONTAP and Cloud Volumes ONTAP, user-defined storage efficiency features are enabled.

For other platforms &dash;

&nbsp;&nbsp;&nbsp;enabled &dash; At least one storage efficiency feature for the volume is enabled.

\* enum: ["disabled", "enabled", "mixed", "custom"]

\* Introduced in: 9.9

```
|storage_efficiency_mode
|string
a|Storage efficiency mode used by volume. This parameter is supported only
on AFF platform.
```

```
|type
|string
a|Sis Type of the volume.
```

```
|===
```

```
[#status]
[.api-collapsible-fifth-title]
status
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Encryption progress message code.
```

```
|message
|string
a|Encryption progress message.
```

```
|===
```

```
[#encryption]
[.api-collapsible-fifth-title]
encryption
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

|enabled  
|boolean  
a|Creates an encrypted or an unencrypted volume. For POST, when set to 'true', a new key is generated and used to encrypt the given volume. In that case, the underlying SVM must be configured with the key manager. When set to 'false', the volume created will be unencrypted. For PATCH, when set to 'true', it encrypts an unencrypted volume. Specifying the parameter as 'false' in a PATCH operation for an encrypted volume is only supported when moving the volume to another aggregate.

|key\_create\_time  
|string  
a|Encryption key creation time of the volume.

|key\_id  
|string  
a|The key ID used for creating encrypted volume. A new key-id is generated for creating an encrypted volume. This key-id is associated with the generated key.

|key\_manager\_attribute  
|string  
a|Specifies an additional key manager attribute that is an identifier-value pair, separated by '='. For example, CRN=unique-value. This parameter is required when using the POST method and an IBM Key Lore key manager is configured on the SVM.

|rekey  
|boolean  
a|If set to 'true', re-encrypts the volume with a new key. Valid in PATCH.

|state  
|string  
a|Volume encryption state.  
encrypted &dash; The volume is completely encrypted.  
encrypting &dash; Encryption operation is in progress.  
partial &dash; Some constituents are encrypted and some are not.  
Applicable only for FlexGroup volume.  
rekeying. Encryption of volume with a new key is in progress.  
unencrypted &dash; The volume is a plain-text one.

```

|status
|link:#status[status]
a|

|type
|string
a|Volume encryption type.
none &dash; The volume is a plain-text one.
volume &dash; The volume is encrypted with NVE (NetApp Volume Encryption).
aggregate &dash; The volume is encrypted with NAE (NetApp Aggregate Encryption).

|===

[#error_state]
[.api-collapsible-fifth-title]
error_state

[cols=3*,options=header]
|===
|Name
|Type
|Description

|has_bad_blocks
|boolean
a|Indicates whether the volume has any corrupt data blocks. If the damaged data block is accessed, an IO error, such as EIO for NFS or STATUS_FILE_CORRUPT for CIFS, is returned.

|is_inconsistent
|boolean
a|Indicates whether the file system has any inconsistencies.
true &dash; File system is inconsistent.
false &dash; File system in not inconsistent.

|===

[#files]
[.api-collapsible-fifth-title]
files

```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|maximum
```

```
|integer
```

a|The maximum number of files (inodes) for user-visible data allowed on the volume. This value can be increased or decreased. Increasing the maximum number of files does not immediately cause additional disk space to be used to track files. Instead, as more files are created on the volume, the system dynamically increases the number of disk blocks that are used to track files. The space assigned to track files is never freed, and this value cannot be decreased below the current number of files that can be tracked within the assigned space for the volume. Valid in PATCH.

```
|used
```

```
|integer
```

a|Number of files (inodes) used for user-visible data permitted on the volume. This field is valid only when the volume is online.

```
|===
```

```
[#flash_pool]
```

```
[.api-collapsible-fifth-title]
```

```
flash_pool
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cache_eligibility
```

```
|string
```

a|If this parameter is specified, the command displays information only about the volume or volumes with the specified Flash Pool caching attributes.

```
|cache_retention_priority
```

```
|string
```

a|If this parameter is specified, the command displays the volumes that

match the specified cache retention priority policy. A cache retention priority defines how long the blocks of a volume will be cached in the Flash Pool once they become cold.

|caching\_policy

|string

a|This optionally specifies the caching policy to apply to the volume. A caching policy defines how the system caches a volume's data in Flash Cache modules. If a caching policy is not assigned to a volume, the system uses the caching policy that is assigned to the containing SVM. If a caching policy is not assigned to the containing SVM, the system uses the default cluster-wide policy.

|===

[#flexgroup]

[.api-collapsible-fifth-title]

flexgroup

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name

|string

a|Name of the FlexGroup volume that the constituent is part of.

|uuid

|string

a|Unique identifier for the FlexGroup volume that the constituent is part of.

|===

[#guarantee]

[.api-collapsible-fifth-title]

guarantee

[cols=3\*,options=header]

```
|===  
|Name  
|Type  
|Description  
  
|honored  
|boolean  
a|Is the space guarantee of this volume honored in the aggregate?
```

```
|type  
|string  
a|The type of space guarantee of this volume in the aggregate.
```

```
|===
```

```
[#idcs_scanner]  
[.api-collapsible-fifth-title]  
idcs_scanner
```

Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

```
[cols=3*,options=header]
```

```
|===  
|Name  
|Type  
|Description  
  
|enabled  
|boolean  
a|Specifies the administrative state of the inactive data compression scanner.
```

```
|mode  
|string  
a|Specifies the mode of inactive data compression scanner. Valid for PATCH and GET.
```



|operation\_state  
|string  
a|Specifies the operational state of the inactive data compression scanner. VALID for PATCH and GET. Valid options for PATCH are "idle" and "active".

|status  
|string  
a|Status of last inactive data compression scan on the volume.

|threshold\_inactive\_time  
|string  
a|Time interval after which inactive data compression will be triggered automatically. The value is in days and is represented in the ISO-8601 format as "P+++<num>+++D" , for example "P3D" represents a duration of 3 days.+++</num>+++

|===

[#iops]  
[.api-collapsible-fifth-title]  
iops

The rate of I/O operations observed at the storage object.

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|other  
|integer  
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

|read  
|integer  
a|Performance metric for read I/O operations.

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#latency]
[.api-collapsible-fifth-title]
latency
```

The round trip latency in microseconds observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.
```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]  
[.api-collapsible-fifth-title]  
cloud
```

Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|duration
```

```
|string
```

a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

```
|iops
```

```
|link:#iops[iops]
```

a|The rate of I/O operations observed at the storage object.

```
|latency
```

```
|link:#latency[latency]
```

a|The round trip latency in microseconds observed at the storage object.

```
|status
```

```
|string
```

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#flexcache]
[.api-collapsible-fifth-title]
flexcache
```

Performance number for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|bandwidth_savings
|integer
a|Bandwidth savings denoting the amount of data served locally by the
cache, in bytes.
```

```
|cache_miss_percent
|integer
a|Cache miss percentage.
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations
are represented in the ISO-8601 standard format. Samples can be calculated
over the following durations:
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
```

the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#throughput]
[.api-collapsible-fifth-title]
throughput
```

The rate of throughput bytes per second observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#metric]
[.api-collapsible-fifth-title]
metric
```

Performance numbers, such as IOPS, latency and throughput.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|cloud
|link:#cloud[cloud]
a|Performance numbers (IOPS and latency) for cloud store. These numbers
are relevant only for volumes hosted on FabricPools.
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations
are represented in the ISO-8601 standard format. Samples can be calculated
over the following durations:
```

```
|flexcache
|link:#flexcache[flexcache]
a|Performance number for FlexCache used to measure cache effectiveness.
```

```
|iops
|link:#iops[iops]
a|The rate of I/O operations observed at the storage object.
```

```
|latency
|link:#latency[latency]
a|The round trip latency in microseconds observed at the storage object.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
```

```
|throughput
|link:#throughput[throughput]
a|The rate of throughput bytes per second observed at the storage object.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|cutover_window
|integer
a|Time window in seconds for cutover. The allowed range is between 30 to
300 seconds.
```

```
|destination_aggregate
|link:#destination_aggregate[destination_aggregate]
a|Aggregate
```

```
|percent_complete
|integer
a|Completion percentage
```

```
|start_time
|string
a|Start time of volume move.
```

```
|state
|string
a|State of volume move operation. PATCH the state to "aborted" to abort
the move operation. PATCH the state to "cutover" to trigger cutover. PATCH
the state to "paused" to pause the volume move operation in progress.
PATCH the state to "replicating" to resume the paused volume move
operation. PATCH the state to "cutover_wait" to go into cutover manually.
When volume move operation is waiting to go into "cutover" state, this is
indicated by the "cutover_pending" state. A change of state is only
supported if volume movement is in progress.
```

```
|tiering_policy
|string
a|Tiering policy for FabricPool
```

```
|===
```

```
[#export_policy]
[.api-collapsible-fifth-title]
export_policy
```

Export Policy



```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|id
|integer
a|

|name
|string
a|

|===

[#junction_parent]
[.api-collapsible-fifth-title]
junction_parent

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the parent volume that contains the junction inode of this
volume. The junction parent volume must belong to the same SVM that owns
this volume.

|uuid
|string
a|Unique identifier for the parent volume.

```

```
|===
```

```
[#nas]
```

```
[.api-collapsible-fifth-title]
```

```
nas
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|export_policy
```

```
|link:#export_policy[export_policy]
```

```
a|Export Policy
```

```
|gid
```

```
|integer
```

```
a|The UNIX group ID of the volume. Valid in POST or PATCH.
```

```
|junction_parent
```

```
|link:#junction_parent[junction_parent]
```

```
a|
```

```
|path
```

```
|string
```

```
a|The fully-qualified path in the owning SVM's namespace at which the volume is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one volume can be mounted at any given junction path. An empty path in POST creates an unmounted volume. An empty path in PATCH deactivates and unmounts the volume. Taking a volume offline or restricted state removes its junction path. This attribute is reported in GET only when the volume is mounted.
```

```
|security_style
```

```
|string
```

```
a|Security style associated with the volume. Valid in POST or PATCH.
```

```
mixed &dash; Mixed-style security
```

```
ntfs &dash; NTFS/Windows-style security
```

```
unified &dash; Unified-style security, unified UNIX, NFS and CIFS
```

permissions

unix &dash; Unix-style security.

|uid

|integer

a|The UNIX user ID of the volume. Valid in POST or PATCH.

|unix\_permissions

|integer

a|UNIX permissions to be viewed as an octal number. It consists of 4 digits derived by adding up bits 4 (read), 2 (write) and 1 (execute). First digit selects the set user ID(4), set group ID (2) and sticky (1) attributes. The second digit selects permission for the owner of the file; the third selects permissions for other users in the same group; the fourth for other users not in the group. Valid in POST or PATCH. For security style "mixed" or "unix", the default setting is 0755 in octal (493 in decimal) and for security style "ntfs", the default setting is 0000. In cases where only owner, group and other permissions are given (as in 755, representing the second, third and fourth digit), first digit is assumed to be zero.

|===

[#policy]

[.api-collapsible-fifth-title]

policy

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|max\_throughput\_iops

|integer

a|Specifies the maximum throughput in IOPS, 0 means none. This is mutually exclusive with name and UUID during POST and PATCH.

```

|max_throughput_mbps
|integer
a|Specifies the maximum throughput in Megabytes per sec, 0 means none.
This is mutually exclusive with name and UUID during POST and PATCH.

|min_throughput_iops
|integer
a|Specifies the minimum throughput in IOPS, 0 means none. Setting
"min_throughput" is supported on AFF platforms only, unless FabricPool
tiering policies are set. This is mutually exclusive with name and UUID
during POST and PATCH.

|min_throughput_mbps
|integer
a|Specifies the minimum throughput in Megabytes per sec, 0 means none.
This is mutually exclusive with name and UUID during POST and PATCH.

|name
|string
a|The QoS policy group name. This is mutually exclusive with UUID and
other QoS attributes during POST and PATCH.

|uuid
|string
a|The QoS policy group UUID. This is mutually exclusive with name and
other QoS attributes during POST and PATCH.

|===

[#qos]
[.api-collapsible-fifth-title]
qos

QoS information

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```
|policy
|link:#policy[policy]
a|
```

```
|===
```

```
[#quota]
[.api-collapsible-fifth-title]
quota
```

Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|enabled
|boolean
```

a|This option is used to enable or disable the quota for the volume. This option is valid only in PATCH. Quotas are enabled for FlexVols or FlexGroup volumes when the quota state is "on". Quotas are disabled for FlexVols or FlexGroup volumes when the quota state is "off".

```
|state
|string
a|Quota state of the volume
```

```
|===
```

```
[#failure_reason]
[.api-collapsible-fifth-title]
failure_reason
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Error code of volume capacity rebalancing operation.
```

```
|message
|string
a|Details why the volume capacity rebalancing operation failed.
```

```
|===
```

```
[#rebalancing]
[.api-collapsible-fifth-title]
rebalancing
```

Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|data_moved
|integer
a|The amount of data that has been moved in or out of a constituent. A positive value represents data moving into the constituent while a negative value is data moving out of the constituent.
```

```
|exclude_snapshots
|boolean
a|Specifies whether or not to exclude files that are stuck in Snapshot copies during rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "exclude_snapshots" value. Once the operation is started, any changes to the "exclude_snapshots" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will
```

use the new "exclude\_snapshots" value.

```
|failure_reason  
|link:#failure_reason[failure_reason]  
a|
```

```
|imbalance_percent  
|integer  
a|Represents the percentage the volume is out of balance.
```

```
|imbalance_size  
|integer  
a|Represents how much the volume is out of balance, in bytes.
```

```
|max_constituent_imbalance_percent  
|integer  
a|Absolute percentage of the constituent that is most out of balance.
```

```
|max_file_moves  
|integer  
a|Specifies the maximum number of file moves in a volume capacity rebalancing operation on a constituent of the FlexGroup volume. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max_file_moves" value. Once the operation is started, any changes to the "max_file_moves" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max_file_moves" value.
```

```
|max_runtime  
|string  
a|This optional field specifies the maximum time a capacity rebalancing operation runs for. Once the maximum runtime has passed, the capacity rebalancing operation stops. If it is not set, the default value is 6 hours. This value cannot be updated while a capacity rebalancing operation is running. The maximum runtime can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P3D" represents a duration of 3 days. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++
```

|max\_threshold

|integer

a|Specifies the maximum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is larger than this value, files are moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_threshold" value. Once the operation is started, any changes to the "max\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_threshold" value.

|min\_file\_size

|integer

a|Specifies the minimum file size to consider for a volume capacity rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "min\_file\_size" value. Once the operation is started, any changes to the "min\_file\_size" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_file\_size" value. The value must be a multiple of 4KB. If it is not set, the default value will be 4KB.

|min\_threshold

|integer

a|Specifies the minimum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is smaller than this value, files are not moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it will use the current "min\_threshold" value. Once the operation is started, any changes to the "min\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_threshold" value.

|runtime

|string

a|Duration the capacity rebalancing operation has been running.

|start\_time

|string

a|Time when the current capacity rebalancing operation started.



```

|state
|string
a|State of volume capacity rebalancing operation. PATCH the state to
"starting" to trigger the capacity rebalance operation. PATCH the state to
"stopping" to stop the capacity rebalance operation.

|stop_time
|string
a|Time when the capacity rebalancing operation stopped.

|target_used
|integer
a|Represents the ideal used size of each constituent. Calculated by
dividing the total FlexGroup volume used size by the number of
constituents.

|===

[#retention]
[.api-collapsible-fifth-title]
retention

[cols=3*,options=header]
|===
|Name
|Type
|Description

|default
|string
a|Specifies the default retention period that is applied to files while
committing them to the WORM state without an associated retention period.
The retention value represents a duration and must be specified in the
ISO-8601 duration format. The retention period can be in years, months,
days, hours, and minutes. A duration specified for years, months, and days
is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M",
"P+++<num>+++D" respectively, for example "P10Y" represents a duration of
10 years. A duration in hours and minutes is represented by
"PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string
must contain only a single time element that is, either years, months,
days, hours, or minutes. A duration which combines different periods is
not supported, for example "P1Y10M" is not supported. Apart from the
duration specified in the ISO-8601 format, the duration field also accepts

```

the string "infinite" to set an infinite retention period and the string "unspecified" to set an unspecified retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|maximum

|string

a|Specifies the maximum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention

period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|minimum

|string

a|Specifies the minimum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, month,s and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention

period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|===

```
[#snaplock]
```

```
[.api-collapsible-fifth-title]
```

```
snaplock
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|append_mode_enabled
```

```
|boolean
```

a|Specifies if the volume append mode is enabled or disabled. When it is enabled, all the files created with write permissions on the volume are, by default, WORM appendable files. The user can append the data to a WORM appendable file but cannot modify the existing contents of the file nor delete the file until it expires.

```
|autocommit_period
```

```
|string
```

a|Specifies the autocommit period for SnapLock volume. All files which are not modified for a period greater than the autocommit period of the volume are committed to the WORM state. The autocommit period value represents a duration and must be specified in the ISO-8601 duration format. The autocommit period can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The period string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the autocommit field also accepts the string "none".+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

```
|compliance_clock_time
```

```
|string
```

a|This is the volume compliance clock time which is used to manage the SnapLock objects in the volume.

```
|expiry_time
```

```
|string
```

a|Expiry time of the volume.

|is\_audit\_log

|boolean

a|Indicates if this volume has been configured as SnapLock audit log volume for the SVM .

|litigation\_count

|integer

a|Litigation count indicates the number of active legal-holds on the volume.

|privileged\_delete

|string

a|Specifies the privileged-delete attribute of a SnapLock volume. On a SnapLock Enterprise (SLE) volume, a designated privileged user can selectively delete files irrespective of the retention time of the file. SLE volumes can have privileged delete as disabled, enabled or permanently\_disabled and for SnapLock Compliance (SLC) volumes it is always permanently\_disabled.

|retention

|link:#retention[retention]

a|

|type

|string

a|The SnapLock type of the volume.

compliance &dash; A SnapLock Compliance(SLC) volume provides the highest level of WORM protection and an administrator cannot destroy a SLC volume if it contains unexpired WORM files.

enterprise &dash; An administrator can delete a SnapLock Enterprise(SLE) volume.

non\_snaplock &dash; Indicates the volume is non-snaplock.

|unspecified\_retention\_file\_count

|integer

a|Indicates the number of files with an unspecified retention time in the volume.

|===

```

[#destinations]
[.api-collapsible-fifth-title]
destinations

[cols=3*,options=header]
|===
|Name
|Type
|Description

|is_cloud
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data to a cloud destination.

|is_ontap
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data to an ONTAP destination.

* readOnly: 1
* Introduced in: 9.9

|===

[#snapmirror]
[.api-collapsible-fifth-title]
snapmirror

Specifies attributes for SnapMirror protection.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|destinations
|link:#destinations[destinations]
a|

```

```
|is_protected
|boolean
a|Specifies whether a volume is a SnapMirror source volume, using
SnapMirror to protect its data.
```

```
|===
```

```
[#snapshot_policy]
[.api-collapsible-fifth-title]
snapshot_policy
```

This is a reference to the Snapshot copy policy.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

```
|===
```

```
[#logical_space]
[.api-collapsible-fifth-title]
logical_space
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

|available

|integer

a|The amount of space available in this volume with storage efficiency space considered used, in bytes.

|enforcement

|boolean

a|Specifies whether space accounting for operations on the volume is done along with storage efficiency.

|reporting

|boolean

a|Specifies whether space reporting on the volume is done along with storage efficiency.

|used

|integer

a|SUM of (physical-used, shared\_refs, compression\_saved\_in\_plane0, vbn\_zero, future\_blk\_cnt), in bytes.

|used\_by\_afs

|integer

a|The virtual space used by AFS alone (includes volume reserves) and along with storage efficiency, in bytes.

|used\_by\_snapshots

|integer

a|Size that is logically used across all Snapshot copies in the volume, in bytes.

|used\_percent

|integer

a|SUM of (physical-used, shared\_refs, compression\_saved\_in\_plane0, vbn\_zero, future\_blk\_cnt), as a percentage.

|===

[#snapshot]

[.api-collapsible-fifth-title]

## snapshot

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|autodelete\_enabled

|boolean

a|Specifies whether Snapshot copy autodelete is currently enabled on this volume.

|autodelete\_trigger

|string

a|Specifies when the system should trigger an autodelete of Snapshot copies. When set to `_volume_`, autodelete is triggered based on volume fullness. When set to `_snap_reserve_`, autodelete is triggered based on Snapshot reserve fullness. The default value is `_volume_`.

|reserve\_available

|integer

a|Size available for Snapshot copies within the Snapshot copy reserve, in bytes.

|reserve\_percent

|integer

a|The space that has been set aside as a reserve for Snapshot copy usage, in percent.

|reserve\_size

|integer

a|Size in the volume that has been set aside as a reserve for Snapshot copy usage, in bytes.

|space\_used\_percent

|integer

a|Percentage of snapshot reserve size that has been used.

|used

|integer



a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|afs\_total

|integer

a|Total size of AFS, excluding snap-reserve, in bytes.

|auto\_adaptive\_compression\_footprint\_data\_reduction

|integer

a|Savings achieved due to Auto Adaptive Compression, in bytes.

|available

|integer

a|The available space, in bytes.

|available\_percent

|integer

a|The space available, as a percent.

|block\_storage\_inactive\_user\_data

|integer

a|The size that is physically used in the block storage of the volume and has a cold temperature. In bytes. This parameter is only supported if the volume is in an aggregate that is either attached to a cloud store or could be attached to a cloud store.

|block\_storage\_inactive\_user\_data\_percent

|integer

a|Percentage of size that is physically used in the performance tier of

the volume.

|capacity\_tier\_footprint

|integer

a|Space used by capacity tier for this volume in the FabricPool aggregate, in bytes.

|cross\_volume\_dedupe\_metafiles\_footprint

|integer

a|Cross volume deduplication metadata footprint, in bytes.

|cross\_volume\_dedupe\_metafiles\_temporary\_footprint

|integer

a|Cross volume temporary deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_footprint

|integer

a|Deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_temporary\_footprint

|integer

a|Temporary deduplication metadata footprint, in bytes.

|delayed\_free\_footprint

|integer

a|Delayed free blocks footprint, in bytes.

|effective\_total\_footprint

|integer

a|Volume footprint after efficiency savings, in bytes.

|expected\_available

|integer

a|Size that should be available for the volume, irrespective of available size in the aggregate, in bytes.

|file\_operation\_metadata

|integer

a|File operation metadata footprint, in bytes.

|filesystem\_size

|integer

a|Total usable size of the volume, in bytes.

|filesystem\_size\_fixed

|boolean

a|Specifies whether the file system is to remain of the same size when set to true or to grow when set to false. This option is automatically set to true when a volume becomes SnapMirrored.

|footprint

|integer

a|Data used for this volume in the aggregate, in bytes.

|fractional\_reserve

|integer

a|Used to change the amount of space reserved for overwrites of reserved objects in a volume.

|full\_threshold\_percent

|integer

a|Volume full threshold percentage at which EMS warnings can be sent.

|local\_tier\_footprint

|integer

a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical\_space

|link:#logical\_space[logical\_space]

a|

|metadata

|integer

a|Space used by the volume metadata in the aggregate, in bytes.

|nearly\_full\_threshold\_percent

|integer

a|Volume nearly full threshold percentage at which EMS warnings can be sent.

|over\_provisioned

|integer

a|The amount of space not available for this volume in the aggregate, in bytes.

|overwrite\_reserve

|integer

a|Reserved space for overwrites, in bytes.

|overwrite\_reserve\_used

|integer

a|Overwrite logical reserve space used, in bytes.

|percent\_used

|integer

a|Percentage of the volume size that is used.

|performance\_tier\_footprint

|integer

a|Space used by the performance tier for this volume in the FabricPool aggregate, in bytes.

|physical\_used

|integer

a|Size that is physically used in the volume, in bytes.

|physical\_used\_percent

|integer

a|Size that is physically used in the volume, as a percentage.

|size

|integer

a|Total provisioned size. The default size is equal to the minimum size of 20MB, in bytes.

```
|size_available_for_snapshots
|integer
a|Available space for Snapshot copies from snap-reserve, in bytes.

|snapmirror_destination_footprint
|integer
a|SnapMirror destination footprint, in bytes.

|snapshot
|link:#snapshot[snapshot]
a|

|snapshot_reserve_unusable
|integer
a|Snapshot reserve that is not available for Snapshot copy creation, in
bytes.

|snapshot_spill
|integer
a|Space used by the snapshot copies beyond the snap-reserve, in bytes.

|total_footprint
|integer
a|Data and metadata used for this volume in the aggregate, in bytes.

|used
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.

|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.

|user_data
|integer
a|User data, in bytes.

|volume_guarantee_footprint
```

```
|integer
a|Space reserved for future writes in the volume, in bytes.
```

```
|===
```

```
[#access]
[.api-collapsible-fifth-title]
access
```

Raw count and latency data for access operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#audit]
[.api-collapsible-fifth-title]
audit
```

Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```

|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```

[#dir]
[.api-collapsible-fifth-title]
dir

```

Raw count and latency data for directory-create operations.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```
[#file]  
[.api-collapsible-fifth-title]  
file
```

Raw count and latency data for file-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#other]  
[.api-collapsible-fifth-title]  
other
```

Raw count and latency data for create operations on objects other than files, directories and symlinks.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```



```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#symlink]
[.api-collapsible-fifth-title]
symlink
```

Raw count and latency data for symlink-create operations.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#create]
[.api-collapsible-fifth-title]
create
```

Raw count and latency data for create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|dir
```

```
|link:#dir[dir]
```

```
a|Raw count and latency data for directory-create operations.
```

```
|file
```

```
|link:#file[file]
```

```
a|Raw count and latency data for file-create operations.
```

```
|other
```

```
|link:#other[other]
```

```
a|Raw count and latency data for create operations on objects other than files, directories and symlinks.
```

```
|symlink
```

```
|link:#symlink[symlink]
```

```
a|Raw count and latency data for symlink-create operations.
```

```
|===
```

```
[#getattr]
```

```
[.api-collapsible-fifth-title]
```

```
getattr
```

Raw count and latency data for getattr operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#link]
[.api-collapsible-fifth-title]
link
```

Raw count and latency data for link operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#lock]  
[.api-collapsible-fifth-title]  
lock
```

Raw count and latency data for lock operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#lookup]  
[.api-collapsible-fifth-title]  
lookup
```

Raw count and latency data for lookup operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#open]
[.api-collapsible-fifth-title]
open
```

Raw count and latency data for open operations.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#read]
```

```
[.api-collapsible-fifth-title]
```

```
read
```

Raw count and latency data for read operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* readOnly: 1
```

```
* x-ntap-advanced: true
```

```
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
```

```
|array[string]
```

```
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_size_histogram_labels
```

```
|array[string]
```

```
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#readdir]  
[.api-collapsible-fifth-title]  
readdir
```

Raw count and latency data for readdir operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#readlink]  
[.api-collapsible-fifth-title]  
readlink
```

Raw count and latency data for readlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#rename]
[.api-collapsible-fifth-title]
rename
```

Raw count and latency data for rename operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```



```
[#setattr]
[.api-collapsible-fifth-title]
setattr
```

Raw count and latency data for setattr operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#unlink]
[.api-collapsible-fifth-title]
unlink
```

Raw count and latency data for unlink operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|count
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#watch]
[.api-collapsible-fifth-title]
watch
```

Raw count and latency data for watch operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#write]
[.api-collapsible-fifth-title]
write
```

Raw count and latency data for write operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* readOnly: 1
```

```
* x-ntap-advanced: true
```

```
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
```

```
|array[string]
```

```
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_size_histogram_labels
```

```
|array[string]
```

```
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#cifs_ops_raw]
[.api-collapsible-fifth-title]
cifs_ops_raw
```

Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|access
```

```
|link:#access[access]
```

```
a|Raw count and latency data for access operations.
```

```
|audit
```

```
|link:#audit[audit]
```

```
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
```

```
|link:#create[create]
```

```
a|Raw count and latency data for create operations.
```

```
|getattr
```

```
|link:#getattr[getattr]
```

```
a|Raw count and latency data for getattr operations.
```

```
|link
```

```
|link:#link[link]
```

```
a|Raw count and latency data for link operations.
```

```
|lock
```

```
|link:#lock[lock]
```

```
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#iops_raw]
[.api-collapsible-fifth-title]
iops_raw
```

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#latency_raw]
[.api-collapsible-fifth-title]
latency_raw
```

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#cloud]
```

```
[.api-collapsible-fifth-title]
```

```
cloud
```

These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase

with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|iops_raw
```

```
|link:#iops_raw[iops_raw]
```

a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
|latency_raw
```

```
|link:#latency_raw[latency_raw]
```

a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
|status
```

```
|string
```

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
```

```
|string
```

a|The timestamp of the performance data.

```
|===
```



```
[#flexcache_raw]
[.api-collapsible-fifth-title]
flexcache_raw
```

Performance numbers for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|cache_miss_blocks
|integer
a|Blocks retrieved from origin in case of a cache miss. This can be
divided by the raw client_requested_blocks and multiplied by 100 to
calculate the cache miss percentage.
```

```
|client_requested_blocks
|integer
a|Total blocks requested by the client.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#nfs_ops_raw]
[.api-collapsible-fifth-title]
nfs_ops_raw
```

Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|access
```

```
|link:#access[access]
```

```
a|Raw count and latency data for access operations.
```

```
|audit
```

```
|link:#audit[audit]
```

```
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
```

```
|link:#create[create]
```

```
a|Raw count and latency data for create operations.
```

```
|getattr
```

```
|link:#getattr[getattr]
```

```
a|Raw count and latency data for getattr operations.
```

```
|link
```

```
|link:#link[link]
```

```
a|Raw count and latency data for link operations.
```

```
|lock
```

```
|link:#lock[lock]
```

```
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#throughput_raw]
[.api-collapsible-fifth-title]
throughput_raw
```

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
```

```
|integer
```

a|Performance metric for read I/O operations.

```
|total
```

```
|integer
```

a|Performance metric aggregated over all types of I/O operations.

```
|write
```

```
|integer
```

a|Performance metric for write I/O operations.

```
|===
```

```
[#statistics]
[.api-collapsible-fifth-title]
statistics
```

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cifs_ops_raw
```

```
|link:#cifs_ops_raw[cifs_ops_raw]
```

a|Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
|cloud
```

```
|link:#cloud[cloud]
```

a|These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
|flexcache_raw
```

```
|link:#flexcache_raw[flexcache_raw]
```

a|Performance numbers for FlexCache used to measure cache effectiveness.

```
|iops_raw
```

```
|link:#iops_raw[iops_raw]
```

a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
|latency_raw
```

```
|link:#latency_raw[latency_raw]
```

a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

|nfs\_ops\_raw

|link:#nfs\_ops\_raw[nfs\_ops\_raw]

a|Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

|status

|string

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|throughput\_raw

|link:#throughput\_raw[throughput\_raw]

a|Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

|timestamp

|string

a|The timestamp of the performance data.

|===

[#svm]

[.api-collapsible-fifth-title]

svm

SVM containing the volume. Required on POST.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|The name of the SVM.
```

```
|uuid
```

```
|string
```

```
a|The unique identifier of the SVM.
```

```
|===
```

```
[#tiering]
```

```
[.api-collapsible-fifth-title]
```

```
tiering
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|min_cooling_days
```

```
|integer
```

```
a|This parameter specifies the minimum number of days that user data blocks of the volume must be cooled before they can be considered cold and tiered out to the cloud tier. Note that this parameter is only used for tiering purposes and does not affect the reporting of inactive data. The value specified should be greater than the frequency with which applications in the volume shift between different sets of data. This parameter cannot be set when volume tiering policy is either "none" or "all". The default value of this parameter depends on the volume's tiering policy. See the tiering policy section of this documentation for
```

corresponding default values. If the tiering policy on the volume gets changed, then this parameter will be reset to the default value corresponding to the new tiering policy.

|object\_tags

|array[string]

a|This parameter specifies tags of a volume for objects stored on a FabricPool-enabled aggregate. Each tag is a key,value pair and should be in the format "key=value".

|policy

|string

a|Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold. FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH. all &dash; This policy allows tiering of both Snapshot copies and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.

auto &dash; This policy allows tiering of both snapshot and active file system user data to the cloud store

none &dash; Volume blocks will not be tiered to the cloud store.

snapshot\_only &dash; This policy allows tiering of only the volume Snapshot copies not associated with the active file system. The default tiering policy is "snapshot-only" for a FlexVol and "none" for a FlexGroup. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy is 31 days.

|supported

|boolean

a|This parameter specifies whether or not FabricPools are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only FabricPool aggregates are used if this parameter is set to true and only non FabricPool aggregates are used if this parameter is set to false. Tiering support for a FlexGroup can be changed by moving all of the constituents to the required aggregates. Note that in order to tier data, not only does the volume need to support tiering by using FabricPools, the tiering "policy" must not be 'none'. A volume that uses FabricPools but has a tiering "policy" of 'none' supports tiering, but will not tier any data.



```
|===
```

```
[#error_arguments]  
[.api-collapsible-fifth-title]  
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|code  
|string  
a|Argument code
```

```
|message  
|string  
a|Message argument
```

```
|===
```

```
[#error]  
[.api-collapsible-fifth-title]  
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|arguments  
|array[link:#error_arguments[error_arguments]]  
a|Message arguments
```

```
|code  
|string  
a|Error code
```

```
|message
```

```
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
====
```

```
[[ID8dae8633d369bbbd412af8c57ef805dc]]
```

```
= Update volume attributes
```

```
[.api-doc-operation .api-doc-operation-patch]#PATCH# [.api-doc-code-  
block]#`/storage/volumes/{uuid}`#
```

```
*Introduced In:* 9.6
```

Updates the attributes of a volume. For movement, use the "validate\_only" field on the request to validate but not perform the operation. The PATCH API can be used to enable or disable quotas for a FlexVol or a FlexGroup volume. An empty path in PATCH deactivates and unmounts the volume. Taking a volume offline removes its junction path.

A PATCH request for volume encryption performs conversion/rekey operations asynchronously. You can retrieve the conversion/rekey progress details by calling a GET request on the corresponding volume endpoint.

```
== Optional properties
```

\* `queue\_for\_encryption` - Queue volumes for encryption when `encryption.enabled=true`. If this option is not provided or is false, conversion of volumes starts immediately. When there are volumes in the queue and less than four encryptions are running, volumes are encrypted in the order in which they are queued.

\* `encryption.action` - You can pause an ongoing rekey/conversion operation or resume a paused rekey/conversion operation using this field. The following actions are supported for this field: &dash;

conversion\_pause - Pause an encryption conversion operation currently in progress &dash; conversion\_resume - Resume a paused encryption conversion

operation &dash; rekey\_pause - Pause an encryption rekey operation currently in progress &dash; rekey\_resume - Resume a paused encryption rekey operation

== Related ONTAP commands

- \* `volume unmount`
- \* `volume mount`
- \* `volume online`
- \* `volume offline`
- \* `volume modify`
- \* `volume clone modify`
- \* `volume efficiency modify`
- \* `volume quota on`
- \* `volume quota off`
- \* `volume snaplock modify`
- \* `volume encryption conversion start`
- \* `volume encryption rekey start`
- \* `security anti-ransomware volume enable`
- \* `security anti-ransomware volume disable`
- \* `security anti-ransomware volume dry-run`
- \* `security anti-ransomware volume pause`
- \* `security anti-ransomware volume resume`
- \* `volume file async-delete client disable`
- \* `volume file async-delete client enable`

== Parameters

[cols=5\*,options=header]

|===

|Name

|Type

|In

|Required

|Description

|uuid

|string

|path

|True

a|Unique identifier of the volume.

|restore\_to.snapshot.uuid

|string

```
|query
|False
a|UUID of the Snapshot copy to restore volume to the point in time the
Snapshot copy was taken.

|restore_to.snapshot.name
|string
|query
|False
a|Name of the Snapshot copy to restore volume to the point in time the
Snapshot copy was taken.

|restore_to.path
|string
|query
|False
a|Path to the file which is restored from the Snapshot copy.

* Introduced in: 9.10

|restore_to.restore_path
|string
|query
|False
a|Specifies the destination location inside the volume where the file is
restored.

* Introduced in: 9.10

|restore_to.start_byte
|number
|query
|False
a|Starting byte offset of the source file, in multiples of 4096.

* Introduced in: 9.10

|restore_to.byte_count
|number
|query
|False
a|Number of bytes to restore from the source file, in multiples of 4096.
```

\* Introduced in: 9.10

|preserve\_lun\_ids

|boolean

|query

|False

a|Specifies whether LUN IDs need to be preserved during a Snapshot copy restore operation.

\* Introduced in: 9.10

\* Default value:

|nvfail

|string

|query

|False

a|When this option is "on", the filer performs additional work at boot time if it finds that there has been any potential data loss due to an NVRAM failure. In such situations, it causes the invalidation of all NFS file handles on all volumes affected by the problem so that client-side users are forced to remount the affected file system (and thus not continue to use potentially incorrect data). It is also possible to specify a set of files per volume that are renamed in such cases. The filer sends error messages to the console whenever such problems are found.

\* Introduced in: 9.10

\* enum: ["off", "on"]

|snapshot\_directory\_access\_enabled

|boolean

|query

|False

a|This field, if true, enables the visible ".snapshot" directory from the client. The ".snapshot" directory will be available in every directory on the volume.

\* Introduced in: 9.10

\* Default value: 1

|sizing\_method

|string

```

|query
|False
a|Represents the method to modify the size of a Flexgroup. The following
methods are supported:

* use_existing_resources - Increases or decreases the size of the
FlexGroup by increasing or decreasing the size of the current FlexGroup
resources
* add_new_resources - Increases the size of the FlexGroup by adding new
resources. This is limited to two new resources per available aggregate.
* Default value: 1
* enum: ["use_existing_resources", "add_new_resources"]

|scheduled_snapshot_naming_scheme
|string
|query
|False
a|Naming Scheme for automatic Snapshot copies:

* create_time - Automatic Snapshot copies are saved as per the start of
their current date and time.
* ordinal - Latest automatic snapshot copy is saved as
+++<scheduled_frequency>+++0 and subsequent copies will follow the
create_time naming convention.+++</scheduled_frequency>+++
* Introduced in: 9.10
* Default value: 1
* enum: ["create_time", "ordinal"]

</scheduled_frequency>

|clone.match_parent_storage_tier
|boolean
|query
|False
a|Specifies whether the FlexClone volume splits the data blocks by
matching its parent storage tier. This option is applicable only if the
tiering policy and the tiering minimum cooling days of the parent volume
and the FlexClone volume are the same.

* Introduced in: 9.9

|return_timeout
|integer
|query

```

```

|False
a|The number of seconds to allow the call to execute before returning.
When doing a POST, PATCH, or DELETE operation on a single record, the
default is 0 seconds. This means that if an asynchronous operation is
started, the server immediately returns HTTP code 202 (Accepted) along
with a link to the job. If a non-zero value is specified for POST, PATCH,
or DELETE operations, ONTAP waits that length of time to see if the job
completes so it can return something other than 202.

* Default value: 1
* Max value: 120
* Min value: 0

|validate_only
|boolean
|query
|False
a|Validate the operation and its parameters, without actually performing
the operation.

|===

== Request Body

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|access_time_enabled
|boolean
a|Indicates whether or not access time updates are enabled on the volume.

|activity_tracking
|link:#activity_tracking[activity_tracking]
a|

|aggregates

```

```
|array[link:#aggregates[aggregates]]
a|Aggregate hosting the volume. Required on POST.
```

```
|analytics
|link:#analytics[analytics]
a|
```

```
|anti_ransomware
|link:#anti_ransomware[anti_ransomware]
a|Anti-ransomware related information of the volume.
```

```
|anti_ransomware_state
|string
a|The Anti-ransomware state of the volume. If no "anti_ransomware_state" property is specified, the volume inherits the value from its parent SVM's "anti_ransomware_default_volume_state" property. If this value is "disabled", Anti-ransomware is disabled on the volume. If this value is "enabled", Anti-ransomware is enabled on the volume and alerts are raised if any suspect is detected for those volumes. If this value is "dry_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable_in_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry_run_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.
```

```
|application
|link:#application[application]
a|
```

```
|asynchronous_directory_delete
|link:#asynchronous_directory_delete[asynchronous_directory_delete]
a|Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.
```

```
|autosize
```



```
|link:#autosize[autosize]
```

```
a|
```

```
|clone
```

```
|link:#clone[clone]
```

```
a|
```

```
|cloud_retrieval_policy
```

```
|string
```

```
a|This parameter specifies the cloud retrieval policy for the volume. This policy determines which tiered out blocks to retrieve from the capacity tier to the performance tier. The available cloud retrieval policies are "default" policy retrieves tiered data based on the underlying tiering policy. If the tiering policy is 'auto', tiered data is retrieved only for random client driven data reads. If the tiering policy is 'none' or 'snapshot_only', tiered data is retrieved for random and sequential client driven data reads. If the tiering policy is 'all', tiered data is not retrieved.
```

```
"on_read" policy retrieves tiered data for all client driven data reads.
```

```
"never" policy never retrieves tiered data.
```

```
"promote" policy retrieves all eligible tiered data automatically during the next scheduled scan. It is only supported when the tiering policy is 'none' or 'snapshot_only'. If the tiering policy is 'snapshot_only', the only data brought back is the data in the AFS. Data that is only in a snapshot copy stays in the cloud and if tiering policy is 'none' then all data is retrieved.
```

```
|comment
```

```
|string
```

```
a|A comment for the volume. Valid in POST or PATCH.
```

```
|consistency_group
```

```
|link:#consistency_group[consistency_group]
```

```
a|Consistency group the volume is part of.
```

```
|constituents
```

```
|array[link:#constituents[constituents]]
```

```
a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more efficiently by specifying "is_constituent=true" or "is_constituent=true&flexgroup.uid=+++<flexgroup.uid>+++> as query parameters.+++</flexgroup.uid>+++>
```

```
|constituents_per_aggregate
```

```
|integer
a|Specifies the number of times to iterate over the aggregates listed with
the "aggregates.name" or "aggregates.uuid" when creating or expanding a
FlexGroup volume. If a volume is being created on a single aggregate, the
system creates a flexible volume if the "constituents_per_aggregate" field
is not specified, or a FlexGroup volume if it is specified. If a volume is
being created on multiple aggregates, the system always creates a
FlexGroup volume. The root constituent of a FlexGroup volume is always
placed on the first aggregate in the list.

|convert_unicode
|boolean
a|Specifies whether directory Unicode format conversion is enabled when
directories are accessed by NFS clients.

|create_time
|string
a|Creation time of the volume. This field is generated when the volume is
created.

|efficiency
|link:#efficiency[efficiency]
a|

|encryption
|link:#encryption[encryption]
a|

|error_state
|link:#error_state[error_state]
a|

|files
|link:#files[files]
a|

|flash_pool
|link:#flash_pool[flash_pool]
a|

|flexcache_endpoint_type
|string
a|FlexCache endpoint type.
none &dash; The volume is neither a FlexCache nor origin of any FlexCache.
```

cache &dash; The volume is a FlexCache volume.  
origin &dash; The volume is origin of a FlexCache volume.

|flexgroup  
|link:#flexgroup[flexgroup]  
a|

|granular\_data  
|boolean  
a|State of granular data on the volume. This setting is true by default when creating a new FlexGroup volume, but can be specified as false at the time of creation via a POST request. On FlexVol volumes, the setting is always false, as only FlexGroup volumes and FlexGroup constituents support this feature. Once enabled, this setting can only be disabled by restoring a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible with this feature. Therefore, reverting to an earlier version of ONTAP is not possible unless this volume is deleted or restored to a Snapshot copy that was taken before the setting was enabled.

\* Introduced in: 9.11

|guarantee  
|link:#guarantee[guarantee]  
a|

|idcs\_scanner  
|link:#idcs\_scanner[idcs\_scanner]  
a|Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(threshold\_inactive\_days). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

|is\_object\_store  
|boolean  
a|Specifies whether the volume is provisioned for an object store server.

|is\_svm\_root  
|boolean  
a|Specifies whether the volume is a root volume of the SVM it belongs to.

|language

```
|string
a|Language encoding setting for volume. If no language is specified, the
volume inherits its SVM language encoding setting.

|max_dir_size
|integer
a|Maximum directory size. This value sets maximum size, in bytes, to which
a directory can grow. The default maximum directory size for FlexVol
volumes is model-dependent, and optimized for the size of system memory.
Before increasing the maximum directory size, involve technical support.

|metric
|link:#metric[metric]
a|Performance numbers, such as IOPS, latency and throughput.

|movement
|link:#movement[movement]
a|Volume movement. All attributes are modify, that is, not writable
through POST. Set PATCH state to destination_aggregate to initiate a
volume move operation. Volume movement on FlexGroup constituents are not
supported.

|msid
|integer
a|The volume's Mirror Set ID.

|name
|string
a|Volume name. The name of volume must start with an alphabetic character
(a to z or A to Z) or an underscore (_). The name must be 197 or fewer
characters in length for FlexGroups, and 203 or fewer characters in length
for all other types of volumes. Volume names must be unique within an SVM.
Required on POST.

|nas
|link:#nas[nas]
a|

|qos
|link:#qos[qos]
a|QoS information
```

|queue\_for\_encryption  
|boolean  
a|Specifies whether the volume is queued for encryption.

|quota  
|link:#quota[quota]  
a|Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

|rebalancing  
|link:#rebalancing[rebalancing]  
a|Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

|scheduled\_snapshot\_naming\_scheme  
|string  
a|Naming Scheme for automatic Snapshot copies:

\* create\_time - Automatic Snapshot copies are saved as per the start of their current date and time.  
\* ordinal - Latest automatic snapshot copy is saved as +++<scheduled\_frequency>+++0 and subsequent copies will follow the create\_time naming convention.+++</scheduled\_frequency>+++

|size  
|integer  
a|Physical size of the volume, in bytes. The minimum size for a FlexVol volume is 20MB and the minimum size for a FlexGroup volume is 200MB per constituent. The recommended size for a FlexGroup volume is a minimum of 100GB per constituent. For all volumes, the default size is equal to the minimum size.

|snaplock  
|link:#snaplock[snaplock]  
a|

|snapmirror  
|link:#snapmirror[snapmirror]  
a|Specifies attributes for SnapMirror protection.

```
|snapshot_count
|integer
a|Number of Snapshot copies in the volume.
```

```
|snapshot_policy
|link:#snapshot_policy[snapshot_policy]
a|This is a reference to the Snapshot copy policy.
```

```
|space
|link:#space[space]
a|
```

```
|state
|string
a|Volume state. Client access is supported only when volume is online and
junctioned. Taking volume to offline or restricted state removes its
junction path and blocks client access. When volume is in restricted state
some operations like parity reconstruction and iron on commit are allowed.
The 'mixed' state applies to FlexGroup volumes only and cannot be
specified as a target state. An 'error' state implies that the volume is
not in a state to serve data.
```

```
|statistics
|link:#statistics[statistics]
a|These are raw performance numbers, such as IOPS latency and throughput.
These numbers are aggregated across all nodes in the cluster and increase
with the uptime of the cluster.
```

```
|status
|array[string]
a|Describes the current status of a volume.
```

```
|style
|string
a|The style of the volume. If "style" is not specified, the volume type is
determined based on the specified aggregates. Specifying a single
aggregate, without "constituents_per_aggregate", creates a flexible
volume. Specifying multiple aggregates, or a single aggregate with
"constituents_per_aggregate", creates a FlexGroup. Specifying a volume
"style" creates a volume of that type. For example, if the style is
"flexvol" you must specify a single aggregate. If the style is
```

"flexgroup", the system either uses the specified aggregates or automatically provisions aggregates if there are no specified aggregates. The style "flexgroup\_constituent" is not supported when creating a volume.

flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm  
|link:#svm[svm]  
a|SVM containing the volume. Required on POST.

|tiering  
|link:#tiering[tiering]  
a|

|type  
|string  
a|Type of the volume.  
rw &dash; read-write volume.  
dp &dash; data-protection volume.  
ls &dash; load-sharing `dp` volume. Valid in GET.

|use\_mirrored\_aggregates  
|boolean  
a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.

|uuid  
|string  
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7  
\* readOnly: 1  
\* Introduced in: 9.6

```
|===
```

```
.Example request
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "activity_tracking": {
    "state": "off",
    "unsupported_reason": {
      "code": "124518405",
      "message": "Volume activity tracking cannot be enabled on volumes
that contain LUNs."
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "analytics": {
    "scan_progress": 17,
    "state": "unknown",
    "unsupported_reason": {
      "code": "111411207",
      "message": "File system analytics cannot be enabled on volumes that
contain LUNs."
    }
  },
  "anti_ransomware": {
    "attack_probability": "none",
    "attack_reports": {
      "_links": {
        "suspects": {
          "href": "/api/resourcelink"
        }
      }
    }
  }
}
```



```

    }
  },
  "time": "2021-06-01T20:36:41+05:30"
},
"dry_run_start_time": "string",
"space": {
  "snapshot_count": 0,
  "used": 0,
  "used_by_logs": 0,
  "used_by_snapshots": 0
},
"state": "disabled",
"suspect_files": {
  "count": 0,
  "entropy": "string",
  "format": "string"
}
},
"anti_ransomware_state": "disabled",
"application": {
  "name": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"autosize": {
  "mode": "grow"
},
"clone": {
  "parent_snapshot": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "this_snapshot",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "parent_svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "parent_volume": {

```

```

    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "split_complete_percent": 0,
  "split_estimate": 0
},
"cloud_retrieval_policy": "default",
"comment": "string",
"consistency_group": {
  "name": "consistency_group_1",
  "uuid": "1cd8a442-86d1-11e0-ae1d-123478563412"
},
"constituents": {
  "aggregates": {
    "name": "string",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "movement": {
    "cutover_window": 30,
    "destination_aggregate": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "percent_complete": 0,
    "state": "replicating",
    "tiering_policy": "all"
  },
  "name": "string",
  "space": {
    "available": 0,
    "block_storage_inactive_user_data": 0,
    "capacity_tier_footprint": 0,
    "footprint": 0,
    "local_tier_footprint": 0,
    "logical_space": {
      "available": 0,

```

```
    "used_by_afs": 0
  },
  "metadata": 0,
  "over_provisioned": 0,
  "performance_tier_footprint": 0,
  "snapshot": {
    "used": 0
  },
  "total_footprint": 0,
  "used": 0
}
},
"create_time": "2018-06-04T19:00:00Z",
"efficiency": {
  "application_io_size": "8k",
  "compaction": "inline",
  "compression": "inline",
  "compression_type": "none",
  "cross_volume_dedupe": "inline",
  "dedupe": "inline",
  "last_op_begin": "string",
  "last_op_end": "string",
  "last_op_err": "string",
  "last_op_size": 0,
  "last_op_state": "string",
  "op_state": "idle",
  "path": "string",
  "progress": "string",
  "scanner": {
    "state": "idle"
  },
},
"schedule": "string",
"space_savings": {
  "compression": 0,
  "compression_percent": 0,
  "dedupe": 0,
  "dedupe_percent": 0,
  "dedupe_sharing": 0,
  "total": 0,
  "total_percent": 0
},
"state": "disabled",
"storage_efficiency_mode": "default",
"type": "regular"
},
"encryption": {
```

```
"key_create_time": "2022-01-01T19:00:00Z",
"key_id": "string",
"key_manager_attribute": "CRN=v1:bluemix:public:containers-
kubernetes:us-south:a/asdfghjkl1234:asdfghjkl1234:worker:kubernetes-
asdfghjkl-worker1",
"state": "encrypted",
"status": {
  "code": "string",
  "message": "string"
},
"type": "none"
},
"files": {
  "used": 0
},
"flash_pool": {
  "cache_eligibility": "read",
  "cache_retention_priority": "normal",
  "caching_policy": "none"
},
"flexcache_endpoint_type": "none",
"flexgroup": {
  "name": "my_flexgroup",
  "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
},
"guarantee": {
  "type": "volume"
},
"idcs_scanner": {
  "mode": "default",
  "operation_state": "idle",
  "status": "success"
},
"language": "ar",
"metric": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  }
},
"cloud": {
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  }
}
```

```

    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "duration": "PT15S",
  "flexcache": {
    "bandwidth_savings": 4096,
    "cache_miss_percent": 20,
    "duration": "PT1D",
    "status": "ok",
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
},
"movement": {
  "cutover_window": 30,
  "destination_aggregate": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
},

```

```

    "percent_complete": 0,
    "start_time": "2020-12-07T03:45:12-05:00",
    "state": "replicating",
    "tiering_policy": "all"
  },
  "name": "vol_cs_dept",
  "nas": {
    "export_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 100,
      "name": "default"
    },
    "junction_parent": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "vs1_root",
      "uuid": "75c9cfb0-3eb4-11eb-9fb4-005056bb088a"
    },
    "path": "/user/my_volume",
    "security_style": "mixed",
    "unix_permissions": 755
  },
  "qos": {
    "policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "max_throughput_iops": 10000,
      "max_throughput_mbps": 500,
      "min_throughput_iops": 2000,
      "min_throughput_mbps": 500,
      "name": "performance",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "quota": {
    "state": "corrupt"
  }
}

```

```

},
"rebalancing": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "data_moved": 0,
  "failure_reason": {
    "code": "string",
    "message": "string"
  },
  "imbalance_percent": 0,
  "imbalance_size": 0,
  "max_constituent_imbalance_percent": 0,
  "runtime": "string",
  "start_time": "string",
  "state": "rebalancing",
  "stop_time": "string",
  "target_used": 0
},
"scheduled_snapshot_naming_scheme": "create_time",
"snaplock": {
  "append_mode_enabled": "",
  "autocommit_period": "P30M",
  "compliance_clock_time": "2018-06-04T19:00:00Z",
  "expiry_time": "Wed Sep 5 11:02:42 GMT 2018",
  "is_audit_log": 1,
  "litigation_count": 10,
  "privileged_delete": "enabled",
  "retention": {
    "default": "P30Y",
    "maximum": "P30Y",
    "minimum": "P30Y"
  },
  "type": "enterprise",
  "unspecified_retention_file_count": 10
},
"snapshot_count": 0,
"snapshot_policy": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "default",

```

```
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"space": {
  "auto_adaptive_compression_footprint_data_reduction": 0,
  "available": 0,
  "block_storage_inactive_user_data": 0,
  "block_storage_inactive_user_data_percent": 0,
  "capacity_tier_footprint": 0,
  "cross_volume_dedupe_metafiles_footprint": 0,
  "cross_volume_dedupe_metafiles_temporary_footprint": 0,
  "dedupe_metafiles_footprint": 0,
  "dedupe_metafiles_temporary_footprint": 0,
  "delayed_free_footprint": 0,
  "effective_total_footprint": 0,
  "file_operation_metadata": 0,
  "filesystem_size": 0,
  "footprint": 0,
  "local_tier_footprint": 0,
  "logical_space": {
    "available": 0,
    "used": 0,
    "used_by_afs": 0,
    "used_by_snapshots": 0,
    "used_percent": 0
  },
  "metadata": 0,
  "over_provisioned": 0,
  "overwrite_reserve": 0,
  "overwrite_reserve_used": 0,
  "percent_used": 0,
  "performance_tier_footprint": 0,
  "size_available_for_snapshots": 0,
  "snapmirror_destination_footprint": 0,
  "snapshot": {
    "autodelete_trigger": "volume",
    "reserve_available": 0,
    "reserve_size": 0,
    "space_used_percent": 0,
    "used": 0
  },
  "snapshot_reserve_unusable": 0,
  "snapshot_spill": 0,
  "total_footprint": 0,
  "used": 0,
  "user_data": 0,
  "volume_guarantee_footprint": 0
}
```



```
},
"state": "error",
"statistics": {
  "cifs_ops_raw": {
    "access": {
      "count": 1000,
      "total_time": 200
    },
    "audit": {
      "count": 1000,
      "total_time": 200
    },
    "create": {
      "dir": {
        "count": 1000,
        "total_time": 200
      },
      "file": {
        "count": 1000,
        "total_time": 200
      },
      "other": {
        "count": 1000,
        "total_time": 200
      },
      "symlink": {
        "count": 1000,
        "total_time": 200
      }
    },
    "getattr": {
      "count": 1000,
      "total_time": 200
    },
    "link": {
      "count": 1000,
      "total_time": 200
    },
    "lock": {
      "count": 1000,
      "total_time": 200
    },
    "lookup": {
      "count": 1000,
      "total_time": 200
    }
  }
},
```



```
0,  
0  
],  
"volume_protocol_latency_histogram_labels": [  
  "<2us",  
  "<6us",  
  "<10us",  
  "<14us",  
  "<20us",  
  "<40us",  
  "<60us",  
  "<80us",  
  "<100us",  
  "<200us",  
  "<400us",  
  "<600us",  
  "<800us",  
  "<1ms",  
  "<2ms",  
  "<4ms",  
  "<6ms",  
  "<8ms",  
  "<10ms",  
  "<12ms",  
  "<14ms",  
  "<16ms",  
  "<18ms",  
  "<20ms",  
  "<40ms",  
  "<60ms",  
  "<80ms",  
  "<100ms",  
  "<200ms",  
  "<400ms",  
  "<600ms",  
  "<800ms",  
  "<1s",  
  "<2s",  
  "<4s",  
  "<6s",  
  "<8s",  
  "<10s",  
  "<20s",  
  ">20s"  
],  
"volume_protocol_size_histogram_counts": [  

```

```

    2400,
    1055,
    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},

```



```
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
0,  
],  
"volume_protocol_latency_histogram_labels": [  
  "<2us",  
  "<6us",  
  "<10us",  
  "<14us",  
  "<20us",  
  "<40us",  
  "<60us",  
  "<80us",  
  "<100us",  
  "<200us",  
  "<400us",  
  "<600us",  
  "<800us",  
  "<1ms",  
  "<2ms",  
  "<4ms",  
  "<6ms",  
  "<8ms",  
  "<10ms",  
  "<12ms",  
  "<14ms",  
  "<16ms",  
  "<18ms",  
  "<20ms",  
  "<40ms",  
  "<60ms",  
  "<80ms",  
  "<100ms",  
  "<200ms",  
  "<400ms",  
  "<600ms",  
  "<800ms",  
  "<1s",  
  "<2s",
```

```

    "<4s",
    "<6s",
    "<8s",
    "<10s",
    "<20s",
    ">20s"
  ],
  "volume_protocol_size_histogram_counts": [
    2400,
    1055,
    1100,
    700,
    500,
    300,
    200,
    100,
    100,
    50,
    50,
    75,
    25,
    0,
    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
}
},
"cloud": {
  "iops_raw": {
    "read": 200,

```

```

    "total": 1000,
    "write": 100
  },
  "latency_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "timestamp": "2017-01-25T11:20:13Z"
},
"flexcache_raw": {
  "cache_miss_blocks": 10,
  "client_requested_blocks": 500,
  "status": "ok",
  "timestamp": "2017-01-25T11:20:13Z"
},
"iops_raw": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"latency_raw": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"nfs_ops_raw": {
  "access": {
    "count": 1000,
    "total_time": 200
  },
  "audit": {
    "count": 1000,
    "total_time": 200
  },
  "create": {
    "dir": {
      "count": 1000,
      "total_time": 200
    },
    "file": {
      "count": 1000,
      "total_time": 200
    }
  },
  "other": {

```



```
    "count": 1000,  
    "total_time": 200  
  },  
  "symlink": {  
    "count": 1000,  
    "total_time": 200  
  }  
},  
"getattr": {  
  "count": 1000,  
  "total_time": 200  
},  
"link": {  
  "count": 1000,  
  "total_time": 200  
},  
"lock": {  
  "count": 1000,  
  "total_time": 200  
},  
"lookup": {  
  "count": 1000,  
  "total_time": 200  
},  
"open": {  
  "count": 1000,  
  "total_time": 200  
},  
"read": {  
  "count": 1000,  
  "total_time": 200,  
  "volume_protocol_latency_histogram_counts": [  
    0,  
    0,  
    0,  
    0,  
    0,  
    15,  
    35,  
    100,  
    200,  
    200,  
    300,  
    500,  
    500,  
    500,  
  ]  
}
```



```
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
  0
],
"volume_protocol_size_histogram_labels": [
  "< 4KB",
  "= 4KB",
  "< 8KB",
  "= 8KB",
  "< 16KB",
```

```

    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
},
"readdir": {
  "count": 1000,
  "total_time": 200
},
"readlink": {
  "count": 1000,
  "total_time": 200
},
"rename": {
  "count": 1000,
  "total_time": 200
},
"setattr": {
  "count": 1000,
  "total_time": 200
},
"unlink": {
  "count": 1000,
  "total_time": 200
},
"watch": {
  "count": 1000,
  "total_time": 200
},
"write": {
  "count": 1000,
  "total_time": 200,
  "volume_protocol_latency_histogram_counts": [
    0,
    0,
    0,
    0,
    0,
    15,

```



```
"<400us",
"<600us",
"<800us",
"<1ms",
"<2ms",
"<4ms",
"<6ms",
"<8ms",
"<10ms",
"<12ms",
"<14ms",
"<16ms",
"<18ms",
"<20ms",
"<40ms",
"<60ms",
"<80ms",
"<100ms",
"<200ms",
"<400ms",
"<600ms",
"<800ms",
"<1s",
"<2s",
"<4s",
"<6s",
"<8s",
"<10s",
"<20s",
">20s"
],
"volume_protocol_size_histogram_counts": [
  2400,
  1055,
  1100,
  700,
  500,
  300,
  200,
  100,
  100,
  50,
  50,
  75,
  25,
  0,
```

```

    0
  ],
  "volume_protocol_size_histogram_labels": [
    "< 4KB",
    "= 4KB",
    "< 8KB",
    "= 8KB",
    "< 16KB",
    "= 16KB",
    "< 32KB",
    "= 32KB",
    "< 64KB",
    "= 64KB",
    "< 256KB",
    "= 256KB",
    "< 1024KB",
    "= 1024KB",
    "> 1024KB"
  ]
}
},
"status": "ok",
"throughput_raw": {
  "read": 200,
  "total": 1000,
  "write": 100
},
"timestamp": "2017-01-25T11:20:13Z"
},
"status": {
},
"style": "flexvol",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"tiering": {
  "object_tags": {
  },
  "policy": "all"
},
},

```

```
"type": "rw",
"uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
====
== Response
```

Status: 202, Accepted

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===

.Example response
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
====

== Error
```

Status: Default

```
ONTAP Error Response Codes

|===
```



| Error Code | Description   |
|------------|---|
| 787141     | The specified "aggregates.name" and "aggregates.uuid" refer to different aggregates.                              |
| 917829     | Volume autosize grow threshold must be larger than autosize shrink threshold.                                     |
| 917831     | Volume minimum autosize must be smaller than the maximum autosize.  |
| 918193     | Cannot modify tiering min cooling days when vol move is in progress.  |
| 918194     | Tiering min cooling days not supported for SVMDR.   |
| 918195     | Tiering min cooling days not supported for non data volumes.  |
| 918196     | Tiering min cooling days not allowed for the provided tiering policy.   |
| 918248     | Specifying a value is not valid for initiating volume FlexClone split operation.                                  |
| 918251     | Specifying a value is not valid for a Snapshot copy restore operation.  |
| 918252     | specified "nas.path" is invalid.  |
| 918265     | Volume is on the same aggregate.  |
| 918266     | "movement.destination_aggregate" and "movement.state" are mutually exclusive, unless the state is "cutover-wait". |
| 918267     | The specified "movement.destination_aggregate" does not exist.  |
| 918291     | Invalid volume cloud retrieval policy for the provided tiering policy.  |

| 918292  
| cloud retrieval policy not supported for non data volume.

| 918293  
| Cannot modify cloud retrieval policy when vol move is in progress.

| 918521  
| The volume maximum autosize must be smaller than or equal to the maximum volume size.

| 918532  
| The FlexClone match-parent-storage-tier option requires an effective cluster version of 9.9.1 or later.

| 918533  
| The FlexClone match-parent-storage-tier option not applicable for FlexClone volumes hosted on non-FabricPool storage.

| 918534  
| The tiering policy values are different for the FlexClone volume and its parent volume. The match-parent-storage-tier option cannot be set to true.

| 918535  
| The tiering minimum cooling day values are different for the FlexClone volume and its parent volume. The match-parent-storage-tier option cannot be set to true.

| 918537  
| Could not get the FlexClone volume tiering policy or its parent volume tiering policy. Wait a minute and try again.

| 918538  
| The match-parent-storage-tier option is not supported for clone creation.

| 13107404  
| When adding new resources to a FlexGroup by specifying "aggregates.name" or "aggregates.uuid", the FlexGroup cannot be resized using "size". These operations must be done separately.

| 13109187  
| When adding new resources to a FlexGroup using "sizing\_method", "size" must be specified. Neither "aggregates.name" nor "aggregates.uuid" are allowed to be specified, as the aggregates are selected automatically by the system.

```
| 13109198
| Resizing by adding new resources is only supported for FlexGroups.

| 111411201
| File system analytics cannot be enabled on the target volume because of
the specified reason.

| 111411202
| File system analytics cannot be disabled on the target volume because of
the specified reason.

| 111411205
| File system analytics requires an effective cluster version of 9.8 or
later.

| 111411206
| The specified "analytics.state" is invalid.

| 111411207
| File system analytics cannot be enabled on volumes that contain LUNs.
|===
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|error
```

```
|link:#error[error]
```

```
a|
```

```
|===
```

```
.Example error
```

```
[%collapsible%closed]
```

```
=====
```

```
[source,json,subs=+macros]
```

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },

```

```
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

====

== Definitions

```
[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
```

====

```
[#href]
[.api-collapsible-fifth-title]
href
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|href
|string
a|
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```

[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If volume activity tracking is not supported on the volume, this field
provides an appropriate error code.

|message
|string
a|If volume activity tracking is not supported on the volume, this field
provides an error message detailing why this is the case.

|===

[#activity_tracking]
[.api-collapsible-fifth-title]
activity_tracking

[cols=3*,options=header]
|===
|Name
|Type
|Description

|state
|string
a|Activity tracking state of the volume. If this value is "on", ONTAP
collects top metrics information for the volume in real time. There is a
slight impact to I/O performance in order to collect this information. If
this value is "off", no activity tracking information is collected or
available to view.

* enum: ["off", "on"]
* Introduced in: 9.10

```

```
|supported
|boolean
a|This field indicates whether or not volume activity tracking is
supported on the volume. If volume activity tracking is not supported, the
reason why is provided in the "activity_tracking.unsupported_reason"
field.
```

```
|unsupported_reason
|link:#unsupported_reason[unsupported_reason]
a|
```

```
|===
```

```
[#aggregates]
[.api-collapsible-fifth-title]
aggregates
```

Aggregate

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|
```

```
|uuid
|string
a|
```

```
|===
```

```
[#unsupported_reason]
[.api-collapsible-fifth-title]
unsupported_reason
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|If file system analytics is not supported on the volume, this field
provides the error code explaining why.
```

```
|message
|string
a|If file system analytics is not supported on the volume, this field
provides the error message explaining why.
```

```
|===
```

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|scan_progress
|integer
a|Percentage of files in the volume that the file system analytics
initialization scan has processed. Only returned when the state is
`initializing`.
```

```
|state
|string
a|File system analytics state of the volume. If this value is "on", ONTAP
collects extra file system analytics information for all directories on
the volume. There will be a slight impact to I/O performance to collect
this information. If this value is "off", file system analytics
information is not collected and not available to be viewed. If this value
is "initializing", that means file system analytics was recently turned
```

on, and the initialization scan to gather information all all existing files and directories is currently running. If this value is 'unknown' that means there was an internal error when determining the file system analytics state for the volume.

\* enum: ["unknown", "initializing", "off", "on"]

\* Introduced in: 9.8

|supported

|boolean

a|This field indicates whether or not file system analytics is supported on the volume. If file system analytics is not supported, the reason will be specified in the "analytics.unsupported\_reason" field.

|unsupported\_reason

|link:#unsupported\_reason[unsupported\_reason]

a|

|===

[#\_links]

[.api-collapsible-fifth-title]

\_links

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|suspects

|link:#href[href]

a|

|===

[#anti\_ransomware\_attack\_report]

[.api-collapsible-fifth-title]

anti\_ransomware\_attack\_report

[cols=3\*,options=header]

|===

|Name



```

|Type
|Description

|_links
|link:#_links[_links]
a|

|time
|string
a|Timestamp at which ransomware attack is observed.

|===

[#space]
[.api-collapsible-fifth-title]
space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|snapshot_count
|integer
a|Total number of Anti-ransomware backup Snapshot copies.

|used
|integer
a|Total space in bytes used by the Anti-ransomware feature.

|used_by_logs
|integer
a|Space in bytes used by the Anti-ransomware analytics logs.

|used_by_snapshots
|integer
a|Space in bytes used by the Anti-ransomware backup Snapshot copies.

|===

```

```

[#suspect_files]
[.api-collapsible-fifth-title]
suspect_files

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Total number of `suspect_files.format` files observed by the Anti-
ransomware analytics engine on the volume.

|entropy
|string
a|Indicates the entropy level of this file type.

|format
|string
a|File formats observed by the Anti-ransomware analytics engine on the
volume.

|===

[#anti_ransomware]
[.api-collapsible-fifth-title]
anti_ransomware

Anti-ransomware related information of the volume.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|attack_probability
|string
a|Probability of a ransomware attack.

```

```

`none` No files are suspected of ransomware activity.
`low` A number of files are suspected of ransomware activity.
`moderate` A moderate number of files are suspected of ransomware
activity.
`high` A large number of files are suspected of ransomware activity.

|attack_reports
|array[link:#anti_ransomware_attack_report[anti_ransomware_attack_report]]
a|

|dry_run_start_time
|string
a|Time when Anti-ransomware monitoring `state` is set to dry-run value for
starting evaluation mode.

|space
|link:#space[space]
a|

|state
|string
a|Anti-ransomware state.
`disabled` Anti-ransomware monitoring is disabled on the volume. This is
the default state in a POST operation.
`disable_in_progress` Anti-ransomware monitoring is being disabled and a
cleanup operation is in effect. Valid in GET operation.
`dry_run` Anti-ransomware monitoring is enabled in the evaluation mode.
`enabled` Anti-ransomware monitoring is active on the volume.
`paused` Anti-ransomware monitoring is paused on the volume.
`enable_paused` Anti-ransomware monitoring is paused on the volume from
its earlier enabled state. Valid in GET operation.
`dry_run_paused` Anti-ransomware monitoring is paused on the volume from
its earlier dry_run state. Valid in GET operation.
For POST, the valid Anti-ransomware states are only `disabled`, `enabled`
and `dry_run`, whereas for PATCH, `paused` is also valid along with the
three valid states for POST.

|surge_as_normal
|boolean
a|Indicates whether or not to set the surge values as historical values.

|suspect_files
|array[link:#suspect_files[suspect_files]]

```

```

a|

|===

[#application]
[.api-collapsible-fifth-title]
application

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|Name of the application to which the volume belongs. Available only when
the volume is part of an application.

|uuid
|string
a|UUID of the application to which the volume belongs. Available only when
the volume is part of an application.

|===

[#asynchronous_directory_delete]
[.api-collapsible-fifth-title]
asynchronous_directory_delete

Configuration for asynchronous directory delete from the client. This is
only supported on Flexible volumes and FlexGroup volumes.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|enabled
|boolean
a|Specifies whether asynchronous directory delete from the client is

```

enabled on the volume.

|trash\_bin

|string

a|Name of the trash bin directory. If no "trash\_bin" property is specified when enabling, the default trash bin name, ".\_ontaptrashbin", is used.

|===

[#autosize]

[.api-collapsible-fifth-title]

autosize

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|grow\_threshold

|integer

a|Used space threshold size, in percentage, for the automatic growth of the volume. When the amount of used space in the volume becomes greater than this threshold, the volume automatically grows unless it has reached the maximum size. The volume grows when 'space.used' is greater than this percent of 'space.size'. The 'grow\_threshold' size cannot be less than or equal to the 'shrink\_threshold' size..

|maximum

|integer

a|Maximum size in bytes up to which a volume grows automatically. This size cannot be less than the current volume size, or less than or equal to the minimum size of volume.

|minimum

|integer

a|Minimum size in bytes up to which the volume shrinks automatically. This size cannot be greater than or equal to the maximum size of volume.

|mode

|string

a|Autosize mode for the volume.  
grow &dash; Volume automatically grows when the amount of used space is above the 'grow\_threshold' value.  
grow\_shrink &dash; Volume grows or shrinks in response to the amount of space used.  
off &dash; Autosizing of the volume is disabled.

|shrink\_threshold  
|integer  
a|Used space threshold size, in percentage, for the automatic shrinkage of the volume. When the amount of used space in the volume drops below this threshold, the volume automatically shrinks unless it has reached the minimum size. The volume shrinks when the 'space.used' is less than the 'shrink\_threshold' percent of 'space.size'. The 'shrink\_threshold' size cannot be greater than or equal to the 'grow\_threshold' size.

|===

[#snapshot\_reference]  
[.api-collapsible-fifth-title]  
snapshot\_reference

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|\_links

|link:#\_links[\_links]

a|

|name

|string

a|

|uuid

|string

a|

|===

[#parent\_svm]

```

[.api-collapsible-fifth-title]
parent_svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#parent_volume]
[.api-collapsible-fifth-title]
parent_volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string

```

a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7

\* Introduced in: 9.6

|===

[#clone]

[.api-collapsible-fifth-title]

clone

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|is\_flexclone

|boolean

a|Specifies if this volume is a normal FlexVol or FlexClone. This field needs to be set when creating a FlexClone. Valid in POST.

|parent\_snapshot

|link:#snapshot\_reference[snapshot\_reference]

a|

|parent\_svm

|link:#parent\_svm[parent\_svm]

a|

|parent\_volume

|link:#parent\_volume[parent\_volume]

a|

|split\_complete\_percent

|integer

a|Percentage of FlexClone blocks split from its parent volume.

|split\_estimate

|integer

a|Space required by the containing-aggregate to split the FlexClone



volume.

|split\_initiated

|boolean

a|This field is set when split is executed on any FlexClone, that is when the FlexClone volume is split from its parent FlexVol. This field needs to be set for splitting a FlexClone form FlexVol. Valid in PATCH.

|===

[#consistency\_group]

[.api-collapsible-fifth-title]

consistency\_group

Consistency group the volume is part of.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|name

|string

a|The name of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

|uuid

|string

a|The UUID of the consistency group to which the volume belongs. Available only when the volume is part of a consistency group. If this volume belongs to a child consistency group, then this will be the UUID of the parent consistency group.

|===

[#aggregates]

[.api-collapsible-fifth-title]

aggregates

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

```
a|Name of the aggregate hosting the FlexGroup Constituent.
```

```
|uuid
```

```
|string
```

```
a|Unique identifier for the aggregate.
```

```
|===
```

```
[#destination_aggregate]
```

```
[.api-collapsible-fifth-title]
```

```
destination_aggregate
```

Aggregate

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|uuid
```

```
|string
```

```
a|
```

```
|===
```

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cutover_window
```

```
|integer
```

```
a|Time window in seconds for cutover. The allowed range is between 30 to 300 seconds.
```

```
|destination_aggregate
```

```
|link:#destination_aggregate[destination_aggregate]
```

```
a|Aggregate
```

```
|percent_complete
```

```
|integer
```

```
a|Completion percentage
```

```
|state
```

```
|string
```

```
a|State of volume move operation. PATCH the state to "aborted" to abort the move operation. PATCH the state to "cutover" to trigger cutover. PATCH the state to "paused" to pause the volume move operation in progress. PATCH the state to "replicating" to resume the paused volume move operation. PATCH the state to "cutover_wait" to go into cutover manually. When volume move operation is waiting to go into "cutover" state, this is indicated by the "cutover_pending" state. A change of state is only supported if volume movement is in progress.
```

```
|tiering_policy
```

```
|string
```

a|Tiering policy for FabricPool

|===

[#logical\_space]

[.api-collapsible-fifth-title]

logical\_space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|available

|integer

a|The amount of space available in this volume with storage efficiency space considered used, in bytes.

|enforcement

|boolean

a|Specifies whether space accounting for operations on the volume is done along with storage efficiency.

|reporting

|boolean

a|Specifies whether space reporting on the volume is done along with storage efficiency.

|used\_by\_afs

|integer

a|The virtual space used by AFS alone (includes volume reserves) and along with storage efficiency, in bytes.

|===

[#snapshot]

[.api-collapsible-fifth-title]

snapshot

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|autodelete_enabled
|boolean
a|Specifies whether Snapshot copy autodelete is currently enabled on this
volume.

|reserve_percent
|integer
a|The space that has been set aside as a reserve for Snapshot copy usage,
in percent.

|used
|integer
a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]
[.api-collapsible-fifth-title]
space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|afs_total
|integer
a|Total size of AFS, excluding snap-reserve, in bytes.

|available
|integer
a|The available space, in bytes.

|available_percent

```

```
|integer
a|The space available, as a percent.

|block_storage_inactive_user_data
|integer
a|The size that is physically used in the block storage of the volume and
has a cold temperature. In bytes. This parameter is only supported if the
volume is in an aggregate that is either attached to a cloud store or
could be attached to a cloud store.

|capacity_tier_footprint
|integer
a|Space used by capacity tier for this volume in the FabricPool aggregate,
in bytes.

|footprint
|integer
a|Data used for this volume in the aggregate, in bytes.

|local_tier_footprint
|integer
a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical_space
|link:#logical_space[logical_space]
a|

|metadata
|integer
a|Space used by the volume metadata in the aggregate, in bytes.

|over_provisioned
|integer
a|The amount of space not available for this volume in the aggregate, in
bytes.

|performance_tier_footprint
|integer
a|Space used by the performance tier for this volume in the FabricPool
aggregate, in bytes.
```

```
|size
|integer
a|Total provisioned size. The default size is equal to the minimum size of
20MB, in bytes.
```

```
|snapshot
|link:#snapshot[snapshot]
a|
```

```
|total_footprint
|integer
a|Data and metadata used for this volume in the aggregate, in bytes.
```

```
|used
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.
```

```
|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.
```

```
|used_percent
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, as a percent.
```

```
|===
```

```
[#constituents]
[.api-collapsible-fifth-title]
constituents
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```

|aggregates
|link:#aggregates[aggregates]
a|

|movement
|link:#movement[movement]
a|Volume movement. All attributes are modify, that is, not writable
through POST. Set PATCH state to destination_aggregate to initiate a
volume move operation. Volume movement on FlexGroup constituents are not
supported.

|name
|string
a|FlexGroup Constituents name.

|space
|link:#space[space]
a|

|===

[#policy]
[.api-collapsible-fifth-title]
policy

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|Specifies the name of the efficiency policy.

|===

[#scanner]
[.api-collapsible-fifth-title]
scanner

[cols=3*,options=header]

```



```

|===
|Name
|Type
|Description

|compression
|boolean
a|Start compression if scanning old data. Valid for PATCH and GET.

|dedupe
|boolean
a|Start deduplication if scanning old data. Valid for PATCH and GET.

|scan_old_data
|boolean
a|Indicates whether or not to scan old data. Valid for PATCH and GET.

|state
|string
a|State of the volume efficiency scanner. Valid for PATCH and GET. Valid
options for PATCH are "idle" and "active".

|===

[#space_savings]
[.api-collapsible-fifth-title]
space_savings

[cols=3*,options=header]
|===
|Name
|Type
|Description

|compression
|integer
a|Total disk space that is saved by compressing blocks on the referenced
file system, in bytes.

|compression_percent
|integer

```

a|Percentage of total disk space that is saved by compressing blocks on the referenced file system.

|dedupe

|integer

a|Total disk space that is saved by deduplication and file cloning, in bytes.

|dedupe\_percent

|integer

a|Percentage of total disk space that is saved by deduplication and file cloning.

|dedupe\_sharing

|integer

a|Total disk space that is shared due to deduplication and file cloning.

|total

|integer

a|Total disk space saved in the volume due to deduplication, compression and file cloning, in bytes.

|total\_percent

|integer

a|Percentage of total disk space saved in the volume due to deduplication, compression and file cloning.

|===

[#efficiency]

[.api-collapsible-fifth-title]

efficiency

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|application\_io\_size

|string  
a|Block size to use by compression.

|compaction

|string

a|The system can be enabled/disabled compaction.

inline &dash; Data will be compacted first and written to the volume.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are compaction enabled and some are disabled.

|compression

|string

a|The system can be enabled/disabled compression.

inline &dash; Data will be compressed first and written to the volume.

background &dash; Data will be written to the volume and compressed later.

both &dash; Inline compression compresses the data and write to the

volume, background compression compresses only the blocks on which inline compression is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are compression enabled and some are disabled.

NOTE: that On volumes with container compression enabled, background compression refers to inactive data compression scan enabled on the volume.

|compression\_type

|string

a|Compression type to use by compression. Valid for PATCH and GET.

|cross\_volume\_dedupe

|string

a|The system can be enabled/disabled cross volume dedupe. it can be enabled only when dedupe is enabled.

inline &dash; Data will be cross volume deduped first and written to the volume.

background &dash; Data will be written to the volume and cross volume deduped later.

both &dash; Inline cross volume dedupe dedupes the data and write to the volume, background cross volume dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are cross volume dedupe enabled and some are disabled.

|dedupe

|string

a|The system can be enabled/disabled dedupe.

inline &dash; Data will be deduped first and written to the volume.

background &dash; Data will be written to the volume and deduped later.

both &dash; Inline dedupe dedupes the data and write to the volume,

background dedupe dedupes only the blocks on which inline dedupe is not run.

none &dash; None

mixed &dash; Read only field for FlexGroups, where some of the constituent volumes are dedupe enabled and some are disabled.

|has\_savings

|boolean

a|When true, indicates that the volume contains shared(deduplication, file clones) or compressed data.

|last\_op\_begin

|string

a|Last sis operation begin timestamp.

|last\_op\_end

|string

a|Last sis operation end timestamp.

|last\_op\_err

|string

a|Last sis operation error text.

|last\_op\_size

|integer

a|Last sis operation size.

|last\_op\_state

|string

a|Last sis operation state.

|logging\_enabled  
|boolean  
a|When true, indicates that space savings for any newly-written data are being logged.

|op\_state  
|string  
a|Sis status of the volume.

|path  
|string  
a|Absolute volume path of the volume.

|policy  
|link:#policy[policy]  
a|

|progress  
|string  
a|Sis progress of the volume.

|scanner  
|link:#scanner[scanner]  
a|

|schedule  
|string  
a|Schedule associated with volume.

|space\_savings  
|link:#space\_savings[space\_savings]  
a|

|state  
|string  
a|Storage efficiency state of the volume. Currently, this field supports POST/PATCH only for RW (Read-Write) volumes on FSx for ONTAP and Cloud Volumes ONTAP.  
disabled &dash; All storage efficiency features are disabled.  
mixed &dash; Read-only field for FlexGroup volumes, storage efficiency is

enabled on certain constituents and disabled on others.

On FSx for ONTAP and Cloud Volumes ONTAP &dash;

&nbsp; enabled &dash; All supported storage efficiency features for the volume are enabled.

&nbsp; custom &dash; Read-only field currently only supported for the FSx for ONTAP and Cloud Volumes ONTAP, user-defined storage efficiency features are enabled.

For other platforms &dash;

&nbsp; enabled &dash; At least one storage efficiency feature for the volume is enabled.

\* enum: ["disabled", "enabled", "mixed", "custom"]

\* Introduced in: 9.9

|storage\_efficiency\_mode

|string

a|Storage efficiency mode used by volume. This parameter is supported only on AFF platform.

|type

|string

a|Sis Type of the volume.

|===

[#status]

[.api-collapsible-fifth-title]

status

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|code

|string

a|Encryption progress message code.

|message

|string

a|Encryption progress message.

```
|===
```

```
[#encryption]  
[.api-collapsible-fifth-title]  
encryption
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|enabled
```

```
|boolean
```

```
a|Creates an encrypted or an unencrypted volume. For POST, when set to 'true', a new key is generated and used to encrypt the given volume. In that case, the underlying SVM must be configured with the key manager. When set to 'false', the volume created will be unencrypted. For PATCH, when set to 'true', it encrypts an unencrypted volume. Specifying the parameter as 'false' in a PATCH operation for an encrypted volume is only supported when moving the volume to another aggregate.
```

```
|key_create_time
```

```
|string
```

```
a|Encryption key creation time of the volume.
```

```
|key_id
```

```
|string
```

```
a|The key ID used for creating encrypted volume. A new key-id is generated for creating an encrypted volume. This key-id is associated with the generated key.
```

```
|key_manager_attribute
```

```
|string
```

```
a|Specifies an additional key manager attribute that is an identifier-value pair, separated by '='. For example, CRN=unique-value. This parameter is required when using the POST method and an IBM Key Lore key manager is configured on the SVM.
```

```
|rekey
```

```

|boolean
a|If set to 'true', re-encrypts the volume with a new key. Valid in PATCH.

|state
|string
a|Volume encryption state.
encrypted &dash; The volume is completely encrypted.
encrypting &dash; Encryption operation is in progress.
partial &dash; Some constituents are encrypted and some are not.
Applicable only for FlexGroup volume.
rekeying. Encryption of volume with a new key is in progress.
unencrypted &dash; The volume is a plain-text one.

|status
|link:#status[status]
a|

|type
|string
a|Volume encryption type.
none &dash; The volume is a plain-text one.
volume &dash; The volume is encrypted with NVE (NetApp Volume Encryption).
aggregate &dash; The volume is encrypted with NAE (NetApp Aggregate
Encryption).

|===

[#error_state]
[.api-collapsible-fifth-title]
error_state

[cols=3*,options=header]
|===
|Name
|Type
|Description

|has_bad_blocks
|boolean
a|Indicates whether the volume has any corrupt data blocks. If the damaged
data block is accessed, an IO error, such as EIO for NFS or
STATUS_FILE_CORRUPT for CIFS, is returned.

```



```
|is_inconsistent
|boolean
a|Indicates whether the file system has any inconsistencies.
true &dash; File system is inconsistent.
false &dash; File system in not inconsistent.
```

```
|===
```

```
[#files]
[.api-collapsible-fifth-title]
files
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|maximum
```

```
|integer
```

a|The maximum number of files (inodes) for user-visible data allowed on the volume. This value can be increased or decreased. Increasing the maximum number of files does not immediately cause additional disk space to be used to track files. Instead, as more files are created on the volume, the system dynamically increases the number of disk blocks that are used to track files. The space assigned to track files is never freed, and this value cannot be decreased below the current number of files that can be tracked within the assigned space for the volume. Valid in PATCH.

```
|used
```

```
|integer
```

a|Number of files (inodes) used for user-visible data permitted on the volume. This field is valid only when the volume is online.

```
|===
```

```
[#flash_pool]
[.api-collapsible-fifth-title]
flash_pool
```

```
[cols=3*,options=header]
```

```

|===
|Name
|Type
|Description

|cache_eligibility
|string
a|If this parameter is specified, the command displays information only
about the volume or volumes with the specified Flash Pool caching
attributes.

|cache_retention_priority
|string
a|If this parameter is specified, the command displays the volumes that
match the specified cache retention priority policy. A cache retention
priority defines how long the blocks of a volume will be cached in the
Flash Pool once they become cold.

|caching_policy
|string
a|This optionally specifies the caching policy to apply to the volume. A
caching policy defines how the system caches a volume's data in Flash
Cache modules. If a caching policy is not assigned to a volume, the system
uses the caching policy that is assigned to the containing SVM. If a
caching policy is not assigned to the containing SVM, the system uses the
default cluster-wide policy.

|===

[#flexgroup]
[.api-collapsible-fifth-title]
flexgroup

[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|Name of the FlexGroup volume that the constituent is part of.

```

```
|uuid
|string
a|Unique identifier for the FlexGroup volume that the constituent is part
of.
```

```
|===
```

```
[#guarantee]
[.api-collapsible-fifth-title]
guarantee
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|honored
|boolean
a|Is the space guarantee of this volume honored in the aggregate?
```

```
|type
|string
a|The type of space guarantee of this volume in the aggregate.
```

```
|===
```

```
[#idcs_scanner]
[.api-collapsible-fifth-title]
idcs_scanner
```

Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(`threshold_inactive_days`). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op\_state' that is valid for PATCH and GET, and is used to start/stop the scanner.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|enabled
|boolean
a|Specifies the administrative state of the inactive data compression
scanner.

|mode
|string
a|Specifies the mode of inactive data compression scanner. Valid for PATCH
and GET.

|operation_state
|string
a|Specifies the operational state of the inactive data compression
scanner. VALID for PATCH and GET. Valid options for PATCH are "idle" and
"active".

|status
|string
a|Status of last inactive data compression scan on the volume.

|threshold_inactive_time
|string
a|Time interval after which inactive data compression will be triggered
automatically.The value is in days and is represented in the ISO-8601
format as "P+++<num>+++D" , for example "P3D" represents a duration of 3
days.+++</num>+++

|===

[#iops]
[.api-collapsible-fifth-title]
iops

The rate of I/O operations observed at the storage object.

[cols=3*,options=header]
|===

```

```

|Name
|Type
|Description

|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.

|read
|integer
a|Performance metric for read I/O operations.

|total
|integer
a|Performance metric aggregated over all types of I/O operations.

|write
|integer
a|Performance metric for write I/O operations.

|===

[#latency]
[.api-collapsible-fifth-title]
latency

The round trip latency in microseconds observed at the storage object.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.

```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]
[.api-collapsible-fifth-title]
cloud
```

Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
```

```
|iops
|link:#iops[iops]
a|The rate of I/O operations observed at the storage object.
```

```
|latency
|link:#latency[latency]
a|The round trip latency in microseconds observed at the storage object.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#flexcache]
[.api-collapsible-fifth-title]
flexcache
```

Performance number for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|bandwidth_savings
```

```
|integer
```

```
a|Bandwidth savings denoting the amount of data served locally by the
cache, in bytes.
```

```
|cache_miss_percent
```

```
|integer
```

```
a|Cache miss percentage.
```

```
|duration
|string
a|The duration over which this sample is calculated. The time durations
are represented in the ISO-8601 standard format. Samples can be calculated
over the following durations:
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of
data over multiple nodes fails, then any partial errors might return "ok"
on success or "error" on an internal uncategorized failure. Whenever a
sample collection is missed but done at a later time, it is back filled to
the previous 15 second timestamp and tagged with "backfilled_data".
"Inconsistent_delta_time" is encountered when the time between two
collections is not the same for all nodes. Therefore, the aggregated value
might be over or under inflated. "Negative_delta" is returned when an
expected monotonically increasing value has decreased in value.
"Inconsistent_old_data" is returned when one or more nodes do not have the
latest data.
```

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#throughput]
[.api-collapsible-fifth-title]
throughput
```

The rate of throughput bytes per second observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
|integer
```



a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

|read

|integer

a|Performance metric for read I/O operations.

|total

|integer

a|Performance metric aggregated over all types of I/O operations.

|write

|integer

a|Performance metric for write I/O operations.

|===

[#metric]

[.api-collapsible-fifth-title]

metric

Performance numbers, such as IOPS, latency and throughput.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|cloud

|link:#cloud[cloud]

a|Performance numbers (IOPS and latency) for cloud store. These numbers are relevant only for volumes hosted on FabricPools.

|duration

|string

a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

|flexcache

|link:#flexcache[flexcache]

a|Performance number for FlexCache used to measure cache effectiveness.

|iops

|link:#iops[iops]

a|The rate of I/O operations observed at the storage object.

|latency

|link:#latency[latency]

a|The round trip latency in microseconds observed at the storage object.

|status

|string

a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data".

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.

"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|throughput

|link:#throughput[throughput]

a|The rate of throughput bytes per second observed at the storage object.

|timestamp

|string

a|The timestamp of the performance data.

|===

```
[#movement]
[.api-collapsible-fifth-title]
movement
```

Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to `destination_aggregate` to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|cutover_window
```

```
|integer
```

```
a|Time window in seconds for cutover. The allowed range is between 30 to 300 seconds.
```

```
|destination_aggregate
```

```
|link:#destination_aggregate[destination_aggregate]
```

```
a|Aggregate
```

```
|percent_complete
```

```
|integer
```

```
a|Completion percentage
```

```
|start_time
```

```
|string
```

```
a|Start time of volume move.
```

```
|state
```

```
|string
```

```
a|State of volume move operation. PATCH the state to "aborted" to abort the move operation. PATCH the state to "cutover" to trigger cutover. PATCH the state to "paused" to pause the volume move operation in progress. PATCH the state to "replicating" to resume the paused volume move operation. PATCH the state to "cutover_wait" to go into cutover manually. When volume move operation is waiting to go into "cutover" state, this is indicated by the "cutover_pending" state. A change of state is only supported if volume movement is in progress.
```

```
|tiering_policy
|string
a|Tiering policy for FabricPool
```

```
|===
```

```
[#export_policy]
[.api-collapsible-fifth-title]
export_policy
```

Export Policy

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|id
```

```
|integer
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|===
```

```
[#junction_parent]
[.api-collapsible-fifth-title]
junction_parent
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the parent volume that contains the junction inode of this
volume. The junction parent volume must belong to the same SVM that owns
this volume.

|uuid
|string
a|Unique identifier for the parent volume.

|===

[#nas]
[.api-collapsible-fifth-title]
nas

[cols=3*,options=header]
|===
|Name
|Type
|Description

|export_policy
|link:#export_policy[export_policy]
a|Export Policy

|gid
|integer
a|The UNIX group ID of the volume. Valid in POST or PATCH.

|junction_parent
|link:#junction_parent[junction_parent]
a|

|path
|string
a|The fully-qualified path in the owning SVM's namespace at which the

```

volume is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one volume can be mounted at any given junction path. An empty path in POST creates an unmounted volume. An empty path in PATCH deactivates and unmounts the volume. Taking a volume offline or restricted state removes its junction path. This attribute is reported in GET only when the volume is mounted.

|security\_style

|string

a|Security style associated with the volume. Valid in POST or PATCH.

mixed &dash; Mixed-style security

ntfs &dash; NTFS/Windows-style security

unified &dash; Unified-style security, unified UNIX, NFS and CIFS

permissions

unix &dash; Unix-style security.

|uid

|integer

a|The UNIX user ID of the volume. Valid in POST or PATCH.

|unix\_permissions

|integer

a|UNIX permissions to be viewed as an octal number. It consists of 4 digits derived by adding up bits 4 (read), 2 (write) and 1 (execute). First digit selects the set user ID(4), set group ID (2) and sticky (1) attributes. The second digit selects permission for the owner of the file; the third selects permissions for other users in the same group; the fourth for other users not in the group. Valid in POST or PATCH. For security style "mixed" or "unix", the default setting is 0755 in octal (493 in decimal) and for security style "ntfs", the default setting is 0000. In cases where only owner, group and other permissions are given (as in 755, representing the second, third and fourth digit), first digit is assumed to be zero.

|===

[#policy]

[.api-collapsible-fifth-title]

policy

[cols=3\*,options=header]

```

|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|max_throughput_iops
|integer
a|Specifies the maximum throughput in IOPS, 0 means none. This is mutually
exclusive with name and UUID during POST and PATCH.

|max_throughput_mbps
|integer
a|Specifies the maximum throughput in Megabytes per sec, 0 means none.
This is mutually exclusive with name and UUID during POST and PATCH.

|min_throughput_iops
|integer
a|Specifies the minimum throughput in IOPS, 0 means none. Setting
"min_throughput" is supported on AFF platforms only, unless FabricPool
tiering policies are set. This is mutually exclusive with name and UUID
during POST and PATCH.

|min_throughput_mbps
|integer
a|Specifies the minimum throughput in Megabytes per sec, 0 means none.
This is mutually exclusive with name and UUID during POST and PATCH.

|name
|string
a|The QoS policy group name. This is mutually exclusive with UUID and
other QoS attributes during POST and PATCH.

|uuid
|string
a|The QoS policy group UUID. This is mutually exclusive with name and
other QoS attributes during POST and PATCH.

```

```
|===
```

```
[#qos]  
[.api-collapsible-fifth-title]  
qos
```

QoS information

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|policy  
|link:#policy[policy]  
a|
```

```
|===
```

```
[#quota]  
[.api-collapsible-fifth-title]  
quota
```

Quotas track the space or file usage of a user, group, or qtree in a FlexVol or a FlexGroup volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|enabled  
|boolean
```

a|This option is used to enable or disable the quota for the volume. This option is valid only in PATCH. Quotas are enabled for FlexVols or FlexGroup volumes when the quota state is "on". Quotas are disabled for FlexVols or FlexGroup volumes when the quota state is "off".

```
|state  
|string
```



a|Quota state of the volume

|===

[#failure\_reason]

[.api-collapsible-fifth-title]

failure\_reason

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|code

|string

a|Error code of volume capacity rebalancing operation.

|message

|string

a|Details why the volume capacity rebalancing operation failed.

|===

[#rebalancing]

[.api-collapsible-fifth-title]

rebalancing

Configurations and settings involving non-disruptive volume capacity rebalancing for a FlexGroup volume.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|data\_moved

|integer

a|The amount of data that has been moved in or out of a constituent. A positive value represents data moving into the constituent while a negative value is data moving out of the constituent.

|exclude\_snapshots

|boolean

a|Specifies whether or not to exclude files that are stuck in Snapshot copies during rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "exclude\_snapshots" value. Once the operation is started, any changes to the "exclude\_snapshots" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "exclude\_snapshots" value.

|failure\_reason

|link:#failure\_reason[failure\_reason]

a|

|imbalance\_percent

|integer

a|Represents the percentage the volume is out of balance.

|imbalance\_size

|integer

a|Represents how much the volume is out of balance, in bytes.

|max\_constituent\_imbalance\_percent

|integer

a|Absolute percentage of the constituent that is most out of balance.

|max\_file\_moves

|integer

a|Specifies the maximum number of file moves in a volume capacity rebalancing operation on a constituent of the FlexGroup volume. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_file\_moves" value. Once the operation is started, any changes to the "max\_file\_moves" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_file\_moves" value.

|max\_runtime

|string

a|This optional field specifies the maximum time a capacity rebalancing operation runs for. Once the maximum runtime has passed, the capacity rebalancing operation stops. If it is not set, the default value is 6 hours. This value cannot be updated while a capacity rebalancing operation is running. The maximum runtime can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P3D" represents a duration of 3 days. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

|max\_threshold

|integer

a|Specifies the maximum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is larger than this value, files are moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "max\_threshold" value. Once the operation is started, any changes to the "max\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "max\_threshold" value.

|min\_file\_size

|integer

a|Specifies the minimum file size to consider for a volume capacity rebalancing operation. When a new capacity rebalancing operation is started on a FlexGroup volume, it uses the current "min\_file\_size" value. Once the operation is started, any changes to the "min\_file\_size" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_file\_size" value. The value must be a multiple of 4KB. If it is not set, the default value will be 4KB.

|min\_threshold

|integer

a|Specifies the minimum imbalance percentage for FlexGroup volume constituents. When a constituent's imbalance percentage is smaller than this value, files are not moved from the constituent. When a new capacity rebalancing operation is started on a FlexGroup volume, it will use the

current "min\_threshold" value. Once the operation is started, any changes to the "min\_threshold" value do not affect the currently running capacity rebalancing operation. Only future capacity rebalancing operations will use the new "min\_threshold" value.

|runtime  
|string  
a|Duration the capacity rebalancing operation has been running.

|start\_time  
|string  
a|Time when the current capacity rebalancing operation started.

|state  
|string  
a|State of volume capacity rebalancing operation. PATCH the state to "starting" to trigger the capacity rebalance operation. PATCH the state to "stopping" to stop the capacity rebalance operation.

|stop\_time  
|string  
a|Time when the capacity rebalancing operation stopped.

|target\_used  
|integer  
a|Represents the ideal used size of each constituent. Calculated by dividing the total FlexGroup volume used size by the number of constituents.

|===

[#retention]  
[.api-collapsible-fifth-title]  
retention

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|default

|string

a|Specifies the default retention period that is applied to files while committing them to the WORM state without an associated retention period. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period and the string "unspecified" to set an unspecified retention period.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

|maximum

|string

a|Specifies the maximum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++++</num>++++++</num>++++++</num>++++++</num>+++

|minimum

|string

a|Specifies the minimum allowed retention period for files committed to the WORM state on the volume. The retention value represents a duration and must be specified in the ISO-8601 duration format. The retention period can be in years, months, days, hours, and minutes. A duration

specified for years, month,s and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and "PT+++<num>+++M" respectively. The retention string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the duration field also accepts the string "infinite" to set an infinite retention period.+++</num>++++</num>++++</num>++++</num>++++</num>+++

|===

[#snaplock]

[.api-collapsible-fifth-title]

snaplock

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|append\_mode\_enabled

|boolean

a|Specifies if the volume append mode is enabled or disabled. When it is enabled, all the files created with write permissions on the volume are, by default, WORM appendable files. The user can append the data to a WORM appendable file but cannot modify the existing contents of the file nor delete the file until it expires.

|autocommit\_period

|string

a|Specifies the autocommit period for SnapLock volume. All files which are not modified for a period greater than the autocommit period of the volume are committed to the WORM state. The autocommit period value represents a duration and must be specified in the ISO-8601 duration format. The autocommit period can be in years, months, days, hours, and minutes. A period specified for years, months, and days is represented in the ISO-8601 format as "P+++<num>+++Y", "P+++<num>+++M", "P+++<num>+++D" respectively, for example "P10Y" represents a duration of 10 years. A duration in hours and minutes is represented by "PT+++<num>+++H" and

"PT+++<num>+++M" respectively. The period string must contain only a single time element that is, either years, months, days, hours, or minutes. A duration which combines different periods is not supported, for example "P1Y10M" is not supported. Apart from the duration specified in the ISO-8601 format, the autocommit field also accepts the string "none".+++</num>++++</num>++++</num>++++</num>++++</num>+++

|compliance\_clock\_time

|string

a|This is the volume compliance clock time which is used to manage the SnapLock objects in the volume.

|expiry\_time

|string

a|Expiry time of the volume.

|is\_audit\_log

|boolean

a|Indicates if this volume has been configured as SnapLock audit log volume for the SVM .

|litigation\_count

|integer

a|Litigation count indicates the number of active legal-holds on the volume.

|privileged\_delete

|string

a|Specifies the privileged-delete attribute of a SnapLock volume. On a SnapLock Enterprise (SLE) volume, a designated privileged user can selectively delete files irrespective of the retention time of the file. SLE volumes can have privileged delete as disabled, enabled or permanently\_disabled and for SnapLock Compliance (SLC) volumes it is always permanently\_disabled.

|retention

|link:#retention[retention]

a|

|type

|string

a|The SnapLock type of the volume.  
compliance &dash; A SnapLock Compliance (SLC) volume provides the highest level of WORM protection and an administrator cannot destroy a SLC volume if it contains unexpired WORM files.  
enterprise &dash; An administrator can delete a SnapLock Enterprise (SLE) volume.  
non\_snaplock &dash; Indicates the volume is non-snaplock.

|unspecified\_retention\_file\_count  
|integer  
a|Indicates the number of files with an unspecified retention time in the volume.

|===

[#destinations]  
[.api-collapsible-fifth-title]  
destinations

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|is\_cloud  
|boolean  
a|Specifies whether a volume is a SnapMirror source volume, using SnapMirror to protect its data to a cloud destination.

|is\_ontap  
|boolean  
a|Specifies whether a volume is a SnapMirror source volume, using SnapMirror to protect its data to an ONTAP destination.

\* readOnly: 1  
\* Introduced in: 9.9

|===

[#snapmirror]



```
[.api-collapsible-fifth-title]
```

```
snapmirror
```

Specifies attributes for SnapMirror protection.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|destinations
```

```
|link:#destinations[destinations]
```

```
a|
```

```
|is_protected
```

```
|boolean
```

```
a|Specifies whether a volume is a SnapMirror source volume, using SnapMirror to protect its data.
```

```
|===
```

```
[#snapshot_policy]
```

```
[.api-collapsible-fifth-title]
```

```
snapshot_policy
```

This is a reference to the Snapshot copy policy.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|
```

```
|uuid
```

```

|string
a|

|===

[#logical_space]
[.api-collapsible-fifth-title]
logical_space

[cols=3*,options=header]
|===
|Name
|Type
|Description

|available
|integer
a|The amount of space available in this volume with storage efficiency
space considered used, in bytes.

|enforcement
|boolean
a|Specifies whether space accounting for operations on the volume is done
along with storage efficiency.

|reporting
|boolean
a|Specifies whether space reporting on the volume is done along with
storage efficiency.

|used
|integer
a|SUM of (physical-used, shared_refs, compression_saved_in_plane0,
vbn_zero, future_blk_cnt), in bytes.

|used_by_afs
|integer
a|The virtual space used by AFS alone (includes volume reserves) and along
with storage efficiency, in bytes.

|used_by_snapshots

```

```

|integer
a|Size that is logically used across all Snapshot copies in the volume, in
bytes.

|used_percent
|integer
a|SUM of (physical-used, shared_refs, compression_saved_in_plane0,
vbn_zero, future_blk_cnt), as a percentage.

|===

[#snapshot]
[.api-collapsible-fifth-title]
snapshot

[cols=3*,options=header]
|===
|Name
|Type
|Description

|autodelete_enabled
|boolean
a|Specifies whether Snapshot copy autodelete is currently enabled on this
volume.

|autodelete_trigger
|string
a|Specifies when the system should trigger an autodelete of Snapshot
copies. When set to _volume_, autodelete is triggered based on volume
fullness. When set to _snap_reserve_, autodelete is triggered based on
Snapshot reserve fullness. The default value is _volume_.

|reserve_available
|integer
a|Size available for Snapshot copies within the Snapshot copy reserve, in
bytes.

|reserve_percent
|integer
a|The space that has been set aside as a reserve for Snapshot copy usage,

```

in percent.

|reserve\_size

|integer

a|Size in the volume that has been set aside as a reserve for Snapshot copy usage, in bytes.

|space\_used\_percent

|integer

a|Percentage of snapshot reserve size that has been used.

|used

|integer

a|The total space used by Snapshot copies in the volume, in bytes.

|===

[#space]

[.api-collapsible-fifth-title]

space

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|afs\_total

|integer

a|Total size of AFS, excluding snap-reserve, in bytes.

|auto\_adaptive\_compression\_footprint\_data\_reduction

|integer

a|Savings achieved due to Auto Adaptive Compression, in bytes.

|available

|integer

a|The available space, in bytes.

|available\_percent

|integer

a|The space available, as a percent.

|block\_storage\_inactive\_user\_data

|integer

a|The size that is physically used in the block storage of the volume and has a cold temperature. In bytes. This parameter is only supported if the volume is in an aggregate that is either attached to a cloud store or could be attached to a cloud store.

|block\_storage\_inactive\_user\_data\_percent

|integer

a|Percentage of size that is physically used in the performance tier of the volume.

|capacity\_tier\_footprint

|integer

a|Space used by capacity tier for this volume in the FabricPool aggregate, in bytes.

|cross\_volume\_dedupe\_metafiles\_footprint

|integer

a|Cross volume deduplication metadata footprint, in bytes.

|cross\_volume\_dedupe\_metafiles\_temporary\_footprint

|integer

a|Cross volume temporary deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_footprint

|integer

a|Deduplication metadata footprint, in bytes.

|dedupe\_metafiles\_temporary\_footprint

|integer

a|Temporary deduplication metadata footprint, in bytes.

|delayed\_free\_footprint

|integer

a|Delayed free blocks footprint, in bytes.

|effective\_total\_footprint

|integer

a|Volume footprint after efficiency savings, in bytes.

|expected\_available

|integer

a|Size that should be available for the volume, irrespective of available size in the aggregate, in bytes.

|file\_operation\_metadata

|integer

a|File operation metadata footprint, in bytes.

|filesystem\_size

|integer

a|Total usable size of the volume, in bytes.

|filesystem\_size\_fixed

|boolean

a|Specifies whether the file system is to remain of the same size when set to true or to grow when set to false. This option is automatically set to true when a volume becomes SnapMirrored.

|footprint

|integer

a|Data used for this volume in the aggregate, in bytes.

|fractional\_reserve

|integer

a|Used to change the amount of space reserved for overwrites of reserved objects in a volume.

|full\_threshold\_percent

|integer

a|Volume full threshold percentage at which EMS warnings can be sent.

```
|local_tier_footprint
|integer
a|Space used by the local tier for this volume in the aggregate, in bytes.

|logical_space
|link:#logical_space[logical_space]
a|

|metadata
|integer
a|Space used by the volume metadata in the aggregate, in bytes.

|nearly_full_threshold_percent
|integer
a|Volume nearly full threshold percentage at which EMS warnings can be
sent.

|over_provisioned
|integer
a|The amount of space not available for this volume in the aggregate, in
bytes.

|overwrite_reserve
|integer
a|Reserved space for overwrites, in bytes.

|overwrite_reserve_used
|integer
a|Overwrite logical reserve space used, in bytes.

|percent_used
|integer
a|Percentage of the volume size that is used.

|performance_tier_footprint
|integer
a|Space used by the performance tier for this volume in the FabricPool
aggregate, in bytes.
```

```
|physical_used
|integer
a|Size that is physically used in the volume, in bytes.

|physical_used_percent
|integer
a|Size that is physically used in the volume, as a percentage.

|size
|integer
a|Total provisioned size. The default size is equal to the minimum size of
20MB, in bytes.

|size_available_for_snapshots
|integer
a|Available space for Snapshot copies from snap-reserve, in bytes.

|snapmirror_destination_footprint
|integer
a|SnapMirror destination footprint, in bytes.

|snapshot
|link:#snapshot[snapshot]
a|

|snapshot_reserve_unusable
|integer
a|Snapshot reserve that is not available for Snapshot copy creation, in
bytes.

|snapshot_spill
|integer
a|Space used by the snapshot copies beyond the snap-reserve, in bytes.

|total_footprint
|integer
a|Data and metadata used for this volume in the aggregate, in bytes.

|used
```



```
|integer
a|The virtual space used (includes volume reserves) before storage
efficiency, in bytes.
```

```
|used_by_afs
|integer
a|The space used by Active Filesystem, in bytes.
```

```
|user_data
|integer
a|User data, in bytes.
```

```
|volume_guarantee_footprint
|integer
a|Space reserved for future writes in the volume, in bytes.
```

```
|===
```

```
[#access]
[.api-collapsible-fifth-title]
access
```

Raw count and latency data for access operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
```

\* Introduced in: 9.11

|===

```
[#audit]
[.api-collapsible-fifth-title]
audit
```

Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

|===

```
[#dir]
[.api-collapsible-fifth-title]
dir
```

Raw count and latency data for directory-create operations.

```
[cols=3*,options=header]
```

|===

```
|Name
```

```
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#file]
[.api-collapsible-fifth-title]
file
```

Raw count and latency data for file-create operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#other]  
[.api-collapsible-fifth-title]  
other
```

Raw count and latency data for create operations on objects other than files, directories and symlinks.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#symlink]  
[.api-collapsible-fifth-title]  
symlink
```

Raw count and latency data for symlink-create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#create]
[.api-collapsible-fifth-title]
create
```

Raw count and latency data for create operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|dir
```

```
|link:#dir[dir]
```

a|Raw count and latency data for directory-create operations.

```
|file
```

```
|link:#file[file]
```

a|Raw count and latency data for file-create operations.

```
|other
```

```
|link:#other[other]
```

a|Raw count and latency data for create operations on objects other than files, directories and symlinks.

```
|symlink
```

```
|link:#symlink[symlink]
```

```
a|Raw count and latency data for symlink-create operations.
```

```
|===
```

```
[#getattr]
```

```
[.api-collapsible-fifth-title]
```

```
getattr
```

```
Raw count and latency data for getattr operations.
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#link]
```

```
[.api-collapsible-fifth-title]
```

```
link
```

```
Raw count and latency data for link operations.
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```

[#lock]
[.api-collapsible-fifth-title]
lock

```

Raw count and latency data for lock operations.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11

```

```
|===
```

```
[#lookup]  
[.api-collapsible-fifth-title]  
lookup
```

Raw count and latency data for lookup operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#open]  
[.api-collapsible-fifth-title]  
open
```

Raw count and latency data for open operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```



```
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#read]
[.api-collapsible-fifth-title]
read
```

Raw count and latency data for read operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* readOnly: 1
* x-ntap-advanced: true
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
```

```
|array[string]
```

```
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_size_histogram_labels
```

```
|array[string]
```

```
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#readdir]
```

```
[.api-collapsible-fifth-title]
```

```
readdir
```

Raw count and latency data for readdir operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#readlink]  
[.api-collapsible-fifth-title]  
readlink
```

Raw count and latency data for readlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
```

a|Number of operations of the given type performed on this volume.

```
|total_time
```

```
|integer
```

a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.

\* example: 200

\* Introduced in: 9.11

```
|===
```

```
[#rename]  
[.api-collapsible-fifth-title]  
rename
```

Raw count and latency data for rename operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|count
```

```
|integer
a|Number of operations of the given type performed on this volume.

|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

|===

```
[#setattr]
[.api-collapsible-fifth-title]
setattr
```

Raw count and latency data for setattr operations.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|count
|integer
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.

* example: 200
* Introduced in: 9.11
```

|===

```
[#unlink]
```

```
[.api-collapsible-fifth-title]
```

```
unlink
```

Raw count and latency data for unlink operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for all operations of the given type.
```

```
* example: 200
```

```
* Introduced in: 9.11
```

```
|===
```

```
[#watch]
```

```
[.api-collapsible-fifth-title]
```

```
watch
```

Raw count and latency data for watch operations. These statistics are only applicable for CIFS protocol operations.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
|integer
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* Introduced in: 9.11
```

```
|===
```

```
[#write]
[.api-collapsible-fifth-title]
write
```

Raw count and latency data for write operations, including histograms categorizing operations by size and latency.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|count
```

```
|integer
```

```
a|Number of operations of the given type performed on this volume.
```

```
|total_time
```

```
|integer
```

```
a|The raw data component latency in microseconds measured within ONTAP for
all operations of the given type.
```

```
* example: 200
* readOnly: 1
* x-ntap-advanced: true
* Introduced in: 9.11
```

```
|volume_protocol_latency_histogram_counts
```

```
|array[integer]
```

```
a|
```

```
|volume_protocol_latency_histogram_labels
|array[string]
a|Labels for the latency histogram, ranging from <2us to >20s.
```

```
|volume_protocol_size_histogram_counts
|array[integer]
a|
```

```
|volume_protocol_size_histogram_labels
|array[string]
a|Labels for the size histogram, ranging from <4KB to >1024KB.
```

```
|===
```

```
[#cifs_ops_raw]
[.api-collapsible-fifth-title]
cifs_ops_raw
```

Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|access
|link:#access[access]
a|Raw count and latency data for access operations.
```

```
|audit
|link:#audit[audit]
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
|link:#create[create]
a|Raw count and latency data for create operations.
```

```
|getattr
|link:#getattr[getattr]
a|Raw count and latency data for getattr operations.
```

```
|link
|link:#link[link]
a|Raw count and latency data for link operations.
```

```
|lock
|link:#lock[lock]
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```



```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#iops_raw]
[.api-collapsible-fifth-title]
iops_raw
```

The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#latency_raw]
[.api-collapsible-fifth-title]
latency_raw
```

The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#cloud]
[.api-collapsible-fifth-title]
cloud
```

These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|iops_raw
```

```
|link:#iops_raw[iops_raw]
```

```
a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.
```

```
|latency_raw
```

```
|link:#latency_raw[latency_raw]
```

```
a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.
```

```
|status
```

```
|string
```

```
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".
```

"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#flexcache_raw]
[.api-collapsible-fifth-title]
flexcache_raw
```

Performance numbers for FlexCache used to measure cache effectiveness.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|cache_miss_blocks
|integer
a|Blocks retrieved from origin in case of a cache miss. This can be divided by the raw client_requested_blocks and multiplied by 100 to calculate the cache miss percentage.
```

```
|client_requested_blocks
|integer
a|Total blocks requested by the client.
```

```
|status
|string
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to
```

the previous 15 second timestamp and tagged with "backfilled\_data".  
"Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value.  
"Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

```
|timestamp  
|string  
a|The timestamp of the performance data.
```

```
|===
```

```
[#nfs_ops_raw]  
[.api-collapsible-fifth-title]  
nfs_ops_raw
```

Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|access
```

```
|link:#access[access]
```

```
a|Raw count and latency data for access operations.
```

```
|audit
```

```
|link:#audit[audit]
```

```
a|Raw count and latency data for audit operations. These statistics are only applicable for CIFS protocol operations.
```

```
|create
```

```
|link:#create[create]
```

```
a|Raw count and latency data for create operations.
```

```
|getattr
|link:#getattr[getattr]
a|Raw count and latency data for getattr operations.
```

```
|link
|link:#link[link]
a|Raw count and latency data for link operations.
```

```
|lock
|link:#lock[lock]
a|Raw count and latency data for lock operations.
```

```
|lookup
|link:#lookup[lookup]
a|Raw count and latency data for lookup operations.
```

```
|open
|link:#open[open]
a|Raw count and latency data for open operations.
```

```
|read
|link:#read[read]
a|Raw count and latency data for read operations, including histograms
categorizing operations by size and latency.
```

```
|readdir
|link:#readdir[readdir]
a|Raw count and latency data for readdir operations.
```

```
|readlink
|link:#readlink[readlink]
a|Raw count and latency data for readlink operations.
```

```
|rename
|link:#rename[rename]
a|Raw count and latency data for rename operations.
```

```
|setattr
|link:#setattr[setattr]
a|Raw count and latency data for setattr operations.
```

```
|unlink
|link:#unlink[unlink]
a|Raw count and latency data for unlink operations.
```

```
|watch
|link:#watch[watch]
a|Raw count and latency data for watch operations. These statistics are
only applicable for CIFS protocol operations.
```

```
|write
|link:#write[write]
a|Raw count and latency data for write operations, including histograms
categorizing operations by size and latency.
```

```
|===
```

```
[#throughput_raw]
[.api-collapsible-fifth-title]
throughput_raw
```

Throughput bytes observed at the storage object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
```

a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#statistics]
[.api-collapsible-fifth-title]
statistics
```

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|cifs_ops_raw
|link:#cifs_ops_raw[cifs_ops_raw]
a|Raw data component performance values for CIFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.
```

```
|cloud
|link:#cloud[cloud]
a|These are raw performance numbers (IOPS and latency) for the cloud store. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. These numbers are relevant only for volumes hosted on FabricPools.
```



|flexcache\_raw  
|link:#flexcache\_raw[flexcache\_raw]  
a|Performance numbers for FlexCache used to measure cache effectiveness.

|iops\_raw  
|link:#iops\_raw[iops\_raw]  
a|The number of I/O operations observed at the storage object. This can be used along with delta time to calculate the rate of I/O operations per unit of time.

|latency\_raw  
|link:#latency\_raw[latency\_raw]  
a|The raw latency in microseconds observed at the storage object. This can be divided by the raw IOPS value to calculate the average latency per I/O operation.

|nfs\_ops\_raw  
|link:#nfs\_ops\_raw[nfs\_ops\_raw]  
a|Raw data component performance values for NFS operations on this volume, including number of operations and raw latency, in microseconds for each operation. The values are cumulative and increase while the volume is online.

|status  
|string  
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|throughput\_raw  
|link:#throughput\_raw[throughput\_raw]  
a|Throughput bytes observed at the storage object. This can be used along

with delta time to calculate the rate of throughput bytes per unit of time.

```
|timestamp
|string
a|The timestamp of the performance data.
```

```
|===
```

```
[#svm]
[.api-collapsible-fifth-title]
svm
```

SVM containing the volume. Required on POST.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#tiering]
[.api-collapsible-fifth-title]
tiering
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|min_cooling_days
```

```
|integer
```

a|This parameter specifies the minimum number of days that user data blocks of the volume must be cooled before they can be considered cold and tiered out to the cloud tier. Note that this parameter is only used for tiering purposes and does not affect the reporting of inactive data. The value specified should be greater than the frequency with which applications in the volume shift between different sets of data. This parameter cannot be set when volume tiering policy is either "none" or "all". The default value of this parameter depends on the volume's tiering policy. See the tiering policy section of this documentation for corresponding default values. If the tiering policy on the volume gets changed, then this parameter will be reset to the default value corresponding to the new tiering policy.

```
|object_tags
```

```
|array[string]
```

a|This parameter specifies tags of a volume for objects stored on a FabricPool-enabled aggregate. Each tag is a key,value pair and should be in the format "key=value".

```
|policy
```

```
|string
```

a|Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold. FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH.

- all &dash; This policy allows tiering of both Snapshot copies and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.
- auto &dash; This policy allows tiering of both snapshot and active file system user data to the cloud store
- none &dash; Volume blocks will not be tiered to the cloud store.
- snapshot\_only &dash; This policy allows tiering of only the volume Snapshot copies not associated with the active file system. The default tiering policy is "snapshot-only" for a FlexVol and "none" for a FlexGroup. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy is 31 days.

```
|supported
|boolean
a|This parameter specifies whether or not FabricPools are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only FabricPool aggregates are used if this parameter is set to true and only non FabricPool aggregates are used if this parameter is set to false. Tiering support for a FlexGroup can be changed by moving all of the constituents to the required aggregates. Note that in order to tier data, not only does the volume need to support tiering by using FabricPools, the tiering "policy" must not be 'none'. A volume that uses FabricPools but has a tiering "policy" of 'none' supports tiering, but will not tier any data.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|access_time_enabled
|boolean
a|Indicates whether or not access time updates are enabled on the volume.
```

```
|activity_tracking
|link:#activity_tracking[activity_tracking]
a|
```

```
|aggregates
|array[link:#aggregates[aggregates]]
a|Aggregate hosting the volume. Required on POST.
```

```
|analytics
```

```
|link:#analytics[analytics]
```

```
a|
```

```
|anti_ransomware
```

```
|link:#anti_ransomware[anti_ransomware]
```

```
a|Anti-ransomware related information of the volume.
```

```
|anti_ransomware_state
```

```
|string
```

```
a|The Anti-ransomware state of the volume. If no "anti_ransomware_state" property is specified, the volume inherits the value from its parent SVM's "anti_ransomware_default_volume_state" property. If this value is "disabled", Anti-ransomware is disabled on the volume. If this value is "enabled", Anti-ransomware is enabled on the volume and alerts are raised if any suspect is detected for those volumes. If this value is "dry_run", Anti-ransomware is enabled in the dry-run or learning mode on the volume. The "dry_run" state is same as the "enabled" state except that the analytics data is used here for learning. No alerts are raised for any detections or violations. If this value is "paused", Anti-ransomware is paused on the volume. Additionally, three more states are available, which are only valid for GET. If this value is "disable_in_progress", Anti-ransomware monitoring is being disabled and a cleanup operation is in effect. If this value is "enable_paused", Anti-ransomware is paused on the volume from its earlier enabled state. If this value is "dry_run_paused", Anti-ransomware monitoring is paused on the volume from its earlier dry_run state. For POST, the valid Anti-ransomware states are only "disabled", "enabled" and "dry_run", whereas for PATCH, "paused" is also valid along with the three valid states for POST.
```

```
|application
```

```
|link:#application[application]
```

```
a|
```

```
|asynchronous_directory_delete
```

```
|link:#asynchronous_directory_delete[asynchronous_directory_delete]
```

```
a|Configuration for asynchronous directory delete from the client. This is only supported on Flexible volumes and FlexGroup volumes.
```

```
|autosize
```

```
|link:#autosize[autosize]
```

```
a|
```

```
|clone
```

|link:#clone[clone]

a|

|cloud\_retrieval\_policy

|string

a|This parameter specifies the cloud retrieval policy for the volume. This policy determines which tiered out blocks to retrieve from the capacity tier to the performance tier. The available cloud retrieval policies are "default" policy retrieves tiered data based on the underlying tiering policy. If the tiering policy is 'auto', tiered data is retrieved only for random client driven data reads. If the tiering policy is 'none' or 'snapshot\_only', tiered data is retrieved for random and sequential client driven data reads. If the tiering policy is 'all', tiered data is not retrieved.

"on\_read" policy retrieves tiered data for all client driven data reads.

"never" policy never retrieves tiered data.

"promote" policy retrieves all eligible tiered data automatically during the next scheduled scan. It is only supported when the tiering policy is 'none' or 'snapshot\_only'. If the tiering policy is 'snapshot\_only', the only data brought back is the data in the AFS. Data that is only in a snapshot copy stays in the cloud and if tiering policy is 'none' then all data is retrieved.

|comment

|string

a|A comment for the volume. Valid in POST or PATCH.

|consistency\_group

|link:#consistency\_group[consistency\_group]

a|Consistency group the volume is part of.

|constituents

|array[link:#constituents[constituents]]

a|FlexGroup Constituents. FlexGroup Constituents can be retrieved more efficiently by specifying "is\_constituent=true" or "is\_constituent=true&flexgroup.uuid=+++<flexgroup.uuid>+++" as query parameters.+++</flexgroup.uuid>+++

|constituents\_per\_aggregate

|integer

a|Specifies the number of times to iterate over the aggregates listed with the "aggregates.name" or "aggregates.uuid" when creating or expanding a

FlexGroup volume. If a volume is being created on a single aggregate, the system creates a flexible volume if the "constituents\_per\_aggregate" field is not specified, or a FlexGroup volume if it is specified. If a volume is being created on multiple aggregates, the system always creates a FlexGroup volume. The root constituent of a FlexGroup volume is always placed on the first aggregate in the list.

|convert\_unicode

|boolean

a|Specifies whether directory Unicode format conversion is enabled when directories are accessed by NFS clients.

|create\_time

|string

a|Creation time of the volume. This field is generated when the volume is created.

|efficiency

|link:#efficiency[efficiency]

a|

|encryption

|link:#encryption[encryption]

a|

|error\_state

|link:#error\_state[error\_state]

a|

|files

|link:#files[files]

a|

|flash\_pool

|link:#flash\_pool[flash\_pool]

a|

|flexcache\_endpoint\_type

|string

a|FlexCache endpoint type.

none &dash; The volume is neither a FlexCache nor origin of any FlexCache.  
cache &dash; The volume is a FlexCache volume.

origin &dash; The volume is origin of a FlexCache volume.

```
|flexgroup
|link:#flexgroup[flexgroup]
a|
```

```
|granular_data
|boolean
a|State of granular data on the volume. This setting is true by default when creating a new FlexGroup volume, but can be specified as false at the time of creation via a POST request. On FlexVol volumes, the setting is always false, as only FlexGroup volumes and FlexGroup constituents support this feature. Once enabled, this setting can only be disabled by restoring a Snapshot copy. Earlier versions of ONTAP (pre 9.11) are not compatible with this feature. Therefore, reverting to an earlier version of ONTAP is not possible unless this volume is deleted or restored to a Snapshot copy that was taken before the setting was enabled.
```

\* Introduced in: 9.11

```
|guarantee
|link:#guarantee[guarantee]
a|
```

```
|idcs_scanner
|link:#idcs_scanner[idcs_scanner]
a|Inactive data compression scan looks and picks up blocks that have not been read for a certain amount of time(threshold_inactive_days). These blocks are then compressed in 32K chunks. All attributes are valid for GET only, expect for 'op_state' that is valid for PATCH and GET, and is used to start/stop the scanner.
```

```
|is_object_store
|boolean
a|Specifies whether the volume is provisioned for an object store server.
```

```
|is_svm_root
|boolean
a|Specifies whether the volume is a root volume of the SVM it belongs to.
```

```
|language
|string
a|Language encoding setting for volume. If no language is specified, the volume inherits its SVM language encoding setting.
```



|max\_dir\_size  
|integer  
a|Maximum directory size. This value sets maximum size, in bytes, to which a directory can grow. The default maximum directory size for FlexVol volumes is model-dependent, and optimized for the size of system memory. Before increasing the maximum directory size, involve technical support.

|metric  
|link:#metric[metric]  
a|Performance numbers, such as IOPS, latency and throughput.

|movement  
|link:#movement[movement]  
a|Volume movement. All attributes are modify, that is, not writable through POST. Set PATCH state to destination\_aggregate to initiate a volume move operation. Volume movement on FlexGroup constituents are not supported.

|msid  
|integer  
a|The volume's Mirror Set ID.

|name  
|string  
a|Volume name. The name of volume must start with an alphabetic character (a to z or A to Z) or an underscore (\_). The name must be 197 or fewer characters in length for FlexGroups, and 203 or fewer characters in length for all other types of volumes. Volume names must be unique within an SVM. Required on POST.

|nas  
|link:#nas[nas]  
a|

|qos  
|link:#qos[qos]  
a|QoS information

|queue\_for\_encryption

```
|boolean
a|Specifies whether the volume is queued for encryption.

|quota
|link:#quota[quota]
a|Quotas track the space or file usage of a user, group, or qtree in a
FlexVol or a FlexGroup volume.

|rebalancing
|link:#rebalancing[rebalancing]
a|Configurations and settings involving non-disruptive volume capacity
rebalancing for a FlexGroup volume.

|scheduled_snapshot_naming_scheme
|string
a|Naming Scheme for automatic Snapshot copies:

* create_time - Automatic Snapshot copies are saved as per the start of
their current date and time.
* ordinal - Latest automatic snapshot copy is saved as
+++<scheduled_frequency>+++0 and subsequent copies will follow the
create_time naming convention.+++</scheduled_frequency>+++

|size
|integer
a|Physical size of the volume, in bytes. The minimum size for a FlexVol
volume is 20MB and the minimum size for a FlexGroup volume is 200MB per
constituent. The recommended size for a FlexGroup volume is a minimum of
100GB per constituent. For all volumes, the default size is equal to the
minimum size.

|snaplock
|link:#snaplock[snaplock]
a|

|snapmirror
|link:#snapmirror[snapmirror]
a|Specifies attributes for SnapMirror protection.

|snapshot_count
|integer
```

a|Number of Snapshot copies in the volume.

|snapshot\_policy

|link:#snapshot\_policy[snapshot\_policy]

a|This is a reference to the Snapshot copy policy.

|space

|link:#space[space]

a|

|state

|string

a|Volume state. Client access is supported only when volume is online and junctioned. Taking volume to offline or restricted state removes its junction path and blocks client access. When volume is in restricted state some operations like parity reconstruction and iron on commit are allowed. The 'mixed' state applies to FlexGroup volumes only and cannot be specified as a target state. An 'error' state implies that the volume is not in a state to serve data.

|statistics

|link:#statistics[statistics]

a|These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

|status

|array[string]

a|Describes the current status of a volume.

|style

|string

a|The style of the volume. If "style" is not specified, the volume type is determined based on the specified aggregates. Specifying a single aggregate, without "constituents\_per\_aggregate", creates a flexible volume. Specifying multiple aggregates, or a single aggregate with "constituents\_per\_aggregate", creates a FlexGroup. Specifying a volume "style" creates a volume of that type. For example, if the style is "flexvol" you must specify a single aggregate. If the style is "flexgroup", the system either uses the specified aggregates or automatically provisions aggregates if there are no specified aggregates. The style "flexgroup\_constituent" is not supported when creating a volume.

flexvol &dash; flexible volumes and FlexClone volumes  
flexgroup &dash; FlexGroup volumes  
flexgroup\_constituent &dash; FlexGroup constituents.

|svm  
|link:#svm[svm]  
a|SVM containing the volume. Required on POST.

|tiering  
|link:#tiering[tiering]  
a|

|type  
|string  
a|Type of the volume.  
rw &dash; read-write volume.  
dp &dash; data-protection volume.  
ls &dash; load-sharing `dp` volume. Valid in GET.

|use\_mirrored\_aggregates  
|boolean  
a|Specifies whether mirrored aggregates are selected when provisioning a FlexGroup without specifying "aggregates.name" or "aggregates.uuid". Only mirrored aggregates are used if this parameter is set to 'true' and only unmirrored aggregates are used if this parameter is set to 'false'. Aggregate level mirroring for a FlexGroup can be changed by moving all of the constituents to the required aggregates. The default value is 'true' for a MetroCluster configuration and is 'false' for a non-MetroCluster configuration.

|uuid  
|string  
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7  
\* readOnly: 1  
\* Introduced in: 9.6

|===

```

[#job_link]
[.api-collapsible-fifth-title]
job_link

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|uuid
|string
a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or
DELETE operation.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument

|===

```

```

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

:leveloffset: -1

= Manage files and directories

:leveloffset: +1

[[ID6e5a1c95dcce1df763d6cd87ad02f16]]

```

= Storage volumes volume.uuid files path endpoint overview

== Overview

This API is used to read a file, write to a file, retrieve a list of files and directories, and retrieve or modify certain properties of files and directories. The path field is used to specify the path to the directory or file to be acted on. The path field requires using "%2E" to represent "." and "%2F" to represent "/" for the path provided.

== File data

Read and write data from/to a named file. To read a file, the Accept request HTTP header must be specified as multipart/form-data, and a value for the `length` query property, which represents the number of bytes to be read, must be specified. The API will fail if the length of data being read/written exceeds 1 MB. This API should only be used on normal files or streams associated with files. The results for other file types, such as LUNs is undefined.

The following APIs are used to read or write data to a file:

&ndash; GET

```
/api/storage/volumes/{volume.uuid}/files/{path}?byte_offset=0&length=40  
-H "Accept: multipart/form-data"
```

&ndash; POST        /api/storage/volumes/{volume.uuid}/files/{path} -H  
"Content-Type: multipart/form-data" --form "file=the data to be written to  
the new file"

&ndash; PATCH

```
/api/storage/volumes/{volume.uuid}/files/{path}?byte_offset=10 -H  
"Content-Type: multipart/form-data" --form "file=the new data to be  
written or overwritten to the existing file starting at byte_offset"
```

== Listing directories and files

A list of files and directories and their properties can be retrieved for a specified path.

The following APIs are used to view a list of files and directories:

&ndash; GET                /api/storage/volumes/{volume.uuid}/files

&ndash; GET                /api/storage/volumes/{volume.uuid}/files/{path}

&ndash; GET  
/api/storage/volumes/{volume.uuid}/files/{path}?fields=\*

== File information

The metadata and detailed information about a single directory or file can be retrieved by setting the `return_metadata` query property to `true`. The information returned includes `type`, `creation_time`, `modified_time`, `changed_time`, `accessed_time`, `unix_permissions`, `owner_id`, `group_id`, `size`, `hard_links_count`, `inode_number`, `is_empty`, `bytes_used`, `unique_bytes`, `inode_generation`, `is_vm_aligned`, `is_junction`, `links`, and `analytics` (if requested).

The following API is used to view the properties of a single file or directory:

&ndash; GET  
/api/storage/volumes/{volume.uuid}/files/{path}?return\_metadata=true

== File usage

Custom details about the usage of a file can be retrieved by specifying a value for the `byte_offset` and `length` query properties.

The following API is used to view the unique bytes, and bytes used, by a file based on the range defined by `byte_offset` and `length`:

&ndash; GET  
/api/storage/volumes/{volume.uuid}/files/{path}?return\_metadata=true&byte\_offset={int}&length={int}

== Create a directory

The following API is used to create a directory:

&ndash; POST /api/storage/volumes/{volume.uuid}/files/{path} -d '{"type" : "directory", "unix-permissions" : "644"}'

== Delete an entire directory

A directory can be deleted. The behavior of this call is equivalent to `rm -rf`.

The following API is used to delete an entire directory:

&ndash; DELETE



```
/api/storage/volumes/{volume.uuid}/files/{path}?recurse=true
```

== Delete a file or an empty directory

The following API is used to delete a file or an empty directory:

```
&ndash; DELETE    /api/storage/volumes/{volume.uuid}/files/{path}
```

```
&ndash; DELETE
```

```
/api/storage/volumes/{volume.uuid}/files/{path}?recurse=false
```

== File system analytics

File system analytics provide a quick method for obtaining information summarizing properties of all files within any directory tree of a volume. When file system analytics are enabled on a volume, ``analytics.+++`` fields may be requested, and will be populated in the response records corresponding to directories. The API does not support file system analytics for requests that are made beyond the boundary of the specified ``volume.uuid``.

The following APIs are used to obtain analytics information for a directory:

```
&ndash; GET
```

```
/api/storage/volumes/{volume.uuid}/files/{path}?fields=analytics
```

```
&ndash; GET    /api/storage/volumes/{volume.uuid}/files/{path}?fields=**
```

== QoS

QoS policies and settings enforce Service Level Objectives (SLO) on a file. A pre-created QoS policy can be used by specifying the ``qos.name`` or ``qos.uuid`` properties.

The following APIs are used to assign a QoS policy to a file:

```
&ndash; PATCH    /api/storage/volumes/{volume.uuid}/files/{path} -d '{  
"qos_policy.name" : "policy" }'
```

```
&ndash; PATCH    /api/storage/volumes/{volume.uuid}/files/{path} -d '{  
"qos_policy.uuid" : "b89bc5dd-94a3-11e8-a7a3-0050568edf84" }'
```

== Symlinks

The following APIs are used to create a symlink and read the contents of a symlink:

```
&ndash; POST /api/storage/volumes/{volume.uuid}/files/{path} -d '{
"target" : "directory2/file1" }'
```

```
&ndash; GET
```

```
/api/storage/volumes/{volume.uuid}/files/{path}?return_metadata=true&fiel
ds=target
```

```
== Rename a file or a directory
```

The following API can be used to rename a file or a directory. Note that you need to provide the path relative to the root of the volume in the `path` body parameter.

```
&ndash; PATCH /api/storage/volumes/{volume.uuid}/files/{path} -d '{
"path" : "directory1/directory2" }'
```

```
&ndash; PATCH /api/storage/volumes/{volume.uuid}/files/{path} -d '{
"path" : "directory1/directory2/file1" }'
```

```
== Examples
```

```
=== Writing to a new file
```

```
----
```

```
# The API:
```

```
POST /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
```

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes/54c06ce2-5430-11ea-
90f9-005056a73aff/files/aNewFile" -H "Content-Type: multipart/form-data"
--form "file=the data to be written to the new file"
```

```
----
```

```
=== Writing to an existing file
```

```
----
```

```
# The API:
```

```
PATCH /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
```

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/54c06ce2-5430-11ea-
90f9-005056a73aff/files/aNewFile?byte_offset=39" -H "Content-Type:
multipart/form-data" --form "file=*here is a little more data"
```

```
----
```

```
=== Reading a file
```

```
----
```

```
# The API:
```

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/54c06ce2-5430-11ea-90f9-005056a73aff/files/aNewFile?byte_offset=0&length=100" -H "Accept: multipart/form-data"
```

```
# Response for file data:
```

```
--ec51b3541741ade7
```

```
Content-Disposition: form-data; name="bytes_read"
```

```
Content-Type: text/plain
```

```
66
```

```
--ec51b3541741ade7
```

```
Content-Disposition: form-data; filename="aNewFile"
```

```
Content-Type: application/octet-stream
```

```
the data to be written to the new file*here is a little more data
```

```
--ec51b3541741ade7--
```

```
----
```

```
=== Creating a directory
```

```
You can use the POST request to create a directory.
```

```
----
```

```
# The API:
```

```
POST /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
```

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/dir1" -H 'accept: application/hal+json' -d '{"type": "directory", "unix_permissions": "644"}'
```

```
# The response:
```

```
{  
  "num_records": 1,  
  "records": [  
    {  
      "path": "dir1",  
      "type": "directory",  
      "unix_permissions": 644
```

```

    }
  ]
}
----

=== Creating a stream on a file

----

# The API:
POST /api/storage/volumes/{volume.uuid}/files/{path}?overwrite=true

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/volumes/54c06ce2-5430-11ea-90f9-005056a73aff/files/aNewFile?overwrite=true&byte_offset=1&stream_name=someStream" -H "Content-Type: multipart/form-data" --form "file=the data to be written to the new file"
----

=== Retrieving the list of files in a directory

----

# The API:
GET /api/storage/volumes/{volume.uuid}/files/{path}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/d1%2Fd2%2Fd3"

# Response for file records:
{
  "records": [
    {
      "path": "d1/d2/d3",
      "name": ".",
      "type": "directory",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2F%2E"
        },
        "metadata": {
          "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2F%2E?return_metadata=true"
        }
      }
    }
  ]
}

```

```

    }
  },
  {
    "path": "d1/d2/d3",
    "name": "..",
    "type": "directory",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2F%2E%2E"
      },
      "metadata": {
        "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2F%2E%2E?return_metadata=true"
      }
    }
  },
  {
    "path": "d1/d2/d3",
    "name": "f1",
    "type": "file",
    "_links": {
      "metadata": {
        "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2Ffile1?return_metadata=true"
      }
    }
  },
  {
    "path": "d1/d2/d3",
    "name": "d5",
    "type": "directory",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2Fd5"
      },
      "metadata": {
        "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2Fd5?return_metadata=true"
      }
    }
  }
],
"num_records": 4,
"_links": {

```

```

    "self": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3"
    }
  }
}
}
-----

```

=== Retrieving a list of files based on file type

You can filter the list of files you retrieve based on multiple file types by including a query parameter in the following format

```
type="file|symlink"
```

-----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/d1%2Fd2%2Fd3?type=file&#124;directory"
```

# Response for file records:

```

{
  "records": [
    {
      "path": "d1/d2/d3",
      "name": ".",
      "type": "directory",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2F%2E"
        },
        "metadata": {
          "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2F%2E?return_metadata=true"
        }
      }
    },
    {
      "path": "d1/d2/d3",
      "name": "..",
      "type": "directory",
      "_links": {

```

```

    "self": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2F%2E%2E"
    },
    "metadata": {
      "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2F%2E%2E?return_metadata=true"
    }
  },
  {
    "path": "d1/d2/d3",
    "name": "f1",
    "type": "file",
    "_links": {
      "metadata": {
        "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2Ffile1?return_metadata=true"
      }
    }
  },
  {
    "path": "d1/d2/d3",
    "name": "d5",
    "type": "directory",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3%2Fd5"
      },
      "metadata": {
        "href": "/api/storage/volumes/e8274d79-3bba-11ea-b780-005056a7d72a/files/d1%2Fd2%2Fd3%2Fd5?return_metadata=true"
      }
    }
  }
],
"num_records": 4,
"_links": {
  "self": {
    "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d1%2Fd2%2Fd3"
  }
}
}
-----

```

=== Retrieving the properties of a directory or a file

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}?return_metadata=true
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/d1%2Fd2%2Fd3%2Ff1?return_metadata=true"
```

# Response for file properties:

```
{
  "records": [
    {
      "path": "d1/d2/d3/f1",
      "name": "",
      "type": "file",
      "creation_time": "2019-06-12T21:27:28-04:00",
      "modified_time": "2019-06-12T21:27:28-04:00",
      "changed_time": "2019-06-12T21:27:28-04:00",
      "accessed_time": "2019-06-12T21:27:28-04:00",
      "unix_permissions": 644,
      "owner_id": 54738,
      "group_id": 30,
      "size": 200,
      "hard_links_count": 1,
      "inode_number": 1233,
      "bytes_used": 4096,
      "unique_bytes": 4096,
      "inode_generation": 214488325,
      "is_vm_aligned": false,
      "is_junction": false
    }
  ],
  "num_records": 1,
  "_links": {
    "self": {
      "href": "/api/storage/volumes/da8bb06c-823e-11e9-b790-005056acdcb0/files/d1%2Fd2%2Fd3%2Ff1?return_metadata=true"
    }
  }
}
```

----



=== Creating a symlink to a relative path

You can use the POST request to create a symlink.

----

# The API:

```
POST /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X POST "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-  
b926-05056aca658/files/symlink1" -H 'accept: application/hal+json' -d '{  
"target" : "d1/f1"}'
```

# The response:

```
{  
"num_records": 1,  
"records": [  
  {  
    "path": "symlink1",  
    "target": "d1/f1"  
  }  
]  
}
```

----

=== Retrieving the target of a symlink

You can use the GET request to view the target of a symlink.

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-  
b926-05056aca658/files/symlink1?return_metadata=true&fields=target"
```

# The response:

```
{  
"records": [  
  {  
    "path": "symlink1",  
    "target": "d1/f1"  
  }  
],
```

```
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/storage/volumes/54c06ce2-5430-11ea-90f9-
005056a73aff/files/symlink1?return_metadata=true&fields=target"
  }
}
}
}
-----
```

=== Retrieving the usage information for a file

You can use the GET request to retrieve the unique bytes held in a file with or without specifying the offset.

-----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-
b926-05056aca658/files/f1?return_metadata=true&byte_offset=100&length=200"
```

# The response:

```
{
"records": [
  {
    "path": "d1/d2/d3/f1",
    "type": "file",
    "creation_time": "2019-06-12T21:27:28-04:00",
    "modified_time": "2019-06-12T21:27:28-04:00",
    "changed_time": "2019-06-12T21:27:28-04:00",
    "accessed_time": "2019-06-12T21:27:28-04:00",
    "unix_permissions": 644,
    "owner_id": 54738,
    "group_id": 30,
    "size": 200,
    "hard_links_count": 1,
    "inode_number": 1233,
    "bytes_used": 4096,
    "unique_bytes": 4096,
    "inode_generation": 214488325,
    "is_vm_aligned": false,
    "is_junction": false
  }
}
```

```
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/storage/volumes/cb6b139-8d21-11e9-b926-
05056aca658/files/f1?return_metadata=true&byte_offset=100&length=200"
  }
}
}
}
-----
```

=== Retrieving all information (including analytics) for a directory

-----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/1ef5d1b2-f9d7-11e9-
8043-00505682f860/files/d1?return_metadata=true&fields=**"
```

# Response for all fields of the directory:

```
{
"records": [
  {
    "svm": {
      "uuid": "58a996a2-f9d5-11e9-8043-00505682f860",
      "_links": {
        "self": {
          "href": "/api/svm/svms/58a996a2-f9d5-11e9-8043-00505682f860"
        }
      }
    },
    "volume": {
      "uuid": "1ef5d1b2-f9d7-11e9-8043-00505682f860",
      "_links": {
        "self": {
          "href": "/api/storage/volumes/1ef5d1b2-f9d7-11e9-8043-
00505682f860"
        }
      }
    },
    "path": "d1",
    "type": "directory",
    "creation_time": "2019-10-28T23:04:13+00:00",
```

```
"modified_time": "2019-10-28T23:10:30+00:00",
"changed_time": "2019-10-28T23:10:30+00:00",
"accessed_time": "2019-10-28T23:10:38+00:00",
"unix_permissions": 755,
"owner_id": 1002,
"group_id": 65533,
"size": 4096,
"hard_links_count": 5,
"inode_number": 96,
"is_empty": false,
"bytes_used": 4096,
"inode_generation": 214514951,
"is_vm_aligned": false,
"is_junction": false,
"analytics": {
  "file_count": 668,
  "bytes_used": 209657856,
  "subdir_count": 18,
  "by_modified_time": {
    "bytes_used": {
      "values": [
        0,
        0,
        0,
        0,
        3112960,
        0,
        14041088,
        20545536,
        0,
        57933824,
        61947904,
        68804608,
        188686336,
        0,
        0,
        0,
        20971520,
        0
      ],
      "percentages": [
        0,
        0,
        0,
        0,
        1.48,
```

```
    0,  
    6.7,  
    9.8,  
    0,  
    27.63,  
    29.55,  
    32.82,  
    90,  
    0,  
    0,  
    0,  
    10,  
    0  
  ],  
  "labels": [  
    "2019-W42",  
    "2019-W41",  
    "2019-W40",  
    "2019-W39",  
    "2019-W38",  
    "2019-10",  
    "2019-09",  
    "2019-08",  
    "2019-Q4",  
    "2019-Q3",  
    "2019-Q2",  
    "2019-Q1",  
    "2019",  
    "2018",  
    "2017",  
    "2016",  
    "--2015",  
    "unknown"  
  ]  
}  
},  
"by_accessed_time": {  
  "bytes_used": {  
    "values": [  
      102760448,  
      1867776,  
      1245184,  
      2179072,  
      1556480,  
      105873408,  
      9027584,  
    ]  
  }  
}
```

```
8093696,  
105873408,  
23969792,  
32382976,  
26460160,  
188686336,  
0,  
0,  
0,  
20971520,  
0  
],  
"percentages": [  
  49.01,  
  0.89,  
  0.59,  
  1.04,  
  0.74,  
  50.5,  
  4.31,  
  3.86,  
  50.5,  
  11.43,  
  15.45,  
  12.62,  
  90,  
  0,  
  0,  
  0,  
  10,  
  0  
],  
"labels": [  
  "2019-W42",  
  "2019-W41",  
  "2019-W40",  
  "2019-W39",  
  "2019-W38",  
  "2019-10",  
  "2019-09",  
  "2019-08",  
  "2019-Q4",  
  "2019-Q3",  
  "2019-Q2",  
  "2019-Q1",  
  "2019",
```

```

        "2018",
        "2017",
        "2016",
        "--2015",
        "unknown"
    ]
  }
}
}
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/storage/volumes/1ef5d1b2-f9d7-11e9-8043-00505682f860/files/d1?return_metadata=true&fields=**"
  }
}
}
-----

```

=== Retrieving file system analytics information for a set of histogram buckets

-----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/d3?type=directory&fields=analytics&analytics.histogram_by_time_labels=2019-Q3,2019-Q2,2019-Q1,2018-Q4"
```

# Response with analytics data

```
{
"records": [
  {
    "path": "d3",
    "name": ".",
    "type": "directory",
    "analytics": {
      "file_count": 44,
      "bytes_used": 244240384,
      "subdir_count": 14,

```

```

    "by_modified_time": {
      "bytes_used": {
        "values": [
          57344,
          29720576,
          196141056,
          57344
        ],
        "percentages": [
          0.02,
          12.17,
          80.31,
          0.02
        ]
      }
    },
    "by_accessed_time": {
      "bytes_used": {
        "values": [
          69632,
          244170752,
          0,
          0
        ],
        "percentages": [
          0.03,
          99.97,
          0,
          0
        ]
      }
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3%2F%2E"
    },
    "metadata": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3%2F%2E?return_metadata=true"
    }
  }
},
{
  "path": "d3",

```



```
"name": "..",
"type": "directory",
"analytics": {
  "file_count": 515,
  "bytes_used": 3034574848,
  "subdir_count": 23,
  "by_modified_time": {
    "bytes_used": {
      "values": [
        61440,
        1756479488,
        214622208,
        1191936
      ],
      "percentages": [
        0,
        57.88,
        7.07,
        0.04
      ]
    }
  },
  "by_accessed_time": {
    "bytes_used": {
      "values": [
        282624,
        3034292224,
        0,
        0
      ],
      "percentages": [
        0.01,
        99.99,
        0,
        0
      ]
    }
  }
},
"_links": {
  "self": {
    "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3%2F%2E%2E"
  },
  "metadata": {
    "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-
```

```
005056aca658/files/d3%2F%2E%2E?return_metadata=true"
```

```
    }  
  }  
},  
{  
  "path": "d3",  
  "name": "d5",  
  "type": "directory",  
  "analytics": {  
    "file_count": 10,  
    "bytes_used": 47648768,  
    "subdir_count": 4,  
    "by_modified_time": {  
      "bytes_used": {  
        "values": [  
          0,  
          29638656,  
          0,  
          0  
        ],  
        "percentages": [  
          0,  
          62.20,  
          0,  
          0  
        ]  
      }  
    },  
    "by_accessed_time": {  
      "bytes_used": {  
        "values": [  
          0,  
          47648768,  
          0,  
          0  
        ],  
        "percentages": [  
          0,  
          100,  
          0,  
          0  
        ]  
      }  
    }  
  }  
},  
  "_links": {
```

```

    "self": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3%2Fd5"
    },
    "metadata": {
      "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3%2Fd5?return_metadata=true"
    }
  }
},
"num_records": 3,
"analytics": {
  "by_modified_time": {
    "bytes_used": {
      "labels": [
        "2019-Q3",
        "2019-Q2",
        "2019-Q1",
        "2018-Q4"
      ]
    }
  },
  "by_accessed_time": {
    "bytes_used": {
      "labels": [
        "2019-Q3",
        "2019-Q2",
        "2019-Q1",
        "2018-Q4"
      ]
    }
  }
},
"_links": {
  "self": {
    "href": "/api/storage/volumes/cb6b1b39-8d21-11e9-b926-005056aca658/files/d3?type=directory&fields=analytics&analytics.histogram_by_time_labels=2019-Q3,2019-Q2,2019-Q1,2018-Q4"
  }
}
}
}
-----

```

=== Identifying the largest subdirectories

```
-----  
  
# The API:  
GET /api/storage/volumes/{volume.uuid}/files/{path}  
  
# The call:  
curl -X GET "https://<mgmt-ip>/api/storage/volumes/1ef5d1b2-f9d7-11e9-  
8043-  
00505682f860/files/d1?fields=analytics.bytes_used&type=directory&order_by=  
analytics.bytes_used%20desc"  
  
# Response with the largest subdirectories sorted by their usage:  
{  
  "records": [  
    {  
      "path": "d1",  
      "name": "..",  
      "type": "directory",  
      "analytics": {  
        "bytes_used": 56623104  
      }  
    },  
    {  
      "path": "d1",  
      "name": ".",  
      "type": "directory",  
      "analytics": {  
        "bytes_used": 35651584  
      }  
    },  
    {  
      "path": "d1",  
      "name": "biggest",  
      "type": "directory",  
      "analytics": {  
        "bytes_used": 17825792  
      }  
    },  
    {  
      "path": "d1",  
      "name": "bigger",  
      "type": "directory",  
      "analytics": {  
        "bytes_used": 10485760  
      }  
    },  
  ],  
}
```

```

{
  "path": "d1",
  "name": "big",
  "type": "directory",
  "analytics": {
    "bytes_used": 5242880
  }
}
],
"num_records": 5,
"_links": {
  "self": {
    "href": "/api/storage/volumes/1ef5d1b2-f9d7-11e9-8043-00505682f860/files/d1?fields=analytics.bytes_used&type=directory&order_by=analytics.bytes_used%20desc"
  }
}
}

```

----

=== Assigning a QoS policy to a file

You can use the PATCH request to assign a QoS policy to a file.

----

# The API:

```
PATCH /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/directory1%2Ffile1" -d '{ "qos_policy": { "name": "policy" } }'
```

# The response:

```
{}
```

----

=== Retrieving QoS information for a file

You can use the GET request for all fields with `return_metadata="true"` to retrieve QoS information for the file.

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
curl -X GET "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-
b926-05056aca658/files/file?return_metadata=true&fields=**"
```

```
# The response:
```

```
{
"records": [
  {
    "svm": {
      "uuid": "42ee3002-67dd-11ea-8508-005056a7b8ac"
    },
    "volume": {
      "uuid": "c05eb66a-685f-11ea-8508-005056a7b8ac"
    },
    "path": "file",
    "type": "lun",
    "creation_time": "2020-03-17T10:58:40-04:00",
    "modified_time": "2020-03-24T18:15:40-04:00",
    "changed_time": "2020-03-24T18:15:40-04:00",
    "accessed_time": "2020-03-24T18:15:40-04:00",
    "unix_permissions": 644,
    "owner_id": 0,
    "group_id": 0,
    "size": 1048576,
    "hard_links_count": 2,
    "inode_number": 96,
    "bytes_used": 1056768,
    "inode_generation": 219748425,
    "is_vm_aligned": false,
    "is_junction": false,
    "is_snapshot": false,
    "qos_policy": {
      "name": "pg1",
      "uuid": "00725264-688f-11ea-8f10-005056a7b8ac"
    }
  }
] ,
"num_records": 1
}
----
```

```
=== Deleting an entire directory
```

You can use the DELETE request to remove an entire directory recursively.

```
-----  
  
# The API:  
DELETE /api/storage/volumes/{volume.uuid}/files/{path}  
  
# The call:  
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-  
b926-05056aca658/files/directory1%2Fdirectory2?recurse=true"  
  
# The response:  
{  
  "job": {  
    "uuid": "27d287e8-fcd4-11e9-b8a4-005056a7b97b",  
    "_links": {  
      "self": {  
        "href": "/api/cluster/jobs/27d287e8-fcd4-11e9-b8a4-005056a7b97b"  
      }  
    }  
  }  
}  
}
```

=== Deleting an entire directory with specified throttling threshold

You can specify the maximum number of directory delete operations per second when removing an entire directory recursively.

```
-----  
  
# The API:  
DELETE /api/storage/volumes/{volume.uuid}/files/{path}  
  
# The call:  
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-  
b926-  
05056aca658/files/directory1%2Fdirectory2?recurse=true&throttle_deletion=1  
00"  
  
# The response:  
{  
  "job": {  
    "uuid": "27d287e8-fcd4-11e9-b8a4-005056a7b97b",  
    "_links": {  
      "self": {  
        "href": "/api/cluster/jobs/27d287e8-fcd4-11e9-b8a4-005056a7b97b"  
      }  
    }  
  }  
}
```

```
}  
}  
}
```

==== Deleting an empty directory

You can use the DELETE request to remove an empty directory.

-----  
  
# The API:

```
DELETE /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/directory1%2Fdirectory2"
```

# The response:

```
{}
```

==== Deleting a file

You can use the DELETE request to remove a file.

-----  
  
# The API:

```
DELETE /api/storage/volumes/{volume.uuid}/files/{path}
```

# The call:

```
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-b926-05056aca658/files/directory1%2Ffile2"
```

# The response:

```
{}
```

==== Renaming a file

You can use the PATCH request to rename a file.

-----  
  
# The API:

```
PATCH /api/storage/volumes/{volume.uuid}/files/{path}
```



```
# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-
b926-05056aca658/files/directory1%2Fdirectory2%2Ffile1" -d '{ "path":
"directory1/file2" }'
```

```
# The response:
```

```
{ }
-----
```

```
=== Renaming a directory
```

```
You can use the PATCH request to rename a directory.
```

```
-----
```

```
# The API:
```

```
PATCH /api/storage/volumes/{volume.uuid}/files/{path}
```

```
# The call:
```

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/cb6b1b39-8d21-11e9-
b926-05056aca658/files/directory1%2Fdirectory2" -d '{ "path": "d3/d4" }'
```

```
# The response:
```

```
{ }
-----
```

```
[[IDbdae668a34eba30483e2eba19d96fcb2]]
```

```
= Delete an existing file or directory
```

```
[.api-doc-operation .api-doc-operation-delete]#DELETE# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/files/{path}`#
```

```
*Introduced In:* 9.8
```

```
Deletes an existing file or directory. Query-based DELETE operations are
not supported.
```

```
== Parameters
```

```
[cols=5*,options=header]
```

```
|===
```

|Name  
|Type  
|In  
|Required  
|Description

|volume.uuid  
|string  
|path  
|True  
a|Volume UUID

|path  
|string  
|path  
|True  
a|The relative path of a directory in the volume. The path field requires using "%2E" to represent "." and "%2F" to represent "/" for the path provided.

|recurse  
|boolean  
|query  
|False  
a|Delete an entire directory. The behaviour of this call is equivalent to `rm -rf`.

\* Default value:

|throttle\_deletion  
|integer  
|query  
|False  
a|The maximum number of directory delete operations per second. A valid `throttle_deletion` number is an integer from 10 to 100000.

|return\_records  
|boolean  
|query  
|False  
a|The default is false. If set to true, the records are returned.

\* Default value:

```
|return_timeout  
|integer  
|query  
|False
```

a|The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.

\* Default value: 1  
\* Max value: 120  
\* Min value: 0

```
|===
```

```
== Response
```

Status: 200, Ok

```
== Response
```

Status: 202, Accepted

```
== Error
```

Status: Default

ONTAP Error Response Codes

```
|===  
| Error Code | Description  
  
| 131074  
| No such file or directory.  
  
| 131102  
| Read-only file system.
```

```
| 131138
| Directory not empty.

| 918235
| A volume with UUID {volume.uuid} was not found.

| 6488081
| The \{field} field is not supported for DELETE operations.
|===
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|error
```

```
|link:#error[error]
```

```
a|
```

```
|===
```

```
.Example error
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

```
====
```

```
== Definitions
```

```
[.api-def-first-level]
```

```
.See Definitions
```

```
[%collapsible%closed]
```

```

//Start collapsible Definitions block
====
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string

```

```
a|Error message
```

```
|target
```

```
|string
```

```
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
```

```
=====
```

```
[[ID5bf2c1dd751739b27ebf64c54530df0b]]
```

```
= Retrieve files and directories
```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-  
block]#`/storage/volumes/{volume.uuid}/files/{path}`#
```

```
*Introduced In:* 9.7
```

Retrieves a list of files and directories for a given directory or returns only the properties of a single given directory or file of a volume.

```
== Expensive properties
```

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query property. See [xref:{relative\\_path}getting\\_started\\_with\\_the\\_ontap\\_rest\\_api.html#Requesting\\_specific\\_fields\[Requesting specific fields\]](#) to learn more.

```
*** `analytics`
```

```
*** `qos_policy.name`
```

```
*** `qos_policy.uuid`
```

```
== Parameters
```

```
[cols=5*,options=header]
```

```
|===
```

|Name  
|Type  
|In  
|Required  
|Description

|volume.uuid  
|string  
|path  
|True  
a|Volume UUID

|path  
|string  
|path  
|True  
a|Relative path of a file or directory in the volume. The path field requires using "%2E" to represent "." and "%2F" to represent "/" for the path provided.

|byte\_offset  
|integer  
|query  
|False  
a|The file offset to start reading from.

\* Introduced in: 9.8

|length  
|integer  
|query  
|False  
a|Length of the range in bytes.

\* Introduced in: 9.8

|return\_metadata  
|boolean  
|query  
|False  
a|If true, the request returns metadata for the the directory or file specified in the path.

\* Introduced in: 9.8

\* Default value:

|constituent.name

|string

|query

|False

a|Filter by constituent.name

\* Introduced in: 9.10

|constituent.uuid

|string

|query

|False

a|Filter by constituent.uuid

\* Introduced in: 9.10

|unix\_permissions

|integer

|query

|False

a|Filter by unix\_permissions

|hard\_links\_count

|integer

|query

|False

a|Filter by hard\_links\_count

|fill\_enabled

|boolean

|query

|False

a|Filter by fill\_enabled

\* Introduced in: 9.8

|is\_snapshot

|boolean



```
|query
|False
a|Filter by is_snapshot
```

\* Introduced in: 9.8

```
|target
|string
|query
|False
a|Filter by target
```

\* Introduced in: 9.8

```
|creation_time
|string
|query
|False
a|Filter by creation_time
```

```
|owner_id
|integer
|query
|False
a|Filter by owner_id
```

```
|unique_bytes
|integer
|query
|False
a|Filter by unique_bytes
```

\* Introduced in: 9.8

```
|qos_policy.uuid
|string
|query
|False
a|Filter by qos_policy.uuid
```

\* Introduced in: 9.8

```
|qos_policy.name
|string
|query
|False
a|Filter by qos_policy.name
```

\* Introduced in: 9.8

```
|volume.name
|string
|query
|False
a|Filter by volume.name
```

```
|bytes_used
|integer
|query
|False
a|Filter by bytes_used
```

```
|is_empty
|boolean
|query
|False
a|Filter by is_empty
```

```
|type
|string
|query
|False
a|Filter by type
```

```
|inode_generation
|integer
|query
|False
a|Filter by inode_generation
```

```
|accessed_time
|string
```

```
|query
|False
a|Filter by accessed_time
```

```
|modified_time
|string
|query
|False
a|Filter by modified_time
```

```
|is_junction
|boolean
|query
|False
a|Filter by is_junction
```

```
|changed_time
|string
|query
|False
a|Filter by changed_time
```

```
|inode_number
|integer
|query
|False
a|Filter by inode_number
```

```
|analytics.file_count
|integer
|query
|False
a|Filter by analytics.file_count
```

\* Introduced in: 9.8

```
|analytics.by_accessed_time.bytes_used.values
|integer
|query
|False
a|Filter by analytics.by_accessed_time.bytes_used.values
```

\* Introduced in: 9.8

```
|analytics.by_accessed_time.bytes_used.newest_label  
|string  
|query  
|False  
a|Filter by analytics.by_accessed_time.bytes_used.newest_label
```

\* Introduced in: 9.8

```
|analytics.by_accessed_time.bytes_used.labels  
|string  
|query  
|False  
a|Filter by analytics.by_accessed_time.bytes_used.labels
```

\* Introduced in: 9.8

```
|analytics.by_accessed_time.bytes_used.oldest_label  
|string  
|query  
|False  
a|Filter by analytics.by_accessed_time.bytes_used.oldest_label
```

\* Introduced in: 9.8

```
|analytics.by_accessed_time.bytes_used.percentages  
|number  
|query  
|False  
a|Filter by analytics.by_accessed_time.bytes_used.percentages
```

\* Introduced in: 9.8

```
|analytics.bytes_used  
|integer  
|query  
|False  
a|Filter by analytics.bytes_used
```

\* Introduced in: 9.8

```
|analytics.by_modified_time.bytes_used.values
|integer
|query
|False
a|Filter by analytics.by_modified_time.bytes_used.values
```

\* Introduced in: 9.8

```
|analytics.by_modified_time.bytes_used.newest_label
|string
|query
|False
a|Filter by analytics.by_modified_time.bytes_used.newest_label
```

\* Introduced in: 9.8

```
|analytics.by_modified_time.bytes_used.labels
|string
|query
|False
a|Filter by analytics.by_modified_time.bytes_used.labels
```

\* Introduced in: 9.8

```
|analytics.by_modified_time.bytes_used.oldest_label
|string
|query
|False
a|Filter by analytics.by_modified_time.bytes_used.oldest_label
```

\* Introduced in: 9.8

```
|analytics.by_modified_time.bytes_used.percentages
|number
|query
|False
a|Filter by analytics.by_modified_time.bytes_used.percentages
```

\* Introduced in: 9.8

```
|analytics.subdir_count  
|integer  
|query  
|False  
a|Filter by analytics.subdir_count
```

\* Introduced in: 9.8

```
|size  
|integer  
|query  
|False  
a|Filter by size
```

```
|holes.size  
|integer  
|query  
|False  
a|Filter by holes.size
```

\* Introduced in: 9.11

```
|holes.start  
|integer  
|query  
|False  
a|Filter by holes.start
```

\* Introduced in: 9.11

```
|is_vm_aligned  
|boolean  
|query  
|False  
a|Filter by is_vm_aligned
```

```
|name  
|string  
|query  
|False  
a|Filter by name
```

```
|overwrite_enabled
|boolean
|query
|False
a|Filter by overwrite_enabled
```

\* Introduced in: 9.8

```
|group_id
|integer
|query
|False
a|Filter by group_id
```

```
|analytics.histogram_by_time_labels
|array[string]
|query
|False
a|Request that returned
xref:{relative_path}analytics_histogram_by_time.html[analytics_histogram_b
y_time] objects including values associated with the specified labels.
```

As described in the object description, the labels may take the following forms:<ul>

```
__partial-date_
+++<tt>+++--+++</tt>+++ __partial-date_
__partial-date_ +++<tt>+++--+++</tt>+++
__partial-date_+++<tt>+++--+++</tt>+++_-__partial-date_
+++<tt>+++unknown+++</tt>+++
```

</ul>Intervals that the system would not normally return may be specified. In this case, the appropriate values and percentages summarizing all files with a time-based attribute within the indicated period of time are calculated and returned in the response. However, there are some restrictions:<ul>

Any \_\_partial-date\_ specified as the beginning or end of an interval must be tracked by the system. Valid \_\_partial-date\_s may be determined by making an OPTIONS request to the  
+++<tt>+++/storage/volumes/{volume.uuid}/files/{path}+++</tt>+++  
endpoint.

Intervals may not mix week-based \_\_partial-date\_s in the form \_yyyy\_-W\_\_ww\_\_ with other types of \_\_partial-date\_s.

</ul>

\* Introduced in: 9.8

|fields  
|array[string]  
|query  
|False  
a|Specify the fields to return.

|max\_records  
|integer  
|query  
|False  
a|Limit the number of records returned.

|return\_records  
|boolean  
|query  
|False  
a|The default is true for GET calls. When set to false, only the number of records is returned.

\* Default value: 1

|return\_timeout  
|integer  
|query  
|False  
a|The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.

\* Default value: 1

\* Max value: 120

\* Min value: 0

|order\_by  
|array[string]  
|query  
|False



a|Order results by specified fields and optional [asc|desc] direction.  
Default direction is 'asc' for ascending.

|===

== Response

Status: 200, Ok

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|analytics
```

```
|link:#analytics[analytics]
```

```
a|Additional file system analytics information that is invariant amongst  
all elements in the collection.
```

This property is only populated if file system analytics is enabled on the containing volume.

This analytics object captures properties that are invariant amongst all elements included in the `records` array. The invariant properties are included here, rather than within the information for each element, to avoid returning an excessive amount of duplicated information when the collection is large.

```
|num_records
```

```
|integer
```

```
a|Number of records.
```

```
|records
```

```
|array[link:#file_info[file_info]]
```

```
a|
```

```
|===
```

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "analytics": {
    "by_accessed_time": {
      "bytes_used": {
        "labels": [
          "2019-07",
          "2019-06",
          "2019-05",
          2019,
          2018,
          "--2017",
          "unknown"
        ]
      }
    },
    "by_modified_time": {
      "bytes_used": {
        "labels": [
          "2019-07",
          "2019-06",
          "2019-05",
          2019,
          2018,
          "--2017",
          "unknown"
        ]
      }
    }
  },
  "records": {
    "_links": {
      "metadata": {
        "href": "/api/resourcelink"
      }
    },
  },
}
```

```
"self": {
  "href": "/api/resourcelink"
},
"accessed_time": "2019-06-12T11:00:16-04:00",
"analytics": {
  "by_accessed_time": {
    "bytes_used": {
      "labels": [
        "2019-07",
        "2019-06",
        "2019-05",
        2019,
        2018,
        "--2017",
        "unknown"
      ],
      "newest_label": "2019-07",
      "oldest_label": "2019-07",
      "percentages": [
        0.1,
        11.24,
        0.18,
        15.75,
        0.75,
        83.5,
        0
      ],
      "values": [
        15925248,
        1735569408,
        27672576,
        2430595072,
        116105216,
        12889948160,
        0
      ]
    }
  },
  "by_modified_time": {
    "bytes_used": {
      "labels": [
        "2019-07",
        "2019-06",
        "2019-05",
        2019,
```

```

    2018,
    "--2017",
    "unknown"
  ],
  "newest_label": "2019-07",
  "oldest_label": "2019-07",
  "percentages": [
    0.1,
    11.24,
    0.18,
    15.75,
    0.75,
    83.5,
    0
  ],
  "values": [
    15925248,
    1735569408,
    27672576,
    2430595072,
    116105216,
    12889948160,
    0
  ]
}
},
"bytes_used": 15436648448,
"file_count": 21134,
"subdir_count": 35
},
"bytes_used": 4096,
"changed_time": "2019-06-12T11:00:16-04:00",
"constituent": {
  "name": "fg__0001",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"creation_time": "2019-06-12T11:00:16-04:00",
"group_id": 30,
"hard_links_count": 1,
"holes": {
},
"inode_generation": 214753547,
"inode_number": 1695,
"is_empty": "",
"is_junction": "",
"is_snapshot": "",

```

```

"is_vm_aligned": "",
"modified_time": "2019-06-12T11:00:16-04:00",
"name": "test_file",
"owner_id": 54738,
"path": "d1/d2/d3",
"qos_policy": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "qos1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 200,
"target": "some_directory/some_other_directory/some_file",
"type": "file",
"unique_bytes": 4096,
"unix_permissions": 755,
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

```

```

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]

```

`_links`

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|next
```

```
|link:href[href]
```

```
a|
```

```
|self
```

```
|link:href[href]
```

```
a|
```

```
|===
```

```
[#bytes_used]
```

```
[.api-collapsible-fifth-title]
```

```
bytes_used
```

Number of bytes used on-disk, broken down by date of last access.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|labels
```

```
|array[string]
```

```
a|Labels for this histogram
```

```
|===
```

```
[#by_accessed_time]
```

```
[.api-collapsible-fifth-title]
```

```
by_accessed_time
```

File system analytics information, broken down by date of last access.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|bytes_used
|link:#bytes_used[bytes_used]
a|Number of bytes used on-disk, broken down by date of last access.

|===

[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used

Number of bytes used on-disk, broken down by date of last modification.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|labels
|array[string]
a|Labels for this histogram

|===

[#by_modified_time]
[.api-collapsible-fifth-title]
by_modified_time

File system analytics information, broken down by date of last
modification.

[cols=3*,options=header]
|===
|Name
|Type

```



```
|Description

|bytes_used
|link:#bytes_used[bytes_used]
a|Number of bytes used on-disk, broken down by date of last modification.
```

```
|===
```

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

Additional file system analytics information that is invariant amongst all elements in the collection.

This property is only populated if file system analytics is enabled on the containing volume.

This analytics object captures properties that are invariant amongst all elements included in the `records` array. The invariant properties are included here, rather than within the information for each element, to avoid returning an excessive amount of duplicated information when the collection is large.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|by_accessed_time
|link:#by_accessed_time[by_accessed_time]
a|File system analytics information, broken down by date of last access.
```

```
|by_modified_time
|link:#by_modified_time[by_modified_time]
a|File system analytics information, broken down by date of last
modification.
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|metadata
|link:#href[href]
a|
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```
[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used
```

Number of bytes used on-disk, broken down by date of last access.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|labels
|array[string]
a|Labels for this histogram
```

```
|newest_label
|string
a|Each label indicates the period of time the corresponding data is
associated with. A label can take one of the following forms:<ul>
  a partial date in an extended ISO8601 representation
  an interval between partial dates in an extended ISO8601 representation,
where "--" is used to separate the beginning and end of the interval
  the string literal "unknown"
```

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `__yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>

- a partial date in an extended ISO8601 representation
- an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval
- the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `_yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `_yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

```
|percentages
|array[number]
a|Percentages for this histogram
```

```
|values
|array[integer]
a|Values for this histogram
```

```
|===
```

```
[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used
```

Number of bytes used on-disk, broken down by date of last modification.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|labels
|array[string]
a|Labels for this histogram
```

|newest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>  
a partial date in an extended ISO8601 representation  
an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval  
the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `__yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>  
a partial date in an extended ISO8601 representation  
an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval  
the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `_yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `_yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

```
|percentages
|array[number]
a|Percentages for this histogram
```

```
|values
|array[integer]
a|Values for this histogram
```

```
|===
```

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

Additional file system analytics information summarizing all descendents of a directory.

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `file-info-response(#model-file-info-response)`. This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html<<model-file_info_response,file_info_response>>`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `<<model-file_info_response,file_info_response>>`. This avoids an excessive amount of duplicated information when a `[GET /storage/volumes/{volume.uuid}/files/{path}]` call returns a large collection.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|by_accessed_time
```

```
|link:#by_accessed_time[by_accessed_time]
```

```
a|File system analytics information, broken down by date of last access.
```

```
|by_modified_time
```

```
|link:#by_modified_time[by_modified_time]
```

```
a|File system analytics information, broken down by date of last modification.
```

```
|bytes_used
```

```
|integer
```

```
a|Number of bytes used on-disk
```

```
|file_count
```

```
|integer
```

```
a|Number of descendants
```

```
|subdir_count
```

```
|integer
```

```
a|Number of sub directories
```

```
|===
```

```
[#constituent]
```

```
[.api-collapsible-fifth-title]
```

```
constituent
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|name
```

```
|string
```

```
a|FlexGroup volume constituent name.
```

```
|uuid
```

```
|string
```

```
a|FlexGroup volume constituent UUID.
```

```
|===
```

```
[#file_hole]
```

```
[.api-collapsible-fifth-title]
```

```
file_hole
```

```
Range of a hole in a file.
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```



```
|size
|integer
a|Size of the hole, in bytes.
```

```
|start
|integer
a|Starting offset of the hole.
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```
[#qos_policy]
[.api-collapsible-fifth-title]
qos_policy
```

The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both ``qos_policy.uuid`` and ``qos_policy.name`` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property ``qos_policy.name`` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on `/storage/luns` to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the QoS policy. To remove the file from a QoS policy, set
this property to an empty string "" or set it to "none" in a PATCH
request.

|uuid
|string
a|The unique identifier of the QoS policy. Valid in PATCH.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid

```

that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7  
\* Introduced in: 9.6

|===

```
[#file_info]
[.api-collapsible-fifth-title]
file_info
```

Information about a single file.

```
[cols=3*,options=header]
```

|===

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|accessed_time
|string
a|Last access time of the file in date-time format.
```

```
|analytics
|link:#analytics[analytics]
a|Additional file system analytics information summarizing all descendents of a directory.
```

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the file-info-response(`#model-file-info-`

response). This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html` <<model-file\_info\_response, file\_info\_response>>, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the <<model-file\_info\_response, file\_info\_response>>. This avoids an excessive amount of duplicated information when a `[GET /storage/volumes/{volume.uuid}/files/{path}]` call returns a large collection.

|bytes\_used

|integer

a|The actual number of bytes used on disk by this file. If `byte_offset` and `length` parameters are specified, this will return the bytes used by the file within the given range.

|changed\_time

|string

a|Last time data or attributes changed on the file in date-time format.

|constituent

|link:#constituent[constituent]

a|

|creation\_time

|string

a|Creation time of the file in date-time format.

|fill\_enabled

|boolean

a|Returns "true" if the space reservation is enabled. The field `overwrite_enabled` must also be set to the same value as this field.

|group\_id

|integer

a|The integer ID of the group of the file owner.

|hard\_links\_count

|integer

a|The number of hard links to the file.

|holes

|array[link:#file\_hole[file\_hole]]

a|List of hole ranges in the file.

|inode\_generation

|integer

a|Inode generation number.

|inode\_number

|integer

a|The file inode number.

|is\_empty

|boolean

a|Specifies whether or not a directory is empty. A directory is considered empty if it only contains entries for "." and "..". This element is present if the file is a directory. In some special error cases, such as when the volume goes offline or when the directory is moved while retrieving this info, this field might not get set.

|is\_junction

|boolean

a|Returns "true" if the directory is a junction.

|is\_snapshot

|boolean

a|Returns "true" if the directory is a Snapshot copy.

|is\_vm\_aligned

|boolean

a|Returns true if the file is vm-aligned. A vm-aligned file is a file that is initially padded with zero-filled data so that its actual data starts at an offset other than zero. The amount by which the start offset is adjusted depends on the vm-align setting of the hosting volume.

|modified\_time

|string

a|Last data modification time of the file in date-time format.

|name

|string

a|Name of the file.

|overwrite\_enabled

|boolean

a|Returns "true" if the space reservation for overwrites is enabled. The field fill\_enabled must also be set to the same value as this field.

|owner\_id

|integer

a|The integer ID of the file owner.

|path

|string

a|Path of the file.

|qos\_policy

|link:#qos\_policy[qos\_policy]

a|The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both `qos\_policy.uuid` and `qos\_policy.name` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property `qos\_policy.name` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

|size

|integer

a|The size of the file, in bytes.

|target

|string

a|The relative or absolute path contained in a symlink, in the form

```
+++<some>+++/  
+++<path>+++.  
+++</path>++++++</some>+++
```

```
|type  
|string  
a|Type of the file.
```

```
|unique_bytes  
|integer  
a|Number of bytes uniquely held by this file. If byte_offset and length  
parameters are specified, this will return bytes uniquely held by the file  
within the given range.
```

```
|unix_permissions  
|integer  
a|UNIX permissions to be viewed as an octal number. It consists of 4  
digits derived by adding up bits 4 (read), 2 (write), and 1 (execute). The  
first digit selects the set user ID(4), set group ID (2), and sticky (1)  
attributes. The second digit selects permissions for the owner of the  
file; the third selects permissions for other users in the same group; the  
fourth selects permissions for other users not in the group.
```

```
|volume  
|link:#volume[volume]  
a|
```

```
|===
```

```
[#error_arguments]  
[.api-collapsible-fifth-title]  
error_arguments
```

```
[cols=3*,options=header]
```

```
|===  
|Name  
|Type  
|Description
```

```
|code  
|string  
a|Argument code
```

```
|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
=====
```

```
[[ID1490a269d1b434547fe002c9f7116584]]
```



= Write to an existing file with the supplied data

```
[.api-doc-operation .api-doc-operation-patch]#PATCH# [.api-doc-code-  
block]#`/storage/volumes/{volume.uuid}/files/{path}`#
```

\*Introduced In:\* 9.8

Writes to an existing file with the supplied data or modifies the size, name, space reservation information, QoS policy, or hole range information of a file. Query-based PATCH operations are not supported.

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|volume.uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Volume UUID
```

```
|path
```

```
|string
```

```
|path
```

```
|True
```

```
a|Relative path of a file in the volume. The path field requires using  
"%2E" to represent "." and "%2F" to represent "/" for the path provided.
```

```
|byte_offset
```

```
|integer
```

```
|query
```

```
|False
```

```
a|How many bytes into the file to begin writing. Use -1 to append  
(default).
```

```
|overwrite
```

```
|boolean
|query
|False
a|If false, and the file exists, the write will fail. Default is false.
```

```
|stream_name
|string
|query
|False
a|Name of stream associated with the file to write data to.
```

```
|data
|string
|formData
|False
a|Data to write to the file.
```

```
|return_records
|boolean
|query
|False
a|The default is false. If set to true, the records are returned.
```

\* Default value:

```
|===
```

```
== Request Body
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|accessed_time
|string
a|Last access time of the file in date-time format.
```

|analytics  
|link:#analytics[analytics]  
a|Additional file system analytics information summarizing all descendents of a directory.

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `file-info-response(#model-file-info-response)`. This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html<<model-file_info_response,file_info_response>>`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `<<model-file_info_response,file_info_response>>`. This avoids an excessive amount of duplicated information when a `[GET /storage/volumes/{volume.uuid}/files/{path}]` call returns a large collection.

|bytes\_used  
|integer  
a|The actual number of bytes used on disk by this file. If `byte_offset` and `length` parameters are specified, this will return the bytes used by the file within the given range.

|changed\_time  
|string  
a|Last time data or attributes changed on the file in date-time format.

|constituent  
|link:#constituent[constituent]  
a|

|creation\_time

```
|string
a|Creation time of the file in date-time format.

|fill_enabled
|boolean
a|Returns "true" if the space reservation is enabled. The field
overwrite_enabled must also be set to the same value as this field.

|group_id
|integer
a|The integer ID of the group of the file owner.

|hard_links_count
|integer
a|The number of hard links to the file.

|holes
|array[link:#file_hole[file_hole]]
a|List of hole ranges in the file.

|inode_generation
|integer
a|Inode generation number.

|inode_number
|integer
a|The file inode number.

|is_empty
|boolean
a|Specifies whether or not a directory is empty. A directory is considered
empty if it only contains entries for "." and "..". This element is
present if the file is a directory. In some special error cases, such as
when the volume goes offline or when the directory is moved while
retrieving this info, this field might not get set.

|is_junction
|boolean
a|Returns "true" if the directory is a junction.
```

|is\_snapshot  
|boolean  
a|Returns "true" if the directory is a Snapshot copy.

|is\_vm\_aligned  
|boolean  
a|Returns true if the file is vm-aligned. A vm-aligned file is a file that is initially padded with zero-filled data so that its actual data starts at an offset other than zero. The amount by which the start offset is adjusted depends on the vm-align setting of the hosting volume.

|modified\_time  
|string  
a|Last data modification time of the file in date-time format.

|name  
|string  
a|Name of the file.

|overwrite\_enabled  
|boolean  
a|Returns "true" if the space reservation for overwrites is enabled. The field fill\_enabled must also be set to the same value as this field.

|owner\_id  
|integer  
a|The integer ID of the file owner.

|path  
|string  
a|Path of the file.

|qos\_policy  
|link:#qos\_policy[qos\_policy]  
a|The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both `qos\_policy.uuid` and `qos\_policy.name` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property `qos\_policy.name`

in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

|size  
|integer  
a|The size of the file, in bytes.

|target  
|string  
a|The relative or absolute path contained in a symlink, in the form  
+++<some>+++ /+++<path>+++ .+++</path>++++++</some>+++

|type  
|string  
a|Type of the file.

|unique\_bytes  
|integer  
a|Number of bytes uniquely held by this file. If byte\_offset and length parameters are specified, this will return bytes uniquely held by the file within the given range.

|unix\_permissions  
|integer  
a|UNIX permissions to be viewed as an octal number. It consists of 4 digits derived by adding up bits 4 (read), 2 (write), and 1 (execute). The first digit selects the set user ID(4), set group ID (2), and sticky (1) attributes. The second digit selects permissions for the owner of the file; the third selects permissions for other users in the same group; the fourth selects permissions for other users not in the group.

|volume  
|link:#volume[volume]  
a|

|===

```
.Example request
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "_links": {
    "metadata": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "accessed_time": "2019-06-12T11:00:16-04:00",
  "analytics": {
    "by_accessed_time": {
      "bytes_used": {
        "labels": [
          "2019-07",
          "2019-06",
          "2019-05",
          2019,
          2018,
          "--2017",
          "unknown"
        ],
        "newest_label": "2019-07",
        "oldest_label": "2019-07",
        "percentages": [
          0.1,
          11.24,
          0.18,
          15.75,
          0.75,
          83.5,
          0
        ],
        "values": [
          15925248,
          1735569408,
          27672576,
          2430595072,
          116105216,
          12889948160,

```

```

    0
  ]
}
},
"by_modified_time": {
  "bytes_used": {
    "labels": [
      "2019-07",
      "2019-06",
      "2019-05",
      2019,
      2018,
      "--2017",
      "unknown"
    ],
    "newest_label": "2019-07",
    "oldest_label": "2019-07",
    "percentages": [
      0.1,
      11.24,
      0.18,
      15.75,
      0.75,
      83.5,
      0
    ],
    "values": [
      15925248,
      1735569408,
      27672576,
      2430595072,
      116105216,
      12889948160,
      0
    ]
  }
},
"bytes_used": 15436648448,
"file_count": 21134,
"subdir_count": 35
},
"bytes_used": 4096,
"changed_time": "2019-06-12T11:00:16-04:00",
"constituent": {
  "name": "fg__0001",
  "uid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```



```
},
"creation_time": "2019-06-12T11:00:16-04:00",
"group_id": 30,
"hard_links_count": 1,
"holes": {
},
"inode_generation": 214753547,
"inode_number": 1695,
"is_empty": "",
"is_junction": "",
"is_snapshot": "",
"is_vm_aligned": "",
"modified_time": "2019-06-12T11:00:16-04:00",
"name": "test_file",
"owner_id": 54738,
"path": "d1/d2/d3",
"qos_policy": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "qos1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 200,
"target": "some_directory/some_other_directory/some_file",
"type": "file",
"unique_bytes": 4096,
"unix_permissions": 755,
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
====

== Response
```

Status: 200, Ok

```
== Error
```

## Status: Default

### ONTAP Error Response Codes

```
|===  
| Error Code | Description  
  
| 918235  
| A volume with UUID {volume.uuid} was not found.  
  
| 6488081  
| The \{field} field is not supported for PATCH operations.  
  
| 6488082  
| Failed to rename \{path}.  
  
| 6488083  
| Failed to rename \{path} to \{path} because a directory named \{path}  
already exists.  
|===
```

```
[cols=3*,options=header]
```

```
|===  
|Name  
|Type  
|Description  
  
|error  
|link:#error[error]  
a|  
  
|===
```

```
.Example error
```

```
[%collapsible%closed]  
====  
[source,json,subs=+macros]  
{  
  "error": {  
    "arguments": {
```

```

    "code": "string",
    "message": "string"
  },
  "code": "4",
  "message": "entry doesn't exist",
  "target": "uuid"
}
}
====

```

== Definitions

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====

```

```

[#href]
[.api-collapsible-fifth-title]
href

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

```

```

[#_links]
[.api-collapsible-fifth-title]
_links

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|metadata
|link:#href[href]

```

```
a|
```

```
|self  
|link:#href[href]  
a|
```

```
|===
```

```
[#bytes_used]  
[.api-collapsible-fifth-title]  
bytes_used
```

Number of bytes used on-disk, broken down by date of last access.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|labels
```

```
|array[string]
```

```
a|Labels for this histogram
```

```
|newest_label
```

```
|string
```

```
a|Each label indicates the period of time the corresponding data is  
associated with. A label can take one of the following forms:<ul>  
  a partial date in an extended ISO8601 representation  
  an interval between partial dates in an extended ISO8601 representation,  
  where "--" is used to separate the beginning and end of the interval  
  the string literal "unknown"
```

```
</ul>For partial dates and partial date intervals where components of a  
date are unspecified, the label allows for any valid normalized values the  
unspecified components might take. For example, the label "2017" allows  
for any time within the year 2017. Essentially, this is the fully  
specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly,  
the interval "2018-05--2018-07" allows for any time within the months of  
May, June, and July in 2018, corresponding to the fully specified interval  
2018-05-01T00:00:00--2018-07-31T23:59:59.
```

```
The following extensions to ISO8601 are used:<ul>
```

```
  Quarters may be specified. The form yyyy-Q_q is used to represent
```

the `__q__`th quarter of the year `__yyyy__`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>

- a partial date in an extended ISO8601 representation
- an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval
- the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `__yyyy__-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy__`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

```
|percentages
|array[number]
a|Percentages for this histogram
```

```
|values
|array[integer]
a|Values for this histogram
```

```
|===
```

```
[#by_accessed_time]
[.api-collapsible-fifth-title]
by_accessed_time
```

File system analytics information, broken down by date of last access.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|bytes_used
|link:#bytes_used[bytes_used]
a|Number of bytes used on-disk, broken down by date of last access.
```

```
|===
```

```
[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used
```

Number of bytes used on-disk, broken down by date of last modification.

```
[cols=3*,options=header]
```

|===

|Name

|Type

|Description

|labels

|array[string]

a|Labels for this histogram

|newest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>  
a partial date in an extended ISO8601 representation  
an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval  
the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `_yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `_yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>

- a partial date in an extended ISO8601 representation
- an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval
- the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `__yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|percentages

|array[number]

a|Percentages for this histogram

|values

|array[integer]

a|Values for this histogram



```
|===
```

```
[#by_modified_time]  
[.api-collapsible-fifth-title]  
by_modified_time
```

File system analytics information, broken down by date of last modification.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|bytes_used
```

```
|link:#bytes_used[bytes_used]
```

a|Number of bytes used on-disk, broken down by date of last modification.

```
|===
```

```
[#analytics]  
[.api-collapsible-fifth-title]  
analytics
```

Additional file system analytics information summarizing all descendents of a directory.

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `file-info-response(#model-file-info-response)`. This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html<<model-file_info_response,file_info_response>>`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels,

since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the <<model-file\_info\_response,file\_info\_response>>. This avoids an excessive amount of duplicated information when a [GET /storage/volumes/{volume.uuid}/files/{path}] call returns a large collection.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|by_accessed_time
```

```
|link:#by_accessed_time[by_accessed_time]
```

```
a|File system analytics information, broken down by date of last access.
```

```
|by_modified_time
```

```
|link:#by_modified_time[by_modified_time]
```

```
a|File system analytics information, broken down by date of last modification.
```

```
|bytes_used
```

```
|integer
```

```
a|Number of bytes used on-disk
```

```
|file_count
```

```
|integer
```

```
a|Number of descendants
```

```
|subdir_count
```

```
|integer
```

```
a|Number of sub directories
```

```
|===
```

```
[#constituent]
```

```
[.api-collapsible-fifth-title]
```

```
constituent
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|name
|string
a|FlexGroup volume constituent name.
```

```
|uuid
|string
a|FlexGroup volume constituent UUID.
```

```
|===
```

```
[#file_hole]
[.api-collapsible-fifth-title]
file_hole
```

Range of a hole in a file.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|size
|integer
a|Size of the hole, in bytes.
```

```
|start
|integer
a|Starting offset of the hole.
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
```

`_links`

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|self
```

```
|link:#href[href]
```

```
a|
```

```
|===
```

```
[#qos_policy]
```

```
[.api-collapsible-fifth-title]
```

`qos_policy`

The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both ``qos_policy.uuid`` and ``qos_policy.name`` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property ``qos_policy.name`` in a PATCH request to an empty string `""` or `"none"`.

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on `/storage/luns` to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|name
```

```
|string
```

```
a|The name of the QoS policy. To remove the file from a QoS policy, set this property to an empty string "" or set it to "none" in a PATCH request.
```

```
|uuid
|string
a|The unique identifier of the QoS policy. Valid in PATCH.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the volume.
```

```
|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6
```

```
|===
```

```
[#file_info]
[.api-collapsible-fifth-title]
file_info
```

```
Information about a single file.
```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|accessed_time
|string
a|Last access time of the file in date-time format.

|analytics
|link:#analytics[analytics]
a|Additional file system analytics information summarizing all descendents
of a directory.

```

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `file-info-response(#model-file-info-response)`. This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html<<model-file_info_response,file_info_response>>`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `<<model-file_info_response,file_info_response>>`. This avoids an excessive amount of duplicated information when a `[GET /storage/volumes/{volume.uuid}/files/{path}]` call returns a large collection.

```

|bytes_used

```

```
|integer
a|The actual number of bytes used on disk by this file. If byte_offset and
length parameters are specified, this will return the bytes used by the
file within the given range.

|changed_time
|string
a|Last time data or attributes changed on the file in date-time format.

|constituent
|link:#constituent[constituent]
a|

|creation_time
|string
a|Creation time of the file in date-time format.

|fill_enabled
|boolean
a|Returns "true" if the space reservation is enabled. The field
overwrite_enabled must also be set to the same value as this field.

|group_id
|integer
a|The integer ID of the group of the file owner.

|hard_links_count
|integer
a|The number of hard links to the file.

|holes
|array[link:#file_hole[file_hole]]
a|List of hole ranges in the file.

|inode_generation
|integer
a|Inode generation number.

|inode_number
```

|integer

a|The file inode number.

|is\_empty

|boolean

a|Specifies whether or not a directory is empty. A directory is considered empty if it only contains entries for "." and "..". This element is present if the file is a directory. In some special error cases, such as when the volume goes offline or when the directory is moved while retrieving this info, this field might not get set.

|is\_junction

|boolean

a|Returns "true" if the directory is a junction.

|is\_snapshot

|boolean

a|Returns "true" if the directory is a Snapshot copy.

|is\_vm\_aligned

|boolean

a|Returns true if the file is vm-aligned. A vm-aligned file is a file that is initially padded with zero-filled data so that its actual data starts at an offset other than zero. The amount by which the start offset is adjusted depends on the vm-align setting of the hosting volume.

|modified\_time

|string

a|Last data modification time of the file in date-time format.

|name

|string

a|Name of the file.

|overwrite\_enabled

|boolean

a|Returns "true" if the space reservation for overwrites is enabled. The field fill\_enabled must also be set to the same value as this field.



|owner\_id  
|integer  
a|The integer ID of the file owner.

|path  
|string  
a|Path of the file.

|qos\_policy  
|link:#qos\_policy[qos\_policy]  
a|The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both `qos\_policy.uuid` and `qos\_policy.name` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property `qos\_policy.name` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

|size  
|integer  
a|The size of the file, in bytes.

|target  
|string  
a|The relative or absolute path contained in a symlink, in the form +++<some>+++ /+++<path>+++ .+++</path>++++++</some>+++

|type  
|string  
a|Type of the file.

|unique\_bytes  
|integer  
a|Number of bytes uniquely held by this file. If byte\_offset and length parameters are specified, this will return bytes uniquely held by the file within the given range.

```
|unix_permissions
|integer
a|UNIX permissions to be viewed as an octal number. It consists of 4
digits derived by adding up bits 4 (read), 2 (write), and 1 (execute). The
first digit selects the set user ID(4), set group ID (2), and sticky (1)
attributes. The second digit selects permissions for the owner of the
file; the third selects permissions for other users in the same group; the
fourth selects permissions for other users not in the group.
```

```
|volume
|link:#volume[volume]
a|
```

```
|===
```

```
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|code
|string
a|Argument code
```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```

|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

[[ID4bcffa96a6694cc57facdddca62ab139]]
= Create a new file with the supplied data

[.api-doc-operation .api-doc-operation-post]#POST# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/files/{path}`#

*Introduced In:* 9.8

Creates a new file with the supplied data, creates a new directory or
creates a new symlink.

== Parameters

[cols=5*,options=header]

```

```

|===

|Name
|Type
|In
|Required
|Description

|volume.uuid
|string
|path
|True
a|Volume UUID

|path
|string
|path
|True
a|Relative path of a new file, directory or symlink. The path field
requires using "%2E" to represent "." and "%2F" to represent "/" for the
path provided.

|byte_offset
|integer
|query
|False
a|How many bytes into the file to begin writing. Use -1 to append
(default).

|overwrite
|boolean
|query
|False
a|If false, and the file exists, the write will fail. Default is false.

|stream_name
|string
|query
|False
a|Name of stream associated with the file to write data to.

|data

```

```
|string
|formData
|False
a|Data to write to the file.
```

```
|return_records
|boolean
|query
|False
a|The default is false. If set to true, the records are returned.
```

\* Default value:

```
|===
```

```
== Request Body
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|accessed_time
```

```
|string
```

```
a|Last access time of the file in date-time format.
```

```
|analytics
```

```
|link:#analytics[analytics]
```

```
a|Additional file system analytics information summarizing all descendents of a directory.
```

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histograms.

amlabels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the file-info-response (#model-file-info-response). This avoids an excessive amount of duplicated information when a get-storage-volumes-files-.html<<model-file\_info\_response,file\_info\_response>>, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the <<model-file\_info\_response,file\_info\_response>>. This avoids an excessive amount of duplicated information when a [GET /storage/volumes/{volume.uuid}/files/{path}] call returns a large collection.

|bytes\_used

|integer

a|The actual number of bytes used on disk by this file. If byte\_offset and length parameters are specified, this will return the bytes used by the file within the given range.

|changed\_time

|string

a|Last time data or attributes changed on the file in date-time format.

|constituent

|link:#constituent[constituent]

a|

|creation\_time

|string

a|Creation time of the file in date-time format.

|fill\_enabled

|boolean

a|Returns "true" if the space reservation is enabled. The field overwrite\_enabled must also be set to the same value as this field.

|group\_id

|integer

a|The integer ID of the group of the file owner.

|hard\_links\_count  
|integer  
a|The number of hard links to the file.

|holes  
|array[link:#file\_hole[file\_hole]]  
a|List of hole ranges in the file.

|inode\_generation  
|integer  
a|Inode generation number.

|inode\_number  
|integer  
a|The file inode number.

|is\_empty  
|boolean  
a|Specifies whether or not a directory is empty. A directory is considered empty if it only contains entries for "." and "..". This element is present if the file is a directory. In some special error cases, such as when the volume goes offline or when the directory is moved while retrieving this info, this field might not get set.

|is\_junction  
|boolean  
a|Returns "true" if the directory is a junction.

|is\_snapshot  
|boolean  
a|Returns "true" if the directory is a Snapshot copy.

|is\_vm\_aligned  
|boolean  
a|Returns true if the file is vm-aligned. A vm-aligned file is a file that is initially padded with zero-filled data so that its actual data starts at an offset other than zero. The amount by which the start offset is adjusted depends on the vm-align setting of the hosting volume.

|modified\_time  
|string  
a|Last data modification time of the file in date-time format.

|name  
|string  
a|Name of the file.

|overwrite\_enabled  
|boolean  
a|Returns "true" if the space reservation for overwrites is enabled. The field fill\_enabled must also be set to the same value as this field.

|owner\_id  
|integer  
a|The integer ID of the file owner.

|path  
|string  
a|Path of the file.

|qos\_policy  
|link:#qos\_policy[qos\_policy]  
a|The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both `qos\_policy.uuid` and `qos\_policy.name` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property `qos\_policy.name` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

|size  
|integer  
a|The size of the file, in bytes.



```
|target
|string
a|The relative or absolute path contained in a symlink, in the form
+++<some>+++ /+++<path>+++ .+++</path>++++++</some>+++
```

```
|type
|string
a|Type of the file.
```

```
|unique_bytes
|integer
a|Number of bytes uniquely held by this file. If byte_offset and length
parameters are specified, this will return bytes uniquely held by the file
within the given range.
```

```
|unix_permissions
|integer
a|UNIX permissions to be viewed as an octal number. It consists of 4
digits derived by adding up bits 4 (read), 2 (write), and 1 (execute). The
first digit selects the set user ID(4), set group ID (2), and sticky (1)
attributes. The second digit selects permissions for the owner of the
file; the third selects permissions for other users in the same group; the
fourth selects permissions for other users not in the group.
```

```
|volume
|link:#volume[volume]
a|
```

```
|===
```

```
.Example request
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
{
  "_links": {
    "metadata": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  }
}
```

```
},
"accessed_time": "2019-06-12T11:00:16-04:00",
"analytics": {
  "by_accessed_time": {
    "bytes_used": {
      "labels": [
        "2019-07",
        "2019-06",
        "2019-05",
        2019,
        2018,
        "--2017",
        "unknown"
      ],
      "newest_label": "2019-07",
      "oldest_label": "2019-07",
      "percentages": [
        0.1,
        11.24,
        0.18,
        15.75,
        0.75,
        83.5,
        0
      ],
      "values": [
        15925248,
        1735569408,
        27672576,
        2430595072,
        116105216,
        12889948160,
        0
      ]
    }
  },
  "by_modified_time": {
    "bytes_used": {
      "labels": [
        "2019-07",
        "2019-06",
        "2019-05",
        2019,
        2018,
        "--2017",
        "unknown"
      ]
    }
  }
}
```

```

    ],
    "newest_label": "2019-07",
    "oldest_label": "2019-07",
    "percentages": [
        0.1,
        11.24,
        0.18,
        15.75,
        0.75,
        83.5,
        0
    ],
    "values": [
        15925248,
        1735569408,
        27672576,
        2430595072,
        116105216,
        12889948160,
        0
    ]
}
},
"bytes_used": 15436648448,
"file_count": 21134,
"subdir_count": 35
},
"bytes_used": 4096,
"changed_time": "2019-06-12T11:00:16-04:00",
"constituent": {
    "name": "fg__0001",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"creation_time": "2019-06-12T11:00:16-04:00",
"group_id": 30,
"hard_links_count": 1,
"holes": {
},
"inode_generation": 214753547,
"inode_number": 1695,
"is_empty": "",
"is_junction": "",
"is_snapshot": "",
"is_vm_aligned": "",
"modified_time": "2019-06-12T11:00:16-04:00",
"name": "test_file",

```

```
"owner_id": 54738,
"path": "d1/d2/d3",
"qos_policy": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "qos1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"size": 200,
"target": "some_directory/some_other_directory/some_file",
"type": "file",
"unique_bytes": 4096,
"unix_permissions": 755,
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
====
```

== Response

Status: 201, Created

```
== Error
```

Status: Default

ONTAP Error Response Codes

```
|===
| Error Code | Description
| 917505
| The SVM does not exist.
| 917525
```

```
| The volume in the symlink path does not exist in the SVM.

| 917698
| The volume in the symlink path is not mounted in the namespace.

| 6488064
| This command is not supported.

| 6488065
| The volume in the symlink path is invalid.

| 6488066
| Mounting the unjunctioned volume in the symlink path failed.

| 6488069
| Internal file error.

| 6488084
| Failed to create \{path} because the "unix_permissions" field was not
specified.

| 6488085
| Failed to create \{path} because the "type" field was not specified.

| 8257536
| This operation is not supported for the system volume specified in the
symlink path.

| 8257541
| Failed to compute the SVM identification from this content.

| 8257542
| This operation is not supported for the administrative SVM.

| 9437549
| This operation is not allowed on SVMs with Infinite Volume.

| 13172837
| This operation is not permitted because the SVM is locked for a migrate
operation.
|===

[cols=3*,options=header]
|===
|Name
```

```

|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
=====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
=====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string

```

```

a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|metadata
|link:#href[href]
a|

|self
|link:#href[href]
a|

|===

[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used

Number of bytes used on-disk, broken down by date of last access.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|labels
|array[string]
a|Labels for this histogram

|newest_label
|string
a|Each label indicates the period of time the corresponding data is

```

associated with. A label can take one of the following forms:<ul>  
a partial date in an extended ISO8601 representation  
an interval between partial dates in an extended ISO8601 representation,  
where "--" is used to separate the beginning and end of the interval  
the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `_yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `_yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>  
a partial date in an extended ISO8601 representation  
an interval between partial dates in an extended ISO8601 representation,  
where "--" is used to separate the beginning and end of the interval  
the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully



specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `_yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `_yyyy_`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

```
|percentages
|array[number]
a|Percentages for this histogram
```

```
|values
|array[integer]
a|Values for this histogram
```

```
|===
```

```
[#by_accessed_time]
[.api-collapsible-fifth-title]
by_accessed_time
```

File system analytics information, broken down by date of last access.

```
[cols=3*,options=header]
|===
|Name
|Type
```

```
|Description

|bytes_used
|link:#bytes_used[bytes_used]
a|Number of bytes used on-disk, broken down by date of last access.

|===

[#bytes_used]
[.api-collapsible-fifth-title]
bytes_used

Number of bytes used on-disk, broken down by date of last modification.
```

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description
```

```
|labels
|array[string]
a|Labels for this histogram
```

```
|newest_label
|string
a|Each label indicates the period of time the corresponding data is
associated with. A label can take one of the following forms:<ul>
  a partial date in an extended ISO8601 representation
  an interval between partial dates in an extended ISO8601 representation,
where "--" is used to separate the beginning and end of the interval
  the string literal "unknown"
```

```
</ul>For partial dates and partial date intervals where components of a
date are unspecified, the label allows for any valid normalized values the
unspecified components might take. For example, the label "2017" allows
for any time within the year 2017. Essentially, this is the fully
specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly,
the interval "2018-05--2018-07" allows for any time within the months of
May, June, and July in 2018, corresponding to the fully specified interval
2018-05-01T00:00:00--2018-07-31T23:59:59.
```

```
The following extensions to ISO8601 are used:<ul>
```

Quarters may be specified. The form `__yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy__`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

|oldest\_label

|string

a|Each label indicates the period of time the corresponding data is associated with. A label can take one of the following forms:<ul>

- a partial date in an extended ISO8601 representation
- an interval between partial dates in an extended ISO8601 representation, where "--" is used to separate the beginning and end of the interval
- the string literal "unknown"

</ul>For partial dates and partial date intervals where components of a date are unspecified, the label allows for any valid normalized values the unspecified components might take. For example, the label "2017" allows for any time within the year 2017. Essentially, this is the fully specified interval 2017-01-01T00:00:00--2017-12-31T23:59:59. Similarly, the interval "2018-05--2018-07" allows for any time within the months of May, June, and July in 2018, corresponding to the fully specified interval 2018-05-01T00:00:00--2018-07-31T23:59:59.

The following extensions to ISO8601 are used:<ul>

Quarters may be specified. The form `__yyyy_-Q__q__` is used to represent the `__q__`th quarter of the year `__yyyy__`. Q1 consists of the months January, February, and March; Q2 consists of April, May, and June; Q3 consists of July, August, and September; Q4 consists of October, November, and December. For example, the label "2019-Q2" represents the second quarter of the year 2019, which corresponds to the interval 2019-04-01T00:00:00--2019-06-30T23:59:59.

Either the beginning or end of an interval may be omitted. When the beginning is omitted, the interval includes points in time arbitrarily far in the past. When the end is omitted, the interval includes points in time

through the end of the current week.

</ul>The "unknown" label tracks data that could not be associated with any other time period. This usually occurs when the data was at some point associated with a time in the future.

```
|percentages
|array[number]
a|Percentages for this histogram
```

```
|values
|array[integer]
a|Values for this histogram
```

```
|===
```

```
[#by_modified_time]
[.api-collapsible-fifth-title]
by_modified_time
```

File system analytics information, broken down by date of last modification.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|bytes_used
|link:#bytes_used[bytes_used]
a|Number of bytes used on-disk, broken down by date of last modification.
```

```
|===
```

```
[#analytics]
[.api-collapsible-fifth-title]
analytics
```

Additional file system analytics information summarizing all descendents

of a directory.

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `file-info-response(#model-file-info-response)`. This avoids an excessive amount of duplicated information when a `get-storage-volumes-files-.html` `<<model-file_info_response,file_info_response>>`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection. The invariant information is instead available via the analytics property of the `<<model-file_info_response,file_info_response>>`. This avoids an excessive amount of duplicated information when a `[GET /storage/volumes/{volume.uuid}/files/{path}]` call returns a large collection.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|by_accessed_time
```

```
|link:#by_accessed_time[by_accessed_time]
```

```
a|File system analytics information, broken down by date of last access.
```

```
|by_modified_time
```

```
|link:#by_modified_time[by_modified_time]
```

```
a|File system analytics information, broken down by date of last modification.
```

```
|bytes_used
```

```
|integer
```

```
a|Number of bytes used on-disk
```

```
|file_count
|integer
a|Number of descendants
```

```
|subdir_count
|integer
a|Number of sub directories
```

```
|===
```

```
[#constituent]
[.api-collapsible-fifth-title]
constituent
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|name
|string
a|FlexGroup volume constituent name.
```

```
|uuid
|string
a|FlexGroup volume constituent UUID.
```

```
|===
```

```
[#file_hole]
[.api-collapsible-fifth-title]
file_hole
```

Range of a hole in a file.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
```

```
|Description
```

```
|size
```

```
|integer
```

```
a|Size of the hole, in bytes.
```

```
|start
```

```
|integer
```

```
a|Starting offset of the hole.
```

```
|===
```

```
[#_links]
```

```
[.api-collapsible-fifth-title]
```

```
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|self
```

```
|link:#href[href]
```

```
a|
```

```
|===
```

```
[#qos_policy]
```

```
[.api-collapsible-fifth-title]
```

```
qos_policy
```

The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both ``qos_policy.uuid`` and ``qos_policy.name`` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property ``qos_policy.name`` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the QoS policy. To remove the file from a QoS policy, set
this property to an empty string "" or set it to "none" in a PATCH
request.

|uuid
|string
a|The unique identifier of the QoS policy. Valid in PATCH.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid

```



```
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
```

```
* Introduced in: 9.6
```

```
|===
```

```
[#file_info]
[.api-collapsible-fifth-title]
file_info
```

Information about a single file.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|accessed_time
|string
a|Last access time of the file in date-time format.
```

```
|analytics
|link:#analytics[analytics]
a|Additional file system analytics information summarizing all descendents
of a directory.
```

This property is only populated if file system analytics is enabled on the containing volume.

In the context of the `records` property of a `xref:{relative_path}file-info-response(#model-file-info-response)`, analytics objects will only include properties that may vary between elements within the collection. For example, the analytics objects will not contain histogram labels, since the same histogram labels are used for all elements within the collection.

on.theinvariantinformationisinsteadavailableviaanalyticsofthefi  
le-info-response(#model-file-info-  
response).thisavoidsanexcessiveamountofduplicatedinformationwhenaget-  
storage-volumes-files-.html<<model-  
file\_info\_response,file\_info\_response>>, analytics objects will only  
include properties that may vary between elements within the collection.  
For example, the analytics objects will not contain histogram labels,  
since the same histogram labels are used for all elements within the  
collection. The invariant information is instead available via the  
analytics property of the <<model-file\_info\_response,file\_info\_response>>.  
This avoids an excessive amount of duplicated information when a [GET  
/storage/volumes/{volume.uuid}/files/{path}] call returns a large  
collection.

|bytes\_used

|integer

a|The actual number of bytes used on disk by this file. If byte\_offset and  
length parameters are specified, this will return the bytes used by the  
file within the given range.

|changed\_time

|string

a|Last time data or attributes changed on the file in date-time format.

|constituent

|link:#constituent[constituent]

a|

|creation\_time

|string

a|Creation time of the file in date-time format.

|fill\_enabled

|boolean

a|Returns "true" if the space reservation is enabled. The field  
overwrite\_enabled must also be set to the same value as this field.

|group\_id

|integer

a|The integer ID of the group of the file owner.

|hard\_links\_count  
|integer  
a|The number of hard links to the file.

|holes  
|array[link:#file\_hole[file\_hole]]  
a|List of hole ranges in the file.

|inode\_generation  
|integer  
a|Inode generation number.

|inode\_number  
|integer  
a|The file inode number.

|is\_empty  
|boolean  
a|Specifies whether or not a directory is empty. A directory is considered empty if it only contains entries for "." and "..". This element is present if the file is a directory. In some special error cases, such as when the volume goes offline or when the directory is moved while retrieving this info, this field might not get set.

|is\_junction  
|boolean  
a|Returns "true" if the directory is a junction.

|is\_snapshot  
|boolean  
a|Returns "true" if the directory is a Snapshot copy.

|is\_vm\_aligned  
|boolean  
a|Returns true if the file is vm-aligned. A vm-aligned file is a file that is initially padded with zero-filled data so that its actual data starts at an offset other than zero. The amount by which the start offset is adjusted depends on the vm-align setting of the hosting volume.

|modified\_time  
|string  
a|Last data modification time of the file in date-time format.

|name  
|string  
a|Name of the file.

|overwrite\_enabled  
|boolean  
a|Returns "true" if the space reservation for overwrites is enabled. The field fill\_enabled must also be set to the same value as this field.

|owner\_id  
|integer  
a|The integer ID of the file owner.

|path  
|string  
a|Path of the file.

|qos\_policy  
|link:#qos\_policy[qos\_policy]  
a|The QoS policy for the file. Both traditional and adaptive QoS policies are supported. If both `qos\_policy.uuid` and `qos\_policy.name` properties are specified in the same request, they must refer to the same QoS policy. To remove the file from a QoS policy, set the property `qos\_policy.name` in a PATCH request to an empty string "" or "none".

NOTE: Files which are in use as a LUN cannot be assigned to a QoS policy, instead use PATCH on /storage/luns to assign a QoS policy for such files.

Note that a QoS policy can be set on a file, or a file's volume, but not on both.

|size  
|integer  
a|The size of the file, in bytes.

|target

```

|string
a|The relative or absolute path contained in a symlink, in the form
+++<some>+++ /+++<path>+++ .+++</path>+++++</some>+++

|type
|string
a|Type of the file.

|unique_bytes
|integer
a|Number of bytes uniquely held by this file. If byte_offset and length
parameters are specified, this will return bytes uniquely held by the file
within the given range.

|unix_permissions
|integer
a|UNIX permissions to be viewed as an octal number. It consists of 4
digits derived by adding up bits 4 (read), 2 (write), and 1 (execute). The
first digit selects the set user ID(4), set group ID (2), and sticky (1)
attributes. The second digit selects permissions for the owner of the
file; the third selects permissions for other users in the same group; the
fourth selects permissions for other users not in the group.

|volume
|link:#volume[volume]
a|

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
====
```

```
[[ID8ff48dc147421ac11ad2c7426ae2b79a]]
= Retrieve historical performance metrics for a volume
```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-  
block]#`/storage/volumes/{volume.uuid}/metrics`#
```

\*Introduced In:\* 9.7

Retrieves historical performance metrics for a volume.

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|duration
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by duration
```

```
|throughput.other
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by throughput.other
```

```
|throughput.read
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by throughput.read
```

```
|throughput.write
```

```
|integer
```

```
|query
```

```
|False  
a|Filter by throughput.write
```

```
|throughput.total  
|integer  
|query  
|False  
a|Filter by throughput.total
```

```
|timestamp  
|string  
|query  
|False  
a|Filter by timestamp
```

```
|cloud.duration  
|string  
|query  
|False  
a|Filter by cloud.duration
```

```
|cloud.status  
|string  
|query  
|False  
a|Filter by cloud.status
```

```
|cloud.iops.other  
|integer  
|query  
|False  
a|Filter by cloud.iops.other
```

```
|cloud.iops.read  
|integer  
|query  
|False  
a|Filter by cloud.iops.read
```

```
|cloud.iops.write
```



```
|integer  
|query  
|False  
a|Filter by cloud.iops.write
```

```
|cloud.iops.total  
|integer  
|query  
|False  
a|Filter by cloud.iops.total
```

```
|cloud.latency.other  
|integer  
|query  
|False  
a|Filter by cloud.latency.other
```

```
|cloud.latency.read  
|integer  
|query  
|False  
a|Filter by cloud.latency.read
```

```
|cloud.latency.write  
|integer  
|query  
|False  
a|Filter by cloud.latency.write
```

```
|cloud.latency.total  
|integer  
|query  
|False  
a|Filter by cloud.latency.total
```

```
|cloud.timestamp  
|string  
|query  
|False  
a|Filter by cloud.timestamp
```

```
|flexcache.timestamp
|string
|query
|False
a|Filter by flexcache.timestamp
```

\* Introduced in: 9.8

```
|flexcache.duration
|string
|query
|False
a|Filter by flexcache.duration
```

\* Introduced in: 9.8

```
|flexcache.bandwidth_savings
|integer
|query
|False
a|Filter by flexcache.bandwidth_savings
```

\* Introduced in: 9.9

```
|flexcache.status
|string
|query
|False
a|Filter by flexcache.status
```

\* Introduced in: 9.8

```
|flexcache.cache_miss_percent
|integer
|query
|False
a|Filter by flexcache.cache_miss_percent
```

\* Introduced in: 9.8

```
|status
```

```
|string  
|query  
|False  
a|Filter by status
```

```
|iops.other  
|integer  
|query  
|False  
a|Filter by iops.other
```

```
|iops.read  
|integer  
|query  
|False  
a|Filter by iops.read
```

```
|iops.write  
|integer  
|query  
|False  
a|Filter by iops.write
```

```
|iops.total  
|integer  
|query  
|False  
a|Filter by iops.total
```

```
|latency.other  
|integer  
|query  
|False  
a|Filter by latency.other
```

```
|latency.read  
|integer  
|query  
|False  
a|Filter by latency.read
```

```
|latency.write
|integer
|query
|False
a|Filter by latency.write
```

```
|latency.total
|integer
|query
|False
a|Filter by latency.total
```

```
|volume.uuid
|string
|path
|True
a|Unique identifier of the volume.
```

```
|interval
|string
|query
|False
a|The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y.
The period for each time range is as follows:
```

- \* 1h: Metrics over the most recent hour sampled over 15 seconds.
- \* 1d: Metrics over the most recent day sampled over 5 minutes.
- \* 1w: Metrics over the most recent week sampled over 30 minutes.
- \* 1m: Metrics over the most recent month sampled over 2 hours.
- \* 1y: Metrics over the most recent year sampled over a day.
- \* Default value: 1
- \* enum: ["1h", "1d", "1w", "1m", "1y"]

```
|return_timeout
|integer
|query
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.
```

\* Default value: 1

\* Max value: 120

\* Min value: 0

|fields

|array[string]

|query

|False

a|Specify the fields to return.

|max\_records

|integer

|query

|False

a|Limit the number of records returned.

|order\_by

|array[string]

|query

|False

a|Order results by specified fields and optional [asc|desc] direction.  
Default direction is 'asc' for ascending.

|return\_records

|boolean

|query

|False

a|The default is true for GET calls. When set to false, only the number  
of records is returned.

\* Default value: 1

|===

== Response

Status: 200, Ok

[cols=3\*,options=header]

|===

|Name

|Type

```
|Description
```

```
  |_links
```

```
  |link:#_links[_links]
```

```
a|
```

```
  |num_records
```

```
  |integer
```

```
a|Number of records
```

```
  |records
```

```
  |array[link:#records[records]]
```

```
a|
```

```
|===
```

```
.Example response
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{  
  "_links": {  
    "next": {  
      "href": "/api/resourcelink"  
    },  
    "self": {  
      "href": "/api/resourcelink"  
    }  
  },  
  "records": {  
    "_links": {  
      "self": {  
        "href": "/api/resourcelink"  
      }  
    },  
    "duration": "PT15S",  
    "iops": {  
      "read": 200,  
      "total": 1000,  
      "write": 100  
    },  
    "latency": {  
      "read": 200,  
      "total": 1000,  
    }  
  }  
}
```

```

    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25T11:20:13Z"
}
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
}

```

```

====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|next
|link:#href[href]
a|

|self
|link:#href[href]
a|

|===

```



```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```
[#iops]
[.api-collapsible-fifth-title]
iops
```

The rate of I/O operations observed at the storage object.

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|other
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.
```

```
|read
|integer
a|Performance metric for read I/O operations.
```

```
|total
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#latency]
[.api-collapsible-fifth-title]
latency
```

The round trip latency in microseconds observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|other
```

```
|integer
a|Performance metric for other I/O operations. Other I/O operations can be
metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#throughput]
[.api-collapsible-fifth-title]
throughput
```

The rate of throughput bytes per second observed at the storage object.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|other
```

```
|integer
```

```
a|Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
```

```
|read
```

```
|integer
```

```
a|Performance metric for read I/O operations.
```

```
|total
```

```
|integer
```

```
a|Performance metric aggregated over all types of I/O operations.
```

```
|write
```

```
|integer
```

```
a|Performance metric for write I/O operations.
```

```
|===
```

```
[#records]
```

```
[.api-collapsible-fifth-title]
```

```
records
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

|duration  
|string  
a|The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

|iops  
|link:#iops[iops]  
a|The rate of I/O operations observed at the storage object.

|latency  
|link:#latency[latency]  
a|The round trip latency in microseconds observed at the storage object.

|status  
|string  
a|Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled\_data". "Inconsistent\_delta\_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative\_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent\_old\_data" is returned when one or more nodes do not have the latest data.

|throughput  
|link:#throughput[throughput]  
a|The rate of throughput bytes per second observed at the storage object.

|timestamp  
|string  
a|The timestamp of the performance data.

|===

[#error\_arguments]

```
[.api-collapsible-fifth-title]
```

```
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Argument code
```

```
|message
```

```
|string
```

```
a|Message argument
```

```
|===
```

```
[#error]
```

```
[.api-collapsible-fifth-title]
```

```
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|arguments
```

```
|array[link:#error_arguments[error_arguments]]
```

```
a|Message arguments
```

```
|code
```

```
|string
```

```
a|Error code
```

```
|message
```

```
|string
```

```
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
=====
```

```
:leveloffset: -1
```

```
= Manage volume Snapshot copies
```

```
:leveloffset: +1
```

```
[[ID3eb8627d980627a3282437d6c8449069]]
```

```
= Storage volumes volume.uuid snapshots endpoint overview
```

```
== Overview
```

A Snapshot copy is the view of the filesystem as it exists at the time when the Snapshot copy is created.

In ONTAP, different types of Snapshot copies are supported, such as scheduled Snapshot copies, user requested Snapshot copies, SnapMirror Snapshot copies, and so on.

ONTAP Snapshot copy APIs allow you to create, modify, delete and retrieve Snapshot copies.

ONTAP Bulk Snapshot copy APIs allow you to create, modify, delete and retrieve Snapshot copies on multiple volumes in one request.

```
== Snapshot copy APIs
```

The following APIs are used to perform operations related to Snapshot copies.

```
&ndash; POST /api/storage/volumes/{volume.uuid}/snapshots
```

```
&ndash; GET      /api/storage/volumes/{volume.uuid}/snapshots
&ndash; GET      /api/storage/volumes/{volume.uuid}/snapshots/{uuid}
&ndash; PATCH     /api/storage/volumes/{volume.uuid}/snapshots/{uuid}
&ndash; DELETE    /api/storage/volumes/{volume.uuid}/snapshots/{uuid}
```

The following APIs are used to perform bulk operations related to Snapshot copies.

```
&ndash; POST      /api/storage/volumes/*/snapshots
&ndash; GET      /api/storage/volumes/*/snapshots
&ndash; PATCH     /api/storage/volumes/*/snapshots/{uuid}
&ndash; DELETE    /api/storage/volumes/*/snapshots/{uuid}
```

== Examples

=== Creating a Snapshot copy

The POST operation is used to create a Snapshot copy with the specified attributes.

----

# The API:

```
/api/storage/volumes/{volume.uuid}/snapshots
```

# The call:

```
curl -X POST "https://<mgmt-
ip>/api/storage/volumes/{volume.uuid}/snapshots" -H "accept:
application/hal+json" -d '{"name": "snapshot_copy", "comment": "Store this
copy." }'
```

# The response:

```
HTTP/1.1 202 Accepted
Date: Wed, 13 Mar 2019 22:43:34 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Location: /api/storage/volumes/0353dc05-405f-11e9-acb6-
005056bbc848/snapshots/?name=snapshot_copy
Content-Length: 189
Content-Type: application/json
```

```

{
  "num_records": 1,
  "records": [
    {
      "volume": {
        "name": "v2"
      },
      "svm": {
        "uuid": "8139f958-3c6e-11e9-a45f-005056bbc848",
        "name": "vs0"
      },
      "name": "snapshot_copy",
      "comment": "Store this copy."
    }
  ],
  "job": {
    "uuid": "6f68c85b-45e1-11e9-8fc7-005056bbc848",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/6f68c85b-45e1-11e9-8fc7-005056bbc848"
      }
    }
  }
}

```

# The Job:

HTTP/1.1 200 OK

Date: Wed, 13 Mar 2019 22:43:57 GMT

Server: libzapid-httpd

X-Content-Type-Options: nosniff

Cache-Control: no-cache,no-store,must-revalidate

Content-Length: 224

Content-Type: application/json

```

{
  "uuid": "6f68c85b-45e1-11e9-8fc7-005056bbc848",
  "description": "POST /api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848/snapshots/?name=snapshot_copy",
  "state": "success",
  "message": "success",
  "code": 0
}

```

----

=== Retrieving Snapshot copy attributes

The GET operation is used to retrieve Snapshot copy attributes.



----

# The API:

```
/api/storage/volumes/{volume.uuid}/snapshots
```

# The call:

```
curl -X GET "https://<mgmt-  
ip>/api/storage/volumes/{volume.uuid}/snapshots" -H "accept:  
application/hal+json"
```

# The response:

HTTP/1.1 200 OK

Date: Wed, 13 Mar 2019 21:14:06 GMT

Server: libzapid-httpd

X-Content-Type-Options: nosniff

Cache-Control: no-cache,no-store,must-revalidate

Content-Type: application/json

Transfer-Encoding: chunked

```
{  
"records": [  
  {  
    "uuid": "402b6c73-73a0-4e89-a58a-75ee0ab3e8c0",  
    "name": "hourly.2019-03-13_1305",  
    "_links": {  
      "self": {  
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-  
005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0"  
      }  
    }  
  },  
  {  
    "uuid": "f0dd497f-efe8-44b7-a4f4-bdd3890bc0c8",  
    "name": "hourly.2019-03-13_1405",  
    "_links": {  
      "self": {  
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-  
005056bbc848/snapshots/f0dd497f-efe8-44b7-a4f4-bdd3890bc0c8"  
      }  
    }  
  },  
  {  
    "uuid": "02701900-51bd-46b8-9c77-47d9a9e2ce1d",  
    "name": "hourly.2019-03-13_1522",  
    "_links": {  
      "self": {
```

```

        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-
005056bbc848/snapshots/02701900-51bd-46b8-9c77-47d9a9e2ce1d"
    }
}
]
,
"num_records": 3,
"_links": {
    "self": {
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-
005056bbc848/snapshots"
    }
}
}
}
-----

```

=== Creating bulk Snapshot copies

The POST operation is used to create a Snapshot copy with the same name on multiple volumes in one request.

This operation accepts a volume UUID or volume name and SVM, and a Snapshot copy name.

This operation only supports SnapMirror label attributes to be added to Snapshot copies during creation.

-----

# The API:

```
/api/storage/volumes/*/snapshots
```

# The call:

```
curl -k -u admin -X POST "https://<mgmt-
ip>/api/storage/volumes/*/snapshots" -H 'accept: application/hal+json' -d
'{"records": [{"volume.uuid": "e8815adb-5209-11ec-b4ad-005056bbc3e8",
"name": "snapshot_copy"}, {"volume.uuid": "efda9101-5209-11ec-b4ad-
005056bbc3e8", "name": "snapshot_copy"}]}'
```

# The response:

```
HTTP/1.1 202 Accepted
Date: Tue, 14 Dec 2021 20:18:13 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Security-Policy: default-src 'self'; script-src 'self' 'unsafe-
inline'; style-src 'self' 'unsafe-inline'; img-src 'self' data:; frame-
ancestors: 'self'
```

```
Location: /api/storage/volumes/*/snapshots/
Content-Length: 209
Content-Type: application/json
{
  "num_records": 2,
  "job": {
    "uuid": "f7130fc0-5d1a-11ec-b78c-005056bbb467",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/f7130fc0-5d1a-11ec-b78c-005056bbb467"
      }
    }
  }
}
```

# The Job:

```
HTTP/1.1 200 OK
Date: Tue, 14 Dec 2021 20:20:54 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Security-Policy: default-src 'self'; script-src 'self' 'unsafe-
inline'; style-src 'self' 'unsafe-inline'; img-src 'self' data;; frame-
ancestors: 'self'
Content-Length: 258
Content-Type: application/json
Vary: Accept-Encoding
{
  "uuid": "f7130fc0-5d1a-11ec-b78c-005056bbb467",
  "description": "POST /api/storage/volumes/*/snapshots/",
  "state": "success",
  "message": "success",
  "code": 0,
  "start_time": "2021-12-14T15:18:13-05:00",
  "end_time": "2021-12-14T15:18:13-05:00"
}
----
```

=== Retrieving Snapshot copy advanced attributes

A collection GET request is used to calculate the amount of Snapshot copy reclaimable space.

When the advanced privilege field 'reclaimable space' is requested, the API returns the amount of reclaimable space for the queried list of Snapshot copies.

```
-----  
  
# The API:  
/api/storage/volumes/{volume.uuid}/snapshots?fields=reclaimable_space  
  
# The call:  
curl -X GET "https://<mgmt-  
ip>/api/storage/volumes/{volume.uuid}/snapshots?fields=reclaimable_space&n  
ame=hourly.2019-03-13_1305&#124;hourly.2019-03-13_1405&#124;hourly.2019-  
03-13_1522" -H "accept: application/hal+json"  
  
# The response:  
HTTP/1.1 200 OK  
Date: Wed, 13 Mar 2019 21:14:06 GMT  
Server: libzapid-httpd  
X-Content-Type-Options: nosniff  
Cache-Control: no-cache,no-store,must-revalidate  
Content-Type: application/json  
Transfer-Encoding: chunked  
{  
"records": [  
  {  
    "uuid": "402b6c73-73a0-4e89-a58a-75ee0ab3e8c0",  
    "name": "hourly.2019-03-13_1305",  
    "_links": {  
      "self": {  
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-  
005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0"  
      }  
    }  
  },  
  {  
    "uuid": "f0dd497f-efe8-44b7-a4f4-bdd3890bc0c8",  
    "name": "hourly.2019-03-13_1405",  
    "_links": {  
      "self": {  
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-  
005056bbc848/snapshots/f0dd497f-efe8-44b7-a4f4-bdd3890bc0c8"  
      }  
    }  
  },  
  {  
    "uuid": "02701900-51bd-46b8-9c77-47d9a9e2ce1d",  
    "name": "hourly.2019-03-13_1522",  
    "_links": {  
      "self": {
```

```

        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-
005056bbc848/snapshots/02701900-51bd-46b8-9c77-47d9a9e2ce1d"
    }
}
]
,
"num_records": 3,
"reclaimable_space": 1567832,
"_links": {
    "self": {
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-
005056bbc848/snapshots"
    }
}
}
-----

```

=== Retrieving the attributes of a specific Snapshot copy

The GET operation is used to retrieve the attributes of a specific Snapshot copy.

-----

# The API:

```
/api/storage/volumes/{volume.uuid}/snapshots/{uuid}
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/0353dc05-405f-11e9-
acb6-005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0" -H
"accept: application/hal+json"
```

# The response:

```
HTTP/1.1 200 OK
Date: Wed, 13 Mar 2019 22:39:26 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 308
Content-Type: application/json
{
  "volume": {
    "uuid": "0353dc05-405f-11e9-acb6-005056bbc848",
    "name": "v2",
    "_links": {
      "self": {
```

```

        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848"
    }
}
},
"uuid": "402b6c73-73a0-4e89-a58a-75ee0ab3e8c0",
"svm": {
    "uuid": "8139f958-3c6e-11e9-a45f-005056bbc848",
    "name": "vs0",
    "_links": {
        "self": {
            "href": "/api/svm/svms/8139f958-3c6e-11e9-a45f-005056bbc848"
        }
    }
},
"name": "hourly.2019-03-13_1305",
"create_time": "2019-03-13T13:05:00-04:00",
"size": 122880,
_links": {
    "self": {
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0"
    }
}
}
}
-----

```

=== Retrieving the advanced attributes of a specific Snapshot copy

The GET operation is used to retrieve the attributes of a specific Snapshot copy. Snapshot copy reclaimable space can be requested during a GET request.

When the advanced privilege field reclaimable space is requested, the API returns the amount of reclaimable space for the Snapshot copy.

-----

# The API:

```
/api/storage/volumes/{volume.uuid}/snapshots/{uuid}?fields=reclaimable_space
```

# The call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0?fields=*" -H "accept: application/hal+json"
```

# The response:

```
HTTP/1.1 200 OK
Date: Wed, 13 Mar 2019 22:39:26 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 308
Content-Type: application/json
{
  "volume": {
    "uuid": "0353dc05-405f-11e9-acb6-005056bbc848",
    "name": "v2",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848"
      }
    }
  },
  "uuid": "402b6c73-73a0-4e89-a58a-75ee0ab3e8c0",
  "svm": {
    "uuid": "8139f958-3c6e-11e9-a45f-005056bbc848",
    "name": "vs0",
    "_links": {
      "self": {
        "href": "/api/svm/svms/8139f958-3c6e-11e9-a45f-005056bbc848"
      }
    }
  },
  "name": "hourly.2019-03-13_1305",
  "reclaimable_space": 167832,
  "_links": {
    "self": {
      "href": "/api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848/snapshots/402b6c73-73a0-4e89-a58a-75ee0ab3e8c0"
    }
  }
}
-----
```

=== Retrieving bulk Snapshot copies

The bulk GET operation is used to retrieve Snapshot copy attributes across all volumes.

-----

# The API:

```
/api/storage/volumes/*/snapshots
```

```
# The call:
```

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/*/snapshots" -H  
"accept: application/hal+json"
```

```
# The response:
```

```
HTTP/1.1 200 OK
```

```
{  
  "records": [  
    {  
      "volume": {  
        "uuid": "966c285f-47f7-11ec-8407-005056bbc08f",  
        "name": "v1"  
      },  
      "uuid": "3edba912-5507-4535-adce-e12fe5c0e31c",  
      "name": "daily.2021-11-18_0010"  
    },  
    {  
      "volume": {  
        "uuid": "966c285f-47f7-11ec-8407-005056bbc08f",  
        "name": "v1"  
      },  
      "uuid": "3ad61153-d5ef-495d-8e0e-5c3b8bbaf5e6",  
      "name": "hourly.2021-11-18_0705"  
    },  
    {  
      "volume": {  
        "uuid": "99c974e3-47f7-11ec-8407-005056bbc08f",  
        "name": "v2"  
      },  
      "uuid": "3dd0fa97-65d9-41ea-a99d-5ceb9d2f55c5",  
      "name": "daily.2021-11-18_0010"  
    },  
    {  
      "volume": {  
        "uuid": "99c974e3-47f7-11ec-8407-005056bbc08f",  
        "name": "v2"  
      },  
      "uuid": "6ca20a52-c342-4753-8865-3693fa9b7e23",  
      "name": "hourly.2021-11-18_0705"  
    },  
  ],  
  "num_records": 4  
}
```

```
----
```



=== Updating a Snapshot copy

The PATCH operation is used to update the specific attributes of a Snapshot copy.

----

# The API:

```
/api/storage/volumes/{volume.uuid}/snapshots/{uuid}
```

# The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/0353dc05-405f-11e9-  
acb6-005056bbc848/snapshots/16f7008c-18fd-4a7d-8485-a0e290d9db7f" -d  
'{"name": "snapshot_copy_new" }' -H "accept: application/hal+json"
```

# The response:

```
HTTP/1.1 202 Accepted
```

```
Date: Wed, 13 Mar 2019 22:50:44 GMT
```

```
Server: libzapid-httpd
```

```
X-Content-Type-Options: nosniff
```

```
Cache-Control: no-cache,no-store,must-revalidate
```

```
Content-Length: 189
```

```
Content-Type: application/json
```

```
{  
  "job": {  
    "uuid": "6f7c3a82-45e2-11e9-8fc7-005056bbc848",  
    "_links": {  
      "self": {  
        "href": "/api/cluster/jobs/6f7c3a82-45e2-11e9-8fc7-005056bbc848"  
      }  
    }  
  }  
}
```

# The Job:

```
HTTP/1.1 200 OK
```

```
Date: Wed, 13 Mar 2019 22:54:16 GMT
```

```
Server: libzapid-httpd
```

```
X-Content-Type-Options: nosniff
```

```
Cache-Control: no-cache,no-store,must-revalidate
```

```
Content-Length: 242
```

```
Content-Type: application/json
```

```
{  
  "uuid": "6f7c3a82-45e2-11e9-8fc7-005056bbc848",  
  "description": "PATCH /api/storage/volumes/0353dc05-405f-11e9-acb6-
```

```
005056bbc848/snapshots/16f7008c-18fd-4a7d-8485-a0e290d9db7f",
"state": "success",
"message": "success",
"code": 0
}
-----
```

=== Updating bulk Snapshot copies

The bulk PATCH operation is used to update the specific attributes of Snapshot copies across volumes in a single request.

-----

# The API:

```
/api/storage/volumes/*/snapshots
```

# The call:

```
curl -X PATCH "https://<mgmt-ip>/api/storage/volumes/*/snapshots" -d
'{"records": [{"volume.uuid":"e8815adb-5209-11ec-b4ad-005056bbc3e8",
"svm.uuid":"d0e6def5-5209-11ec-b4ad-005056bbc3e8", "uuid":"f9b7714d-1166-
410a-b143-874f27969db6", "comment":"yay"}, {"volume.uuid":"efda9101-5209-
11ec-b4ad-005056bbc3e8", "svm.uuid":"d0e6def5-5209-11ec-b4ad-
005056bbc3e8", "uuid":"514c82a7-bff7-48e2-a13c-5337b09ed41e",
"comment":"yay"}]}' -H "accept: application/hal+json"
```

# The response:

```
HTTP/1.1 202 Accepted
```

```
{
"job": {
  "uuid": "1e9a561f-520f-11ec-b4ad-005056bbc3e8",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/1e9a561f-520f-11ec-b4ad-005056bbc3e8"
    },
    "results": {
      "href": "/api/storage/volumes/*/snapshots?job_results_uuid=1e9a561f-
520f-11ec-b4ad-005056bbc3e8"
    }
  }
}
}
```

# The Job:

```
curl -u admin:netappl! -k -X GET --header 'Content-Type: application/json'
--header 'Accept: application/json' 'https://<mgmt-
```

```

ip>/api/storage/volumes/*/snapshots?job_results_uuid=1e9a561f-520f-11ec-
b4ad-005056bbc3e8'
HTTP/1.1 200 OK
{
"records": [
  {
    "volume": {
      "uuid": "e8815adb-5209-11ec-b4ad-005056bbc3e8",
      "name": "v1"
    },
    "uuid": "f9b7714d-1166-410a-b143-874f27969db6",
    "svm": {
      "uuid": "d0e6def5-5209-11ec-b4ad-005056bbc3e8"
    },
    "name": "s1",
    "comment": "yay"
  },
  {
    "volume": {
      "uuid": "efda9101-5209-11ec-b4ad-005056bbc3e8",
      "name": "v2"
    },
    "uuid": "514c82a7-bff7-48e2-a13c-5337b09ed41e",
    "svm": {
      "uuid": "d0e6def5-5209-11ec-b4ad-005056bbc3e8"
    },
    "name": "s1",
    "comment": "yay"
  }
],
"num_records": 2
}
----

=== Deleting a Snapshot copy

The DELETE operation is used to delete a Snapshot copy.

----

# The API:
/api/storage/volumes/{volume.uuid}/snapshots/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/0353dc05-405f-11e9-
acb6-005056bbc848/snapshots/16f7008c-18fd-4a7d-8485-a0e290d9db7f" -H

```

```
"accept: application/hal+json"

# The response:
HTTP/1.1 202 Accepted
Date: Wed, 13 Mar 2019 22:57:51 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 189
Content-Type: application/json
{
  "job": {
    "uuid": "6da1dfdd-45e3-11e9-8fc7-005056bbc848",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/6da1dfdd-45e3-11e9-8fc7-005056bbc848"
      }
    }
  }
}
}
```

```
# The Job:
HTTP/1.1 200 OK
Date: Wed, 13 Mar 2019 23:02:46 GMT
Server: libzapid-httpd
X-Content-Type-Options: nosniff
Cache-Control: no-cache,no-store,must-revalidate
Content-Length: 243
Content-Type: application/json
{
  "uuid": "6da1dfdd-45e3-11e9-8fc7-005056bbc848",
  "description": "DELETE /api/storage/volumes/0353dc05-405f-11e9-acb6-005056bbc848/snapshots/16f7008c-18fd-4a7d-8485-a0e290d9db7f",
  "state": "success",
  "message": "success",
  "code": 0
}
```

----

=== Deleting bulk Snapshot copies

The bulk DELETE operation is used to delete a Snapshot copies across volumes in a single request.

----

```

# The API:
/api/storage/volumes/*/snapshots

# The call:
curl -X DELETE "https://<mgmt-ip>/api/storage/volumes/*/snapshots" -d
'{"records": [{"volume.uuid": "e8815adb-5209-11ec-b4ad-005056bbc3e8",
"uuid": "f9b7714d-1166-410a-b143-874f27969db6"}, {"volume.uuid": "efda9101-
5209-11ec-b4ad-005056bbc3e8", "uuid": "1d55c97a-25f3-4366-bfa8-
9ea75c255469"}]}' -H "accept: application/hal+json"

# The response:
HTTP/1.1 202 Accepted
{
"job": {
  "uuid": "fe114ed7-520f-11ec-b4ad-005056bbc3e8",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/fe114ed7-520f-11ec-b4ad-005056bbc3e8"
    },
    "results": {
      "href": "/api/storage/volumes/*/snapshots?job_results_uuid=fe114ed7-
520f-11ec-b4ad-005056bbc3e8"
    }
  }
}
}

# The Job:
HTTP/1.1 200 OK
curl -u admin:netapp1! -k -X GET --header 'Content-Type: application/json'
--header 'Accept: application/json' 'https://<mgmt-
ip>/api/storage/volumes/*/snapshots?job_results_uuid=fe114ed7-520f-11ec-
b4ad-005056bbc3e8'
{
"records": [
],
"num_records": 0
}
-----

[[IDfedae9aa97c099c96c36c14e6dedad29]]
= Retrieve volume Snapshot copies

```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volumes/{volume.uuid}/snapshots`#
```

\*Introduced In:\* 9.6

Retrieves a collection of volume Snapshot copies.

== Expensive properties

There is an added cost to retrieving the amount of reclaimable space for Snapshot copies, as the calculation is done on demand based on the list of Snapshot copies provided.

\* `reclaimable\_space`

== Related ONTAP commands

\* `snapshot show`

\* `snapshot compute-reclaimable`

== Learn more

\*

xref:{relative\_path}storage\_volumes\_volume.uuid\_snapshots\_endpoint\_overview.html[DOC /storage/volumes/{volume.uuid}/snapshots]

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|volume.uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Volume
```

```
|size
```

```
|integer
```

```
|query
|False
a|Filter by size
```

\* Introduced in: 9.9

```
|expiry_time
|string
|query
|False
a|Filter by expiry_time
```

```
|svm.uuid
|string
|query
|False
a|Filter by svm.uuid
```

```
|svm.name
|string
|query
|False
a|Filter by svm.name
```

```
|create_time
|string
|query
|False
a|Filter by create_time
```

```
|comment
|string
|query
|False
a|Filter by comment
```

```
|snaplock_expiry_time
|string
|query
|False
a|Filter by snaplock_expiry_time
```

```
|name
|string
|query
|False
a|Filter by name
```

```
|state
|string
|query
|False
a|Filter by state
```

```
|version_uuid
|string
|query
|False
a|Filter by version_uuid
```

\* Introduced in: 9.11

```
|volume.name
|string
|query
|False
a|Filter by volume.name
```

```
|provenance_volume.uuid
|string
|query
|False
a|Filter by provenance_volume.uuid
```

\* Introduced in: 9.11

```
|uuid
|string
|query
|False
a|Filter by uuid
```



```
|owners
|string
|query
|False
a|Filter by owners
```

\* Introduced in: 9.7

```
|snapmirror_label
|string
|query
|False
a|Filter by snapmirror_label
```

\* Introduced in: 9.8

```
|reclaimable_space
|integer
|query
|False
a|Filter by reclaimable_space
```

\* Introduced in: 9.10

```
|fields
|array[string]
|query
|False
a|Specify the fields to return.
```

```
|max_records
|integer
|query
|False
a|Limit the number of records returned.
```

```
|return_records
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
```

of records is returned.

\* Default value: 1

|return\_timeout  
|integer  
|query  
|False

a|The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.

\* Default value: 1

\* Max value: 120

\* Min value: 0

|order\_by  
|array[string]  
|query  
|False

a|Order results by specified fields and optional [asc|desc] direction. Default direction is 'asc' for ascending.

|===

== Response

Status: 200, Ok

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|\_links  
|link:#\_links[\_links]  
a|

|num\_records  
|integer  
a|Number of records

```
|reclaimable_space
|integer
a|Space reclaimed when the Snapshot copy is deleted, in bytes.
```

```
|records
|array[link:#snapshot[snapshot]]
a|
```

```
|===
```

.Example response

```
[%collapsible%closed]
```

```
=====
```

```
[source,json,subs=+macros]
```

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "comment": "string",
    "create_time": "2019-02-04T19:00:00Z",
    "expiry_time": "2019-02-04T19:00:00Z",
    "name": "this_snapshot",
    "owners": {
    },
    "provenance_volume": {
      "uuid": "4cd8a442-86d1-11e0-ae1c-125648563413"
    },
    "size": 122880,
    "snaplock_expiry_time": "2019-02-04T19:00:00Z",
    "state": "valid",
    "svm": {
      "_links": {
```

```

    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
"version_uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
"volume": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "volume1",
  "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
}
}
}
====
== Error

```

Status: Default

ONTAP Error Response Code

```

|===
| Error Code | Description
| 918235
| The specified volume is invalid.
|===

```

[cols=3\*,options=header]

```

|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

```

```
|===
```

```
.Example error
```

```
[%collapsible%closed]
```

```
=====
```

```
[source,json,subs=+macros]
```

```
{  
  "error": {  
    "arguments": {  
      "code": "string",  
      "message": "string"  
    },  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

```
=====
```

```
== Definitions
```

```
[.api-def-first-level]
```

```
.See Definitions
```

```
[%collapsible%closed]
```

```
//Start collapsible Definitions block
```

```
=====
```

```
[#href]
```

```
[.api-collapsible-fifth-title]
```

```
href
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|href
```

```
|string
```

```
a|
```

```
|===
```

```
[#_links]
```

```

[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|next
|link:href[href]
a|

|self
|link:href[href]
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:href[href]
a|

|===

[#provenance_volume]
[.api-collapsible-fifth-title]
provenance_volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```
|uuid
|string
a|UUID for the volume that is used to identify the source volume in a mirroring relationship. When the mirroring relationship is broken, a volume's Instance UUID and Provenance UUID are made identical. An unmirrored volume's Provenance UUID is the same as its Instance UUID. This field is valid for flexible volumes only.
```

```
|===
```

```
[#svm]
[.api-collapsible-fifth-title]
svm
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
```

|Description

|\_links

|link:#\_links[\_links]

a|

|name

|string

a|The name of the volume.

|uuid

|string

a|Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.

\* example: 028baa66-41bd-11e9-81d5-00a0986138f7

\* Introduced in: 9.6

|===

[#snapshot]

[.api-collapsible-fifth-title]

snapshot

The Snapshot copy object represents a point in time Snapshot copy of a volume.

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|comment

|string

a|A comment associated with the Snapshot copy. This is an optional attribute for POST or PATCH.



|create\_time  
|string  
a|Creation time of the Snapshot copy. It is the volume access time when the Snapshot copy was created.

|expiry\_time  
|string  
a|The expiry time for the Snapshot copy. This is an optional attribute for POST or PATCH. Snapshot copies with an expiry time set are not allowed to be deleted until the retention time is reached.

|name  
|string  
a|Snapshot copy. Valid in POST or PATCH.

|owners  
|array[string]  
a|

|provenance\_volume  
|link:#provenance\_volume[provenance\_volume]  
a|

|reclaimable\_space  
|integer  
a|Space reclaimed when the Snapshot copy is deleted, in bytes.

|size  
|integer  
a|Size of the active file system at the time the Snapshot copy is captured. The actual size of the Snapshot copy also includes those blocks trapped by other Snapshot copies. On a Snapshot copy deletion, the "size" amount of blocks is the maximum number of blocks available. On a Snapshot copy restore, the "afs-used size" value will match the Snapshot copy "size" value.

|snaplock\_expiry\_time  
|string  
a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted or renamed until the SnapLock ComplianceClock time goes beyond this

retention time.

|snapmirror\_label

|string

a|Label for SnapMirror operations

|state

|string

a|State of the Snapshot copy. There are cases where some Snapshot copies are not complete. In the "partial" state, the Snapshot copy is consistent but exists only on the subset of the constituents that existed prior to the FlexGroup's expansion. Partial Snapshot copies cannot be used for a Snapshot copy restore operation. A Snapshot copy is in an "invalid" state when it is present in some FlexGroup constituents but not in others. At all other times, a Snapshot copy is valid.

|svm

|link:#svm[svm]

a|

|uuid

|string

a|The UUID of the Snapshot copy in the volume that uniquely identifies the Snapshot copy in that volume.

|version\_uuid

|string

a|The 128 bit identifier that uniquely identifies a snapshot and its logical data layout.

|volume

|link:#volume[volume]

a|

|===

[#error\_arguments]

[.api-collapsible-fifth-title]

error\_arguments

[cols=3\*,options=header]

```
|===  
|Name  
|Type  
|Description  
  
|code  
|string  
a|Argument code
```

```
|message  
|string  
a|Message argument
```

```
|===
```

```
[#error]  
[.api-collapsible-fifth-title]  
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|arguments  
|array[link:#error_arguments[error_arguments]]  
a|Message arguments
```

```
|code  
|string  
a|Error code
```

```
|message  
|string  
a|Error message
```

```
|target  
|string  
a|The target parameter that caused the error.
```

|===

//end collapsible .Definitions block

====

[[IDaad9c78b131a738988d816a20546d9d7]]

= Create a volume Snapshot copy

[.api-doc-operation .api-doc-operation-post]#POST# [.api-doc-code-block]#`/storage/volumes/{volume.uuid}/snapshots`#

\*Introduced In:\* 9.6

Creates a volume Snapshot copy.

== Required properties

\* `name` - Name of the Snapshot copy to be created.

== Recommended optional properties

\* `comment` - Comment associated with the Snapshot copy.

\* `expiry\_time` - Snapshot copies with an expiry time set are not allowed to be deleted until the retention time is reached.

\* `snapmirror\_label` - Label for SnapMirror operations.

== Related ONTAP commands

\* `snapshot create`

== Learn more

\*

xref:{relative\_path}storage\_volumes\_volume.uuid\_snapshots\_endpoint\_overview.html[DOC /storage/volumes/{volume.uuid}/snapshots]

== Parameters

[cols=5\*,options=header]

|===

|Name

```
|Type
|In
|Required
|Description
```

```
|volume.uuid
|string
|path
|True
a|Volume UUID
```

```
|return_timeout
|integer
|query
|False
```

a|The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|return_records
|boolean
|query
|False
```

a|The default is false. If set to true, the records are returned.

```
* Default value:
```

```
|===
```

```
== Request Body
```

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
```

```

|Description

|_links
|link:#_links[_links]
a|

|comment
|string
a|A comment associated with the Snapshot copy. This is an optional
attribute for POST or PATCH.

|create_time
|string
a|Creation time of the Snapshot copy. It is the volume access time when
the Snapshot copy was created.

|expiry_time
|string
a|The expiry time for the Snapshot copy. This is an optional attribute for
POST or PATCH. Snapshot copies with an expiry time set are not allowed to
be deleted until the retention time is reached.

|name
|string
a|Snapshot copy. Valid in POST or PATCH.

|owners
|array[string]
a|

|provenance_volume
|link:#provenance_volume[provenance_volume]
a|

|reclaimable_space
|integer
a|Space reclaimed when the Snapshot copy is deleted, in bytes.

|size
|integer
a|Size of the active file system at the time the Snapshot copy is
captured. The actual size of the Snapshot copy also includes those blocks

```

trapped by other Snapshot copies. On a Snapshot copy deletion, the "size" amount of blocks is the maximum number of blocks available. On a Snapshot copy restore, the "afs-used size" value will match the Snapshot copy "size" value.

|snaplock\_expiry\_time

|string

a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted or renamed until the SnapLock ComplianceClock time goes beyond this retention time.

|snapmirror\_label

|string

a|Label for SnapMirror operations

|state

|string

a|State of the Snapshot copy. There are cases where some Snapshot copies are not complete. In the "partial" state, the Snapshot copy is consistent but exists only on the subset of the constituents that existed prior to the FlexGroup's expansion. Partial Snapshot copies cannot be used for a Snapshot copy restore operation. A Snapshot copy is in an "invalid" state when it is present in some FlexGroup constituents but not in others. At all other times, a Snapshot copy is valid.

|svm

|link:#svm[svm]

a|

|uuid

|string

a|The UUID of the Snapshot copy in the volume that uniquely identifies the Snapshot copy in that volume.

|version\_uuid

|string

a|The 128 bit identifier that uniquely identifies a snapshot and its logical data layout.

|volume

```

|link:#volume[volume]
a|

|===

.Example request
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "create_time": "2019-02-04T19:00:00Z",
  "expiry_time": "2019-02-04T19:00:00Z",
  "name": "this_snapshot",
  "owners": {
  },
  "provenance_volume": {
    "uuid": "4cd8a442-86d1-11e0-ae1c-125648563413"
  },
  "size": 122880,
  "snaplock_expiry_time": "2019-02-04T19:00:00Z",
  "state": "valid",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "version_uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",

```



```
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
====
```

== Response

Status: 202, Accepted

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===
```

.Example response

[%collapsible%closed]

====

```
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
====
```

== Error

Status: Default

ONTAP Error Response Code

|===

| Error Code               | Description   |
|--------------------------|---|
| 524479                   | The specified volume is not online or does not have enough space to create a Snapshot copy.           |
| 2621462                  | The specified SVM name does not exist.  |
| 1638433                  | A Snapshot copy with the specified name already exists.   |
| 1638461                  | Snapshot copies can only be created on read/write (RW) volumes.                                       |
| 1638477                  | User-created Snapshot copy names cannot begin with the specified prefix.                              |
| 1638518                  | The specified Snapshot copy name is invalid.  |
| 1638532                  | Failed to create the Snapshot copy on the specified volume because a revert operation is in progress. |
| 1638537                  | Cannot determine the status of the Snapshot copy create operation for the specified volume.           |
| 1638616                  | Bulk Snapshot copy create is not supported with multiple Snapshot copy names.                         |
| 1638617                  | Bulk Snapshot copy create is not supported with volume names in a mixed-version cluster.              |
| 1638618                  | The property cannot be specified for Snapshot copy create.  |
| ===                      |   |
| [cols=3*,options=header] |   |
| ===                      |   |
| Name                     |   |
| Type                     |   |

```

|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

```

```
|===
```

```
[#_links]  
[.api-collapsible-fifth-title]  
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|self  
|link:#href[href]  
a|
```

```
|===
```

```
[#provenance_volume]  
[.api-collapsible-fifth-title]  
provenance_volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|uuid  
|string  
a|UUID for the volume that is used to identify the source volume in a  
mirroring relationship. When the mirroring relationship is broken, a  
volume's Instance UUID and Provenance UUID are made identical. An  
unmirrored volume's Provenance UUID is the same as its Instance UUID. This  
field is valid for flexible volumes only.
```

```
|===
```

```
[#svm]  
[.api-collapsible-fifth-title]  
svm
```

```
[cols=3*,options=header]
```

```

|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
```

```
* Introduced in: 9.6
```

```
|===
```

```
[#snapshot]
```

```
[.api-collapsible-fifth-title]
```

```
snapshot
```

The Snapshot copy object represents a point in time Snapshot copy of a volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|comment
```

```
|string
```

a|A comment associated with the Snapshot copy. This is an optional attribute for POST or PATCH.

```
|create_time
```

```
|string
```

a|Creation time of the Snapshot copy. It is the volume access time when the Snapshot copy was created.

```
|expiry_time
```

```
|string
```

a|The expiry time for the Snapshot copy. This is an optional attribute for POST or PATCH. Snapshot copies with an expiry time set are not allowed to be deleted until the retention time is reached.

```
|name
```

```
|string
```

a|Snapshot copy. Valid in POST or PATCH.

```
|owners
|array[string]
a|
```

```
|provenance_volume
|link:#provenance_volume[provenance_volume]
a|
```

```
|reclaimable_space
|integer
a|Space reclaimed when the Snapshot copy is deleted, in bytes.
```

```
|size
|integer
a|Size of the active file system at the time the Snapshot copy is captured. The actual size of the Snapshot copy also includes those blocks trapped by other Snapshot copies. On a Snapshot copy deletion, the "size" amount of blocks is the maximum number of blocks available. On a Snapshot copy restore, the "afs-used size" value will match the Snapshot copy "size" value.
```

```
|snaplock_expiry_time
|string
a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted or renamed until the SnapLock ComplianceClock time goes beyond this retention time.
```

```
|snapmirror_label
|string
a|Label for SnapMirror operations
```

```
|state
|string
a|State of the Snapshot copy. There are cases where some Snapshot copies are not complete. In the "partial" state, the Snapshot copy is consistent but exists only on the subset of the constituents that existed prior to the FlexGroup's expansion. Partial Snapshot copies cannot be used for a Snapshot copy restore operation. A Snapshot copy is in an "invalid" state when it is present in some FlexGroup constituents but not in others. At all other times, a Snapshot copy is valid.
```

```

|svm
|link:#svm[svm]
a|

|uuid
|string
a|The UUID of the Snapshot copy in the volume that uniquely identifies the
Snapshot copy in that volume.

|version_uuid
|string
a|The 128 bit identifier that uniquely identifies a snapshot and its
logical data layout.

|volume
|link:#volume[volume]
a|

|===

[#job_link]
[.api-collapsible-fifth-title]
job_link

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|uuid
|string
a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or
DELETE operation.

|===

```



```
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Argument code
```

```
|message
```

```
|string
```

```
a|Message argument
```

```
|===
```

```
[#error]
```

```
[.api-collapsible-fifth-title]
```

```
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|arguments
```

```
|array[link:#error_arguments[error_arguments]]
```

```
a|Message arguments
```

```
|code
```

```
|string
```

```
a|Error code
```

```
|message
```

```
|string
```

```
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
=====
```

```
[[IDc1889c6e22c040b59a09ce83d036ce43]]
= Delete a volume Snapshot copy
```

```
[.api-doc-operation .api-doc-operation-delete]#DELETE# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/snapshots/{uuid}`#
```

```
*Introduced In:* 9.6
```

Deletes a Volume Snapshot copy.

```
== Related ONTAP commands
```

```
* `snapshot delete`
```

```
== Learn more
```

```
*
xref:{relative_path}storage_volumes_volume.uuid_snapshots_endpoint_overvie
w.html[DOC /storage/volumes/{volume.uuid}/snapshots]
```

```
== Parameters
```

```
[cols=5*,options=header]
|===
```

```
|Name
|Type
|In
|Required
|Description
```

```
|volume.uuid  
|string  
|path  
|True  
a|Volume UUID
```

```
|uuid  
|string  
|path  
|True  
a|Snapshot copy UUID
```

```
|return_timeout  
|integer  
|query  
|False  
a|The number of seconds to allow the call to execute before returning.  
When doing a POST, PATCH, or DELETE operation on a single record, the  
default is 0 seconds. This means that if an asynchronous operation is  
started, the server immediately returns HTTP code 202 (Accepted) along  
with a link to the job. If a non-zero value is specified for POST, PATCH,  
or DELETE operations, ONTAP waits that length of time to see if the job  
completes so it can return something other than 202.
```

```
* Default value: 1  
* Max value: 120  
* Min value: 0
```

```
|===
```

```
== Response
```

Status: 202, Accepted

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===

.Example response
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
=====

== Error

```

## Status: Default

### ONTAP Error Response Code

```

|===
| Error Code | Description

| 2
| An invalid value was entered for one of the fields.

| 1638521
| Snapshot copies can only be deleted on read/write (RW) volumes.

| 1638538

```

```
| Cannot determine the status of the Snapshot copy delete operation for  
the specified volume.
```

```
| 1638543
```

```
| Failed to delete Snapshot copy because it has an owner.
```

```
| 1638555
```

```
| The specified Snapshot copy has not expired or is locked.
```

```
| 1638600
```

```
| The Snapshot copy does not exist.
```

```
|===
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|error
```

```
|link:#error[error]
```

```
a|
```

```
|===
```

```
.Example error
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{  
  "error": {  
    "arguments": {  
      "code": "string",  
      "message": "string"  
    },  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

```
====
```

```
== Definitions
```

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#job_link]
[.api-collapsible-fifth-title]
job_link

[cols=3*,options=header]
|===
|Name
|Type

```

```

|Description

|_links
|link:#_links[_links]
a|

|uuid
|string
a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or
DELETE operation.

|===

[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments

[cols=3*,options=header]
|===
|Name
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument

|===

[#error]
[.api-collapsible-fifth-title]
error

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```
|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
=====
```

```
[[ID6d26556860d7c5181f19e81431f9014e]]
= Retrieve volume Snapshot copy details
```

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/snapshots/{uuid}`#
```

**\*Introduced In:\*** 9.6

Retrieves details of a specific volume Snapshot copy.

== Related ONTAP commands

\* `snapshot show`

== Learn more

\*

xref:{relative\_path}storage\_volumes\_volume.uuid\_snapshots\_endpoint\_overvie



```
w.html[DOC /storage/volumes/{volume.uuid}/snapshots]
```

```
== Parameters
```

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|volume.uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Volume UUID
```

```
|uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Snapshot copy UUID
```

```
|fields
```

```
|array[string]
```

```
|query
```

```
|False
```

```
a|Specify the fields to return.
```

```
|===
```

```
== Response
```

Status: 200, Ok

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```

|_links
|link:#_links[_links]
a|

|comment
|string
a|A comment associated with the Snapshot copy. This is an optional
attribute for POST or PATCH.

|create_time
|string
a|Creation time of the Snapshot copy. It is the volume access time when
the Snapshot copy was created.

|expiry_time
|string
a|The expiry time for the Snapshot copy. This is an optional attribute for
POST or PATCH. Snapshot copies with an expiry time set are not allowed to
be deleted until the retention time is reached.

|name
|string
a|Snapshot copy. Valid in POST or PATCH.

|owners
|array[string]
a|

|provenance_volume
|link:#provenance_volume[provenance_volume]
a|

|reclaimable_space
|integer
a|Space reclaimed when the Snapshot copy is deleted, in bytes.

|size
|integer
a|Size of the active file system at the time the Snapshot copy is
captured. The actual size of the Snapshot copy also includes those blocks
trapped by other Snapshot copies. On a Snapshot copy deletion, the "size"
amount of blocks is the maximum number of blocks available. On a Snapshot

```

copy restore, the "afs-used size" value will match the Snapshot copy "size" value.

|snaplock\_expiry\_time

|string

a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted or renamed until the SnapLock ComplianceClock time goes beyond this retention time.

|snapmirror\_label

|string

a|Label for SnapMirror operations

|state

|string

a|State of the Snapshot copy. There are cases where some Snapshot copies are not complete. In the "partial" state, the Snapshot copy is consistent but exists only on the subset of the constituents that existed prior to the FlexGroup's expansion. Partial Snapshot copies cannot be used for a Snapshot copy restore operation. A Snapshot copy is in an "invalid" state when it is present in some FlexGroup constituents but not in others. At all other times, a Snapshot copy is valid.

|svm

|link:#svm[svm]

a|

|uuid

|string

a|The UUID of the Snapshot copy in the volume that uniquely identifies the Snapshot copy in that volume.

|version\_uuid

|string

a|The 128 bit identifier that uniquely identifies a snapshot and its logical data layout.

|volume

|link:#volume[volume]

a|

|===

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "create_time": "2019-02-04T19:00:00Z",
  "expiry_time": "2019-02-04T19:00:00Z",
  "name": "this_snapshot",
  "owners": {
  },
  "provenance_volume": {
    "uuid": "4cd8a442-86d1-11e0-ae1c-125648563413"
  },
  "size": 122880,
  "snaplock_expiry_time": "2019-02-04T19:00:00Z",
  "state": "valid",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "version_uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

```
}  
====  
  
== Error
```

Status: Default

ONTAP Error Response Code

```
|===  
| Error Code | Description  
  
| 2  
| An invalid value was entered for one of the fields.  
  
| 262197  
| An invalid field was specified in the request.  
  
| 1638473  
| Snapshot copy tag not found.  
  
| 1638503  
| The Snapshot copy does not exist on the specified volume.  
  
| 1638600  
| The Snapshot copy does not exist.  
  
| 1638615  
| Bulk operations for Snapshot copies are not supported on multiple SVMs.  
|===
```

```
[cols=3*,options=header]
```

```
|===  
|Name  
|Type  
|Description  
  
|error  
|link:#error[error]  
a|  
  
|===
```

```

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#provenance_volume]
[.api-collapsible-fifth-title]
provenance_volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|uuid
|string
a|UUID for the volume that is used to identify the source volume in a
mirroring relationship. When the mirroring relationship is broken, a
volume's Instance UUID and Provenance UUID are made identical. An
unmirrored volume's Provenance UUID is the same as its Instance UUID. This
field is valid for flexible volumes only.

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the volume.
```

```
|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
```

```
* Introduced in: 9.6
```

```
|===
```

```
[#error_arguments]
```



```
[.api-collapsible-fifth-title]
```

```
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Argument code
```

```
|message
```

```
|string
```

```
a|Message argument
```

```
|===
```

```
[#error]
```

```
[.api-collapsible-fifth-title]
```

```
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|arguments
```

```
|array[link:#error_arguments[error_arguments]]
```

```
a|Message arguments
```

```
|code
```

```
|string
```

```
a|Error code
```

```
|message
```

```
|string
```

```
a|Error message
```

```

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
=====

[[ID0a6161d75adde44a1a27b7ecfe4c4593]]
= Update a volume Snapshot copy

[.api-doc-operation .api-doc-operation-patch]#PATCH# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/snapshots/{uuid}`#

*Introduced In:* 9.6

Updates a Volume Snapshot copy.

== Related ONTAP commands

* `snapshot modify`
* `snapshot rename`

== Learn more

*
xref:{relative_path}storage_volumes_volume.uuid.snapshots_endpoint_overvie
w.html[DOC /storage/volumes/{volume.uuid}/snapshots]

== Parameters

[cols=5*,options=header]
|===

|Name
|Type
|In
|Required
|Description

|volume.uuid

```

```
|string
|path
|True
a|Volume UUID
```

```
|uuid
|string
|path
|True
a|Snapshot copy UUID
```

```
|return_timeout
|integer
|query
|False
a|The number of seconds to allow the call to execute before returning.
When doing a POST, PATCH, or DELETE operation on a single record, the
default is 0 seconds. This means that if an asynchronous operation is
started, the server immediately returns HTTP code 202 (Accepted) along
with a link to the job. If a non-zero value is specified for POST, PATCH,
or DELETE operations, ONTAP waits that length of time to see if the job
completes so it can return something other than 202.
```

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|===
```

```
== Request Body
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
 |_links
|link:#_links[_links]
a|
```

```
|comment
|string
```

a|A comment associated with the Snapshot copy. This is an optional attribute for POST or PATCH.

|create\_time

|string

a|Creation time of the Snapshot copy. It is the volume access time when the Snapshot copy was created.

|expiry\_time

|string

a|The expiry time for the Snapshot copy. This is an optional attribute for POST or PATCH. Snapshot copies with an expiry time set are not allowed to be deleted until the retention time is reached.

|name

|string

a|Snapshot copy. Valid in POST or PATCH.

|owners

|array[string]

a|

|provenance\_volume

|link:#provenance\_volume[provenance\_volume]

a|

|reclaimable\_space

|integer

a|Space reclaimed when the Snapshot copy is deleted, in bytes.

|size

|integer

a|Size of the active file system at the time the Snapshot copy is captured. The actual size of the Snapshot copy also includes those blocks trapped by other Snapshot copies. On a Snapshot copy deletion, the "size" amount of blocks is the maximum number of blocks available. On a Snapshot copy restore, the "afs-used size" value will match the Snapshot copy "size" value.

|snaplock\_expiry\_time

|string

a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted or renamed until the SnapLock ComplianceClock time goes beyond this retention time.

|snapmirror\_label

|string

a|Label for SnapMirror operations

|state

|string

a|State of the Snapshot copy. There are cases where some Snapshot copies are not complete. In the "partial" state, the Snapshot copy is consistent but exists only on the subset of the constituents that existed prior to the FlexGroup's expansion. Partial Snapshot copies cannot be used for a Snapshot copy restore operation. A Snapshot copy is in an "invalid" state when it is present in some FlexGroup constituents but not in others. At all other times, a Snapshot copy is valid.

|svm

|link:#svm[svm]

a|

|uuid

|string

a|The UUID of the Snapshot copy in the volume that uniquely identifies the Snapshot copy in that volume.

|version\_uuid

|string

a|The 128 bit identifier that uniquely identifies a snapshot and its logical data layout.

|volume

|link:#volume[volume]

a|

|===

.Example request

[%collapsible%closed]

```
====
[source,json,subs=+macros]
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "create_time": "2019-02-04T19:00:00Z",
  "expiry_time": "2019-02-04T19:00:00Z",
  "name": "this_snapshot",
  "owners": {
  },
  "provenance_volume": {
    "uuid": "4cd8a442-86d1-11e0-ae1c-125648563413"
  },
  "size": 122880,
  "snaplock_expiry_time": "2019-02-04T19:00:00Z",
  "state": "valid",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "version_uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
}
====

== Response
```

Status: 202, Accepted

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|job
|link:#job_link[job_link]
a|

|===

.Example response
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
====

== Error

```

## Status: Default

### ONTAP Error Response Code

```

|===
| Error Code | Description

| 524508
| The Snapshot copy was not renamed because the name entered is not valid.

| 542797
| The specified file or Snapshot copy does not exist.

| 1638455

```

```
| Failed to set comment for Snapshot copy.

| 1638476
| You cannot rename a Snapshot copy created for use as a reference
Snapshot copy by other jobs.

| 1638477
| User-created Snapshot copy names cannot begin with the specified prefix.

| 1638518
| The specified Snapshot copy name is invalid.

| 1638522
| Snapshot copies can only be renamed on read/write (RW) volumes.

| 1638523
| Failed to set the specified SnapMirror label for the Snapshot copy.

| 1638524
| Adding SnapMirror labels is not allowed in a mixed version cluster.

| 1638539
| Cannot determine the status of the Snapshot copy rename operation for
the specified volume.

| 1638554
| Failed to set expiry time for the Snapshot copy.

| 1638600
| The Snapshot copy does not exist.
|===
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|error
```

```
|link:#error[error]
```

```
a|
```

```
|===
```



```

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
[#href]
[.api-collapsible-fifth-title]
href

[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#provenance_volume]
[.api-collapsible-fifth-title]
provenance_volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|uuid
|string
a|UUID for the volume that is used to identify the source volume in a
mirroring relationship. When the mirroring relationship is broken, a
volume's Instance UUID and Provenance UUID are made identical. An
unmirrored volume's Provenance UUID is the same as its Instance UUID. This
field is valid for flexible volumes only.

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|_links
|link:#_links[_links]
a|
```

```
|name
|string
a|The name of the volume.
```

```
|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.
```

```
* example: 028baa66-41bd-11e9-81d5-00a0986138f7
```

```
* Introduced in: 9.6
```

```
|===
```

```
[#snapshot]
```

```
[.api-collapsible-fifth-title]
```

```
snapshot
```

The Snapshot copy object represents a point in time Snapshot copy of a volume.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
 |_links
```

```
 |link:#_links[_links]
```

```
a|
```

```
 |comment
```

```
 |string
```

```
a|A comment associated with the Snapshot copy. This is an optional attribute for POST or PATCH.
```

```
 |create_time
```

```
 |string
```

```
a|Creation time of the Snapshot copy. It is the volume access time when the Snapshot copy was created.
```

```
 |expiry_time
```

```
 |string
```

```
a|The expiry time for the Snapshot copy. This is an optional attribute for POST or PATCH. Snapshot copies with an expiry time set are not allowed to be deleted until the retention time is reached.
```

```
 |name
```

```
 |string
```

```
a|Snapshot copy. Valid in POST or PATCH.
```

```
 |owners
```

```
 |array[string]
```

```
a|
```

```
 |provenance_volume
```

```
 |link:#provenance_volume[provenance_volume]
```

```
a|

|reclaimable_space
|integer
a|Space reclaimed when the Snapshot copy is deleted, in bytes.

|size
|integer
a|Size of the active file system at the time the Snapshot copy is
captured. The actual size of the Snapshot copy also includes those blocks
trapped by other Snapshot copies. On a Snapshot copy deletion, the "size"
amount of blocks is the maximum number of blocks available. On a Snapshot
copy restore, the "afs-used size" value will match the Snapshot copy
"size" value.

|snaplock_expiry_time
|string
a|SnapLock expiry time for the Snapshot copy, if the Snapshot copy is
taken on a SnapLock volume. A Snapshot copy is not allowed to be deleted
or renamed until the SnapLock ComplianceClock time goes beyond this
retention time.

|snapmirror_label
|string
a|Label for SnapMirror operations

|state
|string
a|State of the Snapshot copy. There are cases where some Snapshot copies
are not complete. In the "partial" state, the Snapshot copy is consistent
but exists only on the subset of the constituents that existed prior to
the FlexGroup's expansion. Partial Snapshot copies cannot be used for a
Snapshot copy restore operation. A Snapshot copy is in an "invalid" state
when it is present in some FlexGroup constituents but not in others. At
all other times, a Snapshot copy is valid.

|svm
|link:#svm[svm]
a|

|uuid
|string
```

a|The UUID of the Snapshot copy in the volume that uniquely identifies the Snapshot copy in that volume.

|version\_uuid

|string

a|The 128 bit identifier that uniquely identifies a snapshot and its logical data layout.

|volume

|link:#volume[volume]

a|

|===

[#job\_link]

[.api-collapsible-fifth-title]

job\_link

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|\_links

|link:#\_links[\_links]

a|

|uuid

|string

a|The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

|===

[#error\_arguments]

[.api-collapsible-fifth-title]

error\_arguments

[cols=3\*,options=header]

|===

|Name

```
|Type
|Description

|code
|string
a|Argument code

|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments
```

```
|code
|string
a|Error code
```

```
|message
|string
a|Error message
```

```
|target
|string
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
```

```
====
```

```
:leveloffset: -1
```

```
= Retrieve clients
```

```
:leveloffset: +1
```

```
[[ID9f36e50417b3b61098f43e1365ffbc09]]
```

```
= Storage volumes volume.uuid top-metrics clients endpoint overview
```

```
== Overview
```

You can use this API to retrieve a list of clients with the most IO activity for a specified volume. Use the `top_metric` parameter to specify which type of IO activity to filter for. This API is used to provide insight into IO activity and supports ordering by IO activity types, namely `iops` and `throughput` metrics. This API supports only returning one IO activity type per request.

```
== Failure to return list of clients with most IO activity
```

The API can sometimes fail to return the list of clients with the most IO activity, due to the following reasons:

&ndash; The volume does not have the activity tracking feature enabled.

&ndash; The volume does not have read/write traffic.

&ndash; The read traffic is served by the NFS/CIFS client filesystem cache.

&ndash; On rare occasions, the incoming traffic pattern is not suitable to obtain the list of clients with the most IO activity.

```
== Retrieve a list of the clients with the most IO activity
```

For a report on the clients with the most IO activity returned in



descending order, specify the IO activity type you want to filter for by passing the `iops` or `throughput` IO activity type into the `top_metric` parameter. If the IO activity type is not specified, by default the API returns a list of clients with the greatest number of average read operations per second. The maximum number of clients returned by the API for an IO activity type is 25.

&ndash; GET `/api/storage/volumes/{volume.uuid}/top-metrics/clients`

== Examples

=== Retrieving a list of the clients with the greatest average number of write operations per second:

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/top-metrics/clients
```

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/clients?top_metric=iops.write"
```

# The Response:

```
{
  "records": [
    {
      "volume": {
        "name": "voll1"
      },
      "iops": {
        "write": 1495,
        "error": {
          "lower_bound": 1495,
          "upper_bound": 1505
        }
      },
      "client_ip": "172.28.71.128",
      "svm": {
        "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
        "name": "vs1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
          }
        }
      }
    }
  ]
}
```

```

    }
  },
  {
    "volume": {
      "name": "vol1"
    },
    "iops": {
      "write": 1022,
      "error": {
        "lower_bound": 1022,
        "upper_bound": 1032
      }
    },
    "client_ip": "172.28.71.179",
    "svm": {
      "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
        }
      }
    }
  },
  {
    "volume": {
      "name": "vol1"
    },
    "iops": {
      "write": 345,
      "error": {
        "lower_bound": 345,
        "upper_bound": 355
      }
    },
    "client_ip": "172.28.51.62",
    "svm": {
      "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
        }
      }
    }
  }
}

```

```
],
"num_records": 3,
"_links": {
  "self": {
    "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-
2df8e52ef864/top-metrics/clients?top_metric=iops.write"
  }
}
}
}
-----
```

== Example showing the behavior of the API when there is no read/write traffic:

-----

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-
metrics/clients?top_metric=throughput.write"
```

# The Response:

```
{
"records": [
],
"num_records": 0,
"notice": {
  "message": "The activity tracking report for volume \"FV\" in SVM
\"vs0\" returned zero records. Check whether the volume have read/write
traffic. Refer to the REST API documentation for more information on why
there might be no records.",
  "code": "124518418"
},
"_links": {
  "self": {
    "href": "/api/storage/volumes/9af63729-8ac8-11ec-b1bc-
005056a79da4/top-metrics/clients?top_metric=throughput.write"
  }
}
}
}
-----
```

[[ID0631ccf74f86cb8f03a38b5911637d7e]]

= Retrieve clients with the most I/O activity

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volumes/{volume.uuid}/top-metrics/clients`#
```

\*Introduced In:\* 9.10

Retrieves a list of clients with the most IO activity.

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|volume.uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Volume UUID
```

```
|top_metric
```

```
|string
```

```
|query
```

```
|False
```

```
a|IO activity type
```

\* Default value: 1

\* enum: ["iops.read", "iops.write", "throughput.read", "throughput.write"]

```
|client_ip
```

```
|string
```

```
|query
```

```
|False
```

```
a|Filter by client_ip
```

```
|iops.read
```

```
|integer
```

```
|query  
|False  
a|Filter by iops.read
```

```
|iops.write  
|integer  
|query  
|False  
a|Filter by iops.write
```

```
|iops.error.lower_bound  
|integer  
|query  
|False  
a|Filter by iops.error.lower_bound
```

```
|iops.error.upper_bound  
|integer  
|query  
|False  
a|Filter by iops.error.upper_bound
```

```
|svm.uuid  
|string  
|query  
|False  
a|Filter by svm.uuid
```

```
|svm.name  
|string  
|query  
|False  
a|Filter by svm.name
```

```
|volume.name  
|string  
|query  
|False  
a|Filter by volume.name
```

```
|throughput.error.lower_bound
|integer
|query
|False
a|Filter by throughput.error.lower_bound
```

```
|throughput.error.upper_bound
|integer
|query
|False
a|Filter by throughput.error.upper_bound
```

```
|throughput.read
|integer
|query
|False
a|Filter by throughput.read
```

```
|throughput.write
|integer
|query
|False
a|Filter by throughput.write
```

```
|fields
|array[string]
|query
|False
a|Specify the fields to return.
```

```
|max_records
|integer
|query
|False
a|Limit the number of records returned.
```

```
|return_records
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
```

of records is returned.

\* Default value: 1

|return\_timeout  
|integer  
|query  
|False

a|The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.

\* Default value: 1

\* Max value: 120

\* Min value: 0

|order\_by  
|array[string]  
|query  
|False

a|Order results by specified fields and optional [asc|desc] direction. Default direction is 'asc' for ascending.

|===

== Response

Status: 200, Ok

[cols=3\*,options=header]

|===

|Name  
|Type  
|Description

|\_links  
|link:#\_links[\_links]

a|

|notice  
|link:#notice[notice]

a|Optional field that indicates why no records are returned by the volume activity tracking REST API.

```
|num_records
|integer
a|Number of records.
```

```
|records
|array[link:#top_metrics_client[top_metrics_client]]
a|
```

```
|===
```

.Example response

[%collapsible%closed]

====

[source,json,subs=+macros]

```
{
  "_links": {
    "next": {
      "href": "/api/resource/link"
    },
    "self": {
      "href": "/api/resource/link"
    }
  },
  "notice": {
    "code": "111411207",
    "message": "No read/write traffic on volume"
  },
  "records": {
    "client_ip": "192.168.185.170",
    "iops": {
      "error": {
        "lower_bound": 34,
        "upper_bound": 54
      },
      "read": 5,
      "write": 10
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resource/link"
        }
      }
    }
  }
}
```



```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "throughput": {
    "error": {
      "lower_bound": 34,
      "upper_bound": 54
    },
    "read": 12,
    "write": 2
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====

```

```
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====
```

== Definitions

```
[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
```

```
[#href]
[.api-collapsible-fifth-title]
href
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|href
|string
a|
```

```
|===
```

```
[_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
|===
|Name
|Type
```

```
|Description
```

```
|next
```

```
|link:#href[href]
```

```
a|
```

```
|self
```

```
|link:#href[href]
```

```
a|
```

```
|===
```

```
[#notice]
```

```
[.api-collapsible-fifth-title]
```

```
notice
```

Optional field that indicates why no records are returned by the volume activity tracking REST API.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Warning code indicating why no records are returned.
```

```
|message
```

```
|string
```

```
a|Details why no records are returned.
```

```
|===
```

```
[#top_metric_value_error_bounds]
```

```
[.api-collapsible-fifth-title]
```

```
top_metric_value_error_bounds
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|lower_bound
|integer
a|Lower bound of the nominal value of a metric.

|upper_bound
|integer
a|Upper bound of the nominal value of a metric.

|===

[#iops]
[.api-collapsible-fifth-title]
iops

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read operations per second.

|write
|integer
a|Average number of write operations per second.

|===

[#_links]
[.api-collapsible-fifth-title]
_links

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#throughput]
[.api-collapsible-fifth-title]
throughput

[cols=3*,options=header]
|===
|Name

```

```

|Type
|Description

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read bytes received per second.

|write
|integer
a|Average number of write bytes received per second.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

```

```
|===
```

```
[#top_metrics_client]  
[.api-collapsible-fifth-title]  
top_metrics_client
```

Information about a client's IO activity.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|client_ip
```

```
|string
```

a|IP address of the client. Both IPv4 and IPv6 IP addresses are supported.

```
|iops
```

```
|link:#iops[iops]
```

a|

```
|svm
```

```
|link:#svm[svm]
```

a|

```
|throughput
```

```
|link:#throughput[throughput]
```

a|

```
|volume
```

```
|link:#volume[volume]
```

a|

```
|===
```

```
[#error_arguments]  
[.api-collapsible-fifth-title]  
error_arguments
```

```
[cols=3*,options=header]
```

```
|===  
|Name  
|Type  
|Description  
  
|code  
|string  
a|Argument code
```

```
|message  
|string  
a|Message argument
```

```
|===
```

```
[#error]  
[.api-collapsible-fifth-title]  
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|arguments  
|array[link:#error_arguments[error_arguments]]  
a|Message arguments
```

```
|code  
|string  
a|Error code
```

```
|message  
|string  
a|Error message
```

```
|target  
|string  
a|The target parameter that caused the error.
```



```
|===
```

```
//end collapsible .Definitions block
```

```
====
```

```
:leveloffset: -1
```

```
= Retrieve directories
```

```
:leveloffset: +1
```

```
[[ID4ffale0dfbb890alc5b65f0a8b104753]]
```

```
= Storage volumes volume.uuid top-metrics directories endpoint overview
```

```
== Overview
```

You can use this API to retrieve a list of directories with the greatest value performance metric or capacity metric for a specified volume. Use the `top_metric` parameter to specify which type of metric to filter for. This API is used to provide insight into IO metrics, namely `iops`, `throughput`, and `non_recursive_bytes_used`. This API only supports returning one metric per request.

```
== Retrieve a list of the directories with the most IO activity
```

For a report on the directories with the most IO activity returned in descending order, specify the performance metric type you want to filter for by passing the `iops` or `throughput` property into the `top_metric` parameter. If the metric type is not specified, by default the API returns a list of the directories with the greatest number of the average read operations per second. The maximum number of directories returned by the API for a metric type is 25.

```
== Failure to return list of directories with most IO activity
```

The API can sometimes fail to return the list of directories with the most IO activity, due to the following reasons:

&ndash; The volume does not have the activity tracking feature enabled.

&ndash; The volume does not have read/write traffic.

&ndash; The read traffic is served by the NFS/CIFS client filesystem cache.

&ndash; On rare occasions, the incoming traffic pattern is not suitable to obtain the list of directories with the most IO activity.

== Failure to return the pathnames for the list of directories with most IO activity

The API can sometimes fail to obtain the filesystem pathnames for the list of directory entries, due to internal transient errors.

In such cases, instead of the pathname, the API will return

"{+++<volume\_instance\_uuid>+++:+<fileid>+++}" for every directory entry.

You can get more information about the directory entry by invoking the GET on the below API using the above obtained fileid. "GET

```
/api/storage/volumes/{+++<volume_instance_uuid>+++}/files/{path}?inode_number=+++<fileid>+++"+</fileid>++++++</volume_instance_uuid>++++++</fileid>++++++</volume_instance_uuid>+++
```

== Retrieve a list of the largest directories

For a report on the largest directories returned in descending order, specify the capacity metric by passing the `non\_recursive\_bytes\_used` property into the top\_metric parameter. If the metric type is not specified, by default the API returns a list of directories with the greatest number of average read operations per second.

&ndash; GET /api/storage/volumes/{volume.uuid}/top-metrics/directories

== Examples

=== Retrieving a list of the directories with the greatest average number of read operations per second

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/top-metrics/directories
```

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/directories?top_metric=iops.read"
```

# The Response:

```

{
  "records": [
    {
      "volume": {
        "name": "vol1",
      },
      "iops": {
        "read": 1495,
        "error": {
          "lower_bound": 1495,
          "upper_bound": 1505
        }
      },
      "path": "/dir1/dir2",
      "svm": {
        "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
        "name": "vs1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
          }
        }
      },
      "_links": {
        "directory": {
          "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir1%2Fdir2"
        },
        "metadata": {
          "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir1%2Fdir2?return_metadata=true"
        }
      }
    },
    {
      "volume": {
        "name": "vol1",
      },
      "iops": {
        "read": 1022,
        "error": {
          "lower_bound": 1022,
          "upper_bound": 1032
        }
      },
      "path": "/dir3/dir4",
    }
  ]
}

```

```

"svm": {
  "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
  "name": "vs1",
  "_links": {
    "self": {
      "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
    }
  }
},
_links": {
  "directory": {
    "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir3%2Fdir4"
  },
  "metadata": {
    "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir3%2Fdir4?return_metadata=true"
  }
},
{
  "volume": {
    "uuid": "73b293df-e9d7-46cc-a9ce-2df8e52ef864",
    "name": "vol1",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864"
      }
    }
  },
  "iops": {
    "read": 345,
    "error": {
      "lower_bound": 345,
      "upper_bound": 355
    }
  },
  "path": "/dir12",
  "svm": {
    "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
    "name": "vs1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
      }
    }
  }
}

```

```

    }
  },
  "_links": {
    "directory": {
      "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir12"
    },
    "metadata": {
      "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/files/dir12?return_metadata=true"
    }
  }
}
],
"num_records": 3,
"_links": {
  "self": {
    "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/top-metrics/directories?top_metric=iops.read"
  }
}
}
}
-----

```

=== Retrieving a list of the directories with the most traffic with failure in obtaining the pathnames for the directories:

-----

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/directories?top_metric=throughput.write"
```

# The Response:

```

{
  "records": [
    {
      "volume": {
        "name": "fv"
      },
      "throughput": {
        "write": 24,
        "error": {
          "lower_bound": 24,
          "upper_bound": 29
        }
      }
    }
  ]
}

```

```

    },
    "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:1232}",
    "svm": {
      "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
        }
      }
    }
  },
  {
    "volume": {
      "name": "fv"
    },
    "throughput": {
      "write": 12,
      "error": {
        "lower_bound": 12,
        "upper_bound": 22
      }
    },
    "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:6754}",
    "svm": {
      "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
        }
      }
    }
  },
  {
    "volume": {
      "name": "fv"
    },
    "throughput": {
      "write": 8,
      "error": {
        "lower_bound": 8,
        "upper_bound": 10
      }
    },
    "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:8654}",

```

```

    "svm": {
      "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
        }
      }
    }
  ],
  "num_records": 3,
  "_links": {
    "self": {
      "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/top-metrics/directories?top_metric=throughput.write"
    }
  }
}
-----

```

== Example showing the behavior of the API when there is no read/write traffic:

-----

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/directories?top_metric=throughput.write"
```

# The Response:

```

{
  "records": [
  ],
  "num_records": 0,
  "notice": {
    "message": "The activity tracking report for volume \"FV\" in SVM \"vs0\" returned zero records. Check whether the volume have read/write traffic. Refer to the REST API documentation for more information on why there might be no records.",
    "code": "124518418"
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/9af63729-8ac8-11ec-b1bc-005056a79da4/top-metrics/directories?top_metric=throughput.write"
    }
  }
}

```

```
}  
}  
}  
----
```

```
[[IDfec0263e8672ca959591d9ccb99df81b]]
```

= Retrieve directories with the greatest value performance metric or capacity metric

```
[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volumes/{volume.uuid}/top-metrics/directories`#
```

\*Introduced In:\* 9.10

Retrieves a list of directories with the greatest value performance metric or capacity metric.

== Parameters

```
[cols=5*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|In
```

```
|Required
```

```
|Description
```

```
|volume.uuid
```

```
|string
```

```
|path
```

```
|True
```

```
a|Volume UUID
```

```
|top_metric
```

```
|string
```

```
|query
```

```
|False
```

```
a|Type of performance metric or capacity metric.
```

\* Default value: 1



```
* enum: ["iops.read", "iops.write", "throughput.read", "throughput.write"]
```

```
|max_records_per_volume  
|integer  
|query  
|False  
a|Max records per volume.
```

```
|iops.read  
|integer  
|query  
|False  
a|Filter by iops.read
```

```
|iops.write  
|integer  
|query  
|False  
a|Filter by iops.write
```

```
|iops.error.lower_bound  
|integer  
|query  
|False  
a|Filter by iops.error.lower_bound
```

```
|iops.error.upper_bound  
|integer  
|query  
|False  
a|Filter by iops.error.upper_bound
```

```
|svm.uuid  
|string  
|query  
|False  
a|Filter by svm.uuid
```

```
|svm.name  
|string
```

```
|query  
|False  
a|Filter by svm.name
```

```
|volume.name  
|string  
|query  
|False  
a|Filter by volume.name
```

```
|path  
|string  
|query  
|False  
a|Filter by path
```

```
|throughput.error.lower_bound  
|integer  
|query  
|False  
a|Filter by throughput.error.lower_bound
```

```
|throughput.error.upper_bound  
|integer  
|query  
|False  
a|Filter by throughput.error.upper_bound
```

```
|throughput.read  
|integer  
|query  
|False  
a|Filter by throughput.read
```

```
|throughput.write  
|integer  
|query  
|False  
a|Filter by throughput.write
```

```
|fields
|array[string]
|query
|False
a|Specify the fields to return.
```

```
|max_records
|integer
|query
|False
a|Limit the number of records returned.
```

```
|return_records
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
of records is returned.
```

\* Default value: 1

```
|return_timeout
|integer
|query
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.
```

\* Default value: 1

\* Max value: 120

\* Min value: 0

```
|order_by
|array[string]
|query
|False
a|Order results by specified fields and optional [asc|desc] direction.
Default direction is 'asc' for ascending.
```

```
|===
```

== Response

Status: 200, Ok

```
[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|notice
|link:#notice[notice]
a|Optional field that indicates why no records are returned by the volume
activity tracking REST API.

|num_records
|integer
a|Number of records.

|records
|array[link:#top_metrics_directory[top_metrics_directory]]
a|

|===

.Example response
[%collapsible%closed]
=====
[source,json,subs=+macros]
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "notice": {
```

```
"code": "111411207",
"message": "No read/write traffic on volume."
},
"records": {
  "_links": {
    "metadata": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "iops": {
    "error": {
      "lower_bound": 34,
      "upper_bound": 54
    },
    "read": 10,
    "write": 5
  },
  "path": "/dir_abc/dir_123/dir_20",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "throughput": {
    "error": {
      "lower_bound": 34,
      "upper_bound": 54
    },
    "read": 3,
    "write": 20
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
```

```

    }
  }
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

== Definitions

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====

```

```
[#href]
[.api-collapsible-fifth-title]
href
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|href
|string
a|
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|next
|link:#href[href]
a|
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```
[#notice]
[.api-collapsible-fifth-title]
notice
```

Optional field that indicates why no records are returned by the volume activity tracking REST API.

```
[cols=3*,options=header]
```

```
|===
|Name
|Type
|Description

|code
|string
a|Warning code indicating why no records are returned.
```

```
|message
|string
a|Details why no records are returned.
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|metadata
|link:#href[href]
a|
```

```
|self
|link:#href[href]
a|
```

```
|===
```

```
[#top_metric_value_error_bounds]
[.api-collapsible-fifth-title]
top_metric_value_error_bounds
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
```



```

|Description

|lower_bound
|integer
a|Lower bound of the nominal value of a metric.

|upper_bound
|integer
a|Upper bound of the nominal value of a metric.

|===

[#iops]
[.api-collapsible-fifth-title]
iops

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read operations per second.

|write
|integer
a|Average number of write operations per second.

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]

```

```

|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#throughput]
[.api-collapsible-fifth-title]
throughput

[cols=3*,options=header]
|===
|Name
|Type

```

```

|Description

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read bytes received per second.

|write
|integer
a|Average number of write bytes received per second.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

```

```
|===
```

```
[#top_metrics_directory]  
[.api-collapsible-fifth-title]  
top_metrics_directory
```

Information about a directory's IO metrics.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name  
|Type  
|Description
```

```
|_links  
|link:#_links[_links]  
a|
```

```
|iops  
|link:#iops[iops]  
a|
```

```
|path  
|string  
a|Path of the directory.
```

```
|svm  
|link:#svm[svm]  
a|
```

```
|throughput  
|link:#throughput[throughput]  
a|
```

```
|volume  
|link:#volume[volume]  
a|
```

```
|===
```

```
[#error_arguments]  
[.api-collapsible-fifth-title]
```

error\_arguments

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|code

|string

a|Argument code

|message

|string

a|Message argument

|===

[#error]

[.api-collapsible-fifth-title]

error

[cols=3\*,options=header]

|===

|Name

|Type

|Description

|arguments

|array[link:#error\_arguments[error\_arguments]]

a|Message arguments

|code

|string

a|Error code

|message

|string

a|Error message

|target

```
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
=====

:leveloffset: -1

= Retrieve files

:leveloffset: +1

[[IDa27e8f090e47ea0b3934e688b435ae23]]
= Storage volumes volume.uuid top-metrics files endpoint overview
```

#### == Overview

You can use this API to retrieve a list of files with the most IO activity for a specified volume. Use the `top_metric` parameter to specify which type of IO activity to filter for. This API is used to provide insight into IO activity and supports ordering by IO activity types, namely `iops` or `throughput` metrics. This API also supports only returning one IO activity type per request.

#### == Failure to return list of files with most IO activity

The API can sometimes fail to return the list of files with the most IO activity, due to the following reasons:

- &ndash; The volume does not have the activity tracking feature enabled.

- &ndash; The volume does not have read/write traffic.

- &ndash; The read traffic is served by the NFS/CIFS client filesystem cache.

- &ndash; On rare occasions, the incoming traffic pattern is not suitable to

obtain the list of files with the most IO activity.

== Failure to return the pathnames for the list of files with most IO activity

The API can sometimes fail to obtain the filesystem pathnames for the list of files, due to internal transient errors.

In such cases, instead of the pathname, the API will return

```
"{+++<volume_instance_uuid>+++::+++<fileid>+++}" for every file entry. You can get more information about the file entry by invoking the GET on the below API using the above obtained fileid. "GET /api/storage/volumes/{+++<volume_instance_uuid>+++}/files/{path}?inode_number=+++<fileid>+++""+++</fileid>++++++</volume_instance_uuid>++++++</fileid>++++++</volume_instance_uuid>+++
```

== Retrieve a list of the files with the most IO activity

For a report on the files with the most IO activity returned in descending order, specify the IO activity type you want to filter for by passing the `iops` or `throughput` property into the `top_metric` parameter. If the IO activity type is not specified, by default the API returns a list of the files with the greatest number of the average read operations per second. The maximum number of files returned by the API for an IO activity type is 25.

```
&ndash; GET /api/storage/volumes/{volume.uuid}/top-metrics/files
```

== Examples

=== Retrieving a list of the files with the greatest average number of write bytes received per second:

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/top-metrics/files
```

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/files?top_metric=throughput.write"
```

# The Response:

```
{  
  "records": [  
    {  
      "volume": {  
        "name": "fv"      }  
    }  
  ]  
}
```

```

},
"throughput": {
  "write": 24,
  "error": {
    "lower_bound": 24,
    "upper_bound": 29
  }
},
"path": "/d5/f5",
"svm": {
  "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
  "name": "vs0",
  "_links": {
    "self": {
      "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
    }
  }
},
"_links": {
  "metadata": {
    "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/files/d5%2Ff5?return_metadata=true"
  }
}
},
{
  "volume": {
    "name": "fv"
  },
  "throughput": {
    "write": 12,
    "error": {
      "lower_bound": 12,
      "upper_bound": 22
    }
  },
  "path": "/d6/f6",
  "svm": {
    "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
    "name": "vs0",
    "_links": {
      "self": {
        "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
      }
    }
  }
},

```



```

    "_links": {
      "metadata": {
        "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/files/d6%2Ff6?return_metadata=true"
      }
    },
    {
      "volume": {
        "name": "fv"
      },
      "throughput": {
        "write": 8,
        "error": {
          "lower_bound": 8,
          "upper_bound": 10
        }
      },
      "path": "/d3/f3",
      "svm": {
        "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
        "name": "vs0",
        "_links": {
          "self": {
            "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
          }
        }
      },
      "_links": {
        "metadata": {
          "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/files/d3%2Ff3?return_metadata=true"
        }
      }
    },
    ],
    "num_records": 3,
    "_links": {
      "self": {
        "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/top-metrics/files?top_metric=throughput.write"
      }
    }
  }
}
-----

```

=== Retrieving a list of the files with the most traffic with failure in obtaining the pathnames for the files:

----

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/files?top_metric=throughput.write"
```

# The Response:

```
{
"records": [
  {
    "volume": {
      "name": "fv"
    },
    "throughput": {
      "write": 24,
      "error": {
        "lower_bound": 24,
        "upper_bound": 29
      }
    },
    "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:1232}",
    "svm": {
      "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
        }
      }
    }
  },
  {
    "volume": {
      "name": "fv"
    },
    "throughput": {
      "write": 12,
      "error": {
        "lower_bound": 12,
        "upper_bound": 22
      }
    },
    "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:6754}",

```

```

    "svm": {
      "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
        }
      }
    },
    {
      "volume": {
        "name": "fv"
      },
      "throughput": {
        "write": 8,
        "error": {
          "lower_bound": 8,
          "upper_bound": 10
        }
      },
      "path": "{4ec6d1ea-d5da-11eb-a25f-005056ac0f77:8654}",
      "svm": {
        "uuid": "0ba74c3e-d5ca-11eb-8fbb-005056ac0f77",
        "name": "vs0",
        "_links": {
          "self": {
            "href": "/api/svm/svms/0ba74c3e-d5ca-11eb-8fbb-005056ac0f77"
          }
        }
      }
    }
  ],
  "num_records": 3,
  "_links": {
    "self": {
      "href": "/api/storage/volumes/4ec6d1ea-d5da-11eb-a25f-005056ac0f77/top-metrics/files?top_metric=throughput.write"
    }
  }
}
-----

```

== Example showing the behavior of the API when there is no read/write traffic:

```

-----
# The Call:
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-
metrics/files?top_metric=throughput.write"

# The Response:
{
"records": [
],
"num_records": 0,
"notice": {
  "message": "The activity tracking report for volume \"FV\" in SVM
\"vs0\" returned zero records. Check whether the volume have read/write
traffic. Refer to the REST API documentation for more information on why
there might be no records.",
  "code": "124518418"
},
"_links": {
  "self": {
    "href": "/api/storage/volumes/9af63729-8ac8-11ec-b1bc-
005056a79da4/top-metrics/files?top_metric=throughput.write"
  }
}
}
}
-----

```

```

[[IDdf1e08a89b6808327b5158d0af83d4a9]]
= Retrieve files with the most I/O activity

```

```

[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-
block]#`/storage/volumes/{volume.uuid}/top-metrics/files`#

```

\*Introduced In:\* 9.10

Retrieves a list of files with the most IO activity.

== Parameters

```

[cols=5*,options=header]
|===

```

```
|Name
|Type
|In
|Required
|Description

|volume.uuid
|string
|path
|True
a|Volume UUID

|top_metric
|string
|query
|False
a|IO activity type

* Default value: 1
* enum: ["iops.read", "iops.write", "throughput.read", "throughput.write"]

|max_records_per_volume
|integer
|query
|False
a|Max records per volume.

|iops.read
|integer
|query
|False
a|Filter by iops.read

|iops.write
|integer
|query
|False
a|Filter by iops.write

|iops.error.lower_bound
|integer
|query
```

```
|False  
a|Filter by iops.error.lower_bound
```

```
|iops.error.upper_bound  
|integer  
|query  
|False  
a|Filter by iops.error.upper_bound
```

```
|svm.uuid  
|string  
|query  
|False  
a|Filter by svm.uuid
```

```
|svm.name  
|string  
|query  
|False  
a|Filter by svm.name
```

```
|volume.name  
|string  
|query  
|False  
a|Filter by volume.name
```

```
|path  
|string  
|query  
|False  
a|Filter by path
```

```
|throughput.read  
|integer  
|query  
|False  
a|Filter by throughput.read
```

```
|throughput.write
```

```
|integer
|query
|False
a|Filter by throughput.write

|throughput.error.lower_bound
|integer
|query
|False
a|Filter by throughput.error.lower_bound

|throughput.error.upper_bound
|integer
|query
|False
a|Filter by throughput.error.upper_bound

|fields
|array[string]
|query
|False
a|Specify the fields to return.

|max_records
|integer
|query
|False
a|Limit the number of records returned.

|return_records
|boolean
|query
|False
a|The default is true for GET calls. When set to false, only the number
of records is returned.

* Default value: 1

|return_timeout
|integer
|query
```

```
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.
```

```
* Default value: 1
* Max value: 120
* Min value: 0
```

```
|order_by
|array[string]
|query
|False
a|Order results by specified fields and optional [asc|desc] direction.
Default direction is 'asc' for ascending.
```

```
|===
```

```
== Response
```

Status: 200, Ok

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|notice
```

```
|link:#notice[notice]
```

```
a|Optional field that indicates why no records are returned by the volume
activity tracking REST API.
```

```
|num_records
```

```
|integer
```

```
a|Number of records.
```

```
|records
```



```
|array[link:#top_metrics_file[top_metrics_file]]
```

```
a|
```

```
|===
```

```
.Example response
```

```
[%collapsible%closed]
```

```
=====
```

```
[source,json,subs=+macros]
```

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "notice": {
    "code": "111411207",
    "message": "No read/write traffic on volume."
  },
  "records": {
    "_links": {
      "metadata": {
        "href": "/api/resourcelink"
      },
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "iops": {
      "error": {
        "lower_bound": 34,
        "upper_bound": 54
      },
      "read": 5,
      "write": 4
    },
    "path": "/dir_abc/dir_123/file_1",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      }
    }
  }
}
```

```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "throughput": {
    "error": {
      "lower_bound": 34,
      "upper_bound": 54
    },
    "read": 2,
    "write": 20
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====

```

```
[source,json,subs=+macros]
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====
```

== Definitions

```
[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====
```

```
[#href]
[.api-collapsible-fifth-title]
href
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|href
|string
a|
```

```
|===
```

```
[#_links]
[.api-collapsible-fifth-title]
_links
```

```
[cols=3*,options=header]
|===
|Name
|Type
```

```
|Description
```

```
|next
```

```
|link:href[href]
```

```
a|
```

```
|self
```

```
|link:href[href]
```

```
a|
```

```
|===
```

```
[#notice]
```

```
[.api-collapsible-fifth-title]
```

```
notice
```

Optional field that indicates why no records are returned by the volume activity tracking REST API.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Warning code indicating why no records are returned.
```

```
|message
```

```
|string
```

```
a|Details why no records are returned.
```

```
|===
```

```
[#_links]
```

```
[.api-collapsible-fifth-title]
```

```
_links
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```

|Type
|Description

|metadata
|link:#href[href]
a|

|self
|link:#href[href]
a|

|===

[#top_metric_value_error_bounds]
[.api-collapsible-fifth-title]
top_metric_value_error_bounds

[cols=3*,options=header]
|===
|Name
|Type
|Description

|lower_bound
|integer
a|Lower bound of the nominal value of a metric.

|upper_bound
|integer
a|Upper bound of the nominal value of a metric.

|===

[#iops]
[.api-collapsible-fifth-title]
iops

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read operations per second.

|write
|integer
a|Average number of write operations per second.

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name
|Type
|Description

|self
|link:#href[href]
a|

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

```

```
|name
|string
a|The name of the SVM.
```

```
|uuid
|string
a|The unique identifier of the SVM.
```

```
|===
```

```
[#throughput]
[.api-collapsible-fifth-title]
throughput
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
|Type
|Description
```

```
|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|
```

```
|read
|integer
a|Average number of read bytes received per second.
```

```
|write
|integer
a|Average number of write bytes received per second.
```

```
|===
```

```
[#volume]
[.api-collapsible-fifth-title]
volume
```

```
[cols=3*,options=header]
```

```
|===
```

```

|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

|===

[#top_metrics_file]
[.api-collapsible-fifth-title]
top_metrics_file

Information about a file's IO activity.

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|iops
|link:#iops[iops]
a|

```



```
|path
|string
a|Path of the file.
```

```
|svm
|link:#svm[svm]
a|
```

```
|throughput
|link:#throughput[throughput]
a|
```

```
|volume
|link:#volume[volume]
a|
```

```
|===
```

```
[#error_arguments]
[.api-collapsible-fifth-title]
error_arguments
```

```
[cols=3*,options=header]
|===
|Name
|Type
|Description
```

```
|code
|string
a|Argument code
```

```
|message
|string
a|Message argument
```

```
|===
```

```
[#error]
[.api-collapsible-fifth-title]
error
```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|arguments
|array[link:#error_arguments[error_arguments]]
a|Message arguments

|code
|string
a|Error code

|message
|string
a|Error message

|target
|string
a|The target parameter that caused the error.

|===

//end collapsible .Definitions block
====

:leveloffset: -1

= Retrieve users

:leveloffset: +1

[[ID2bf1cccf635d65f0214594bec620b3b0]]
= Storage volumes volume.uuid top-metrics users endpoint overview

```

## == Overview

You can use this API to retrieve a list of users with the most IO activity for a specified volume. Use the `top_metric` parameter to specify which type of IO activity to filter for. This API is used to provide insight into IO activity and supports ordering by IO activity types, namely `iops` or `throughput` metrics. This API also supports only returning one IO activity type per request.

## == Failure to return list of users with most IO activity

The API can sometimes fail to return the list of users with the most IO activity, due to the following reasons:

- &ndash; The volume does not have the activity tracking feature enabled.

- &ndash; The volume does not have read/write traffic.

- &ndash; The read traffic is served by the NFS/CIFS client filesystem cache.

- &ndash; On rare occasions, the incoming traffic pattern is not suitable to obtain the list of users with the most IO activity.

## == Failure to return the usernames

The API can sometimes fail to obtain the usernames for the list of user id entries, due to internal transient errors.

In such cases, instead of the username, the API will return "{+++<user-id>+++}" for every user entry.+++</user-id>+++

## == Retrieve a list of the users with the most IO activity

For a report on the users with the most IO activity returned in descending order, specify the IO activity type you want to filter for by passing the `iops` or `throughput` property into the `top_metric` parameter. If the IO activity type is not specified, by default the API returns a list of the users with the greatest number of the average read operations per second. The maximum number of users returned by the API for an IO activity type is 25.

- &ndash; GET `/api/storage/volumes/{volume.uuid}/top-metrics/users`

## == Examples

=== Retrieving a list of the users with the greatest average number of read bytes received per second:

----

# The API:

```
GET /api/storage/volumes/{volume.uuid}/top-metrics/users
```

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-  
metrics/users?top_metric=throughput.read"
```

# The Response:

```
{  
  "records": [  
    {  
      "volume": {  
        "name": "vol1"  
      },  
      "throughput": {  
        "read": 1495,  
        "error": {  
          "lower_bound": 1495,  
          "upper_bound": 1502  
        }  
      },  
      "user_id": "S-1-5-21-256008430-3394229847-3930036330-1001",  
      "user_name": "John",  
      "svm": {  
        "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",  
        "name": "vs1",  
        "_links": {  
          "self": {  
            "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"  
          }  
        }  
      }  
    },  
    {  
      "volume": {  
        "name": "vol1"  
      },  
      "throughput": {  
        "read": 1022,  
        "error": {  
          "lower_bound": 1022,  
          "upper_bound": 1025  
        }  
      }  
    }  
  ]  
}
```

```

    },
    "user_id": "1988",
    "user_name": "Ryan",
    "svm": {
      "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
        }
      }
    }
  },
  {
    "volume": {
      "name": "vol1"
    },
    "throughput": {
      "read": 345,
      "error": {
        "lower_bound": 345,
        "upper_bound": 348
      }
    },
    "user_id": "S-1-5-21-256008430-3394229847-3930036330-1003",
    "user_name": "Julie",
    "svm": {
      "uuid": "572361f3-e769-439d-9c04-2ba48a08ff43",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/572361f3-e769-439d-9c04-2ba48a08ff43"
        }
      }
    }
  }
],
"num_records": 3,
"_links": {
  "self": {
    "href": "/api/storage/volumes/73b293df-e9d7-46cc-a9ce-2df8e52ef864/top-metrics/users?top_metric=throughput.read"
  }
}
}
-----

```

== Example showing the behavior of the API when there is no read/write traffic:

----

# The Call:

```
curl -X GET "https://<mgmt-ip>/api/storage/volumes/{volume.uuid}/top-metrics/users?top_metric=throughput.write"
```

# The Response:

```
{
  "records": [
  ],
  "num_records": 0,
  "notice": {
    "message": "The activity tracking report for volume \"FV\" in SVM \"vs0\" returned zero records. Check whether the volume have read/write traffic. Refer to the REST API documentation for more information on why there might be no records.",
    "code": "124518418"
  },
  "_links": {
    "self": {
      "href": "/api/storage/volumes/9af63729-8ac8-11ec-b1bc-005056a79da4/top-metrics/users?top_metric=throughput.write"
    }
  }
}
```

----

[[ID54dda9844e9268ca7000475140b59f43]]

= Retrieve users with the most I/O activity

[.api-doc-operation .api-doc-operation-get]#GET# [.api-doc-code-block]#`/storage/volumes/{volume.uuid}/top-metrics/users`#

\*Introduced In:\* 9.10

Retrieves a list of users with the most IO activity.

== Parameters

```
[cols=5*,options=header]
|===

|Name
|Type
|In
|Required
|Description

|volume.uuid
|string
|path
|True
a|Volume UUID

|top_metric
|string
|query
|False
a|IO activity type

* Default value: 1
* enum: ["iops.read", "iops.write", "throughput.read", "throughput.write"]

|iops.error.lower_bound
|integer
|query
|False
a|Filter by iops.error.lower_bound

|iops.error.upper_bound
|integer
|query
|False
a|Filter by iops.error.upper_bound

|iops.read
|integer
|query
|False
a|Filter by iops.read
```

```
|iops.write
|integer
|query
|False
a|Filter by iops.write
```

```
|svm.uuid
|string
|query
|False
a|Filter by svm.uuid
```

```
|svm.name
|string
|query
|False
a|Filter by svm.name
```

```
|volume.name
|string
|query
|False
a|Filter by volume.name
```

```
|user_id
|string
|query
|False
a|Filter by user_id
```

```
|user_name
|string
|query
|False
a|Filter by user_name
```

```
|throughput.read
|integer
|query
|False
```



```
a|Filter by throughput.read
```

```
|throughput.write
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by throughput.write
```

```
|throughput.error.lower_bound
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by throughput.error.lower_bound
```

```
|throughput.error.upper_bound
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Filter by throughput.error.upper_bound
```

```
|fields
```

```
|array[string]
```

```
|query
```

```
|False
```

```
a|Specify the fields to return.
```

```
|max_records
```

```
|integer
```

```
|query
```

```
|False
```

```
a|Limit the number of records returned.
```

```
|return_records
```

```
|boolean
```

```
|query
```

```
|False
```

```
a|The default is true for GET calls. When set to false, only the number of records is returned.
```

```
* Default value: 1
```

```
|return_timeout
|integer
|query
|False
a|The number of seconds to allow the call to execute before returning.
When iterating over a collection, the default is 15 seconds. ONTAP
returns earlier if either max records or the end of the collection is
reached.
```

```
* Default value: 1
```

```
* Max value: 120
```

```
* Min value: 0
```

```
|order_by
|array[string]
|query
|False
a|Order results by specified fields and optional [asc|desc] direction.
Default direction is 'asc' for ascending.
```

```
|===
```

```
== Response
```

Status: 200, Ok

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|_links
```

```
|link:#_links[_links]
```

```
a|
```

```
|notice
```

```
|link:#notice[notice]
```

```
a|Optional field that indicates why no records are returned by the volume
activity tracking REST API.
```

```
|num_records
```

```
|integer
```

```
a|Number of records.
```

```
|records  
|array[link:#top_metrics_user[top_metrics_user]]  
a|
```

```
|===
```

```
.Example response
```

```
[%collapsible%closed]
```

```
====
```

```
[source,json,subs=+macros]
```

```
{  
  "_links": {  
    "next": {  
      "href": "/api/resourcelink"  
    },  
    "self": {  
      "href": "/api/resourcelink"  
    }  
  },  
  "notice": {  
    "code": "111411207",  
    "message": "No read/write traffic on volume."  
  },  
  "records": {  
    "iops": {  
      "error": {  
        "lower_bound": 34,  
        "upper_bound": 54  
      },  
      "read": 4,  
      "write": 8  
    },  
    "svm": {  
      "_links": {  
        "self": {  
          "href": "/api/resourcelink"  
        }  
      },  
      "name": "svm1",  
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"  
    },  
    "throughput": {
```

```

    "error": {
      "lower_bound": 34,
      "upper_bound": 54
    },
    "read": 10,
    "write": 7
  },
  "user_id": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "user_name": "James",
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
}
====

== Error

```

Status: Default, Error

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#error[error]
a|

|===

.Example error
[%collapsible%closed]
====
[source,json,subs=+macros]
{
  "error": {

```

```

    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
====

```

== Definitions

```

[.api-def-first-level]
.See Definitions
[%collapsible%closed]
//Start collapsible Definitions block
====

```

```

[#href]
[.api-collapsible-fifth-title]
href

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```

|href
|string
a|

```

```

|===

```

```

[#_links]
[.api-collapsible-fifth-title]
_links

```

```

[cols=3*,options=header]
|===
|Name
|Type
|Description

```

```

|next

```

```
|link:#href[href]
```

```
a|
```

```
|self
```

```
|link:#href[href]
```

```
a|
```

```
|===
```

```
[#notice]
```

```
[.api-collapsible-fifth-title]
```

```
notice
```

Optional field that indicates why no records are returned by the volume activity tracking REST API.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Warning code indicating why no records are returned.
```

```
|message
```

```
|string
```

```
a|Details why no records are returned.
```

```
|===
```

```
[#top_metric_value_error_bounds]
```

```
[.api-collapsible-fifth-title]
```

```
top_metric_value_error_bounds
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```

|lower_bound
|integer
a|Lower bound of the nominal value of a metric.

|upper_bound
|integer
a|Upper bound of the nominal value of a metric.

|===

[#iops]
[.api-collapsible-fifth-title]
iops

[cols=3*,options=header]
|===
|Name
|Type
|Description

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read operations per second.

|write
|integer
a|Average number of write operations per second.

|===

[#_links]
[.api-collapsible-fifth-title]
_links

[cols=3*,options=header]
|===
|Name

```

```

|Type
|Description

|self
|link:#href[href]
a|

|===

[#svm]
[.api-collapsible-fifth-title]
svm

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the SVM.

|uuid
|string
a|The unique identifier of the SVM.

|===

[#throughput]
[.api-collapsible-fifth-title]
throughput

[cols=3*,options=header]
|===
|Name
|Type
|Description

```



```

|error
|link:#top_metric_value_error_bounds[top_metric_value_error_bounds]
a|

|read
|integer
a|Average number of read bytes received per second.

|write
|integer
a|Average number of write bytes received per second.

|===

[#volume]
[.api-collapsible-fifth-title]
volume

[cols=3*,options=header]
|===
|Name
|Type
|Description

|_links
|link:#_links[_links]
a|

|name
|string
a|The name of the volume.

|uuid
|string
a|Unique identifier for the volume. This corresponds to the instance-uuid
that is exposed in the CLI and ONTAPI. It does not change due to a volume
move.

* example: 028baa66-41bd-11e9-81d5-00a0986138f7
* Introduced in: 9.6

|===

```

```
[#top_metrics_user]
[.api-collapsible-fifth-title]
top_metrics_user
```

Information about a user's IO activity.

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|iops
```

```
|link:#iops[iops]
```

```
a|
```

```
|svm
```

```
|link:#svm[svm]
```

```
a|
```

```
|throughput
```

```
|link:#throughput[throughput]
```

```
a|
```

```
|user_id
```

```
|string
```

```
a|User ID of the user.
```

```
|user_name
```

```
|string
```

```
a|Name of the user.
```

```
|volume
```

```
|link:#volume[volume]
```

```
a|
```

```
|===
```

```
[#error_arguments]
```

```
[.api-collapsible-fifth-title]
```

```
error_arguments
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|code
```

```
|string
```

```
a|Argument code
```

```
|message
```

```
|string
```

```
a|Message argument
```

```
|===
```

```
[#error]
```

```
[.api-collapsible-fifth-title]
```

```
error
```

```
[cols=3*,options=header]
```

```
|===
```

```
|Name
```

```
|Type
```

```
|Description
```

```
|arguments
```

```
|array[link:#error_arguments[error_arguments]]
```

```
a|Message arguments
```

```
|code
```

```
|string
```

```
a|Error code
```

```
|message
```

```
|string
```

```
a|Error message
```

```
|target
```

```
|string
```

```
a|The target parameter that caused the error.
```

```
|===
```

```
//end collapsible .Definitions block
```

```
====
```

```
:leveloffset: -1
```

```
:leveloffset: -1
```

```
:leveloffset: -1
```

```
<<<
```

```
*Copyright information*
```

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any

other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b) (3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

\*Trademark information\*

NETAPP, the NETAPP logo, and the marks listed at [link:http://www.netapp.com/TM](http://www.netapp.com/TM)[<http://www.netapp.com/TM^>] are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.