



Manage NVMe namespaces

REST API reference

NetApp

February 07, 2026

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9171/manage_nvme_namespaces.html on February 07, 2026. Always check docs.netapp.com for the latest.

Table of Contents

| | |
|---|-----|
| Manage NVMe namespaces | 1 |
| Manage NVMe namespaces | 1 |
| Overview | 1 |
| Performance monitoring | 1 |
| Examples | 1 |
| Cloning NVMe namespaces | 8 |
| Converting a LUN into an NVMe namespace | 9 |
| Deleting an NVMe namespace | 10 |
| Retrieve NVMe namespaces | 10 |
| Expensive properties | 10 |
| Related ONTAP commands | 10 |
| Learn more | 10 |
| Parameters | 11 |
| Response | 20 |
| Error | 24 |
| Definitions | 25 |
| Create an NVMe namespace | 50 |
| Required properties | 50 |
| Default property values | 50 |
| Related ONTAP commands | 50 |
| Learn more | 51 |
| Parameters | 51 |
| Request Body | 52 |
| Response | 58 |
| Response | 59 |
| Error | 59 |
| Definitions | 61 |
| Retrieve historical performance metrics for an NVMe namespace | 93 |
| Related ONTAP commands | 93 |
| Parameters | 93 |
| Response | 96 |
| Error | 98 |
| Definitions | 98 |
| Retrieve historical performance metrics for an NVMe namespace for a specific time | 102 |
| Related ONTAP commands | 102 |
| Parameters | 102 |
| Response | 102 |
| Error | 104 |
| Definitions | 105 |
| Delete an NVMe namespace | 108 |
| Related ONTAP commands | 108 |
| Learn more | 108 |
| Parameters | 108 |

| | |
|----------------------------------|-----|
| Response | 109 |
| Response | 109 |
| Error | 109 |
| Definitions | 110 |
| Retrieve an NVMe namespace | 111 |
| Expensive properties | 111 |
| Related ONTAP commands | 112 |
| Learn more | 112 |
| Parameters | 112 |
| Response | 112 |
| Error | 119 |
| Definitions | 120 |
| Update an NVMe namespace | 141 |
| Related ONTAP commands | 141 |
| Learn more | 142 |
| Parameters | 142 |
| Request Body | 142 |
| Response | 145 |
| Response | 146 |
| Error | 146 |
| Definitions | 147 |

Manage NVMe namespaces

Manage NVMe namespaces

Overview

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

The NVMe namespace REST API allows you to create, update, delete and discover NVMe namespaces.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

NVMe namespace names are paths of the form `"/vol/<volume>[/<qtree>]/<namespace>"` where the qtree name is optional.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. An NVMe namespace can then be resized or cloned. An NVMe namespace cannot be renamed, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace.

Performance monitoring

Performance of an NVMe namespace can be monitored by observing the `metric.*` and `statistics.*` properties. These properties show the space utilization and performance of an NVMe namespace in terms of IOPS, latency, and throughput. The `metric.*` properties denote an average, whereas `statistics.*` properties denote a real-time monotonically increasing value aggregated across all nodes.

Examples

Creating an NVMe namespace

This example creates a 300 gigabyte NVMe namespace, with 4096-byte blocks, in SVM `svm1`, volume `vol1`, configured for use by `linux` hosts. The `return_records` query parameter is used to retrieve properties of the newly created NVMe namespace in the POST response.

```
# The API:
POST /api/storage/namespaces

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/namespaces?return_records=true' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "os_type": "linux",
```

```

"space": { "block_size": "4096", "size": "300G" }, "name" :
"/vol/vol1/namespace1" }'

# The response:
{
  "num_records": 1,
  "records": [
    {
      "uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
      "svm": {
        "uuid": "6bf967fd-2a1c-11e9-b682-005056bbc17d",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/6bf967fd-2a1c-11e9-b682-005056bbc17d"
          }
        }
      },
      "name": "/vol/vol1/namespace1",
      "location": {
        "namespace": "namespace1",
        "volume": {
          "uuid": "71cd0dba-2a1c-11e9-b682-005056bbc17d",
          "name": "vol1",
          "_links": {
            "self": {
              "href": "/api/storage/volumes/71cd0dba-2a1c-11e9-b682-
005056bbc17d"
            }
          }
        }
      },
      "enabled": true,
      "os_type": "linux",
      "space": {
        "block_size": 4096,
        "size": 322122547200,
        "used": 0,
        "guarantee": {
          "requested": false,
          "reserved": false
        }
      },
      "status": {
        "container_state": "online",
        "read_only": false,

```

```
    "state": "online"
  },
  "_links": {
    "self": {
      "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-f7897f945669"
    }
  }
}
]
```

Updating an NVMe namespace comment

This example sets the `comment` property of an NVMe namespace.

```
# The API:
PATCH /api/storage/namespaces/{uuid}

# The call:
```

Updating the size of an NVMe namespace

This example increases the size of an NVMe namespace.

```
# The API:
PATCH /api/storage/namespaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-f7897f945669' -H 'Accept: application/hal+json' -d '{ "space": { "size": "1073741824" } }'
```

Retrieving NVMe namespaces

This example retrieves summary information for all online NVMe namespaces in SVM `svm1`. The `svm.name` and `status.state` query parameters are to find the desired NVMe namespaces.

```
# The API:
GET /api/storage/namespaces
```

```
# The call:
curl -X GET 'https://<mgmt-
ip>/api/storage/namespaces?svm.name=svm1&status.state=online' -H 'Accept:
application/hal+json'

# The response:
{
  "records": [
    {
      "uuid": "5c254d22-96a6-42ac-aad8-0cd9ebd126b6",
      "svm": {
        "name": "svm1"
      },
      "name": "/vol/vol1/namespace2",
      "status": {
        "state": "online"
      },
      "_links": {
        "self": {
          "href": "/api/storage/namespaces/5c254d22-96a6-42ac-aad8-
0cd9ebd126b6"
        }
      }
    },
    {
      "uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
      "svm": {
        "name": "svm1"
      },
      "name": "/vol/vol1/namespace1",
      "status": {
        "state": "online"
      },
      "_links": {
        "self": {
          "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-
f7897f945669"
        }
      }
    },
    {
      "uuid": "be732687-20cf-47d2-a0e2-2a989d15661d",
      "svm": {
        "name": "svm1"
      },
      "name": "/vol/vol2/namespace3",

```

```

    "status": {
      "state": "online"
    },
    "_links": {
      "self": {
        "href": "/api/storage/namespaces/be732687-20cf-47d2-a0e2-2a989d15661d"
      }
    }
  },
  "num_records": 3,
  "_links": {
    "self": {
      "href": "/api/storage/namespaces?svm.name=svm1&status.state=online"
    }
  }
}

```

Retrieving details for a specific NVMe namespace

In this example, the `fields` query parameter is used to request all fields, including advanced fields, that would not otherwise be returned by default for the NVMe namespace.

```

# The API:
GET /api/storage/namespaces/{uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-f7897f945669?fields=**' -H 'Accept: application/hal+json'

# The response:
{
  "uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
  "svm": {
    "uuid": "6bf967fd-2a1c-11e9-b682-005056bbc17d",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/6bf967fd-2a1c-11e9-b682-005056bbc17d"
      }
    }
  },
  "name": "/vol/vol1/namespace1",

```



```

"location": {
  "namespace": "namespace1",
  "volume": {
    "uuid": "71cd0dba-2a1c-11e9-b682-005056bbc17d",
    "name": "voll",
    "_links": {
      "self": {
        "href": "/api/storage/volumes/71cd0dba-2a1c-11e9-b682-005056bbc17d"
      }
    }
  }
},
"auto_delete": false,
"enabled": true,
"comment": "Data for the research department.",
"os_type": "linux",
"space": {
  "block_size": 4096,
  "size": 322122547200,
  "used": 0,
  "guarantee": {
    "requested": false,
    "reserved": false
  }
},
"status": {
  "container_state": "online",
  "mapped": true,
  "read_only": false,
  "state": "online"
},
"subsystem_map": {
  "nsid": "00000001h",
  "anagrpid": "00000001h",
  "subsystem": {
    "uuid": "01f17d05-2be9-11e9-bed2-005056bbc17d",
    "name": "subsystem1",
    "_links": {
      "self": {
        "href": "/api/protocols/nvme/subsystems/01f17d05-2be9-11e9-bed2-005056bbc17d"
      }
    }
  }
},
"_links": {

```

```
    "self": {
      "href": "/api/protocols/nvme/subsystem-maps/dccdc3e6-cf4e-498f-bec6-f7897f945669/01f17d05-2be9-11e9-bed2-005056bbc17d"
    }
  },
  "metric": {
    "timestamp": "2019-04-09T05:50:15Z",
    "duration": "PT15S",
    "status": "ok",
    "latency": {
      "other": 0,
      "total": 0,
      "read": 0,
      "write": 0
    },
    "iops": {
      "read": 0,
      "write": 0,
      "other": 0,
      "total": 0
    },
    "throughput": {
      "read": 0,
      "write": 0,
      "total": 0
    }
  },
  "statistics": {
    "timestamp": "2019-04-09T05:50:42Z",
    "status": "ok",
    "latency_raw": {
      "other": 38298,
      "total": 38298,
      "read": 0,
      "write": 0
    },
    "iops_raw": {
      "read": 0,
      "write": 0,
      "other": 3,
      "total": 3
    },
    "throughput_raw": {
      "read": 0,
      "write": 0,
```

```

    "total": 0
  }
},
"_links": {
  "self": {
    "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-
f7897f945669?fields=*"
  }
}
}
}

```

Cloning NVMe namespaces

A clone of an NVMe namespace is an independent "copy" of the namespace that shares unchanged data blocks with the original. As blocks of the source and clone are modified, unique blocks are written for each. NVMe namespace clones can be created quickly and consume very little space initially. They can be created for the purpose of back-up, or to replicate data for multiple consumers.

An NVMe namespace clone can also be set to auto-delete by setting the `auto_delete` property. If the namespace's volume is configured for automatic deletion, NVMe namespaces that have auto-delete enabled are deleted when a volume is nearly full to reclaim a target amount of free space in the volume.

Creating a new NVMe namespace clone

You create an NVMe namespace clone as you create any NVMe namespace — a POST to [/storage/namespaces](#). Set `clone.source.uuid` or `clone.source.name` to identify the source NVMe namespace from which the clone is created. The NVMe namespace clone and its source must reside in the same volume.

The source NVMe namespace can reside in a snapshot, in which case, the `clone.source.name` field must be used to identify it. Add `/.snapshot/<snapshot_name>` to the path after the volume name to identify the snapshot. For example `/vol/vol1/.snapshot/snap1/namespace1`.

```

# The API:
POST /api/storage/namespaces

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/namespaces' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "name":
"/vol/vol1/namespace2clone1", "clone": { "source": { "name":
"/vol/vol1/namespace2" } } }'

```

Over-writing an existing NVMe namespace's data as a clone of another

You can over-write an existing NVMe namespace as a clone of another. You do this as a PATCH on the NVMe namespace to overwrite — a PATCH to [/storage/namespaces/{uuid}](#). Set the `clone.source.uuid` or `clone.source.name` property to identify the source NVMe namespace from which the clone data is taken. The NVMe namespace clone and its source must reside in the same volume.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: `auto_delete`, `subsystem_map`, `status.state`, and `uuid`.

```
# The API:
PATCH /api/storage/namespaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-f7897f945669' -H 'Accept: application/hal+json' -d '{ "clone": { "source": { "name": "/vol/vol1/namespace2" } } }'
```

Converting a LUN into an NVMe namespace

An existing LUN can be converted in-place to an NVMe namespace with no modification to the data blocks. In other words, there is no additional copy created for the data blocks. There are certain requirements when converting a LUN to an NVMe namespace. For instance, the LUN should not be mapped to an initiator group, or exist as a protocol endpoint LUN, or in a foreign LUN import relationship. If the LUN exists as a VM volume, it should not be bound to a protocol endpoint LUN. Furthermore, only LUN with a supported operating system type for NVMe namespace can be converted.

The conversion process updates the metadata to the LUN, making it an NVMe namespace. The conversion is both time and space efficient. After conversion, the new namespace behaves as a regular namespace and may be mapped to an NVMe subsystem.

Convert a LUN into an NVMe namespace

You convert a LUN into an NVMe namespace by calling a POST to [/storage/namespaces](#). Set `convert.lun.uuid` or `convert.lun.name` to identify the source LUN which is to be converted in-place into an NVMe namespace.

```
# The API:
POST /api/storage/namespaces

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/namespaces' -H 'Accept: application/hal+json' -d '{ "svm": { "name": "svm1" }, "convert": { "lun": { "name": "/vol/vol1/lun1" } } }'
```

Deleting an NVMe namespace

```
# The API:
DELETE /api/storage/namespaces/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/storage/namespaces/5c254d22-96a6-42ac-aad8-0cd9ebd126b6' -H 'Accept: application/hal+json'
```

Retrieve NVMe namespaces

GET /storage/namespaces

Introduced In: 9.6

Retrieves NVMe namespaces.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `auto_delete`
- `space.physical_used`
- `space.physical_used_by_snapshots`
- `space.efficiency_ratio`
- `subsystem_map.*`
- `status.mapped`
- `statistics.*`
- `metric.*`

Related ONTAP commands

- `vserver nvme namespace show`
- `vserver nvme subsystem map show`

Learn more

- [DOC /storage/namespaces](#) to learn more and examples.

Parameters

| Name | Type | In | Required | Description |
|----------------------------------|---------|-------|----------|---|
| svm.name | string | query | False | Filter by svm.name |
| svm.uuid | string | query | False | Filter by svm.uuid |
| space.physical_used | integer | query | False | Filter by space.physical_used • Introduced in: 9.16 |
| space.block_size | integer | query | False | Filter by space.block_size |
| space.encyrancy_ratio | number | query | False | Filter by space.encyrancy_ratio • Introduced in: 9.16 |
| space.physical_used_by_snapshots | integer | query | False | Filter by space.physical_used_by_snapshots • Introduced in: 9.16 |
| space.used | integer | query | False | Filter by space.used |
| space.size | integer | query | False | Filter by space.size • Max value: 140737488355328 • Min value: 4096 |
| space.guarantee_reserved | boolean | query | False | Filter by space.guarantee_reserved |
| space.guarantee_requested | boolean | query | False | Filter by space.guarantee_requested |

| Name | Type | In | Required | Description |
|-------------------------|---------|-------|----------|---|
| metric.status | string | query | False | Filter by metric.status • Introduced in: 9.8 |
| metric.latency.other | integer | query | False | Filter by metric.latency.other • Introduced in: 9.8 |
| metric.latency.total | integer | query | False | Filter by metric.latency.total • Introduced in: 9.8 |
| metric.latency.read | integer | query | False | Filter by metric.latency.read • Introduced in: 9.8 |
| metric.latency.write | integer | query | False | Filter by metric.latency.write • Introduced in: 9.8 |
| metric.throughput.read | integer | query | False | Filter by metric.throughput.read • Introduced in: 9.8 |
| metric.throughput.total | integer | query | False | Filter by metric.throughput.total • Introduced in: 9.8 |

| Name | Type | In | Required | Description |
|-------------------------|---------|-------|----------|---|
| metric.throughput.write | integer | query | False | Filter by metric.throughput.write • Introduced in: 9.8 |
| metric.timestamp | string | query | False | Filter by metric.timestamp • Introduced in: 9.8 |
| metric.duration | string | query | False | Filter by metric.duration • Introduced in: 9.8 |
| metric.iops.other | integer | query | False | Filter by metric.iops.other • Introduced in: 9.8 |
| metric.iops.total | integer | query | False | Filter by metric.iops.total • Introduced in: 9.8 |
| metric.iops.read | integer | query | False | Filter by metric.iops.read • Introduced in: 9.8 |
| metric.iops.write | integer | query | False | Filter by metric.iops.write • Introduced in: 9.8 |
| comment | string | query | False | Filter by comment • maxLength: 254 • minLength: 0 |

| Name | Type | In | Required | Description |
|------------------------|---------|-------|----------|--|
| status.state | string | query | False | Filter by status.state |
| status.mapped | boolean | query | False | Filter by status.mapped |
| status.container_state | string | query | False | Filter by status.container_state |
| status.read_only | boolean | query | False | Filter by status.read_only |
| uuid | string | query | False | Filter by uuid |
| consistency_group.name | string | query | False | Filter by consistency_group.name • Introduced in: 9.16 |
| consistency_group.uuid | string | query | False | Filter by consistency_group.uuid • Introduced in: 9.16 |
| location.namespace | string | query | False | Filter by location.namespace |
| location.qtree.name | string | query | False | Filter by location.qtree.name |
| location.qtree.id | integer | query | False | Filter by location.qtree.id • Max value: 4994 • Min value: 0 |
| location.node.uuid | string | query | False | Filter by location.node.uuid • Introduced in: 9.10 |

| Name | Type | In | Required | Description |
|------------------------------|---------|-------|----------|--|
| location.node.name | string | query | False | Filter by location.node.name • Introduced in: 9.10 |
| location.volume.uuid | string | query | False | Filter by location.volume.uuid |
| location.volume.name | string | query | False | Filter by location.volume.name |
| statistics.latency_raw.other | integer | query | False | Filter by statistics.latency_raw.other • Introduced in: 9.8 |
| statistics.latency_raw.total | integer | query | False | Filter by statistics.latency_raw.total • Introduced in: 9.8 |
| statistics.latency_raw.read | integer | query | False | Filter by statistics.latency_raw.read • Introduced in: 9.8 |
| statistics.latency_raw.write | integer | query | False | Filter by statistics.latency_raw.write • Introduced in: 9.8 |
| statistics.iops_raw.other | integer | query | False | Filter by statistics.iops_raw.other • Introduced in: 9.8 |

| Name | Type | In | Required | Description |
|---------------------------------|---------|-------|----------|---|
| statistics.iops_raw.total | integer | query | False | Filter by statistics.iops_raw.total • Introduced in: 9.8 |
| statistics.iops_raw.read | integer | query | False | Filter by statistics.iops_raw.read • Introduced in: 9.8 |
| statistics.iops_raw.write | integer | query | False | Filter by statistics.iops_raw.write • Introduced in: 9.8 |
| statistics.throughput_raw.read | integer | query | False | Filter by statistics.throughput_raw.read • Introduced in: 9.8 |
| statistics.throughput_raw.total | integer | query | False | Filter by statistics.throughput_raw.total • Introduced in: 9.8 |
| statistics.throughput_raw.write | integer | query | False | Filter by statistics.throughput_raw.write • Introduced in: 9.8 |
| statistics.status | string | query | False | Filter by statistics.status • Introduced in: 9.8 |

| Name | Type | In | Required | Description |
|--|---------|-------|----------|---|
| statistics.timestamp | string | query | False | Filter by statistics.timestamp • Introduced in: 9.8 |
| enabled | boolean | query | False | Filter by enabled |
| auto_delete | boolean | query | False | Filter by auto_delete |
| name | string | query | False | Filter by name |
| os_type | string | query | False | Filter by os_type |
| create_time | string | query | False | Filter by create_time • Introduced in: 9.7 |
| subsystem_map.ana grpid | string | query | False | Filter by subsystem_map.ana grpid |
| subsystem_map.nsi d | string | query | False | Filter by subsystem_map.nsi d |
| subsystem_map.sub system.hosts.proximi ty.peer_svms.uuid | string | query | False | Filter by subsystem_map.sub system.hosts.proxim ity.peer_svms.uuid • Introduced in: 9.17 |
| subsystem_map.sub system.hosts.proximi ty.peer_svms.name | string | query | False | Filter by subsystem_map.sub system.hosts.proxim ity.peer_svms.name • Introduced in: 9.17 |

| Name | Type | In | Required | Description |
|--|---------|-------|----------|---|
| subsystem_map.subsystem.hosts.proximity.local_svm | boolean | query | False | Filter by subsystem_map.subsystem.hosts.proximity.local_svm • Introduced in: 9.17 |
| subsystem_map.subsystem.hosts.tls.key_type | string | query | False | Filter by subsystem_map.subsystem.hosts.tls.key_type • Introduced in: 9.16 |
| subsystem_map.subsystem.hosts.dh_hmac_chap.hash_function | string | query | False | Filter by subsystem_map.subsystem.hosts.dh_hmac_chap.hash_function • Introduced in: 9.16 |
| subsystem_map.subsystem.hosts.dh_hmac_chap.mode | string | query | False | Filter by subsystem_map.subsystem.hosts.dh_hmac_chap.mode • Introduced in: 9.16 |
| subsystem_map.subsystem.hosts.dh_hmac_chap.group_size | string | query | False | Filter by subsystem_map.subsystem.hosts.dh_hmac_chap.group_size • Introduced in: 9.16 |
| subsystem_map.subsystem.hosts.nqn | string | query | False | Filter by subsystem_map.subsystem.hosts.nqn • Introduced in: 9.16 |

| Name | Type | In | Required | Description |
|--|---------------|-------|----------|--|
| subsystem_map.subsystem.hosts.priority | string | query | False | Filter by subsystem_map.subsystem.hosts.priority <ul style="list-style-type: none"> Introduced in: 9.16 |
| subsystem_map.subsystem.name | string | query | False | Filter by subsystem_map.subsystem.name <ul style="list-style-type: none"> maxLength: 64 minLength: 1 |
| subsystem_map.subsystem.os_type | string | query | False | Filter by subsystem_map.subsystem.os_type <ul style="list-style-type: none"> Introduced in: 9.16 |
| subsystem_map.subsystem.comment | string | query | False | Filter by subsystem_map.subsystem.comment <ul style="list-style-type: none"> Introduced in: 9.16 maxLength: 255 minLength: 0 |
| subsystem_map.subsystem.uuid | string | query | False | Filter by subsystem_map.subsystem.uuid |
| fields | array[string] | query | False | Specify the fields to return. |
| max_records | integer | query | False | Limit the number of records returned. |
| return_records | boolean | query | False | The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> Default value: 1 |

| Name | Type | In | Required | Description |
|----------------|---------------|-------|----------|---|
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> • Max value: 120 • Min value: 0 • Default value: 15 |
| order_by | array[string] | query | False | Order results by specified fields and optional [asc |

Response

Status: 200, Ok

| Name | Type | Description |
|-------------|------------------------|--|
| _links | _links | |
| num_records | integer | The number of records in the response. |
| records | array[nvme_namespace] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "comment": "string",
      "consistency_group": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "cg1",
        "uuid": "4abc2317-4332-9d37-93a0-20bd29c22df0"
      },
      "create_time": "2018-06-04 15:00:00 -0400",
      "location": {
        "namespace": "namespace1",
        "node": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "qtree": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          }
        }
      }
    }
  ]
}
```



```

    },
    "id": 1,
    "name": "qt1"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
},
"metric": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25 06:20:13 -0500"
},
"name": "/vol/volume1/mtree1/namespace1",
"os_type": "string",
"space": {
  "block_size": 512,
  "efficiency_ratio": 2.5,
  "physical_used": 1073741824,
  "physical_used_by_snapshots": 1073741824,

```

```

    "size": 1073741824,
    "used": 0
  },
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 06:20:13 -0500"
  },
  "status": {
    "container_state": "string",
    "state": "online"
  },
  "subsystem_map": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "anagrpid": "00103050h",
    "nsid": "00000001h",
    "subsystem": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "comment": "string",
      "hosts": [
        {
          "dh_hmac_chap": {
            "group_size": "string",
            "hash_function": "string",

```

```

        "mode": "bidirectional"
    },
    "nqn": "nqn.1992-01.example.com:string",
    "priority": "string",
    "proximity": {
        "peer_svms": [
            {
                "_links": {
                    "self": {
                        "href": "/api/resourcelink"
                    }
                },
                "name": "peer1",
                "uuid": "4204cf77-4c82-9bdb-5644-b5a841c097a9"
            }
        ]
    },
    "tls": {
        "key_type": "configured"
    }
},
],
"name": "subsystem1",
"os_type": "string",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
},
"svm": {
    "_links": {
        "self": {
            "href": "/api/resourcelink"
        }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
]
}

```

Error

Status: Default, Error

| Name | Type | Description |
|-------|--------------------------------|-------------|
| error | returned_error | |

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

source

The source NVMe namespace for a namespace clone operation. This can be specified using property `clone.source.uuid` or `clone.source.name`. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: `auto_delete` (unless specified in the request), `subsystem_map`, `status.state`, and `uuid`.

consistency_group

The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the consistency group. |
| uuid | string | The unique identifier of the consistency group. |

lun

The source LUN for convert operation. This can be specified using property `convert.lun.uuid` or `convert.lun.name`. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace come from the source LUN.

convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

node

The cluster node that hosts the NVMe namespace.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties `name` and `location.qtree.name` and/or `location.qtree.uuid` are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

| Name | Type | Description |
|--------|------------------------|---|
| _links | _links | |
| id | integer | The identifier for the qtree, unique within the qtree's volume. |
| name | string | The name of the qtree. |

volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties `name` and `location.volume.name` and/or `location.volume.uuid` are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

| Name | Type | Description |
|---------------------|------------------------|---|
| <code>_links</code> | _links | |
| <code>name</code> | string | The name of the volume. This field cannot be specified in a PATCH method. |
| <code>uuid</code> | string | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none">• example: 028baa66-41bd-11e9-81d5-00a0986138f7• Introduced in: 9.6• x-nullable: true |

location

The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.

| Name | Type | Description |
|------------------------|----------------------|---|
| <code>namespace</code> | string | The base name component of the NVMe namespace. Valid in POST. If properties <code>name</code> and <code>location.namespace</code> are specified in the same request, they must refer to the base name. NVMe namespaces do not support rename. |
| <code>node</code> | node | The cluster node that hosts the NVMe namespace. |

| Name | Type | Description |
|--------|--------|---|
| qtree | qtree | <p>The qtree in which the NVMe namespace is optionally located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.qtree.name</code> and/or <code>location.qtree.uuid</code> are specified in the same request, they must refer to the same qtree.</p> <p>NVMe namespaces do not support rename.</p> |
| volume | volume | <p>The volume in which the NVMe namespace is located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.volume.name</code> and/or <code>location.volume.uuid</code> are specified in the same request, they must refer to the same volume.</p> <p>NVMe namespaces do not support movement between volumes.</p> |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

metric

Performance numbers, such as IOPS latency and throughput

| Name | Type | Description |
|----------|------------------------|--|
| _links | _links | |
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |

| Name | Type | Description |
|------------|----------------------------|---|
| iops | iops | The rate of I/O operations observed at the storage object. |
| latency | latency | The round trip latency in microseconds observed at the storage object. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |

self_link

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

qos_policy

The QoS policy for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. If no `qos_policy` is provided, a policy is be set based on the `storage_service.name`, which defaults to the most performant service available.

| Name | Type | Description |
|------------------------|---------------------------|---|
| _links | self_link | |
| name | string | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |
| uuid | string | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

snapshot_policy_reference

This is a reference to the snapshot policy.

| Name | Type | Description |
|------------------------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

storage_service

Determines the placement of the namespace based on the value specified. Valid in POST.

| Name | Type | Description |
|------|--------|--|
| name | string | Storage service name. If not specified, the default value is the most performant for the platform. |

object_stores

tiering

The tiering placement and policy definitions for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume.

| Name | Type | Description |
|---------------|--|---|
| object_stores | array[object_stores] | Object stores to use. Used for placement. |

| Name | Type | Description |
|--------|--------|---|
| policy | string | <p>Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold.</p> <p>FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH.</p> <p>all &dash; Allows tiering of both snapshots and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.</p> <p>auto &dash; Allows tiering of both snapshot and active file system user data to the cloud store</p> <p>none &dash; Volume blocks are not be tiered to the cloud store.</p> <p>snapshot_only &dash; Allows tiering of only the volume snapshots not associated with the active file system.</p> <p>The default tiering policy is "snapshot-only" for a FlexVol volume and "none" for a FlexGroup volume. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy it is 31 days.</p> |

provisioning_options

Options that are applied to the operation.

guarantee

Properties that request and report the space guarantee for the NVMe namespace.

| Name | Type | Description |
|-----------|---------|---|
| requested | boolean | <p>The requested space reservation policy for the NVMe namespace. If <i>true</i>, a space reservation is requested for the namespace; if <i>false</i>, the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.</p> <p>The space reservation policy for an NVMe namespace is determined by ONTAP.</p> <ul style="list-style-type: none"> • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |
| reserved | boolean | <p>Reports if the NVMe namespace is space guaranteed.</p> <p>This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.</p> |

space

The storage space related properties of the NVMe namespace.

| Name | Type | Description |
|----------------------------|---------------------------|---|
| block_size | integer | <p>The size of blocks in the namespace in bytes. The default for namespaces with an <code>os_type</code> of <i>vmware</i> is 512. All other namespaces default to 4096.</p> <p>Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.</p> |
| efficiency_ratio | number | <p>The storage efficiency ratio of the namespace without snapshots. (Logical Used / Used) This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| guarantee | guarantee | <p>Properties that request and report the space guarantee for the NVMe namespace.</p> |
| physical_used | integer | <p>The number of bytes consumed on the disk by the namespace, excluding snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| physical_used_by_snapshots | integer | <p>The number of bytes consumed on the disk by the namespace's snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |

| Name | Type | Description |
|------|---------|---|
| size | integer | <p>The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.</p> <p>The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • example: 1073741824 • format: int64 • Max value: 140737488355328 • Min value: 4096 • Introduced in: 9.6 • x-nullable: true |

| Name | Type | Description |
|------|---------|---|
| used | integer | <p>The amount of space consumed by the main data stream of the NVMe namespace.</p> <p>This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • format: int64 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name | Type | Description |
|-------|---------|---|
| other | integer | <p>Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.</p> |

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name | Type | Description |
|----------------|--------------------------------|---|
| iops_raw | iops_raw | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time. |
| latency_raw | latency_raw | The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | throughput_raw | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time. |

| Name | Type | Description |
|-----------|--------|--|
| timestamp | string | The timestamp of the performance data. |

status

Status information about the NVMe namespace.

| Name | Type | Description |
|-----------------|---------|---|
| container_state | string | The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available. |
| mapped | boolean | Reports if the NVMe namespace is mapped to an NVMe subsystem. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. |
| read_only | boolean | Reports if the NVMe namespace allows only read access. |
| state | string | The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors. |

consistency_group_nvme_host_dh_hmac_chap

A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host.

| Name | Type | Description |
|---------------|--------|--|
| group_size | string | The Diffie-Hellman group size for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>2048_bit</code> . When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST. |
| hash_function | string | The hash function for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>sha_256</code> . When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST. |
| mode | string | <p>The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:</p> <ul style="list-style-type: none"> • <code>none</code>: The host has neither the host nor controller secret configured, and no authentication is performed. • <code>unidirectional</code>: The host has a host secret configured. The controller will authenticate the host. • <code>bidirectional</code>: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller. |

peer_svms

A reference to an SVM peer relationship.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|------|--------|--|
| name | string | The local name of the peer SVM. This name is unique among all local and peer SVMs. |
| uuid | string | The unique identifier of the SVM peer relationship. This is the UUID of the relationship, not the UUID of the peer SVM itself. |

proximity

Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.

These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.

| Name | Type | Description |
|-----------|------------------------------------|---|
| local_svm | boolean | A boolean that indicates if the host is proximal to the SVM for which it is configured. |
| peer_svms | array[peer_svms] | An array of remote peer SVMs to which the host is proximal. |

tls

A container for the configuration for NVMe/TCP-TLS transport session for the host.

| Name | Type | Description |
|----------|--------|--|
| key_type | string | <p>The method by which the TLS pre-shared key (PSK) is configured for the host. Optional in POST.</p> <p>The values for property <code>key_type</code> and property <code>configured_psk</code> must logically agree.</p> <p>Possible values:</p> <ul style="list-style-type: none"> • <code>none</code> - TLS is not configured for the host connection. No value is allowed for property <code>configured_psk</code>. • <code>configured</code> - A user supplied PSK is configured for the NVMe/TCP-TLS transport connection between the host and the NVMe subsystem. A valid value for property <code>configured_psk</code> is required. <p>This property defaults to <code>none</code> unless a value is supplied for <code>configured_psk</code> in which case it defaults to <code>configured</code>.</p> |

hosts

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

| Name | Type | Description |
|--------------|--|--|
| dh_hmac_chap | consistency_group_nvme_host_dh_hmac_chap | A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host. |
| nqn | string | The NVMe qualified name (NQN) used to identify the NVMe storage target. |

| Name | Type | Description |
|-----------|-----------|--|
| priority | string | The host priority setting allocates appropriate NVMe I/O queues (count and depth) for the host to submit I/O commands. Absence of this property in GET implies io_queue count and I/O queue depth are being used. |
| proximity | proximity | <p>Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.</p> <p>These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.</p> |
| tls | tls | A container for the configuration for NVMe/TCP-TLS transport session for the host. |

subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

| Name | Type | Description |
|---------|--------------|--|
| _links | _links | |
| comment | string | A configurable comment for the NVMe subsystem. Optional in POST. |
| hosts | array[hosts] | The NVMe hosts configured for access to the NVMe subsystem. Optional in POST. |
| name | string | The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Optional in POST. |

| Name | Type | Description |
|---------|--------|--|
| os_type | string | The host operating system of the NVMe subsystem's hosts. Optional in POST. |
| uuid | string | The unique identifier of the NVMe subsystem. |

subsystem_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for `subsystem_map`. They are not populated for a GET request unless explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more. These properties are supported only for GET.

| Name | Type | Description |
|-----------|---------------------------|--|
| _links | _links | |
| anagrpId | string | <p>The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.</p> <p>The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| nsid | string | <p>The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.</p> <p>The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| subsystem | subsystem | The NVMe subsystem to which the NVMe namespace is mapped. |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the SVM. This field cannot be specified in a PATCH method. |
| uuid | string | The unique identifier of the SVM. This field cannot be specified in a PATCH method. |

nvme_namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

NVMe namespace names are paths of the form `"/vol/<volume>[/<qtree>]/<namespace>"` where the qtree name is optional.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. An NVMe namespace can then be resized or cloned. An NVMe namespace cannot be renamed, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|-------------------|-----------------------------------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| create_time | string | The time the NVMe namespace was created. |

| Name | Type | Description |
|----------|--------------------------|--|
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| location | location | <p>The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.</p> <ul style="list-style-type: none"> • Introduced in: 9.6 • readCreate: 1 |
| metric | metric | Performance numbers, such as IOPS latency and throughput |
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| os_type | string | <p>The operating system type of the NVMe namespace.</p> <p>Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.</p> |

| Name | Type | Description |
|---------------|-------------------------------|--|
| space | space | The storage space related properties of the NVMe namespace. |
| statistics | statistics | These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. |
| status | status | Status information about the NVMe namespace. |
| subsystem_map | subsystem_map | <p>The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.</p> <p>There is an added computational cost to retrieving property values for <code>subsystem_map</code>. They are not populated for a GET request unless explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. These properties are supported only for GET.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |
| uuid | string | The unique identifier of the NVMe namespace. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Create an NVMe namespace

POST /storage/namespaces

Introduced In: 9.6

Creates an NVMe namespace.

Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the NVMe namespace.
- `name`, `location.volume.name` or `location.volume.uuid` - Existing volume in which to create the NVMe namespace.
- `name` or `location.namespace` - Base name for the NVMe namespace.
- `os_type` - Operating system from which the NVMe namespace will be accessed. (Not used for clones, which are created based on the `os_type` of the source NVMe namespace.)
- `space.size` - Size for the NVMe namespace. (Not used for clones, which are created based on the size of the source NVMe namespace.)

Default property values

If not specified in POST, the following default property values are assigned:

- `auto_delete` - *false*
- `space.block_size` - 4096 (512 when 'os_type' is *vmware*)

Related ONTAP commands

- `volume file clone autodelete`
- `volume file clone create`
- `vserver nvme namespace convert-from-lun`
- `vserver nvme namespace create`

POST is asynchronous when creating a new namespace. It is synchronous when converting a LUN to a

namespace via the `convert` property.

Learn more

- [DOC /storage/namespaces](#)

Parameters

| Name | Type | In | Required | Description |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none">• Default value: 0• Max value: 120• Min value: 0 |
| return_records | boolean | query | False | <p>The default is false. If set to true, the records are returned.</p> <ul style="list-style-type: none">• Default value: |

Request Body

| Name | Type | Description |
|-------------|-----------------------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |
| clone | clone | <p>This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.</p> <p>When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: <code>auto_delete</code> (unless specified in the request), <code>subsystem_map</code>, <code>status.state</code>, and <code>uuid</code>.</p> |

| Name | Type | Description |
|-------------------|-----------------------------------|---|
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| convert | convert | This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired. |
| create_time | string | The time the NVMe namespace was created. |
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| location | location | <p>The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.</p> <ul style="list-style-type: none"> • Introduced in: 9.6 • readCreate: 1 |

| Name | Type | Description |
|----------------------|--------------------------------------|--|
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| os_type | string | <p>The operating system type of the NVMe namespace.</p> <p>Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.</p> |
| provisioning_options | provisioning_options | Options that are applied to the operation. |
| space | space | The storage space related properties of the NVMe namespace. |
| status | status | Status information about the NVMe namespace. |
| subsystem_map | subsystem_map | <p>The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.</p> <p>There is an added computational cost to retrieving property values for <code>subsystem_map</code>. They are not populated for a GET request unless explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. These properties are supported only for GET.</p> |

| Name | Type | Description |
|------|---------------------|--|
| svm | svm | SVM, applies only to SVM-scoped objects. |
| uuid | string | The unique identifier of the NVMe namespace. |

Example request

```
{
  "clone": {
    "source": {
      "name": "/vol/volume1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "comment": "string",
  "consistency_group": {
    "name": "cg1",
    "uuid": "4abc2317-4332-9d37-93a0-20bd29c22df0"
  },
  "convert": {
    "lun": {
      "name": "/vol/volume1/lun1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "create_time": "2018-06-04 15:00:00 -0400",
  "location": {
    "namespace": "namespace1",
    "node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "qtree": {
      "id": 1,
      "name": "qt1"
    },
    "volume": {
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
    }
  },
  "name": "/vol/volume1/qtree1/namespace1",
  "os_type": "string",
  "provisioning_options": {
    "qos_policy": {
      "name": "performance",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "snapshot_policy": {
      "name": "default",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  }
}
```

```

    },
    "storage_service": {
      "name": "string"
    },
    "tiering": {
      "control": "string",
      "object_stores": [
        {
          "name": "string"
        }
      ],
      "policy": "string"
    }
  },
  "space": {
    "block_size": 512,
    "efficiency_ratio": 2.5,
    "physical_used": 1073741824,
    "physical_used_by_snapshots": 1073741824,
    "size": 1073741824,
    "used": 0
  },
  "status": {
    "container_state": "string",
    "state": "online"
  },
  "subsystem_map": {
    "anagrp_id": "00103050h",
    "nsid": "00000001h",
    "subsystem": {
      "comment": "string",
      "hosts": [
        {
          "dh_hmac_chap": {
            "controller_secret_key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
            "group_size": "string",
            "hash_function": "string",
            "host_secret_key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
            "mode": "bidirectional"
          },
          "nqn": "nqn.1992-01.example.com:string",
          "priority": "string",
          "proximity": {
            "peer_svms": [

```

```

        {
          "name": "peer1",
          "uuid": "4204cf77-4c82-9bdb-5644-b5a841c097a9"
        }
      ],
      "tls": {
        "configured_psk": "NVMeTLSkey-
1:01:VRLbtnN9AQb2WXW3c9+wEf/DRLz0QuLdbYvEhwtdWwNf9LrZ:",
        "key_type": "configured"
      }
    },
    {
      "name": "subsystem1",
      "os_type": "string",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

Response

Status: 202, Accepted

| Name | Type | Description |
|------|--------------------------|-------------|
| job | job_link | |

Example response

```

{
  "job": {
    "uuid": "string"
  }
}

```

Headers

| Name | Description | Type |
|----------|---|--------|
| Location | Useful for tracking the resource location | string |

Response

Status: 201, Created

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 917927 | The specified volume was not found. |
| 918236 | The specified <code>location.volume.uuid</code> and <code>location.volume.name</code> do not refer to the same volume. |
| 1254197 | The LUN specified for conversion to a namespace is mapped. |
| 1260121 | Cloning a namespace to a volume different than the source volume is not supported. |
| 1260136 | The specified destination for a clone operation already exists as a LUN, namespace, or file. |
| 2621462 | The supplied SVM does not exist. |
| 2621706 | The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM. |
| 2621707 | No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be supplied. |
| 5242927 | The specified <code>qtree</code> was not found. |
| 5242950 | The specified <code>location.qtree.id</code> and <code>location.qtree.name</code> do not refer to the same <code>qtree</code> . |
| 5374127 | The specified namespace name is invalid. |
| 5374140 | LUN has a non-zero prefix and/or suffix size. |
| 5374141 | LUN is part of a SnapMirror active sync relationship. |

| Error Code | Description |
|------------|---|
| 5374156 | A protocol endpoint LUN cannot be converted to an NVMe namespace. |
| 5374157 | LUN in an SVM with MetroCluster configured cannot be converted to an NVMe namespace. |
| 5374158 | LUN contains an operating system type that is not supported for NVMe namespace. |
| 5374352 | An invalid name was provided for the NVMe namespace. |
| 5374858 | The volume specified by <code>name</code> is not the same as that specified by <code>location.volume</code> . |
| 5374860 | The <code>qtree</code> specified by <code>name</code> is not the same as that specified by <code>location.qtree</code> . |
| 5374861 | The NVMe namespace base name specified by <code>name</code> is not the same as that specified by <code>location.name</code> . |
| 5374862 | No NVMe namespace path base name was provided for the namespace. |
| 5374876 | The LUN specified for conversion to a namespace was not found. |
| 5376461 | The specified namespace name is invalid. |
| 5376462 | The specified namespace name is too long. |
| 5376463 | The snapshot portion of the specified namespace name is too long. |
| 5440509 | No suitable storage can be found for the specified requirements. |
| 13565952 | The NVMe namespace clone request failed. |
| 72089636 | Creating NVMe namespaces with <code>os_type</code> AIX is not supported until the effective cluster version is 9.13.1 or later. |
| 72089720 | NVMe namespaces cannot be created in snapshots. |
| 72089721 | The volume specified is in a load sharing mirror relationship. Namespaces are not supported in load sharing mirrors. |
| 72089722 | A negative size was provided for the NVMe namespace. |
| 72089723 | The specified size is too small for the NVMe namespace. |
| 72089724 | The specified size is too large for the NVMe namespace. |
| 72089725 | A LUN or NVMe namespace already exists at the specified path. |

| Error Code | Description |
|------------|--|
| 72089727 | NVMe namespaces cannot be created on an SVM root volume. |
| 72089728 | NVMe namespaces cannot be created on a FlexGroup volume. |
| 72089732 | An NVMe namespace name can only contain characters A-Z, a-z, 0-9, "-", ".", "_", "{" and "}". |
| 72090005 | The specified <code>clone.source.uuid</code> and <code>clone.source.name</code> do not refer to the same NVMe namespace. |
| 72090006 | The specified <code>clone.source</code> was not found. |
| 72090007 | The specified <code>clone.source</code> was not found. |
| 72090009 | An error occurred after successfully creating the NVMe namespace. Some properties were not set. |
| 72090012 | The property cannot be specified when creating an NVMe namespace clone. The <code>target</code> property of the error object identifies the property. |
| 72090013 | The property is required except when creating an NVMe namespace clone. The <code>target</code> property of the error object identifies the property. |
| 72090014 | No volume was specified for the NVMe namespace. |
| 72090015 | An error occurred after successfully creating the NVMe namespace preventing the retrieval of its properties. |
| 72090033 | The <code>clone.source.uuid</code> property is not supported when specifying a source NVMe namespace from a snapshot. |
| 72090039 | The property cannot be specified at the same time when creating an NVMe namespace as a clone. The <code>target</code> property of the error object identifies the other property given with clone. |
| 72090040 | The property cannot be specified when converting a LUN into an NVMe namespace. The <code>target</code> property of the error object identifies the property. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

source

The source NVMe namespace for a namespace clone operation. This can be specified using property `clone.source.uuid` or `clone.source.name`. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

| Name | Type | Description |
|------|--------|--|
| name | string | <p>The name of the clone source NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Valid in POST and PATCH.</p> |
| uuid | string | <p>The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.</p> |

clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: `auto_delete` (unless specified in the request), `subsystem_map`, `status.state`, and `uuid`.

| Name | Type | Description |
|--------|------------------------|--|
| source | source | <p>The source NVMe namespace for a namespace clone operation. This can be specified using property <code>clone.source.uuid</code> or <code>clone.source.name</code>. If both properties are supplied, they must refer to the same namespace.</p> <p>Valid in POST to create a new NVMe namespace as a clone of the source.</p> <p>Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.</p> |

consistency_group

The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the consistency group. |
| uuid | string | The unique identifier of the consistency group. |

lun

The source LUN for convert operation. This can be specified using property `convert.lun.uuid` or `convert.lun.name`. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace come from the source LUN.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the source LUN. Valid in POST. A LUN is located within a volume. Optionally, it can be located within a qtree in a volume. LUN names are paths of the form <code>"/vol/<volume>[/<qtree>]/<lun>"</code> where the qtree name is optional. |
| uuid | string | The unique identifier of the source LUN. Valid in POST. |

convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

| Name | Type | Description |
|------|---------------------|---|
| lun | lun | The source LUN for convert operation. This can be specified using property <code>convert.lun.uuid</code> or <code>convert.lun.name</code> . If both properties are supplied, they must refer to the same LUN. Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace come from the source LUN. |

node

The cluster node that hosts the NVMe namespace.

| Name | Type | Description |
|------|--------|-------------|
| name | string | |
| uuid | string | |

qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties `name` and `location.qtree.name` and/or `location.qtree.uuid` are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

| Name | Type | Description |
|------|---------|---|
| id | integer | The identifier for the qtree, unique within the qtree's volume. |
| name | string | The name of the qtree. |

volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties `name` and `location.volume.name` and/or `location.volume.uuid` are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the volume. This field cannot be specified in a PATCH method. |
| uuid | string | Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none">• example: 028baa66-41bd-11e9-81d5-00a0986138f7• Introduced in: 9.6• x-nullable: true |

location

The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.

| Name | Type | Description |
|-----------|------------------------|---|
| namespace | string | <p>The base name component of the NVMe namespace. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.namespace</code> are specified in the same request, they must refer to the base name.</p> <p>NVMe namespaces do not support rename.</p> |
| node | node | The cluster node that hosts the NVMe namespace. |
| qtree | qtree | <p>The qtree in which the NVMe namespace is optionally located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.qtree.name</code> and/or <code>location.qtree.uuid</code> are specified in the same request, they must refer to the same qtree.</p> <p>NVMe namespaces do not support rename.</p> |
| volume | volume | <p>The volume in which the NVMe namespace is located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.volume.name</code> and/or <code>location.volume.uuid</code> are specified in the same request, they must refer to the same volume.</p> <p>NVMe namespaces do not support movement between volumes.</p> |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |

| Name | Type | Description |
|-------|---------|--|
| write | integer | Performance metric for write I/O operations. |

metric

Performance numbers, such as IOPS latency and throughput

| Name | Type | Description |
|----------|-------------------------|---|
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops | iops | The rate of I/O operations observed at the storage object. |
| latency | latency | The round trip latency in microseconds observed at the storage object. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |

| Name | Type | Description |
|------------|----------------------------|---|
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |

self_link

qos_policy

The QoS policy for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. If no `qos_policy` is provided, a policy is be set based on the `storage_service.name`, which defaults to the most performant service available.

| Name | Type | Description |
|------|--------|---|
| name | string | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |
| uuid | string | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

snapshot_policy_reference

This is a reference to the snapshot policy.

| Name | Type | Description |
|------|--------|-------------|
| name | string | |
| uuid | string | |

storage_service

Determines the placement of the namespace based on the value specified. Valid in POST.

| Name | Type | Description |
|------|--------|--|
| name | string | Storage service name. If not specified, the default value is the most performant for the platform. |

object_stores

| Name | Type | Description |
|------|--------|--|
| name | string | The name of the object store to use. Used for placement. |

tiering


The tiering placement and policy definitions for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume.

| Name | Type | Description |
|---------------|--|---|
| control | string | Storage tiering placement rules for the object. |
| object_stores | array[object_stores] | Object stores to use. Used for placement. |

| Name | Type | Description |
|--------|--------|---|
| policy | string | <p>Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold.</p> <p>FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH.</p> <p>all &dash; Allows tiering of both snapshots and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.</p> <p>auto &dash; Allows tiering of both snapshot and active file system user data to the cloud store</p> <p>none &dash; Volume blocks are not be tiered to the cloud store.</p> <p>snapshot_only &dash; Allows tiering of only the volume snapshots not associated with the active file system.</p> <p>The default tiering policy is "snapshot-only" for a FlexVol volume and "none" for a FlexGroup volume. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy it is 31 days.</p> |

provisioning_options

Options that are applied to the operation.



| Name | Type | Description |
|------|---------|--|
| auto | boolean | <p>If the volume specified in the request does not exist, automatically provision one of appropriate size. If the volume does exist, resize it to accommodate the new namespace.</p> <p>This property is only supported on Unified ONTAP.</p> <p>The following behavior is different from a traditional POST request:</p> <ul style="list-style-type: none"> • The operation is asynchronous. • The <code>qos_policy</code> property is supported and is applied to the provisioned volume. A default QoS policy is applied to the volume if one is not provided. • The <code>provisioning_options.count</code> property is supported, provisioning <i>count</i> namespaces on the volume using the specified properties. • The <code>subsystem_map</code> property is supported. If the specified subsystem does not exist, it is created. The namespace is mapped to this subsystem. If a subsystem is provisioned in this way, it is deleted after it is no longer mapped to any namespaces. • The <code>clone</code> and <code>convert</code> properties are not supported. • When performing <code>records</code> based operations, specifying this property in the query applies to the entire operation. Specifying it for an individual record within the request applies to only that record. • Many other <code>provisioning_options</code> properties are supported to control the placement of the namespace and the properties of the volume |

| Name | Type | Description |
|-------------------------|---|---|
| count | integer | The number of namespaces to provision with these properties. Only POST requests based on <code>space.size</code> are supported. When provided, the name is considered a prefix, and a suffix of the form <code>_<N></code> is generated where N is the next available numeric index, starting with 1. |
| qos_policy | qos_policy | The QoS policy for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. If no <code>qos_policy</code> is provided, a policy is be set based on the <code>storage_service.name</code> , which defaults to the most performant service available. |
| snapshot_policy | snapshot_policy_reference | This is a reference to the snapshot policy. |
| storage_service | storage_service | Determines the placement of the namespace based on the value specified. Valid in POST. |
| tiering | tiering | The tiering placement and policy definitions for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. |
| use_mirrored_aggregates | boolean | Specifies whether mirrored aggregates are selected when provisioning the volume to host the namespace. Only mirrored aggregates are used if this parameter is set to <i>true</i> and only unmirrored aggregates are used if this parameter is set to <i>false</i> . The default value is <i>true</i> for a MetroCluster configuration and is <i>false</i> for a non-MetroCluster configuration. |

guarantee

Properties that request and report the space guarantee for the NVMe namespace.

| Name | Type | Description |
|-----------|---------|---|
| requested | boolean | <p>The requested space reservation policy for the NVMe namespace. If <i>true</i>, a space reservation is requested for the namespace; if <i>false</i>, the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.</p> <p>The space reservation policy for an NVMe namespace is determined by ONTAP.</p> <ul style="list-style-type: none">• readOnly: 1• Introduced in: 9.6• x-nullable: true |
| reserved | boolean | <p>Reports if the NVMe namespace is space guaranteed.</p> <p>This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.</p> |

space

The storage space related properties of the NVMe namespace.

| Name | Type | Description |
|----------------------------|---------------------------|---|
| block_size | integer | <p>The size of blocks in the namespace in bytes. The default for namespaces with an <code>os_type</code> of <i>vmware</i> is 512. All other namespaces default to 4096.</p> <p>Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.</p> |
| efficiency_ratio | number | <p>The storage efficiency ratio of the namespace without snapshots. (Logical Used / Used) This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| guarantee | guarantee | <p>Properties that request and report the space guarantee for the NVMe namespace.</p> |
| physical_used | integer | <p>The number of bytes consumed on the disk by the namespace, excluding snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| physical_used_by_snapshots | integer | <p>The number of bytes consumed on the disk by the namespace's snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |

| Name | Type | Description |
|------|---------|---|
| size | integer | <p>The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.</p> <p>The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • example: 1073741824 • format: int64 • Max value: 140737488355328 • Min value: 4096 • Introduced in: 9.6 • x-nullable: true |

| Name | Type | Description |
|------|---------|---|
| used | integer | <p>The amount of space consumed by the main data stream of the NVMe namespace.</p> <p>This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • format: int64 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name | Type | Description |
|-------|---------|---|
| other | integer | <p>Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.</p> |

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name | Type | Description |
|----------------|--------------------------------|---|
| iops_raw | iops_raw | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time. |
| latency_raw | latency_raw | The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | throughput_raw | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time. |

| Name | Type | Description |
|-----------|--------|--|
| timestamp | string | The timestamp of the performance data. |

status

Status information about the NVMe namespace.

| Name | Type | Description |
|-----------------|---------|---|
| container_state | string | The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available. |
| mapped | boolean | Reports if the NVMe namespace is mapped to an NVMe subsystem. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. |
| read_only | boolean | Reports if the NVMe namespace allows only read access. |
| state | string | The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors. |

consistency_group_nvme_host_dh_hmac_chap

A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host.

| Name | Type | Description |
|-----------------------|--------|---|
| controller_secret_key | string | <p>The controller secret for NVMe in-band authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST.</p> <p>This property is write-only. The <code>mode</code> property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.</p> |
| group_size | string | <p>The Diffie-Hellman group size for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>2048_bit</code>. When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST.</p> |
| hash_function | string | <p>The hash function for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>sha_256</code>. When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST.</p> |

| Name | Type | Description |
|-----------------|--------|---|
| host_secret_key | string | <p>The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.</p> <p>This property is write-only. The <code>mode</code> property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.</p> |
| mode | string | <p>The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:</p> <ul style="list-style-type: none"> • none: The host has neither the host nor controller secret configured, and no authentication is performed. • unidirectional: The host has a host secret configured. The controller will authenticate the host. • bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller. |

peer_svms

A reference to an SVM peer relationship.

| Name | Type | Description |
|------|--------|--|
| name | string | The local name of the peer SVM. This name is unique among all local and peer SVMs. |
| uuid | string | The unique identifier of the SVM peer relationship. This is the UUID of the relationship, not the UUID of the peer SVM itself. |

proximity

Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.

These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.

| Name | Type | Description |
|-----------|------------------------------------|---|
| local_svm | boolean | A boolean that indicates if the host is proximal to the SVM for which it is configured. |
| peer_svms | array[peer_svms] | An array of remote peer SVMs to which the host is proximal. |

tls

A container for the configuration for NVMe/TCP-TLS transport session for the host.

| Name | Type | Description |
|----------------|--------|---|
| configured_psk | string | <p>A user supplied pre-shared key (PSK) value in PSK Interchange Format. Optional in POST.</p> <p>The values for property <code>key_type</code> and property <code>configured_psk</code> must logically agree. This property is only allowed when <code>key_type</code> is configured. If <code>configured_psk</code> is supplied and <code>key_type</code> is unset, <code>key_type</code> defaults to <code>configured</code>.</p> <p>This property is write-only. The <code>key_type</code> property can be used to identify if a configured PSK has been set for the host, but the PSK value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.</p> |

| Name | Type | Description |
|----------|--------|--|
| key_type | string | <p>The method by which the TLS pre-shared key (PSK) is configured for the host. Optional in POST.</p> <p>The values for property <code>key_type</code> and property <code>configured_psk</code> must logically agree.</p> <p>Possible values:</p> <ul style="list-style-type: none"> • <code>none</code> - TLS is not configured for the host connection. No value is allowed for property <code>configured_psk</code>. • <code>configured</code> - A user supplied PSK is configured for the NVMe/TCP-TLS transport connection between the host and the NVMe subsystem. A valid value for property <code>configured_psk</code> is required. <p>This property defaults to <code>none</code> unless a value is supplied for <code>configured_psk</code> in which case it defaults to <code>configured</code>.</p> |

hosts

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

| Name | Type | Description |
|--------------|--|--|
| dh_hmac_chap | consistency_group_nvme_host_dh_hmac_chap | A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host. |
| nqn | string | The NVMe qualified name (NQN) used to identify the NVMe storage target. |

| Name | Type | Description |
|-----------|-----------|--|
| priority | string | The host priority setting allocates appropriate NVMe I/O queues (count and depth) for the host to submit I/O commands. Absence of this property in GET implies io_queue count and I/O queue depth are being used. |
| proximity | proximity | <p>Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.</p> <p>These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.</p> |
| tls | tls | A container for the configuration for NVMe/TCP-TLS transport session for the host. |

subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

| Name | Type | Description |
|---------|--------------|--|
| comment | string | A configurable comment for the NVMe subsystem. Optional in POST. |
| hosts | array[hosts] | The NVMe hosts configured for access to the NVMe subsystem. Optional in POST. |
| name | string | The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Optional in POST. |
| os_type | string | The host operating system of the NVMe subsystem's hosts. Optional in POST. |

| Name | Type | Description |
|------|--------|--|
| uuid | string | The unique identifier of the NVMe subsystem. |

subsystem_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for `subsystem_map`. They are not populated for a GET request unless explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more. These properties are supported only for GET.

| Name | Type | Description |
|-----------|---------------------------|--|
| anagrpId | string | <p>The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.</p> <p>The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| nsid | string | <p>The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.</p> <p>The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| subsystem | subsystem | The NVMe subsystem to which the NVMe namespace is mapped. |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the SVM. This field cannot be specified in a PATCH method. |
| uuid | string | The unique identifier of the SVM. This field cannot be specified in a PATCH method. |

nvme_namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

NVMe namespace names are paths of the form `"/vol/<volume>[/<qtree>]/<namespace>"` where the qtree name is optional.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. An NVMe namespace can then be resized or cloned. An NVMe namespace cannot be renamed, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace.

| Name | Type | Description |
|-------------|---------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |

| Name | Type | Description |
|-------------------|-----------------------------------|---|
| clone | clone | <p>This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.</p> <p>When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: <code>auto_delete</code> (unless specified in the request), <code>subsystem_map</code>, <code>status.state</code>, and <code>uuid</code>.</p> |
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| convert | convert | This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired. |
| create_time | string | The time the NVMe namespace was created. |

| Name | Type | Description |
|----------------------|--------------------------------------|--|
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| location | location | <p>The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.</p> <ul style="list-style-type: none"> • Introduced in: 9.6 • readCreate: 1 |
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| os_type | string | <p>The operating system type of the NVMe namespace.</p> <p>Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.</p> |
| provisioning_options | provisioning_options | Options that are applied to the operation. |

| Name | Type | Description |
|---------------|-------------------------------|--|
| space | space | The storage space related properties of the NVMe namespace. |
| status | status | Status information about the NVMe namespace. |
| subsystem_map | subsystem_map | <p>The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.</p> <p>There is an added computational cost to retrieving property values for <code>subsystem_map</code>. They are not populated for a GET request unless explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. These properties are supported only for GET.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |
| uuid | string | The unique identifier of the NVMe namespace. |

job_link

| Name | Type | Description |
|------|--------|---|
| uuid | string | The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Retrieve historical performance metrics for an NVMe namespace

GET /storage/namespaces/{nvme_namespace.uuid}/metrics

Introduced In: 9.14

Retrieves historical space and performance metrics for an NVMe namespace.

Related ONTAP commands

- `statistics namespace show`

Parameters

| Name | Type | In | Required | Description |
|---------------|---------|-------|----------|-------------------------|
| iops.other | integer | query | False | Filter by iops.other |
| iops.total | integer | query | False | Filter by iops.total |
| iops.read | integer | query | False | Filter by iops.read |
| iops.write | integer | query | False | Filter by iops.write |
| latency.other | integer | query | False | Filter by latency.other |
| latency.total | integer | query | False | Filter by latency.total |
| latency.read | integer | query | False | Filter by latency.read |
| latency.write | integer | query | False | Filter by latency.write |

| Name | Type | In | Required | Description |
|---------------------|---------|-------|----------|--|
| timestamp | string | query | False | Filter by timestamp |
| duration | string | query | False | Filter by duration |
| status | string | query | False | Filter by status |
| throughput.read | integer | query | False | Filter by throughput.read |
| throughput.total | integer | query | False | Filter by throughput.total |
| throughput.write | integer | query | False | Filter by throughput.write |
| uuid | string | query | False | Filter by uuid |
| nvme_namespace.uuid | string | path | True | The unique identifier of the NVMe namespace. |

| Name | Type | In | Required | Description |
|----------|--------|-------|----------|---|
| interval | string | query | False | <p>The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows:</p> <ul style="list-style-type: none"> • 1h: Metrics over the most recent hour sampled over 15 seconds. • 1d: Metrics over the most recent day sampled over 5 minutes. • 1w: Metrics over the most recent week sampled over 30 minutes. • 1m: Metrics over the most recent month sampled over 2 hours. • 1y: Metrics over the most recent year sampled over a day. • Default value: 1 • enum: ["1h", "1d", "1w", "1m", "1y"] |

| Name | Type | In | Required | Description |
|--|----------------|---------|----------|---|
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> • Default value: 15 • Max value: 120 • Min value: 0 |
| fields | array[string] | query | False | Specify the fields to return. |
| max_records | integer | query | False | Limit the number of records returned. |
| order_by | array[string] | query | False | Order results by specified fields and optional [asc |
| desc] direction. Default direction is 'asc' for ascending. | return_records | boolean | query | False |

Response

Status: 200, Ok

| Name | Type | Description |
|-------------|----------------------------------|-------------------|
| _links | _links | |
| num_records | integer | Number of records |
| records | array[records] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "iops": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "latency": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 06:20:13 -0500",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 8585947 | No metrics are available for the requested object. |
| 8586225 | An unexpected error occurred retrieving metrics for the requested object. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

| Name | Type | Description |
|-------|--------------------------------|-------------|
| error | returned_error | |

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

records

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

| Name | Type | Description |
|----------|------------------------|--|
| _links | _links | |
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops | iops | The rate of I/O operations observed at the storage object. |

| Name | Type | Description |
|------------|----------------------------|---|
| latency | latency | The round trip latency in microseconds observed at the storage object. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |
| uuid | string | The unique identifier of the NVMe namespace. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Retrieve historical performance metrics for an NVMe namespace for a specific time

GET /storage/namespaces/{nvme_namespace.uuid}/metrics/{timestamp}

Introduced In: 9.14

Retrieves historical space and performance metrics for an NVMe namespace for a specific time.

Related ONTAP commands

- `statistics namespace show`

Parameters

| Name | Type | In | Required | Description |
|---------------------|---------------|-------|----------|--|
| nvme_namespace.uuid | string | path | True | The unique identifier of the NVMe namespace. |
| timestamp | string | path | True | The timestamp of the performance data. <ul style="list-style-type: none"> • format: date-time |
| fields | array[string] | query | False | Specify the fields to return. |

Response

Status: 200, Ok

| Name | Type | Description |
|------------|----------------------------|---|
| _links | _links | |
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops | iops | The rate of I/O operations observed at the storage object. |
| latency | latency | The round trip latency in microseconds observed at the storage object. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |
| uuid | string | The unique identifier of the NVMe namespace. |

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25 06:20:13 -0500",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 8585947 | No metrics are available for the requested object. |
| 8586225 | An unexpected error occurred retrieving metrics for the requested object. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

| Name | Type | Description |
|-------|--------------------------------|-------------|
| error | returned_error | |

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |

| Name | Type | Description |
|-------|---------|---|
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Delete an NVMe namespace

DELETE /storage/namespaces/{uuid}

Introduced In: 9.6

Deletes an NVMe namespace.

Related ONTAP commands

- `vserver nvme namespace delete`

Learn more

- [DOC /storage/namespaces](#)

Parameters

| Name | Type | In | Required | Description |
|---------------------------|---------|-------|----------|---|
| uuid | string | path | True | The unique identifier of the NVMe namespace to delete. |
| allow_delete_while_mapped | boolean | query | False | Allows deletion of a mapped NVMe namespace. A mapped NVMe namespace might be in use. Deleting a mapped namespace also deletes the namespace map and makes the data no longer available, possibly causing a disruption in the availability of data. This parameter should be used with caution. <ul style="list-style-type: none">• Default value: |

| Name | Type | In | Required | Description |
|----------------|---------|-------|----------|--|
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none"> • Default value: 0 • Max value: 120 • Min value: 0 |

Response

Status: 200, Ok

Response

Status: 202, Accepted

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 4 | The specified namespace was not found. |
| 72089796 | The namespace must be unmapped before deletion. |
| 72090016 | The namespace's aggregate is offline. The aggregate must be online to modify or remove the namespace. |
| 72090017 | The namespace's volume is offline. The volume must be online to modify or remove the namespace. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

| Name | Type | Description |
|-------|--------------------------------|-------------|
| error | returned_error | |

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Retrieve an NVMe namespace

GET /storage/namespaces/{uuid}

Introduced In: 9.6

Retrieves an NVMe namespace.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more.

- `auto_delete`
- `space.physical_used`
- `space.physical_used_by_snapshots`
- `space.efficiency_ratio`
- `subsystem_map.*`
- `status.mapped`
- `statistics.*`

- `metric.*`

Related ONTAP commands

- `vserver nvme namespace show`
- `vserver nvme subsystem map show`

Learn more

- [DOC /storage/namespaces](#)

Parameters

| Name | Type | In | Required | Description |
|--------|---------------|-------|----------|--|
| uuid | string | path | True | The unique identifier of the NVMe namespace to retrieve. |
| fields | array[string] | query | False | Specify the fields to return. |

Response

Status: 200, Ok

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|-------------------|-----------------------------------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| create_time | string | The time the NVMe namespace was created. |

| Name | Type | Description |
|----------|--------------------------|--|
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| location | location | <p>The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.</p> <ul style="list-style-type: none"> • Introduced in: 9.6 • readCreate: 1 |
| metric | metric | Performance numbers, such as IOPS latency and throughput |
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| os_type | string | <p>The operating system type of the NVMe namespace.</p> <p>Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.</p> |

| Name | Type | Description |
|---------------|-------------------------------|--|
| space | space | The storage space related properties of the NVMe namespace. |
| statistics | statistics | These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster. |
| status | status | Status information about the NVMe namespace. |
| subsystem_map | subsystem_map | <p>The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.</p> <p>There is an added computational cost to retrieving property values for <code>subsystem_map</code>. They are not populated for a GET request unless explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. These properties are supported only for GET.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |
| uuid | string | The unique identifier of the NVMe namespace. |

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "consistency_group": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "cgl",
    "uuid": "4abc2317-4332-9d37-93a0-20bd29c22df0"
  },
  "create_time": "2018-06-04 15:00:00 -0400",
  "location": {
    "namespace": "namespace1",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "qtrees": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "id": 1,
      "name": "qt1"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "volume1",
    },
  },
}
```

```

    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  },
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 06:20:13 -0500"
  },
  "name": "/vol/volume1/qtree1/namespace1",
  "os_type": "string",
  "space": {
    "block_size": 512,
    "efficiency_ratio": 2.5,
    "physical_used": 1073741824,
    "physical_used_by_snapshots": 1073741824,
    "size": 1073741824,
    "used": 0
  },
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,

```



```

    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput_raw": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25 06:20:13 -0500"
},
"status": {
  "container_state": "string",
  "state": "online"
},
"subsystem_map": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "anagrpid": "00103050h",
  "nsid": "00000001h",
  "subsystem": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "comment": "string",
    "hosts": [
      {
        "dh_hmac_chap": {
          "group_size": "string",
          "hash_function": "string",
          "mode": "bidirectional"
        },
        "nqn": "nqn.1992-01.example.com:string",
        "priority": "string",
        "proximity": {
          "peer_svms": [
            {
              "_links": {
                "self": {
                  "href": "/api/resourcelink"
                }
              }
            }
          ]
        }
      }
    ]
  }
}

```

```

        },
        "name": "peer1",
        "uuid": "4204cf77-4c82-9bdb-5644-b5a841c097a9"
    }
]
},
"tls": {
    "key_type": "configured"
}
},
],
"name": "subsystem1",
"os_type": "string",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
},
"svm": {
    "_links": {
        "self": {
            "href": "/api/resourcelink"
        }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|--|
| 72090006 | The specified namespace was not found. |
| 72090007 | The specified namespace was not found. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

| Name | Type | Description |
|-------|--------------------------------|-------------|
| error | returned_error | |

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

source

The source NVMe namespace for a namespace clone operation. This can be specified using property `clone.source.uuid` or `clone.source.name`. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: `auto_delete` (unless specified in the request), `subsystem_map`, `status.state`, and `uuid`.

consistency_group

The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume.

| Name | Type | Description |
|--------|------------------------|---|
| _links | _links | |
| name | string | The name of the consistency group. |
| uuid | string | The unique identifier of the consistency group. |

lun

The source LUN for convert operation. This can be specified using property `convert.lun.uuid` or

`convert.lun.name`. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace come from the source LUN.

convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

node

The cluster node that hosts the NVMe namespace.

| Name | Type | Description |
|---------------------|------------------------|-------------|
| <code>_links</code> | _links | |
| <code>name</code> | string | |
| <code>uuid</code> | string | |

qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties `name` and `location.qtree.name` and/or `location.qtree.uuid` are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

| Name | Type | Description |
|---------------------|------------------------|---|
| <code>_links</code> | _links | |
| <code>id</code> | integer | The identifier for the qtree, unique within the qtree's volume. |
| <code>name</code> | string | The name of the qtree. |

volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties `name` and `location.volume.name` and/or `location.volume.uuid` are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

| Name | Type | Description |
|---------------------|------------------------|-------------|
| <code>_links</code> | _links | |

| Name | Type | Description |
|------|--------|--|
| name | string | The name of the volume. This field cannot be specified in a PATCH method. |
| uuid | string | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> • example: 028baa66-41bd-11e9-81d5-00a0986138f7 • Introduced in: 9.6 • x-nullable: true |

location

The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.

| Name | Type | Description |
|-----------|-----------------------|--|
| namespace | string | <p>The base name component of the NVMe namespace. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.namespace</code> are specified in the same request, they must refer to the base name.</p> <p>NVMe namespaces do not support rename.</p> |
| node | node | The cluster node that hosts the NVMe namespace. |
| qtree | qtree | <p>The qtree in which the NVMe namespace is optionally located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.qtree.name</code> and/or <code>location.qtree.uuid</code> are specified in the same request, they must refer to the same qtree.</p> <p>NVMe namespaces do not support rename.</p> |

| Name | Type | Description |
|--------|--------|---|
| volume | volume | <p>The volume in which the NVMe namespace is located. Valid in POST.</p> <p>If properties <code>name</code> and <code>location.volume.name</code> and/or <code>location.volume.uuid</code> are specified in the same request, they must refer to the same volume.</p> <p>NVMe namespaces do not support movement between volumes.</p> |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

metric

Performance numbers, such as IOPS latency and throughput

| Name | Type | Description |
|----------|-------------------------|--|
| _links | _links | |
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops | iops | The rate of I/O operations observed at the storage object. |
| latency | latency | The round trip latency in microseconds observed at the storage object. |

| Name | Type | Description |
|------------|----------------------------|---|
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |

self_link

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

qos_policy

The QoS policy for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. If no `qos_policy` is provided, a policy is be set based on the `storage_service.name`, which defaults to the most performant service available.

| Name | Type | Description |
|--------|---------------------------|-------------|
| _links | self_link | |

| Name | Type | Description |
|------|--------|---|
| name | string | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |
| uuid | string | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

snapshot_policy_reference

This is a reference to the snapshot policy.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |
| name | string | |
| uuid | string | |

storage_service

Determines the placement of the namespace based on the value specified. Valid in POST.

| Name | Type | Description |
|------|--------|--|
| name | string | Storage service name. If not specified, the default value is the most performant for the platform. |

object_stores

tiering

The tiering placement and policy definitions for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume.

| Name | Type | Description |
|---------------|--|---|
| object_stores | array[object_stores] | Object stores to use. Used for placement. |

| Name | Type | Description |
|--------|--------|---|
| policy | string | <p>Policy that determines whether the user data blocks of a volume in a FabricPool will be tiered to the cloud store when they become cold.</p> <p>FabricPool combines flash (performance tier) with a cloud store into a single aggregate. Temperature of a volume block increases if it is accessed frequently and decreases when it is not. Valid in POST or PATCH.</p> <p>all &dash; Allows tiering of both snapshots and active file system user data to the cloud store as soon as possible by ignoring the temperature on the volume blocks.</p> <p>auto &dash; Allows tiering of both snapshot and active file system user data to the cloud store</p> <p>none &dash; Volume blocks are not be tiered to the cloud store.</p> <p>snapshot_only &dash; Allows tiering of only the volume snapshots not associated with the active file system.</p> <p>The default tiering policy is "snapshot-only" for a FlexVol volume and "none" for a FlexGroup volume. The default minimum cooling period for the "snapshot-only" tiering policy is 2 days and for the "auto" tiering policy it is 31 days.</p> |

provisioning_options

Options that are applied to the operation.

guarantee

Properties that request and report the space guarantee for the NVMe namespace.

| Name | Type | Description |
|-----------|---------|---|
| requested | boolean | <p>The requested space reservation policy for the NVMe namespace. If <i>true</i>, a space reservation is requested for the namespace; if <i>false</i>, the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.</p> <p>The space reservation policy for an NVMe namespace is determined by ONTAP.</p> <ul style="list-style-type: none"> • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |
| reserved | boolean | <p>Reports if the NVMe namespace is space guaranteed.</p> <p>This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.</p> |

space

The storage space related properties of the NVMe namespace.

| Name | Type | Description |
|----------------------------|---------------------------|---|
| block_size | integer | <p>The size of blocks in the namespace in bytes. The default for namespaces with an <code>os_type</code> of <i>vmware</i> is 512. All other namespaces default to 4096.</p> <p>Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.</p> |
| efficiency_ratio | number | <p>The storage efficiency ratio of the namespace without snapshots. (Logical Used / Used) This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| guarantee | guarantee | <p>Properties that request and report the space guarantee for the NVMe namespace.</p> |
| physical_used | integer | <p>The number of bytes consumed on the disk by the namespace, excluding snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |
| physical_used_by_snapshots | integer | <p>The number of bytes consumed on the disk by the namespace's snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information.</p> |

| Name | Type | Description |
|------|---------|---|
| size | integer | <p>The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.</p> <p>The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • example: 1073741824 • format: int64 • Max value: 140737488355328 • Min value: 4096 • Introduced in: 9.6 • x-nullable: true |

| Name | Type | Description |
|------|---------|---|
| used | integer | <p>The amount of space consumed by the main data stream of the NVMe namespace.</p> <p>This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • format: int64 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name | Type | Description |
|-------|---------|---|
| other | integer | <p>Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.</p> |

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name | Type | Description |
|----------------|--------------------------------|---|
| iops_raw | iops_raw | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time. |
| latency_raw | latency_raw | The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | throughput_raw | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time. |

| Name | Type | Description |
|-----------|--------|--|
| timestamp | string | The timestamp of the performance data. |

status

Status information about the NVMe namespace.

| Name | Type | Description |
|-----------------|---------|---|
| container_state | string | The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available. |
| mapped | boolean | Reports if the NVMe namespace is mapped to an NVMe subsystem. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. |
| read_only | boolean | Reports if the NVMe namespace allows only read access. |
| state | string | The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors. |

consistency_group_nvme_host_dh_hmac_chap

A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host.

| Name | Type | Description |
|---------------|--------|--|
| group_size | string | The Diffie-Hellman group size for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>2048_bit</code> . When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST. |
| hash_function | string | The hash function for NVMe in-band authentication. When property <code>host_secret_key</code> is provided, this property defaults to <code>sha_256</code> . When supplied, the property <code>host_secret_key</code> must also be supplied. Optional in POST. |
| mode | string | <p>The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:</p> <ul style="list-style-type: none"> • <code>none</code>: The host has neither the host nor controller secret configured, and no authentication is performed. • <code>unidirectional</code>: The host has a host secret configured. The controller will authenticate the host. • <code>bidirectional</code>: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller. |

peer_svms

A reference to an SVM peer relationship.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|------|--------|--|
| name | string | The local name of the peer SVM. This name is unique among all local and peer SVMs. |
| uuid | string | The unique identifier of the SVM peer relationship. This is the UUID of the relationship, not the UUID of the peer SVM itself. |

proximity

Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.

These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.

| Name | Type | Description |
|-----------|------------------------------------|---|
| local_svm | boolean | A boolean that indicates if the host is proximal to the SVM for which it is configured. |
| peer_svms | array[peer_svms] | An array of remote peer SVMs to which the host is proximal. |

tls

A container for the configuration for NVMe/TCP-TLS transport session for the host.

| Name | Type | Description |
|----------|--------|--|
| key_type | string | <p>The method by which the TLS pre-shared key (PSK) is configured for the host. Optional in POST.</p> <p>The values for property <code>key_type</code> and property <code>configured_psk</code> must logically agree.</p> <p>Possible values:</p> <ul style="list-style-type: none"> • <code>none</code> - TLS is not configured for the host connection. No value is allowed for property <code>configured_psk</code>. • <code>configured</code> - A user supplied PSK is configured for the NVMe/TCP-TLS transport connection between the host and the NVMe subsystem. A valid value for property <code>configured_psk</code> is required. <p>This property defaults to <code>none</code> unless a value is supplied for <code>configured_psk</code> in which case it defaults to <code>configured</code>.</p> |

hosts

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

| Name | Type | Description |
|--------------|--|--|
| dh_hmac_chap | consistency_group_nvme_host_dh_hmac_chap | A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host. |
| nqn | string | The NVMe qualified name (NQN) used to identify the NVMe storage target. |

| Name | Type | Description |
|-----------|-----------|--|
| priority | string | The host priority setting allocates appropriate NVMe I/O queues (count and depth) for the host to submit I/O commands. Absence of this property in GET implies io_queue count and I/O queue depth are being used. |
| proximity | proximity | <p>Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.</p> <p>These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.</p> |
| tls | tls | A container for the configuration for NVMe/TCP-TLS transport session for the host. |

subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

| Name | Type | Description |
|---------|--------------|--|
| _links | _links | |
| comment | string | A configurable comment for the NVMe subsystem. Optional in POST. |
| hosts | array[hosts] | The NVMe hosts configured for access to the NVMe subsystem. Optional in POST. |
| name | string | The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Optional in POST. |

| Name | Type | Description |
|---------|--------|--|
| os_type | string | The host operating system of the NVMe subsystem's hosts. Optional in POST. |
| uuid | string | The unique identifier of the NVMe subsystem. |

subsystem_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for `subsystem_map`. They are not populated for a GET request unless explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more. These properties are supported only for GET.

| Name | Type | Description |
|-----------|---------------------------|--|
| _links | _links | |
| anagrpId | string | <p>The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.</p> <p>The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| nsid | string | <p>The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.</p> <p>The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |
| subsystem | subsystem | The NVMe subsystem to which the NVMe namespace is mapped. |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the SVM. This field cannot be specified in a PATCH method. |
| uuid | string | The unique identifier of the SVM. This field cannot be specified in a PATCH method. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Update an NVMe namespace

PATCH /storage/namespaces/{uuid}

Introduced In: 9.6

Updates an NVMe namespace.

Related ONTAP commands

- `volume file clone autodelete`
- `vserver nvme namespace modify`

Learn more

- [DOC /storage/namespaces](#)

Parameters

| Name | Type | In | Required | Description |
|----------------|---------|-------|----------|--|
| uuid | string | path | True | The unique identifier of the NVMe namespace to update. |
| return_timeout | integer | query | False | <p>The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202.</p> <ul style="list-style-type: none">• Default value: 0• Max value: 120• Min value: 0 |

Request Body

| Name | Type | Description |
|-------------|-----------------------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |
| clone | clone | <p>This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.</p> <p>When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: <code>auto_delete</code> (unless specified in the request), <code>subsystem_map</code>, <code>status.state</code>, and <code>uuid</code>.</p> |

| Name | Type | Description |
|-------------------|-----------------------------------|--|
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| create_time | string | The time the NVMe namespace was created. |
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| space | space | The storage space related properties of the NVMe namespace. |

| Name | Type | Description |
|--------|--------|--|
| status | status | Status information about the NVMe namespace. |
| uuid | string | The unique identifier of the NVMe namespace. |

Example request

```
{
  "clone": {
    "source": {
      "name": "/vol/volume1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "comment": "string",
  "consistency_group": {
    "name": "cg1",
    "uuid": "4abc2317-4332-9d37-93a0-20bd29c22df0"
  },
  "create_time": "2018-06-04 15:00:00 -0400",
  "name": "/vol/volume1/mtree1/namespace1",
  "space": {
    "efficiency_ratio": 2.5,
    "physical_used": 1073741824,
    "physical_used_by_snapshots": 1073741824,
    "size": 1073741824,
    "used": 0
  },
  "status": {
    "container_state": "string",
    "state": "online"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

Status: 200, Ok

Response

Status: 202, Accepted

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 5374127 | The specified namespace name is invalid. |
| 5376461 | The specified namespace name is invalid. |
| 5376462 | The specified namespace name is too long. |
| 5376463 | The snapshot portion of the specified namespace name is too long. |
| 5376466 | An attempt was made to rename an NVMe namespace to a snapshot name. |
| 5376467 | An attempt was made to rename a primary NVMe namespace to a secondary name. |
| 5376468 | An attempt was made to rename an NVMe namespace to a reserved name. |
| 13565952 | The namespace clone request failed. |
| 72089724 | The specified namespace size is too large. |
| 72089730 | The specified namespace cannot be updated as it resides in a snapshot. |
| 72090005 | The specified <code>clone.source.uuid</code> and <code>clone.source.name</code> do not refer to the same LUN. |
| 72090006 | The specified namespace was not found. This can apply to <code>clone.source</code> or the target namespace. The <code>target</code> property of the error object identifies the property. |
| 72090007 | The specified namespace was not found. This can apply to <code>clone.source</code> or the target namespace. The <code>target</code> property of the error object identifies the property. |
| 72090010 | An error occurred after successfully overwriting data for the namespace as a clone. Some properties were not modified. |

| Error Code | Description |
|------------|--|
| 72090011 | An error occurred after successfully modifying some of the properties of the namespace. Some properties were not modified. |
| 72090016 | The namespace's aggregate is offline. The aggregate must be online to modify or remove the namespace. |
| 72090017 | The namespace's volume is offline. The volume must be online to modify or remove the namespace. |
| 72090038 | An attempt was made to reduce the size of the specified namespace. |

Also see the table of common errors in the [Response body](#) overview section of this documentation.

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

source

The source NVMe namespace for a namespace clone operation. This can be specified using property `clone.source.uuid` or `clone.source.name`. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

| Name | Type | Description |
|------|--------|--|
| name | string | <p>The name of the clone source NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Valid in POST and PATCH.</p> |
| uuid | string | <p>The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.</p> |

clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: `auto_delete` (unless specified in the request), `subsystem_map`, `status.state`, and `uuid`.

| Name | Type | Description |
|--------|--------|--|
| source | source | <p>The source NVMe namespace for a namespace clone operation. This can be specified using property <code>clone.source.uuid</code> or <code>clone.source.name</code>. If both properties are supplied, they must refer to the same namespace.</p> <p>Valid in POST to create a new NVMe namespace as a clone of the source.</p> <p>Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.</p> |

consistency_group

The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the consistency group. |
| uuid | string | The unique identifier of the consistency group. |

lun

The source LUN for convert operation. This can be specified using property `convert.lun.uuid` or `convert.lun.name`. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace come from the source LUN.

convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

node

The cluster node that hosts the NVMe namespace.

| Name | Type | Description |
|------|--------|-------------|
| name | string | |
| uuid | string | |

qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties `name` and `location.qtree.name` and/or `location.qtree.uuid` are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

| Name | Type | Description |
|------|---------|---|
| id | integer | The identifier for the qtree, unique within the qtree's volume. |
| name | string | The name of the qtree. |

volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties `name` and `location.volume.name` and/or `location.volume.uuid` are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

| Name | Type | Description |
|------|--------|--|
| name | string | The name of the volume. This field cannot be specified in a PATCH method. |
| uuid | string | <p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> • example: 028baa66-41bd-11e9-81d5-00a0986138f7 • Introduced in: 9.6 • x-nullable: true |

location

The location of the NVMe namespace within the ONTAP cluster. NVMe namespaces do not support rename, or movement between volumes. Valid in POST.

| Name | Type | Description |
|------|----------------------|---|
| node | node | The cluster node that hosts the NVMe namespace. |

iops

The rate of I/O operations observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency

The round trip latency in microseconds observed at the storage object.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput

The rate of throughput bytes per second observed at the storage object.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

metric

Performance numbers, such as IOPS latency and throughput

| Name | Type | Description |
|----------|-------------------------|--|
| duration | string | The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations: |
| iops | iops | The rate of I/O operations observed at the storage object. |
| latency | latency | The round trip latency in microseconds observed at the storage object. |

| Name | Type | Description |
|------------|------------|---|
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput | throughput | The rate of throughput bytes per second observed at the storage object. |
| timestamp | string | The timestamp of the performance data. |

self_link

qos_policy

The QoS policy for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume. If no `qos_policy` is provided, a policy is be set based on the `storage_service.name`, which defaults to the most performant service available.

| Name | Type | Description |
|------|--------|---|
| name | string | The QoS policy group name. This is mutually exclusive with UUID and other QoS attributes during POST and PATCH. |

| Name | Type | Description |
|------|--------|---|
| uuid | string | The QoS policy group UUID. This is mutually exclusive with name and other QoS attributes during POST and PATCH. |

snapshot_policy_reference

This is a reference to the snapshot policy.

| Name | Type | Description |
|------|--------|-------------|
| name | string | |
| uuid | string | |

storage_service

Determines the placement of the namespace based on the value specified. Valid in POST.

| Name | Type | Description |
|------|--------|--|
| name | string | Storage service name. If not specified, the default value is the most performant for the platform. |

object_stores

| Name | Type | Description |
|------|--------|--|
| name | string | The name of the object store to use. Used for placement. |

tiering

The tiering placement and policy definitions for the volume provisioned to host the namespace. This property is only supported when the request provisions a new volume.

| Name | Type | Description |
|---------------|--|---|
| control | string | Storage tiering placement rules for the object. |
| object_stores | array[object_stores] | Object stores to use. Used for placement. |

provisioning_options

Options that are applied to the operation.

guarantee

Properties that request and report the space guarantee for the NVMe namespace.

| Name | Type | Description |
|-----------|---------|---|
| requested | boolean | <p>The requested space reservation policy for the NVMe namespace. If <i>true</i>, a space reservation is requested for the namespace; if <i>false</i>, the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.</p> <p>The space reservation policy for an NVMe namespace is determined by ONTAP.</p> <ul style="list-style-type: none">• readOnly: 1• Introduced in: 9.6• x-nullable: true |
| reserved | boolean | <p>Reports if the NVMe namespace is space guaranteed.</p> <p>This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.</p> |

space

The storage space related properties of the NVMe namespace.

| Name | Type | Description |
|----------------------------|---------------------------|--|
| efficiency_ratio | number | The storage efficiency ratio of the namespace without snapshots. (Logical Used / Used) This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information. |
| guarantee | guarantee | Properties that request and report the space guarantee for the NVMe namespace. |
| physical_used | integer | The number of bytes consumed on the disk by the namespace, excluding snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information. |
| physical_used_by_snapshots | integer | The number of bytes consumed on the disk by the namespace's snapshots. This property is not available on the namespace object in the REST API and is not reported for GET requests. See the containing volume object for this information. |

| Name | Type | Description |
|------|---------|---|
| size | integer | <p>The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.</p> <p>The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • example: 1073741824 • format: int64 • Max value: 140737488355328 • Min value: 4096 • Introduced in: 9.6 • x-nullable: true |

| Name | Type | Description |
|------|---------|---|
| used | integer | <p>The amount of space consumed by the main data stream of the NVMe namespace.</p> <p>This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.</p> <p>For more information, see <i>Size properties</i> in the <i>docs</i> section of the ONTAP REST API documentation.</p> <ul style="list-style-type: none"> • format: int64 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true |

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

| Name | Type | Description |
|-------|---------|---|
| other | integer | <p>Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.</p> |

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

| Name | Type | Description |
|-------|---------|--|
| other | integer | Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on. |
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

| Name | Type | Description |
|-------|---------|---|
| read | integer | Performance metric for read I/O operations. |
| total | integer | Performance metric aggregated over all types of I/O operations. |
| write | integer | Performance metric for write I/O operations. |

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

| Name | Type | Description |
|----------------|--------------------------------|---|
| iops_raw | iops_raw | The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time. |
| latency_raw | latency_raw | The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation. |
| status | string | Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data. |
| throughput_raw | throughput_raw | Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time. |

| Name | Type | Description |
|-----------|--------|--|
| timestamp | string | The timestamp of the performance data. |

status

Status information about the NVMe namespace.

| Name | Type | Description |
|-----------------|---------|---|
| container_state | string | The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available. |
| mapped | boolean | Reports if the NVMe namespace is mapped to an NVMe subsystem. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more. |
| read_only | boolean | Reports if the NVMe namespace allows only read access. |
| state | string | The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors. |

consistency_group_nvme_host_dh_hmac_chap

A container for the configuration of NVMe in-band authentication using the DH-HMAC-CHAP protocol for a host.

| Name | Type | Description |
|------|--------|---|
| mode | string | <p>The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:</p> <ul style="list-style-type: none"> • none: The host has neither the host nor controller secret configured, and no authentication is performed. • unidirectional: The host has a host secret configured. The controller will authenticate the host. • bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller. |

peer_svms

A reference to an SVM peer relationship.

| Name | Type | Description |
|------|--------|--|
| name | string | The local name of the peer SVM. This name is unique among all local and peer SVMs. |
| uuid | string | The unique identifier of the SVM peer relationship. This is the UUID of the relationship, not the UUID of the peer SVM itself. |

proximity

Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.

These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.

| Name | Type | Description |
|-----------|---------|---|
| local_svm | boolean | A boolean that indicates if the host is proximal to the SVM for which it is configured. |

| Name | Type | Description |
|-----------|------------------------------------|---|
| peer_svms | array[peer_svms] | An array of remote peer SVMs to which the host is proximal. |

tls

A container for the configuration for NVMe/TCP-TLS transport session for the host.

hosts

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

| Name | Type | Description |
|-----------|---------------------------|--|
| proximity | proximity | <p>Properties that define the SVMs to which the host is proximal. This information is used to properly report active optimized and active non-optimized network paths using an NVMe controller. If no configuration has been specified for the host, the sub-object is not present in GET requests.</p> <p>These properties apply to all instances of the host in the NVMe subsystem in the SVM and its peers.</p> |

subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

subsystem_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for `subsystem_map`. They are not populated for a GET request unless explicitly requested using the `fields` query parameter. See [Requesting specific fields](#) to learn more. These properties are supported only for GET.

| Name | Type | Description |
|----------|--------|---|
| anagrpId | string | <p>The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.</p> <p>The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |

| Name | Type | Description |
|------|--------|--|
| nsid | string | <p>The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.</p> <p>The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".</p> |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|------|--------|---|
| name | string | The name of the SVM. This field cannot be specified in a PATCH method. |
| uuid | string | The unique identifier of the SVM. This field cannot be specified in a PATCH method. |

nvme_namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

NVMe namespace names are paths of the form `"/vol/<volume>[/<qtree>]/<namespace>"` where the qtree name is optional.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. An NVMe namespace can then be resized or cloned. An NVMe namespace cannot be renamed, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace.

| Name | Type | Description |
|-------------|-----------------------|---|
| auto_delete | boolean | <p>This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.</p> <p>When set to <i>true</i>, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.</p> <p>This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i>.</p> <p>There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the <code>fields</code> query parameter. See Requesting specific fields to learn more.</p> |
| clone | clone | <p>This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.</p> <p>When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: <code>auto_delete</code> (unless specified in the request), <code>subsystem_map</code>, <code>status.state</code>, and <code>uuid</code>.</p> |

| Name | Type | Description |
|-------------------|-----------------------------------|--|
| comment | string | A configurable comment available for use by the administrator. Valid in POST and PATCH. |
| consistency_group | consistency_group | The namespace's consistency group. This property is populated for namespaces that are members of a consistency group. If the namespace is a member of a child consistency group, the parent consistency group is reported. A namespace's consistency group is the consistency group of its containing volume. |
| create_time | string | The time the NVMe namespace was created. |
| enabled | boolean | The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, check the <code>status.state</code> property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created. |
| name | string | <p>The name of the NVMe namespace. An NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.</p> <p>NVMe namespace names are paths of the form <code>"/vol/<volume>[/<qtree>]/<namespace>"</code> where the qtree name is optional.</p> <p>Renaming an NVMe namespace is not supported. Valid in POST.</p> |
| space | space | The storage space related properties of the NVMe namespace. |

| Name | Type | Description |
|--------|------------------------|--|
| status | status | Status information about the NVMe namespace. |
| uuid | string | The unique identifier of the NVMe namespace. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

returned_error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.